


DISTRIBUTORI OLEODINAMICI



SOLENDID OPERATED
DIRECTIONAL CONTROL VALVES

WE6 SERIES DIRECTIONAL CONTROL VALVES ARE SOLENOID OPERATED DIRECTIONAL SPOOL VALVES.


THESE VALVES ARE USED TO THE START, STOP AND DIRECTION OF FLOW.



TECHNICAL DATA

SIZE		6			
MAX. FLOW RATE (L/MIN)		80			
OPERATING PRESSURE (MPA)	A, B, P PORTS	31.5			
	T PORT	16			
WEIGHT (KG) WITHOUT/WITH HANDLE	1 SOLENOID	1.6/2.2			
	2 SOLENDIDS	2.2/2.8			
VALVE BODY (MATERIAL)		CASTING PHOSPHATING SURFACE			

CHARACTERISTIC CURVES



7 CURVE — SPOOL SYMBOL "R" IN SHIFTED POSITION B \to A; 8 CURVE — SPOOL SYMBOL "G" AND "T" IN CENTRAL POSITION; 9 CURVE — SPOOL SYMBOL "H" AND "T" IN CENTRAL POSITION P \to T.

SPOOL	FLOW DIRECTION					
SYMBOL	Р-А	Р-В	A – T	в-т		
А, В	3	3	_	_		
С	1	1	ß	1		
D, Y	5	5	M	m		
E	M	3	1	1		
F	1	3	1	1		
G	6	6	D	9		
Н	2	4	Ω	2		
J, Q	1	1	2	1		
L	M	3	4	9		
М	2	4	M	M		
Р	M	1	1	1		
R	5	5	4	l		
Т	10	1 🗆	D	9		
П	З	3	9	4		
V	1	2	1	1		
W	1	1	2	2		



SOLENDID OPERATED DIRECTIONAL CONTROL VALVES

DISTRIBUTORI OLEODINAMICI



SPOOL SYMBOLS

2-POSITION VALVES			3-POSITION VALVES			
	A B b P T	A B P T	A P	A, B a 0 b	A B a O b	
a b b		A	a A B b b			E
a A B b/D	XH					G
a b b/OF						J
						L M
AB	A, B a b P'T					Р
A, B A a b b						Q Q
		XIII Y				T
				XXHIIII		v
						w

SEE ALSO: WE10, WEH





DISTRIBUTORI OLEODINAMICI





SOLENDID OPERATED
DIRECTIONAL CONTROL VALVES

SUBPLATE INSTALLATION DIMENSIONS











G12=DC12V G24=DC24V

W220/W110=220/110VAC


W220R/W110R=220/110V AC RECTIFIED

SOLENDID OPERATED DIRECTIONAL CONTROL VALVES

DISTRIBUTORI OLEODINAMICI



ORDER CODE



NO CODE=NBR SEALS V=FKM SEALS

Z5L=SQURE PLUG WITH LAMP Z4=SQURE PLUG

No code=Without throttle insert BO.8=Throttle O.8 mm B1.0=Throttle 1.0 mm B1.2=Throttle 1.2 mm

N9=WITH CONCEALED HAND EMERGENCY
NO CODE=WITHOUT HAND EMERGENCY