IOM

Installation, Operation, and Maintenance



Corner Protectors

STORAGE & HANDLING

The corner protectors are shipped unassembled. Upon receipt, the PVC/Polycarbonate covers should be stored in a horizontal position at room temperature (70 deg F. minimum). This is a finished product, store protected in a clean, dry area away from direct sunlight.

CAUTION! DO NOT WALK ON THIS PRODUCT OR STORE ANYTHING ON TOP OF IT.

INSTALLATION

Using Double Sided Tape

STEP 1. Cut corner protector to required length, ensuring that all cuts are square and burr free.

STEP 2. Wall surfaces must be clean, dry, and free from dust and grease. Wipe the wall surface with a solvent to assure all grease, dust and dirt are removed. Make sure that the cleaning solvent used will not damage the finish on the wall surface.

STEP 3. Peel off backing tape from one wing entirely, then peel back the tape partially on the second wing. Place wing with the fully exposed tape to the wall, then remove the remainder of the tape backing from the second wing. Press firmly along the entire length of the corner protector to ensure a good bond.

NOTE: When applying a PVC Flexible or Rigid (Polycarbonate) corner protector be sure that the protector is properly centered on the corner. Remove the tape backing from one wing and attach to the wall. Remove the tape backing from the second wing and wrap the protector around the corner. Press firmly along both wings of the protector to ensure a proper bond.

INSTALLATION

Using Screws

STEP 1. Cut corner protector to required length, ensuring that all cuts are square and burr free.

STEP 2. Drill holes no more than 1" (25.4mm) from the end of the wing, starting at 2" (50.8mm) from the top and bottom and no more than 24" (609.6mm) O.C., alternate/stagger the holes from one wing to the other along the length of the corner protector.

STEP 3. Using screws (provided by others) attach the corner protector to the wall/corner.

INSTALLATION

Using Adhesive (Provided by Others)

NOTE: Recommended for attaching to unsealed wood, sealed and unsealed plaster, concrete block and brick only.

STEP 1. Cut corner protector to required length, ensuring that all cuts are square and burr free.

STEP 2. Apply beads of adhesive to each wing of the protector following application chart below.

3" (76.2mm) Wings
2-1/2" (63.5mm) Wings
1-1/2" (38.1mm) Wings
1-1/8" (28.57mm) Wings
3 beads per wing
2 beads per wing
1 bead per wing
3/4" (19.05mm) Wings
1 bead per wing
1 bead per wing

STEP 3. Place the corner protector on the corner and push firmly into position. Be sure to use an acceptable PVC adhesive and to follow the recommended usage instructions.

CLEANING INSTRUCTIONS

Do not use chlorinated or aromatic hydrocarbons, esters or ketones to clean Tepromark products. Avoid the use of heavy degreasers or compounds containing surfactants. Avoid the use of abrasive compounds. For best results, the use of mild detergents or multipurpose cleansers is recommended. Do not use powder, bleach or ammonia based cleansers as they can leave residue which is difficult to remove.