CUMULATIVE NAVIGATION / +C, +C2 AND +C3

Quick reference card

Select a pad: **INFO** opens its waveform; **INFO** again opens parameters. From Menu, open **Tools** for globals. Labels identify the first custom release: +c (c1), +c2 or +c3.

Waveform [+c]	Vertical two-finger spread/pinch: amplitude **25-3200%**. Horizontal: time. Stationary two-finger tap: **100% + horizontal fit**.
Dial reset [+c]	Double-tap a numeric dial to restore its base value. Modulation stays assigned.
Speed [+c]	**Sample > LFO/Spd > SPEED**, 50-200%. Select + INFO for modulation. One Speed voice excludes all active Pitch; multiple Pitch voices can coexist.
Live retry [+c3]	A refused operation stays neutral. At **RETRY**, return its control to neutral, then adjust again; or restart the voice.
Display [+c / +c3]	**Tools > Disp**: Scrn saver and Sig wake [+c]; **Saver gfx** blue-purple-white lines [+c3]. First physical input wakes only.
Tone [+c2 / +c3]	**Pad > Tone**: Fidelity, Drive, Filter 2, Res 2, Slope 1 [+c2]. Phone, ADPCM and u-Law join Fidelity [+c3].
Clip tools [+c2]	**Clip > Pos**: Loop Fade ms, Shift ms, Play Len, Sync 1/32 and Live Flip. Timed Sync + Quant Size required for Play Len / Live Flip.
Fills / grid [+c3]	**Clip > Pos**: Live Flip > Breakcut; Fill every Always/2/4/8/16 bars. **Slicer > Pos > Sync Grid**, with Sync On.
Delay [+c3]	**FX1 > INFO > Type**: Digital / Tape / BBD / Codec. **More** opens Flutter; Main returns.
Reverb [+c2 / +c3]	**FX2 > INFO**: Plate / Room / Hall / Chamber [+c2]. **More** on Room/Hall/Chamber opens seven detailed controls [+c3].
FX3 [+c3]	On Pads, tap FX2 to select it, then tap that cell again: **FX 3**. INFO opens the second independent reverb. Repeat to return to FX2.
Sends / KEY [+c3]	**Pad > Pos > FX1/FX2/FX3 Send**: select + INFO. **KEY** is after CC in the source selector. Maximum 12 routes per pad total.
Return routing [+c3]	**Tools > Rec > FX Out** routes FX1/FX2 returns. **FX3 Out** is on its Plate page or More page for other types.
CV utilities [+c3]	**Tools > Rec > CV In**: shared Scale/Offset, pitch Quantize and Root. Back returns to Rec. Defaults: 100% / 0% / Off / C.
Master [+c2 / +c3]	**Tools > Comp**: compressor controls. **Mstr > Section**: Comp env / Master FX [+c2]. Compressor bus Off/Out1/2/FX1/2/Both [+c3].
MIDI / recording	**Tools > MIDI > Monitor** [+c2]. Record dry while monitoring through pad sends [+c2]; all three sends and their routes retained [+c3].
Reset / counter [+c3]	**Tools > Main > RESET**: choose Tools or FX, then confirm. Double-tap top-left counter: next bar reads 1:1; playback stays in place.