Quick reference card

Tap tab boxes directly. Arrows show navigation steps; they are not button-press cycles.

PAD PARAMETERS

SELECT PAD > INFO TWICE; SAMPLE TABS SHOWN

Main	Pos	Tone	LFO/Spd	Gen	Cnf
Pitch, Filter and Resonance	Sends / Dry; Clip / Slice tools	Fidelity / Drive; Filter 2 / Res 2	LFO + Sample Speed 50-200%	Per-pad patterns + fills	Pad settings; Dub source / tap

MODULATION

SUPPORTED DIALS ONLY; ROUTES SAVE WITH THE PAD

Select a dial	→	INFO	→	Source + Amount
Touch its square; do not drag		Open the modulation source / amount page		Native + KEY / ENV; CHAOS / RAND / NET

DELAY

FX1 IS SHARED BY ALL PADS AND LIVE INPUT

FX1	→	INFO	→	Main / More
Select the effect on the Pads view		Open delay controls; Purge clears old echoes		Digital / Tape / BBD / Codec; flutter, drive, tone, return

REVERB

FX2 AND FX3 HAVE SEPARATE SETTINGS AND TAILS

FX2 / FX3	→	INFO	→	Main / More
Tap selected FX2 again to switch to FX3		Open the selected reverb controls		Plate / Room / Hall / Chamber; FX3 Out is on Main or More

TOOLS

OPEN TOOLS FROM HOME MENU; TAP ANY TAB

Main	Rec	MIDI	Disp	Comp	Mstr
Int BPM / Clock; Tools / FX reset	FX Out routing; CV In utilities	MIDI settings; Monitor	Brightness / Flip; Saver / Sig wake	Compressor; parallel Mix	Section selects master / GEN

CLOCK & GEN

TOOLS CONTROLS; STOP HOLDS TIME, NOT ALL AUDIO

Main: Int BPM	Main: Clock	Mstr: GEN Run
Int BPM: fast turn = coarse; hold 3 s = 120 BPM	Run / Stop / Reset; CV and MIDI transport	Mstr > Section > GEN Run; enable Run On for patterns

LIVE INPUT FX

NO SAMPLE OR RECORDING REQUIRED

Empty pad + INFO	→	In 1/2 + RecMon On	→	Input FX pad
Open the pad's Recorder settings		Set input and monitoring; adjust input Gain		Scroll down: fixed Pad 1-16 or Follow selected pad

GESTURES & PERFORMANCE

Drag a dial or turn its encoder to edit.
Double-tap: default value; routes stay intact.

Hold a Trigger pad / Play button 2 s: Stop.
The initial touch still plays or retriggers.

Waveform pinch: vertical amplitude; horizontal time. Two-finger tap restores the stock view.

Speed + Slicer Smooth: one shared stretch voice. Native Pitch remains unrestricted.

INPUT FX & RECORDING

Input FX pad: Main Filter / Resonance, Tone, Pos sends / Dry. Follow switches pad settings.

Mon Output: direct input. **FX Out / FX3 Out:** shared wet returns; routes do not follow pads.

Input Filter/Tone: set values only.
Send / Dry modulation works; raw Rec stays dry.

Recording: tap its destination pad to Stop.
To reopen: select with a left encoder + INFO.

Full setup, routing examples and installation steps are in the reference guide.