Battery Saver Circuit



--- C:\dev\WirelessThermometer\BatterySaver.asc ---