

AETHER STREAMER

Stream from the Beyond

Description

The AetherStramer is a device to listen to audio streams that are broadcast over the internet. The unit uses WiFi for internet access. The unit will store up to 36 stream channels.

There is one major control input and that is the knob on the front panel. It can be turned and it can be pressed as a button. Also on the front panel is the display screen. It will light up when settings are made, then go dark after a few seconds.

There is a toggle switch to set the system mode. The switch has three positions.

1. Up: **Web Portal**
2. Center: **Normal**
3. Down: **Reset**

Initial Set Up

Ensure the toggle switch is in the **Normal** (center) position.

Connect the AetherStreamer to a USB power adapter using the supplied cable.

ONLY USE THE SUPPLIED CABLE !

You may use any Type-A USB power adapter *WITH THE SUPPLIED CABLE*. **DO NOT USE** a generic power pack from another device as it can destroy the AetherStreamer controller chip.

When first powered up, the AetherStreamer will attempt to connect to the last known WiFi network. If a network is not found, the AetherStreamer will wait for the user to configure a local WiFi access point. The AetherStreamer display will show:

WIFI PORTAL
Configure at
ssid: AetherStreamer
ip: 192.168.4.1

Use your smartphone, tablet or laptop, and connect its Wifi to the broadcast name: **AetherStreamer**. There is no password.

Once connected, use a browser and go to the address: **192.168.4.1**
You should see a configuration web page.

Click the **Configure WiFi** button. A list of available WiFi connections will be listed at the top of the page. Select your connection name, then enter its password. Click the **Save** button. The AetherStreamer will connect to the WiFi and is ready for use.

AetherStreamer Usage

Volume Level

Turn the knob to adjust volume level. Volume range is 0 – 100.

When the volume is adjusted, the display will show the name of the currently playing stream channel, the timer time left if the timer is enabled, the Wifi signal strength, and the volume level.

After a few seconds, the display will change and show: **NOW PLAYING**. The title of the current song or stream will be displayed.

Change Station

Press the button then turn the knob to scroll the list to find your desired station. When your desired station is highlighted on the list, press to select. The station stream will be launched immediately upon successful connection. If the connection is not successful, the AetherStreamer will revert to the previous station.

When the button is first pressed, the previous listened to station is displayed. Press again to select the previous station. If you turn the knob, the list of stations will show and you can scroll with the knob. Press to select.

If you make no choice, the current station will continue to play and the screen will go dark.

Automatic Shutdown Timer

The timer, if enabled, will shut down the Aether Streamer after the chosen time duration has elapsed.

To set or disable the timer, set the volume level to 0 (zero), the display will show: **ZERO FUNCTION**, then press the button. The display will show the current timer setting.

Turn the knob to select a different timer value or to disable the timer. Press the button to save the timer setting.

Once a timer value has been set, it will continue to be used, even after the system restarts.

The time remaining until auto-shutdown will display when changing the volume. When the shutdown time arrives, the unit will go quiet and the display will momentarily show: **SHUTDOWN**.

To awaken the AetherStreamer, press the button and the unit will reconnect to the stream. The timer will be reset to the value you have chosen.

Power Down the AetherStreamer

Set the volume to zero, the display will show: ZERO FUNCTION. After a few seconds, the AetherStreamer will shut down. The display will show: **SYSTEM POWER DOWN**.

Turn ON the AetherStreamer after Power Down

Press the button to power up. The display will show: **SYSTEM START UP**. The last used stream will play.

Modify the Station List

Set the side panel switch to the **Portal** position.

The display will show the AetherStreamer configuration portal address. It will look something like:

PORTAL OPEN
192.168.1.10/param

Using a smartphone, tablet or PC that is on the same WiFi network as the AetherStreamer, open a browser and go to the address displayed on the panel.

There will be 36 memory slots displayed, two lines per item containing the Name and URL Address of each slot. Change any slot Name and the URL as desired. Click the **Save** button at the bottom of the page to store the changes into the AetherStreamer unit. The display panel on the AetherStreamer unit will momentarily show: **SAVED**.

Set the side panel switch into the **Normal** (center) position.

URL address must begin with **http://** (*https:// is not supported*).

NOTE - If there is an error in the URL entry, the station select list on the AetherStreamer unit will show only the slot number and it cannot be selected for play. Re-enter the portal and correct the error.

Force Reset Mode

The unit can be placed into a reset hold mode by placing the switch into the **Reset** (bottom) position. All AetherStreamer activity is stopped. Set the switch to **Normal** (center) to start up the unit. This can be used to restart the device if a stream hangs due to an error.

Force a WiFi Configuration Portal

If you need to reset the WiFi system name that the AetherStreamer is connected to, set the side panel switch to **Reset** (bottom) position, then immediately set it to **Portal**. The unit will start up into the WiFi configuration mode. Configure the unit as described above under the **Initial Set Up** instructions.

Technical Information

How to restore the default stream channel list

There is a jumper inside the unit to recover the original stream channel list.

Place a jumper on the J16 pins. Reboot the unit, then remove the jumper.

You may view a video of its usage at:

<https://www.youtube.com/watch?v=RHN2gjRqYpA>

How to locate new stream channels

See instructions at:

<https://alanthus.com/aether>

Firmware Update

When the Zero Function shutdown is performed, the current version of the firmware is displayed. This instruction sheet is based on version: v.20250723.1551

New firmware file and upload instructions at:

<https://alanthus.com/aether>

Project Details

<https://github.com/w8an/streamplayer>

Steven R. Stuart
v.0.2 15-dec-2024