Category	Part Name	Description	Acer Part No.
KEYBOARD	KEYBOARD PRIMAX KB-0511 PS/2 STANDARD 107KEY BLACK BRAZILIAN PORTUGUESE	KB PS2 KB-0511 29- 10503A711	KB.PS20P.033
	KEYBOARD PRIMAX KB-0511 PS/2 STANDARD 104KEY BLACK US	KB PS2 KB-0511 29- 10501G111	KB.PS20P.034
	KEYBOARD PRIMAX KB-0511 PS/2 STANDARD 105KS BLACK YUGOSLAVIA	KB KB-0511 PS/2 105KS BLACK YUGOSLAVIA	KB.PS20P.069
	KEYBOARD PRIMAX KB-0511 PS/2 STANDARD 105KS BLACK CZECH/ SLOVAK	KB PRIMAX KB-0511 PS/ 2 STANDARD 105KS BL	KB.PS20P.070
MAINBOARD	MB KIT EL1850 INTEL G41 ICH7 REALTEK RTL8111DL W/O 1394 LF AUDIO IS REALTEK ALC662	MB KIT EL1852 INTEL G41 ICH7 GMA X4500	MB.NBK09.003
MEMORY	MEMORY APACER DDR3 1333MHZ 1G UNB-DIMM GU502203EP0201 LF 128*8 0.065UM	DIMM 1G 75.073C1.G02 DDR3 1333MHZ	KN.1GB01.031
	MEMORY DDR3 1333MHZ 1G UNBUFFERED DIMM W/O ECC F DIE (46NM)	DIMM 1G M378B2873FHS-CH9	KN.1GB0B.036
	MEMORY UNIFOSA DDR3 1333MHZ 1G UNB-DIMM GU502203EP0201 LF 128*8 0.065UM	M 1G GU502203EP0201 UNB.	KN.1GB0H.015
	MEMORY APACER DDR3 1333MHZ 2G UNBUFFERED DIMM W/O ECC	DIMM 2G 75.A73C1.G02 DDR3 1333MHZ	KN.2GB01.025
	MEMORY KINGSTON DDR3 1333MHZ 2G UNB ACR256X64D3U1333C9	DIMM 2G ACR256X64D3U1333C9	KN.2GB07.002
	MEMORY SAMSUNG DDR3 1333MHZ 2G M378B5673FH0-CH9	DIMM 2G M378B5673FH0-CH9	KN.2GB0B.024
	MEMORY UNIFOSA DDR3 1333MHZ 2G UNB-DIMM GU512303EP0202 LF 128*8 0.065UM	DIMM 2G GU512303EP0202 UNB.	KN.2GB0H.009
POINTING DEVICE	MOUSE LOGITECH OPTICAL MOUSE PS2 M-S0004-O	MOUSE PS2 OPT M- S0004-O FOR ASPIRE/ EM/PB	MS.11200.080
	MOUSE PRIMAX OPTICAL MOUSE PS2 MOFGKO	MOUSE PRIMAX OPTICAL PS2 MOFGKO	MS.11200.082
	MOUSE LOGITECH PS2OPTICAL SBF96	MOUSE PS2 OPT M- SBF96 910-0000	MS.11200.032

84 EL1852 Service Guide