


Smart Password Padlock

P02



operating instruction
(2023)

Dear users,

Hello ! Thank you for choosing a smart fingerprint padlock . In order for you to have a better use experience , please read the instructions carefully before experiencing the product . When you get the product , pull off the plastic film on the back of the product and power the product to work .



The factory default password of this product is ①②③④⑤⑥ . Enter the password will automatically unlock the lock .

Blue light comes on after pressing the number . If the password is incorrect , the red light will light up for one second ; if the password is correct , the green light will light up for one second and unlock .

Intelligent use


1. Bluetooth unlock

Slide the lock sign from left to right to unlock the lock.




2.Add users


①Click on the "Member Management".



②Click "Me" to enter the add interface.



③Click "Add" to add more users.



④Add a password, set a 6-digit password and click "Save", then the user is added successfully.

Cancel

Save

Add Code

Save the code immediately. It is not displayed in the app.

Please enter a 6-digit password




Copy

Code Name


Optional

3. Temporary code sharing


① Click on the 'Temporary code'.



② Select the password type 'Time-Limited' or 'One-Time'.



③ Click on 'Disconnect' or 'Disconnect and wipe data'.



(When the device is connected to Bluetooth, if the user deletes them all, the device will resume the factory setting)

③ Click on 'Get Code'.




④ Click on 'Share'.

⑤ Please enter '111111' on the lock first, and then continue to enter the shared code immediately.

Abnormal treatment method

When there is any abnormality in the product, please try to open the lock several times. If not, please replace the new button battery before trying to open the lock.




Factory data reset

Operation mode : long press the number key "7" to keep the blue light for about 6 seconds, flashing the red light, entering the password at the same time, keep flashing the red light and operating again; if the password is entered correctly, the light is changed by green-yellow-green, the password is cleared, and the equipment shall restore the factory setting.

4. Disconnect

① Click on the upper right corner to edit.



② Click on 'Remove Device'.

