# SONiC overview

SONiC Configuration

SONiC supports 2 methods as below,

1. SONiC CLI (Command line interface)
2. config_db.json file(Edit /etc/sonic/config_db.json directly)

SONiC setting relation

SONiC Architecture

SONiC frr routing relation