# Management and front port IPv4/IPv6 Address

# Configure IP address on management port "eth0"

#### **Procedure:**

```
Steps 1. Configure IP address on management port "eth0"
```

```
admin@sonic:~$ sudo config interface ip add eth0 188.188.97.16/16 188.188.1.1
admin@sonic:~$ sudo config interface ip add eth0 2001::8/64 2001::1
```

```
Steps 2. Check IP address
admin@sonic:~$ show ip interfaces
Interface Master IPv4 address/mask Admin/Oper BGP Neighbor Neighbor
-----
           10.1.0.1/32 up/up N/A
Loopback0
docker0 240.127.1.1/24 up/down N/A N/A
        188.188.97.16/16 up/up N/A
eth0
      127.0.0.1/8 up/up N/A N/A
admin@sonic:~$ show ipv6 interfaces
Interface Master IPv6 address/mask
                                   Admin/Oper BGP Neighbor Neighbor IP
Bridge fe80::4020:6aff:fee4:b0a3%Bridge/64 up/down N/A N/A
         fe80::ba6a:97ff:fee2:479c%Ethernet0/64 up/up N/A
Ethernet0
                                                        N/A
Ethernet1 fe80::ba6a:97ff:fee2:479c%Ethernet1/64 up/up N/A
                                                          N/A
Ethernet48 fe80::ba6a:97ff:fee2:479c%Ethernet48/64 up/up N/A
                                                          N/A
Ethernet52 fe80::ba6a:97ff:fee2:479c%Ethernet52/64 up/up
                                                    N/A
                                                            N/A
           fe80::243e:e6ff:fee7:5ca1%Loopback0/64 up/up
Loopback0
                                                    N/A
                                                            N/A
        2001::8/64
eth0
                             up/up N/A
                                             N/A
       fe80::ba6a:97ff:fee2:479c%eth0/64
        ::1/128
                                          N/A
lo
                          up/up N/A
admin@sonic:~$ show management_interface address
Management IP address = 188.188.97.16/16
Management Network Default Gateway = 188.188.1.1
Management IP address = 2001::8/64
Management Network Default Gateway = 2001::1
```

Caution: "BGP Neighbor" and "Neighbor IP" won't support on 202006 branch.

Steps 3. Save the setting to config\_db.json

```
admin@sonic:~$ sudo config save -y
```

#### Steps 4. Check IP address setting on config\_db.json

## Configure IP address on front port (aka physical interface).

#### **Procedure:**

```
Steps 1. Configure IP address on front port. i.e Ethernet0
admin@sonic:~$ sudo config interface ip add Ethernet0 192.168.1.1/24
admin@sonic:~$ sudo config interface ip add Ethernet0 2002::1/64
Steps 2. Check IP address
admin@sonic:~$ show ip interfaces
Interface IPv4 address/mask Admin/Oper BGP Neighbor Neighbor IP
-----
Ethernet0 192.168.1.1/24 up/down N/A
                                       N/A
docker0 240.127.1.1/24 up/down N/A
eth0
    188.188.97.32/16 up/up N/A
                                     N/A
     127.0.0.1/8
                up/up N/A
                               N/A
     10.1.0.1/32
admin@sonic:~$ show ipv6 interfaces
                        Admin/Oper BGP Neighbor Neighbor IP
Interface IPv6 address/mask
Bridge fe80::f4f6:a4ff:fe97:3c88%Bridge/64 up/up N/A
Ethernet0 2002::1/64
                            up/down N/A
                                            N/A
dummy fe80::90cd:eff:fe7b:359f%dummy/64 up/up N/A
                                                       N/A
```

eth0 fe80::aa2b:b5ff:fe9d:d7db%eth0/64 up/up N/A lo ::1/128 up/up N/A N/A

```
Steps 3. Save the setting to config_db.json
```

```
admin@sonic:~$ sudo config save -y
```

Steps 4. Check IP address setting on config\_db.json

```
admin@sonic:/etc/sonic$ sudo vi config_db.json {
     ...omitted
     "INTERFACE": {
         "Ethernet0": {},
         "Ethernet0|192.168.1.1/24": {},
         "Ethernet0|2002::1/64": {}
},
...omitted
```

### Configure IP address on port channel interface.

### **Procedure:**

Steps 1. Create PortChannel01 and append member.(Please refer to LAG)

Steps 2. Configure IP address on portchannel. i.e PortChannel01

```
admin@sonic:~$ sudo config interface ip add PortChannel01 192.168.1.1/24 admin@sonic:~$ sudo config interface ip add PortChannel01 2002::1/64
```

Steps 3. Check IP address

```
admin@sonic:~$ show ip interfaces
Interface Master IPv4 address/mask Admin/Oper BGP Neighbor Neighbor IP
------
PortChannel01
            192.168.1.1/24 up/down N/A
                                          N/A
docker0 240.127.1.1/24 up/down N/A
                                     N/A
       188.188.98.39/16 up/up N/A
eth0
                                      N/A
       127.0.0.1/8
                  up/up N/A
                                  N/A
admin@sonic:~$ show ipv6 interfaces
Interface Master IPv6 address/mask
                                  Admin/Oper BGP Neighbor Neighbor IP
fe80::5476:b1ff:fe43:a8d2%Bridge/64 up/down N/A
Bridge
                                                     N/A
Ethernet48 fe80::6f8:f8ff:fe6a:f691%Ethernet48/64 up/up
                                              N/A
                                                    N/A
Ethernet56
Ethernet60
            fe80::6f8:f8ff:fe6a:f691%Ethernet56/64 up/up
                                              N/A
                                                      N/A
            fe80::6f8:f8ff:fe6a:f691%Ethernet60/64 up/up
                                              N/A
                                                     N/A
PortChannel01 2002::1/64
                        up/down N/A
                                               N/A
eth0
    2001::6f8:f8ff:fe6a:f691/64
                                up/up
                                       N/A
                                              N/A
```

```
fe80::6f8:f8ff:fe6a:f691%eth0/64
                                        up/up
                                                 N/A
                                                          N/A
lo
           ::1/128
                               up/up
                                        N/A
                                                N/A
Steps 4. Save the setting to config_db.json
admin@sonic:~$ sudo config save -y
Steps 5. Check IP address setting on config_db.json
admin@sonic:/etc/sonic$ sudo vi config_db.json
{
 omitted...
 "PORTCHANNEL_INTERFACE": {
   "PortChannel01": {},
   "PortChannel01|192.168.1.1/24": {},
   "PortChannel01|2002::1/64": {}
 },
 omitted...
Configure IP address on loopback interface.
Procedure:
Steps 1. Configure IP address to loopback interface i.e Loopback0
admin@sonic:~$ sudo config interface ip add Loopback0 4.4.4.4/32
admin@sonic:~$ sudo config interface ip add Loopback0 2002::1/128
Steps 2. Check IP address
admin@sonic:~$ show ip interfaces
Interface Master IPv4 address/mask Admin/Oper BGP Neighbor Neighbor IP
------
Loopback0
              4.4.4.4/32
                           up/up
                                    N/A
docker0
             240.127.1.1/24 up/down N/A
                                                N/A
eth0
          188.188.98.39/16 up/up
                                     N/A
                                              N/A
          127.0.0.1/8
                       up/up
                                N/A
admin@sonic:~$ show ipv6 interfaces
Interface Master IPv6 address/mask
                                         Admin/Oper BGP Neighbor Neighbor IP
            fe80::fc13:74ff:febf:769c%Bridge/64 up/down
Bridge
                                                                N/A
Ethernet48
              fe80::6f8:f8ff:fe6a:f691%Ethernet48/64 up/up
                                                        N/A
                                                                 N/A
Ethernet56
              fe80::6f8:f8ff:fe6a:f691%Ethernet56/64 up/up
                                                        N/A
                                                                 N/A
```

fe80::6f8:f8ff:fe6a:f691%Ethernet60/64 up/up

up/up

N/A

2002::1/128

N/A

N/A

N/A

Ethernet60

Loopback0

```
fe80::500c:7eff:feb7:c607%Loopback0/64 up/up
                                                         N/A
                                                                   N/A
eth0
            2001::6f8:f8ff:fe6a:f691/64
                                          up/up
                                                    N/A
                                                             N/A
          fe80::6f8:f8ff:fe6a:f691%eth0/64
                                           up/up
                                                    N/A
                                                              N/A
lo
           ::1/128
                                up/up
                                          N/A
                                                   N/A
```

Steps 3. Save the setting to config\_db.json

```
admin@sonic:~$ sudo config save -y
```

### Steps 4. Check IP address setting on config\_db.json

```
admin@sonic:/etc/sonic$ sudo vi config_db.json
```

```
{
    omitted...
    "LOOPBACK_INTERFACE": {
        "Loopback0": {},
        "Loopback0|4.4.4.4/32": {},
        "Loopback0|2002::1/128": {}
    },
    omitted...
}
```