

One-Leg Hexapod — PCB-Art Wiring Diagram (A3 Landscape)

With LiPo → UBEC → PCA9685 → Servos power path (standard wiring)





Tip: Add an inline fuse and switch between LiPo and UBEC IN+. Keep UBEC and PCA power wires short.