Maintenence



GENERAC® ACCESSORIES

Liquid-Cooled Engines



DESCRIPTION

Scheduled maintenance is a necessity for all standby generators. The Liquid-Cooled Scheduled Maintenance Kits offer all the components necessary to perform a complete maintenance on Generac liquid-cooled generators. Oil and coolant will need to be purchased separately based upon manufacturer recommendations listed below. Maintenance is recommended at every 200 hours or 2 years. If running in a dusty environment, more frequent maintenance may be required. Further maintenance details can be found in the generator owner's manual.

KIT CONTENTS

| IZI BA I I | 0470 | 5050 | 5004 | 0470 | 0005 | 0474 | 5005 | F000 |
|------------------|-------|-------|------|------|------|------|------|----------------|
| Kit Model | 6176 | 5656 | 5984 | 6172 | 6205 | 6171 | 5985 | 5660 |
| kW Output | 25/30 | 22/27 | 36 | 45 | 48 | 60 | 80 | 70/100/130/150 |
| Engine Size | 1.5L | 2.4L | 2.4L | 2.4L | 5.4L | 2.4L | 4.6L | 6.8L |
| Air Filter | • | • | • | • | • | • | • | • |
| Pre-Cleaner | | | | | • | | • | • |
| Oil Filter | • | • | • | • | • | • | • | • |
| Spark Plug(s) | 4 | 4 | 4 | 4 | 8 | 4 | 8 | 10 |
| Oil Funnel | • | • | • | • | • | • | • | • |
| Chamois | • | • | • | • | • | • | • | • |
| Reminder Sticker | • | • | • | • | • | • | • | • |

^{*}Contents of kits may vary. For specific oil recommendations, refer to the owner's manual. For non-current production product maintenance kits, contact a service dealer.

