

MX ORIGINAL MX SPECIAL MX LOW PROFILE DEVELOPER PAGE BLOG

EN | DE

This website uses cookies to ensure you get the best experience on our website.

ACCEPT

第1页 共8页 2018/11/11 19:13

CHERRY MX SWITCHES — DEVELOPER KIT AND INSTALLATION

Has it always been a wish of yours to own an individually customised keyboard, but you don't know where to start? We have just the thing for you: our individual MX-switches are now available in different variants and as a special developer kit. This gives you the opportunity to design your own keyboard. Let your creativity run wild and build a keyboard that you won't be able to find in stores! On this page, we'll show you what you need, and what you need to know. Get your soldering iron out... ready, steady, go!

Are you a fan of the best mechanical switches on the market? Then this one is for you! Our MX-switches are now available for purchase in retail stores. Whether individually or in a set, you'll have the choice between CHERRY MX Red, Black, Blue, Brown, Green, Clear, Silent Black, Silent Red, and Speed. These last two variants are now also available in the brand-new developer kit, which contains a full set of 110 switches. This lets you create your own keyboards in the extended layout – the only limit is your creativity! All you need to build your dream keyboard is a soldering iron, a PCB, and a keyboard case.

Of course, it helps to know exactly which CHERRY MX switches you want to use for your keyboard. To help you with your choice, we've discussed switch properties first.

This website uses cookies to ensure you get the best experience on our website.

ACCEPT





THE MX SWITCH IN DETAIL

All available variants of the CHERRY MX switch are similar in shape and dimensions: the exact measurements are 18.5 x 15.6 x 15.6 mm (HxWxD).

Inside the housing you'll find a plunger in one of the various colour codings, a matching spring for the necessary actuation force and last but not least, the Gold-Crosspoint contact mechanism. These high-quality components ensure more than 50 million actuations for a long-lasting, consistent typing experience.

This website uses cookies to ensure you get the best experience on our website.






CHERRY MX PRODUCT IDENTIFICATION

To select or identify the correct CHERRY MX switch, have a look at the article number for a comprehensive overview of design and variant. "MX" stands for the product itself. The third and fourth character identify the type of stem (i.e. "Standard" or "Silent") and the type of contact. In the current portfolio of MX-switches you'll only find two variants of these first four characters: MX1A (Standard MX switch) or MX3A (Silent MX switch).

You'll find a lot more variation in the following four characters. The first digit is the most important one of them all: it describes the switch characteristics and basically tells you what stem colour is used. The follow-up digit is not relevant for end users; it represents the key stem configuration and is '1' for every existing switch to date. The last two characters of the article number provide information about the LED, diode, housing and pins. For a complete overview, check out this following graphic.

DOWNLOAD GRAPHIC

This website uses cookies to ensure you get the best experience on our website.




This website uses cookies to ensure you get the best experience on our website.

CHERRY MX SWITCH VERSIONS

CHERRY MX switches are available in different versions and can be fastened in a variety of ways. The last character of the article number shows you there are two different mounting mechanisms you can choose from. Switches ending with 'A' or 'N' are mounted directly on the keyboard housing (no additional mounting pins are implemented), while switches ending with 'B' or 'W' should be mounted directly to the PCB. That's why these switches have mounting pins on the bottom of the switch housing. With this method, CHERRY MX switches can be mounted quasifreestanding on the PCB, resulting in a unique look. However, we do advise you to stabilize the PCB to a robust backplate.


Apart from the mounting method, CHERRY produces switch casings in three different versions. The main difference is in whether or not a LED or diode is integrated.

This website uses cookies to ensure you get the best experience on our website.




SWITCH WITHOUT MOUNTING PINS

Mount in keyboard housing



SWITCH WITH MOUNTING PINS

Direct mount on PCB



ACCEPT

AVAILABILITY OF CHERRY MX SWITCHES

The Developer Kit and individual switches are globally available from Reichelt.de



Individual CHERRY MX switches can be also bought online from Arrow Electronics or Greendich Enterprise. These include the switch versions MX Red, Black, Blue, Brown, Speed, Silent, Green, and Clear.





This website uses cookies to ensure you get the best experience on our website.

CHERRY MX TECHNOLOGIES



About Cherry Press Contact Downloads Imprint Data Policy

Cherry.de



This website uses cookies to ensure you get the best experience on our website.