# **QNX® Neutrino® RTOS**

# Writing a Resource Manager

For QNX Neutrino 6.4 or later

 $\ \, \odot$  2008–2010, QNX Software Systems GmbH & Co. KG. All rights reserved.

Published under license by:

#### QNX Software Systems Co.

175 Terence Matthews Crescent Kanata, Ontario K2M 1W8 Canada Voice: +1 613 591-0931

Fax: +1 613 591-3579
Email: info@qnx.com
Web: http://www.qnx.com/
Electronic edition published 2010

QNX, Neutrino, Photon, Photon microGUI, Momentics, Aviage, and related marks, names, and logos are trademarks, registered in certain jurisdictions, of QNX Software Systems GmbH & Co. KG. and are used under license by QNX Software Systems Co. All other trademarks belong to their respective owners.

	Typographical conventions xi
	Note to Windows users xii
	Technical support xiii
1	Overview 1
	What is a resource manager? 3
	Why write a resource manager? 4
	The types of resource managers 5
	Device resource managers 5
	Filesystem resource managers 5
	Communication via native IPC 6
	Examples of resource managers 7
	Transparent Distributed Processing (Qnet) statistics 7
	Robot arm 8
	GPS devices 8
	Database example 10
	I2C (Inter-Integrated Circuit) driver 11
	When not to use a resource manager 12
2	The Bones of a Resource Manager 13
	Under the covers 15
	Under the client's covers 15
	Under the resource manager's covers 17
	Layers in a resource manager 19
	The iofunc layer 19
	The resmgr layer 19
	The dispatch layer 20
	The thread pool layer 22
	Simple examples of device resource managers 22
	Single-threaded device resource manager 23
	Multithreaded device resource manager 27

ix

хi

**About This Guide** 

What you'll find in this guide

May 10, 2010 Contents iii

Using MsgSend() and MsgReply() 30

3	Fleshing Out the Skeleton 37 Message types 39
	Connect messages 39
	I/O messages 41
	Default message handling 45
	open(), dup(), and close() 45
	Setting resource manager attributes 46
	Ways of adding functionality to the resource manager 48
	Using the default functions 48
	Using the helper functions 49
	Writing the entire function yourself 51
4	POSIX-Layer Data Structures 53
	The iofunc och t (Open Control Block) structure 56
	The iofunc attr t (attribute) structure 57
	The optional iofunc_mount_t (mount) structure 61
5	Handling Read and Write Messages 63
	Handling the _IO_READ message 65
	Sample code for handling IO READ messages 66
	Handling the IO WRITE message 68
	Sample code for handling IO WRITE messages 69
	Methods of returning and replying 71
	Returning with an error 71
	Returning using an IOV array that points to your data 71
	Returning with a single buffer containing data 72
	Returning success but with no data 72
	Getting the resource manager library to do the reply 72
	Performing the reply in the server 73
	Leaving the client blocked, replying later 73
	Returning and telling the library to do the default action 75
	Handling other read/write details 75
	Handling the <i>xtype</i> member 75
	Handling $pread*()$ and $pwrite*()$ 76
	Handling readcond() 78
	Updating the time for reads and writes 79

# 6 Combine Messages 81

Where combine messages are used 83

iv Contents May 10, 2010

7

8

9

10

Atomic operations 83 Bandwidth considerations 84 The library's combine-message handling 84 Component responses 85 Component data access 86 Locking and unlocking the attribute structure 87 Connect message types 87 IO CONNECT COMBINE CLOSE 88 IO CONNECT COMBINE **Extending the POSIX-Layer Data Structures** Overview Extending the OCB and attribute structures 91 Extending the mount structure **Handling Other Messages** 95 97 Custom messages Handling devctl() messages 98 Sample code for handling IO DEVCTL messages 99 Handling *ionotify()* and *select()* 103 Sample code for handling \_IO\_NOTIFY messages 106 Handling out-of-band ( IO MSG) messages Handling private messages and pulses Handling open(), dup(), and close() messages 117 Handling *mount()* 118 *mount()* function call 118 Mount in the resource manager 119 mount utility 122 Handling stat() 123 Handling *lseek()* 124 Signals, Timeouts, and Interrupts 125 Handling client unblocking due to signals or timeouts Handling interrupts 128 Sample code for handling interrupts 129 **Multithreaded Resource Managers** 133 Multithreaded resource manager example Thread pool attributes 136 Thread pool functions 138

89

May 10, 2010 Contents V

## 11 Filesystem Resource Managers 139

Considerations for filesystem resource managers 141
Taking over more than one device 141
Handling directories 142
Matching at or below a mountpoint 143
The \_IO\_OPEN message for filesystems 143
Returning directory entries from \_IO\_READ 144

Glossary 149

Index 165

vi Contents May 10, 2010

# List of Figures

Under-the-cover communication between the client, the process manager, and the resource manager. 16

You can use the resmgr layer to handle \_IO\_\* messages. 20

You can use the dispatch layer to handle <code>\_io\_\*</code> messages, select, pulses, and other messages. 21

A resource manager is responsible for three data structures. 55

Multiple clients with multiple OCBs, all linked to one mount structure. 56

Encapsulating the POSIX-layer data structures. 91

Returning the optional struct dirent\_extra\_stat along with the struct dirent entry can improve efficiency. 147

May 10, 2010 List of Figures VII

# **About This Guide**

May 10, 2010 About This Guide ix

# What you'll find in this guide

This guide will help you create a *resource manager*, a process that registers a name in the filesystem name space, which other processes then use to communicate with the resource manager.

The following table may help you find information quickly:

For information about:	Go to:
What's a resource manager	Overview
The overall structure of a resource manager	The Bones of a Resource Manager
Adding some "meat" to the basic structure	Fleshing Out the Skeleton
Data structures that the POSIX-layer routines use	POSIX-Layer Data Structures
Reading and writing data	Handling Read and Write Messages
Atomic operations	Combine Messages
Adding your own data to resource-manager structures	Extending the POSIX-Layer Data Structures
Handling other types of messages	Handling Other Messages
Handling signals, timeouts, and interrupts	Signals, Timeouts, and Interrupts
Handling more than one message at once	Multithreaded Resource Managers
Taking over a directory	Filesystem Resource Managers
Terms used in QNX docs	Glossary

For another perspective on resource managers, see the Resource Managers chapter of *Getting Started with QNX Neutrino*. In particular, this chapter includes a summary of the handlers for the connect and I/O messages that a resource manager will receive; see "Alphabetical listing of connect and I/O functions" in it.



This book assumes that you're familiar with message passing. If you're not, see the Interprocess Communication (IPC) chapter in the *System Architecture* guide as well as the *MsgSend()*, *MsgReceivev()*, and *MsgReply()* series of calls in the QNX Neutrino *Library Reference*.

For information about programming in Neutrino, see *Getting Started with QNX Neutrino: A Guide for Realtime Programmers* and the Neutrino *Programmer's Guide*.

## Typographical conventions

Throughout this manual, we use certain typographical conventions to distinguish technical terms. In general, the conventions we use conform to those found in IEEE POSIX publications. The following table summarizes our conventions:

May 10, 2010 About This Guide Xi

Reference	Example
Code examples	if( stream == NULL )
Command options	-1R
Commands	make
Environment variables	PATH
File and pathnames	/dev/null
Function names	exit()
Keyboard chords	Ctrl-Alt-Delete
Keyboard input	something you type
Keyboard keys	Enter
Program output	login:
Programming constants	NULL
Programming data types	unsigned short
Programming literals	<pre>0xFF, "message string"</pre>
Variable names	stdin
User-interface components	Cancel

We use an arrow  $(\rightarrow)$  in directions for accessing menu items, like this:

You'll find the **Other...** menu item under **Perspective**→**Show View**.

We use notes, cautions, and warnings to highlight important messages:



Notes point out something important or useful.



**CAUTION:** Cautions tell you about commands or procedures that may have unwanted or undesirable side effects.



WARNING: Warnings tell you about commands or procedures that could be dangerous to your files, your hardware, or even yourself.

### **Note to Windows users**

In our documentation, we use a forward slash (/) as a delimiter in *all* pathnames, including those pointing to Windows files.

We also generally follow POSIX/UNIX filesystem conventions.

XII About This Guide May 10, 2010

# **Technical support**

To obtain technical support for any QNX product, visit the **Support** area on our website (www.qnx.com). You'll find a wide range of support options, including community forums.

May 10, 2010 About This Guide **Xiii** 

# Chapter 1

# **Overview**

# In this chapter...

What is a resource manager?	3	
Why write a resource manager?	4	
The types of resource managers	5	
Communication via native IPC	6	
Examples of resource managers	7	
When not to use a resource manage	er	12

May 10, 2010 Chapter 1 ● Overview 1

## What is a resource manager?

In general terms, a *resource manager* is a process that registers a name in the filesystem name space. Other processes use that path to communicate with the resource manager.

To give QNX Neutrino a great degree of flexibility, to minimize the runtime memory requirements of the final system, and to cope with the wide variety of devices that may be found in a custom embedded system, the OS allows user-written processes to act as resource managers that can be started and stopped dynamically.

Resource managers are typically responsible for presenting an interface to various types of devices. This may involve managing actual hardware devices (like serial ports, parallel ports, network cards, and disk drives) or virtual devices (like /dev/null, a network filesystem, and pseudo-ttys).

In other operating systems, this functionality is traditionally associated with *device drivers*. But unlike device drivers, resource managers don't require any special arrangements with the kernel. In fact, a resource manager runs as a process that's *separate from the kernel* and looks just like any other user-level program.

The kernel (procnto) is itself a resource manager; it handles /dev/null, /proc, and several other resources in the same way any other process handles them.

A resource manager accepts messages from other programs and, optionally, communicates with hardware. It registers a pathname prefix in the pathname space (e.g. /dev/ser1), and other processes can open that name using the standard C library open() function, and then read() from, and write() to, the resulting file descriptor. When this happens, the resource manager receives an open request, followed by read and write requests.

A resource manager isn't restricted to handling just *open()*, *read()*, and *write()* calls — it can support any functions that are based on a file descriptor or file pointer, as well as other forms of IPC.

Adding resource managers in Neutrino won't affect any other part of the OS — the drivers are developed and debugged like any other application. And since the resource managers are in their own protected address space, a bug in a device driver won't cause the entire OS to shut down.

If you've written device drivers in most UNIX variants, you're used to being restricted in what you can do within a device driver; but since a device driver in Neutrino is just a regular process, you aren't restricted in what you can do (except for the restrictions that exist inside an ISR).



In order to register a prefix in the pathname space, a resource manager must be run as root.

For example, a serial port may be managed by a resource manager called devc-ser8250, although the actual resource may be called /dev/ser1 in the

May 10, 2010 Chapter 1 ● Overview

pathname space. When a process requests serial port services, it does so by opening a serial port (in this case /dev/ser1).

```
fd = open("/dev/ser1", O_RDWR);
for (packet = 0; packet < npackets; packet++)
{
    write(fd, packets[packet], PACKET_SIZE);
}
close(fd);</pre>
```

Because resource managers execute as processes, their use isn't restricted to device drivers — any server can be written as a resource manager. For example, a server that's given DVD files to display in a GUI interface wouldn't be classified as a driver, yet it could be written as a resource manager. It can register the name /dev/dvd and as a result, clients can do the following:

```
fd = open("/dev/dvd", O_WRONLY);
while (data = get_dvd_data(handle, &nbytes))
{
    bytes_written = write(fd, data, nbytes);
    if (bytes_written != nbytes)
    {
        perror ("Error writing the DVD data");
    }
}
close(fd);
```

## Why write a resource manager?

Here are a few reasons why you'd want to write a resource manager:

• The client API is POSIX.

The API for communicating with the resource manager is, for the most part, POSIX. All C programmers are familiar with the *open()*, *read()*, and *write()* functions. Training costs are minimized, and so is the need to document the interface to your server.

• You can reduce the number of interface types.

If you have many server processes, writing each server as a resource manager keeps the number of different interfaces that clients need to use to a minimum.

An example of this is if you have a team of programmers building your overall application, and each programmer is writing one or more servers for that application. These programmers may work directly for your company, or they may belong to partner companies who are developing add-on hardware for your modular platform.

If the servers are resource managers, then the interface to all of those servers is the POSIX functions: open(), read(), write(), and whatever else makes sense. For control-type messages that don't fit into a read/write model, there's devctl() (although devctl() isn't POSIX).

Chapter 1 • Overview May 10, 2010

• Command-line utilities can communicate with resource managers.

Since the API for communicating with a resource manager is the POSIX set of functions, and since standard POSIX utilities use this API, the utilities can be used for communicating with the resource managers.

## The types of resource managers

There are two types of resource managers:

- Device resource managers
- Filesystem resource managers

The type you use depends on what you want the resource manager to do, as well as on the amount of work you want to do yourself in order to present a proper POSIX filesystem to the client.

## **Device resource managers**

Device resource managers create only single-file entries in the filesystem, each of which is registered with the process manager. Each name usually represents a single device. These resource managers typically rely on the resource-manager library to do most of the work in presenting a POSIX device to the user.

For example, a serial port driver registers names such as /dev/ser1 and /dev/ser2. When the user does ls -l /dev, the library does the necessary handling to respond to the resulting \_IO\_STAT messages with the proper information. The person who writes the serial port driver is able to concentrate instead on the details of managing the serial port hardware.

## Filesystem resource managers

Filesystem resource managers register a *mountpoint* with the process manager. A mountpoint is the portion of the path that's registered with the process manager. The remaining parts of the path are managed by the filesystem resource manager. For example, when a filesystem resource manager attaches a mountpoint at /mount, and the path /mount/home/thomasf is examined:

/mount/ Identifies the mountpoint that's managed by the process

manager.

home/thomasf Identifies the remaining part that's to be managed by the

filesystem resource manager.

Examples of using filesystem resource managers are:

• flash filesystem drivers (although the source code for flash drivers — available on our Foundry27 community website — takes care of these details)

May 10, 2010 Chapter 1 • Overview 5

- a tar filesystem process that presents the contents of a tar file as a filesystem that the user can cd into and 1s from
- a mailbox-management process that registers the name /mailboxes and manages individual mailboxes that look like directories, and files that contain the actual messages

## Communication via native IPC

Once a resource manager has established its pathname prefix, it will receive messages whenever any client program tries to do an *open()*, *read()*, *write()*, etc. on that pathname. For example, after devc-ser\* has taken over the pathname /dev/ser1, and a client program executes:

```
fd = open ("/dev/ser1", O RDONLY);
```

the client's C library will construct an \_IO\_CONNECT message, which it then sends to the devc-ser\* resource manager via IPC.

Some time later, when the client program executes:

```
read (fd, buf, BUFSIZ);
```

the client's C library constructs an \_IO\_READ message, which is then sent to the resource manager.

A key point is that *all* communications between the client program and the resource manager are done through *native IPC messaging*. This allows for a number of unique features:

- A well-defined interface to application programs. In a development environment, this allows a very clean division of labor for the implementation of the client side and the resource manager side.
- A simple interface to the resource manager. Since all interactions with the resource manager go through native IPC, and there are no special "back door" hooks or arrangements with the OS, the writer of a resource manager can focus on the task at hand, rather than worry about all the special considerations needed in other operating systems.
- Free network transparency. Since the underlying native IPC messaging mechanism is inherently network-distributed without any additional effort required by the client or server (resource manager), programs can seamlessly access resources on other nodes in the network without even being aware that they're going over a network.



All QNX Neutrino device drivers and filesystems are implemented as resource managers. This means that everything that a "native" QNX Neutrino device driver or filesystem can do, a user-written resource manager can do as well.

Chapter 1 ● Overview May 10, 2010

Consider FTP filesystems, for instance. Here a resource manager would take over a portion of the pathname space (e.g. /ftp) and allow users to cd into FTP sites to get files. For example, cd /ftp/rtfm.mit.edu/pub would connect to the FTP site rtfm.mit.edu and change directory to /pub. After that point, the user could open, edit, or copy files.

Application-specific filesystems would be another example of a user-written resource manager. Given an application that makes extensive use of disk-based files, a custom tailored filesystem can be written that works with that application and delivers superior performance.

The possibilities for custom resource managers are limited only by the application developer's imagination.

# **Examples of resource managers**

Before getting into the workings of a resource manager, let's consider some actual and possible uses:

- Transparent Distributed Processing (Qnet) statistics
- Robot arm
- GPS devices
- Database example
- I2C (Inter-Integrated Circuit) driver

## **Transparent Distributed Processing (Qnet) statistics**

For instance, Transparent Distributed Processing (Qnet) — part of the io-pkt core networking stack — contains resource-manager code that registers the name /proc/qnetstats. If you open this name and read from it, the resource manager code responds with a body of text that describes the statistics for Qnet.

The cat utility takes the name of a file and opens the file, reads from it, and displays whatever it reads to standard output (typically the screen). As a result, you can type:

#### cat /proc/qnetstats

The Quet resource manager code responds with text such as:

```
kif net_server
                                   0,3
kif waiting
kif net_client
                                  0,1
kif buffer
                                  0,1
kif outbound_msgs
                                  0,1
kif vtid
                                  0,1
kif server_msgs
                                  0,1
kif nd_down
                                  42
kif nd_up
                                 132
kif nd_changed
```

May 10, 2010 Chapter 1 • Overview **7** 

kif send_ad	cks	:	0
kif client	kercalls	:	14
kif server	msgs	:	202898
kif server	_unblock	:	0
qos tx_beg:	in_errors	:	0
qos tx_done	e_errors	:	0
qos tx_thre	ottled	:	0
qos tx_fai:	led	:	8
qos pkts_r	kd_noL4	:	0
qos tx_con	${\tt n\_created}$	:	43
qos tx_con	${\tt n\_deleted}$	:	41
qos rx_con	$n\_{\tt created}$	:	35
qos rx_con	${\tt n\_deleted}$	:	33
qos rx_seq	_order	:	0

#### Robot arm

You could also use command-line utilities for a robot-arm driver. The driver could register the name, /dev/robot/arm/angle, and any writes to this device are interpreted as the angle to set the robot arm to. To test the driver from the command line, you'd type:

```
echo 87 >/dev/robot/arm/angle
```

The echo utility opens /dev/robot/arm/angle and writes the string ("87") to it. The driver handles the write by setting the robot arm to 87 degrees. Note that this was accomplished without writing a special tester program.

Another example would be names such as /dev/robot/registers/r1, r2, ...

Reading from these names returns the contents of the corresponding registers; writing to these names set the corresponding registers to the given values.

Even if all of your other IPC is done via some non-POSIX API, it's still worth having one thread written as a resource manager for responding to reads and writes for doing things as shown above.

### **GPS** devices

In general, a GPS device sends a stream of data every second. The stream is composed of information organized in command groups. Here's an example of the output from a GPS:

```
$GPGSA,A,3,17,16,22,31,03,18,25,,,,,,1.6,1.0,1.2*39
$GPGGA,185030.30,4532.8959,N,07344.2298,W,1,07,1.0,23.8,M,-32.0,M,,*69
$GPGLL,4532.8959,N,07344.2298,W,185030.30,A*12
$GPRMC,185030.00,A,4532.8959,N,07344.2298,W,0.9,116.9,160198,,*27
$GPVTG,116.9,T,,,0.9,N,1.7,K*2D
$GPZDA,185030.30,16,01,1998,,*65
$GPGSV,2,1,08,03,55,142,50,22,51,059,51,18,48,284,53,31,23,187,52*78
```

Each line corresponds to a data set. Here's the C structure of some of the data sets:

```
typedef struct GPSRMC_s {
   double UTC;
   int Status;
   Degree t Latitude;
```

Chapter 1 ● Overview May 10, 2010

```
NORTHSOUTH Northing;
Degree_t Longitude;
EASTWEST Easting;
float Speed;
float Heading;
} GPSRMC_t;

typedef struct GPSVTG_s {
  float Heading;
  float SpeedInKnots;
  float SpeedInKMH;
} GPSVTG_t;

typedef struct GPSUTM_s {
  UTM_t X;
  UTM_t Y;
} GPSUTM_t;
```

You could provide one API per GPS format command:  $gps\_get\_rmc()$ ,  $gps\_get\_vtg()$ ,  $get\_get\_utm()$ , and so on. Internally, each function would send a message with a different command, and the reply was the data last received by the GPS.

The first obstacle was that *read()* and *write()* are half-duplex operations; you can't use them to send a command and get data back. You could do this:

```
GPSUTM_t utm;
Int cmd = GPS_GET_GSA;
fd = open( "/dev/gps1", O_RDWR );
write( fd, &cmd, sizeof( cmd) );
read( fd, &data, sizeof(data) );
close(fd);
```

but this code looks unnatural. Nobody would expect *read()* and *write()* to be used in that way. You could use *devctl()* to send a command and request specific data, but if you implement the driver as a resource manager, you can have a different path for every command set. The driver would create the following pathnames:

- /dev/gps1/gsa.txt
- /dev/gps1/gsa.bin
- /dev/gps1/gga.bin
- /dev/gps1/gga.txt

and a program wanting to get GSA information would do this:

```
gps_gsa_t gsa;
int fd;

fd = open ( "/dev/gps1/gsa.bin", O_RDONLY );
read( fd, &gsa, sizeof( gsa ) );
close ( fd);
```

The benefit of having both the .txt and .bin extensions is that data returned by the read() would be in ASCII format if you use the .txt file. If you use the .bin file instead, the data is returned in a C structure for easier use. But why support \*.txt if most programs would prefer to use the binary representation? The reason is simple. From the shell you could type:

May 10, 2010 Chapter 1 • Overview 9

```
# cat /dev/gps1/rmc.txt
and you'd see:
```

```
# GPRMC, 185030.00, A, 4532.8959, N, 07344.2298, W, 0.9, 116.9, 160198, , *27
```

You now have access to the GPS data from the shell. But you can do even more:

- If you want to know all the commands the GPS supports, simply type:
   # 1s /dev/gps1
- To do the same from a C program, use *opendir()* and *readdir()*.
- If you want your program to be informed when there's new data available, simply use *select()* or *ionotify()* instead of polling on the data.

Contrary to what you might think, it's quite simple to support these features from within the resource manager.

### **Database example**

This particular design asked for a program to centralize file access. Instead of having each program handle the specific location of the data files (on the hard disk or in FLASH or RAM), the developers decided that one program would handle it. Furthermore, file updates done by one program required that all programs using that file be notified. So instead of having each program notify each other, only one program would take care of the notification. That program was cleverly named "database".

The API in the original design included  $db\_read()$ ,  $db\_write()$ ,  $db\_update\_notification()$ , etc., but a resource manager is an even better fit. The API was changed to the familiar open(), read(), write(), select(), ionotify() and so on.

Client programs were seeing only one path, /dbase/filename, but the files found in /dbase/ weren't physically there; they could be scattered all over the place.

The database resource manager program looked at the filename during <code>open()</code> and decided where the file needed to go or to read from. This, of course, depended on the specific field in the filename. For example, if the file had a <code>.tmp</code> extension, it would go to the RAM disk.

The real beauty of this design is that the designers of the client program could test their application without having the database program running. The *open()* would be handled directly by the filesystem.

To support notification of a file change, a client would use *ionotify()* or *select()* on the file descriptor of the files. Unfortunately, that feature isn't supported natively by the filesystem, so the database program needs to be running in order for you to test the operation.

10 Chapter 1 • Overview May 10, 2010

## **I2C (Inter-Integrated Circuit) driver**

This example is a driver for an I2C bus controller of the PowerPC MPC860. The I2C bus is simply a 2-wire bus, and the hardware is extremely cheap to implement. The bus supports up to 127 devices on the bus, and each device can handle 256 commands. When devices want to read or write information to or from another device, they must first be set up as a master to own the bus. Then the device sends out the device address and command register number. The slave then acts upon the command received.

You think a resource manager wouldn't apply in this case. All *read()* and *write()* operations require a device address and command register. You could use *devctl()*, but a resource manager again provides a cleaner interface.

With a resource manager, each device would live under its own directory, and each register would have a filename:

```
/dev/i2c1//
```

An important thing to note is that each filename (127 devices \* 256 registers = 32512 filenames) doesn't really need to exist. Each device would be created live, as it's required. Therefore, each *open()* is actually an O\_CREATE.

To prevent any problems caused by a high number of possibly existing files, you could make an ls command of the /dev/i2cl directory return nothing. Alternatively, you could make ls list the filenames that have been opened at least once. At this point, it's important to clarify that the existence of the filenames is totally handled by the resource manager; the OS itself isn't used in that process. So it isn't a problem if filenames respond to *open()* requests, but not to ls.

One element is left to solve: the I2C bus has a concept of a baud rate. There are already C functions to set up baud rates, and you can make it work via the stty command from the shell.

People using the driver don't have to worry about libraries or include files because there are none. The resource manager, at no cost, allows each command register to be accessed via the shell, or for that matter, though SAMBA from a Linux or Windows machine. Access via the shell makes debugging so easy — there's no need to write custom test tools, and it's unbelievably flexible, not to mention the support for separate permissions for each and every command register of every device.

One more thing: this code could be clearer:

```
fd = open ( "/dev/i2c1/34/45" );
read( fd, &variable, sizeof( variable ) );
close(fd);
```

It would be much better to have this instead:

```
fd = open ( "/dev/i2cl/flash/page_number" );
read( fd, &page_number, sizeof( page_number ) );
close (fd );
```

Of course, you could use **#define** directives to show meaningful information, but an even better solution is to create a configuration file that the driver could read to create an alias. The configuration file looks like this:

May 10, 2010 Chapter 1 ● Overview 11

[4=temperature\_sensor]
10=max
11=min
12=temperature
13=alarm
[5=flash]
211=page number

The field inside the square brackets defines the device address and name. The data that follows specifies each register of that device. The main advantages to this approach are:

- The configuration file's format helps document the program.
- If the hardware is changed, and devices are assigned new addresses, you simply change the configuration file — there's no need to recompile the program to recompile.

These predefined devices would always show via the 1s command.

## When not to use a resource manager

There are times when a resource manager isn't required.

The most obvious case would be if a program doesn't need to receive messages. But still, if your program is event-driven, you might want to look at using the dispatch library to handle internal events. In the future, if your program ever needs to receive messages, you can easily turn it into a resource manager.

Another case might be if your program interfaces only with its children. The parent has access to all the children's information required to interface with them.

Nevertheless, you can turn almost everything into a resource manager. If your resource manager's client uses only the POSIX API, there's less documentation to write, and the code is very portable. Of course, in many cases, providing an API on top of the POSIX API is often very desirable. You could hide the details of *devctl()* or custom messages. The internals of the API could then be changed if you have to port to a different OS.

If you must transfer high volumes of data at a very high rate, a resource manager can be a problem. Since resource managers basically interface via IPC kernel primitives, they're slower than a simple *memcpy()*, but nothing prevents you from using a mix of shared memory, POSIX API, and custom messages, all to be hidden in your own API. It wouldn't be too difficult to have the API detect whether or not the resource manager is local and to use shared memory when local and IPC when remote — a way to get the best of both worlds.

12 Chapter 1 • Overview May 10, 2010

# Chapter 2

# The Bones of a Resource Manager

# In this chapter...

Under the covers 15
Layers in a resource manager 19
Simple examples of device resource managers 22

### Under the covers

Despite the fact that you'll be using a resource manager API that hides many details from you, it's still important to understand what's going on under the covers. For example, your resource manager is a server that contains a MsgReceive() loop, and clients send you messages using MsgSend\*(). This means that you must reply either to your clients in a timely fashion, or leave your clients blocked but save the rcvid for use in a later reply.

To help you understand, we'll discuss the events that occur under the covers for both the client and the resource manager.

#### Under the client's covers


When a client calls a function that requires pathname resolution (e.g. *open()*, *rename()*, *stat()*, or *unlink()*), the function sends messages to both the process manager and the resource manager to obtain a file descriptor. Once the file descriptor is obtained, the client can use it to send messages to the device associated with the pathname, via the resource manager.

In the following, the file descriptor is obtained, and then the client writes directly to the device:

```
/*
 * In this stage, the client talks
 * to the process manager and the resource manager.
 */
fd = open("/dev/ser1", O_RDWR);

/*
 * In this stage, the client talks directly to the
 * resource manager.
 */
for (packet = 0; packet < npackets; packet++)
{
    write(fd, packets[packet], PACKET_SIZE);
}
close(fd);</pre>
```

For the above example, here's the description of what happened behind the scenes. We'll assume that a serial port is managed by a resource manager called devc-ser8250, that's been registered with the pathname prefix /dev/ser1:



Under-the-cover communication between the client, the process manager, and the resource manager.

- The client's library sends a "query" message. The *open()* in the client's library sends a message to the process manager asking it to look up a name (e.g. /dev/ser1).
- 2 The process manager indicates who's responsible and it returns the *nd*, *pid*, *chid*, and *handle* that are associated with the pathname prefix.

#### Here's what went on behind the scenes...

When the devc-ser8250 resource manager registered its name (/dev/ser1) in the namespace, it called the process manager. The process manager is responsible for maintaining information about pathname prefixes. During registration, it adds an entry to its table that looks similar to this:

The table entries represent:

0	Node descriptor ( <i>nd</i> ).
47167	Process ID (pid) of the resource manager.
1	Channel ID ( <i>chid</i> ) that the resource manager is using to receive messages with.
0	Handle given in case the resource manager has registered more than one name. The handle for the first name is 0, 1 for the next name, etc.
0	The open type passed during name registration (0 is _FTYPE_ANY).

A resource manager is uniquely identified by a node descriptor, process ID, and a channel ID. The process manager's table entry associates the resource

The pathname prefix.

/dev/ser1

manager with a name, a handle (to distinguish multiple names when a resource manager registers more than one name), and an open type.

When the client's library issued the query call in step 1, the process manager looked through all of its tables for any registered pathname prefixes that match the name. If another resource manager had previously registered the name /, more than one match would be found. So, in this case, both / and /dev/ser1 match. The process manager will reply to the *open()* with the list of matched servers or resource managers. The servers are queried in turn about their handling of the path, with the longest match being asked first.

The client's library sends a "connect" message to the resource manager. To do so, it must create a connection to the resource manager's channel:

```
fd = ConnectAttach(nd, pid, chid, 0, 0);
```

The file descriptor that's returned by *ConnectAttach()* is also a connection ID and is used for sending messages directly to the resource manager. In this case, it's used to send a connect message (\_IO\_CONNECT defined in <sys/iomsg.h>) containing the handle to the resource manager requesting that it open /dev/ser1.



Typically, only functions such as *open()* call *ConnectAttach()* with an *index* argument of 0. Most of the time, you should OR \_NTO\_SIDE\_CHANNEL into this argument, so that the connection is made via a *side channel*, resulting in a connection ID that's greater than any valid file descriptor.

When the resource manager gets the connect message, it performs validation using the access modes specified in the *open()* call (e.g. are you trying to write to a read-only device?).

- The resource manager generally responds with a pass (and *open()* returns with the file descriptor) or fail (the next server is queried).
- When the file descriptor is obtained, the client can use it to send messages directly to the device associated with the pathname.

In the sample code, it looks as if the client opens and writes directly to the device. In fact, the *write()* call sends an \_IO\_WRITE message to the resource manager requesting that the given data be written, and the resource manager responds that it either wrote some of all of the data, or that the write failed.

Eventually, the client calls *close()*, which sends an \_IO\_CLOSE\_DUP message to the resource manager. The resource manager handles this by doing some cleanup.

## Under the resource manager's covers

The resource manager is a server that uses the Neutrino send/receive/reply messaging protocol to receive and reply to messages. The following is pseudo-code for a resource manager:

```
initialize the resource manager
register the name with the process manager
DO forever
   receive a message
   SWITCH on the type of message
       CASE IO CONNECT:
          call io open handler
           ENDCASE
       CASE IO READ:
          call io_read handler
           ENDCASE
       CASE IO WRITE:
          call io write handler
           ENDCASE
          /* etc. handle all other messages */
          /* that may occur, performing */
          /* processing as appropriate */
   ENDSWITCH
ENDDO
```

Many of the details in the above pseudo-code are hidden from you by a resource manager library that you'll use. For example, you won't actually call a MsgReceive\*() function — you'll call a library function, such as  $resmgr\_block()$  or  $dispatch\_block()$ , that does it for you. If you're writing a single-threaded resource manager, you might provide a message handling loop, but if you're writing a multithreaded resource manager, the loop is hidden from you.

You don't need to know the format of all the possible messages, and you don't have to handle them all. Instead, you register "handler functions," and when a message of the appropriate type arrives, the library calls your handler. For example, suppose you want a client to get data from you using read() — you'll write a handler that's called whenever an \_IO\_READ message is received. Since your handler handles \_IO\_READ messages, we'll call it an "io\_read handler."

The resource manager library:

- 1 Receives the message.
- **2** Examines the message to verify that it's an \_IO\_READ message.
- **3** Calls your *io read* handler.

However, it's still your responsibility to reply to the \_IO\_READ message. You can do that from within your *io\_read* handler, or later on when data arrives (possibly as the result of an interrupt from some data-generating hardware).

The library does default handling for any messages that you don't want to handle. After all, most resource managers don't care about presenting proper POSIX filesystems to the clients. When writing them, you want to concentrate on the code for talking to the device you're controlling. You don't want to spend a lot of time worrying about the code for presenting a proper POSIX filesystem to the client.

# Layers in a resource manager

A resource manager is composed of some of the following layers:

- thread pool layer (the top layer)
- dispatch layer
- resmgr layer
- iofunc layer (the bottom layer)

Let's look at these from the bottom up.

### The iofunc layer

This layer consists of a set of functions that take care of most of the POSIX filesystem details for you — they provide a POSIX personality. If you're writing a device resource manager, you'll want to use this layer so that you don't have to worry too much about the details involved in presenting a POSIX filesystem to the world.

This layer consists of default handlers that the resource manager library uses if you don't provide a handler. For example, if you don't provide an *io\_open* handler, *iofunc\_open\_default()* is called.

The iofunc layer also contains helper functions that the default handlers call. If you override the default handlers with your own, you can still call these helper functions. For example, if you provide your own *io\_read* handler, you can call *iofunc\_read\_verify()* at the start of it to make sure that the client has access to the resource.

The names of the functions and structures for this layer have the form *iofunc\_\**. The header file is <sys/iofunc.h>. For more information, see the QNX Neutrino *Library Reference*.


## The resmgr layer

This layer manages most of the resource manager library details. It:

- · examines incoming messages
- calls the appropriate handler to process a message

If you don't use this layer, then you'll have to parse the messages yourself. Most resource managers use this layer.

The names of the functions and structures for this layer have the form  $resmgr_*$ . The header file is sys/resmgr.h>. For more information, see the QNX Neutrino
Library Reference.



You can use the resmgr layer to handle \_IO\_\* messages.


## The dispatch layer

This layer acts as a single blocking point for a number of different types of things. With this layer, you can handle:

_IO_* messages	It uses the resmgr layer for this.
select()	Processes that do TCP/IP often call <code>select()</code> to block while waiting for packets to arrive, or for there to be room for writing more data. With the dispatch layer, you register a handler function that's called when a packet arrives. The functions for this are the <code>select_*()</code> functions.
Pulses	As with the other layers, you register a handler function that's called when a specific pulse arrives. The functions for this are the <i>pulse_*()</i> functions.
Other messages	You can give the dispatch layer a range of message types that you make up, and a handler. So if a message arrives and the first few bytes of the message contain a type in the given range, the

*message*\_\*() functions.

dispatch layer calls your handler. The functions for this are the



You can use the dispatch layer to handle IO \* messages, select, pulses, and other messages.

The following describes the manner in which messages are handled via the dispatch layer (or more precisely, through <code>dispatch\_handler()</code>). Depending on the blocking type, the handler may call the <code>message\_\*()</code> subsystem. A search is made, based on the message type or pulse code, for a matching function that was attached using <code>message\_attach()</code> or <code>pulse\_attach()</code>. If a match is found, the attached function is called.

If the message type is in the range handled by the resource manager (I/O messages) and pathnames were attached using  $resmgr\_attach()$ , the resource manager subsystem is called and handles the resource manager message.

If a pulse is received, it may be dispatched to the resource manager subsystem if it's one of the codes handled by a resource manager (UNBLOCK and DISCONNECT pulses). If a *select\_attach()* is done and the pulse matches the one used by *select*, then the *select* subsystem is called and dispatches that event.

If a message is received and no matching handler is found for that message type, MsgError(ENOSYS) is returned to unblock the sender.

### The thread pool layer

This layer allows you to have a single- or multithreaded resource manager. This means that one thread can be handling a *write()* while another thread handles a *read()*.

You provide the blocking function for the threads to use as well as the handler function that's to be called when the blocking function returns. Most often, you give it the dispatch layer's functions. However, you can also give it the resmgr layer's functions or your own.

You can use this layer independently of the resource manager layer.

# Simple examples of device resource managers

The following are complete but **simple** examples of a device resource manager:

- single-threaded device resource manager
- multithreaded device resource manager
- Using *MsgSend()* and *MsgReply()*



As you read through this guide, you'll encounter many code snippets. Most of these code snippets have been written so that they can be combined with either of these simple resource managers.

The first two of these simple device resource managers model their functionality after that provided by /dev/null (although they use /dev/sample to avoid conflict with the "real" /dev/null):

- an *open()* always works
- read() returns zero bytes (indicating EOF)
- a write() of any size "works" (with the data being discarded)
- lots of other POSIX functions work (e.g. *chown()*, *chmod()*, *lseek()*)

The chapters that follow describe how to add more functionality to these simple resource managers.



The QNX Momentics Integrated Development Environment (IDE) includes a sample /dev/sample resource manager that's very similar to the single-threaded one given below. To get the sample in the IDE, choose **Help**→**Welcome**, and then click the Samples icon.

### Single-threaded device resource manager

Here's the complete code for a simple single-threaded device resource manager:

```
#include <errno.h>
#include <stdio.h>
#include <stddef.h>
#include <stdlib.h>
#include <unistd.h>
#include <sys/iofunc.h>
#include <sys/dispatch.h>
static resmgr_connect_funcs_t connect_funcs;
static resmgr_io_funcs_t io_funcs;
static iofunc_attr_t
                                attr;
main(int argc, char **argv)
    /* declare variables we'll be using */
   resmgr_attr_t resmgr_attr;
    dispatch_t
                        *dpp;
    dispatch_context_t *ctp;
                         id;
    /* initialize dispatch interface */
    if((dpp = dispatch_create()) == NULL) {
        fprintf(stderr,
                "%s: Unable to allocate dispatch handle.\n",
               argv[0]);
        return EXIT FAILURE;
    }
    /* initialize resource manager attributes */
    memset(&resmgr attr, 0, sizeof resmgr attr);
    resmgr attr.nparts max = 1;
    resmgr_attr.msg_max_size = 2048;
    /* initialize functions for handling messages */
    iofunc_func_init(_RESMGR_CONNECT_NFUNCS, &connect_funcs,
                     RESMGR IO NFUNCS, &io funcs);
    /* initialize attribute structure used by the device */
    iofunc_attr_init(&attr, S_IFNAM | 0666, 0, 0);
    /* attach our device name */
    id = resmgr attach(
                           /* dispatch handle
            dpp,
            &resmgr_attr, /* resource manager attrs */
"/dev/sample", /* device name */
            _FTYPE_ANY, /* open type 0, /* flags
           &connect_funcs, /* connect routines
                                                      */
           &io_funcs, /* I/O routines
           &attr);
                          /* handle
    if(id == -1) {
       fprintf(stderr, "%s: Unable to attach name.\n", argv[0]);
       return EXIT_FAILURE;
    /* allocate a context structure */
    ctp = dispatch_context_alloc(dpp);
    /* start the resource manager message loop */
```

```
while(1) {
    if((ctp = dispatch_block(ctp)) == NULL) {
        fprintf(stderr, "block error\n");
        return EXIT_FAILURE;
    }
    dispatch_handler(ctp);
}
```



Include <sys/dispatch.h> after <sys/iofunc.h> to avoid warnings about redefining the members of some functions.

Let's examine the sample code step-by-step.

### Initialize the dispatch interface

We need to set up a mechanism so that clients can send messages to the resource manager. This is done via the <code>dispatch\_create()</code> function which creates and returns the dispatch structure. This structure contains the channel ID. Note that the channel ID isn't actually created until you attach something, as in <code>resmgr\_attach()</code>, <code>message\_attach()</code>, and <code>pulse\_attach()</code>.



The dispatch structure (of type dispatch\_t) is opaque; you can't access its contents directly. Use message connect() to create a connection using this hidden channel ID.

#### Initialize the resource manager attributes

When you call *resmgr\_attach()*, you pass a **resmgr\_attr\_t** control structure to it. Our sample code initializes this structure like this:

```
/* initialize resource manager attributes */
memset(&resmgr_attr, 0, sizeof resmgr_attr);
resmgr_attr.nparts_max = 1;
resmgr_attr.msg_max_size = 2048;
```

In this case, we're configuring:

- how many IOV structures are available for server replies (nparts max)
- the minimum receive buffer size (*msg\_max\_size*)

For more information, see *resmgr\_attach()* in the QNX Neutrino *Library Reference*.

### Initialize functions used to handle messages

Here we supply two tables that specify which function to call when a particular message arrives:

- connect functions table
- I/O functions table

Instead of filling in these tables manually, we call <code>iofunc\_func\_init()</code> to place the <code>iofunc\_\*\_default()</code> handler functions into the appropriate spots.

### Initialize the attribute structure used by the device

```
/* initialize attribute structure used by the device */
iofunc_attr_init(&attr, S_IFNAM | 0666, 0, 0);
```

The attribute structure contains information about our particular device associated with the name /dev/sample. It contains at least the following information:

- permissions and type of device
- owner and group ID

Effectively, this is a *per-name* data structure. In the Extending the POSIX-Layer Data Structures chapter, we'll see how you can extend the structure to include your own *per-device* information.

### Put a name into the namespace

To register our resource manager's path, we call resmgr attach() like this:

Before a resource manager can receive messages from other programs, it needs to inform the other programs (via the process manager) that it's the one responsible for a particular pathname prefix. This is done via pathname registration. When the name is registered, other processes can find and connect to this process using the registered name.

In this example, a serial port may be managed by a resource manager called devc-xxx, but the actual resource is registered as /dev/sample in the pathname space. Therefore, when a program requests serial port services, it opens the /dev/sample serial port.

We'll look at the parameters in turn, skipping the ones we've already discussed.

device name	Name associated with our device (i.e. /dev/sample).
open type	Specifies the constant value of _FTYPE_ANY. This tells the process
	manager that our resource manager will accept any type of open

request — we're not limiting the kinds of connections we're going to be handling.

Some resource managers legitimately limit the types of open requests they handle. For instance, the POSIX message queue resource manager accepts only open messages of type FTYPE MQUEUE.

flags

Controls the process manager's pathname resolution behavior. By specifying a value of zero, we indicate that we'll accept only requests for the name "/dev/sample".



The bits that you use in this argument are the \_RESMGR\_FLAG\_\* flags (e.g. \_RESMGR\_FLAG\_BEFORE) defined in <sys/resmgr.h>. We'll discuss some of these flags in this guide, but you can find a full list in the entry for resmgr\_attach() in the QNX Neutrino Library Reference.

There are some other flags whose names *don't* start with an underscore, but they're for the *flags* member of the <code>resmgr\_attr\_t</code> structure, which we'll look at in more detail in "Setting resource manager attributes" in the Fleshing Out the Skeleton chapter.

#### Allocate the context structure

```
/* allocate a context structure */
ctp = dispatch_context_alloc(dpp);
```

The context structure contains a buffer where messages will be received. The size of the buffer was set when we initialized the resource manager attribute structure. The context structure also contains a buffer of IOVs that the library can use for replying to messages. The number of IOVs was set when we initialized the resource manager attribute structure.

For more information, see *dispatch\_context\_alloc()* in the QNX Neutrino *Library Reference*.

### Start the resource manager message loop

```
/* start the resource manager message loop */
while(1) {
    if((ctp = dispatch_block(ctp)) == NULL) {
        fprintf(stderr, "block error\n");
        return EXIT_FAILURE;
    }
    dispatch_handler(ctp);
}
```

Once the resource manager establishes its name, it receives messages when any client program tries to perform an operation (e.g. *open()*, *read()*, *write()*) on that name.

In our example, once /dev/sample is registered, and a client program executes:

```
fd = open ("/dev/sample", O RDONLY);
```

the client's C library constructs an \_IO\_CONNECT message and sends it to our resource manager. Our resource manager receives the message within the <code>dispatch\_block()</code> function. We then call <code>dispatch\_handler()</code>, which decodes the

message and calls the appropriate handler function based on the connect and I/O function tables that we passed in previously. After *dispatch\_handler()* returns, we go back to the *dispatch\_block()* function to wait for another message.



Note that <code>dispatch\_block()</code> returns a pointer to a dispatch context (<code>dispatch\_context\_t</code>) structure — the same type of pointer you pass to the routine:

- If dispatch\_block() returns a non-NULL context pointer, it could be different from the one passed in, as it's possible for the ctp to be reallocated to a larger size. In this case, the old ctp is no longer valid.
- If dispatch\_block() returns NULL (for example, because a signal interrupted the MsgReceive()), the old context pointer is still valid. Typically, a resource manager targets any signals to a thread that's dedicated to handling signals. However, if a signal can be targeted to the thread doing dispatch\_block(), you could use the following code:

```
dispatch_context_t *ctp, *new_ctp;
ctp = dispatch_context_alloc( ... );
while (1) {
   new_ctp = dispatch_block( ctp );
   if ( new_ctp ) {
      ctp = new_ctp
      }
   else {
      /* handle the error condition */
      :
      }
}
```

At some later time, when the client program executes:

```
read (fd, buf, BUFSIZ);
```

the client's C library constructs an \_IO\_READ message, which is then sent directly to our resource manager, and the decoding cycle repeats.

## Multithreaded device resource manager

Here's the complete code for a simple multithreaded device resource manager:

```
#include <errno.h>
#include <stdio.h>
#include <stddef.h>
#include <stdlib.h>
#include <unistd.h>

/*
 * Define THREAD_POOL_PARAM_T such that we can avoid a compiler
 * warning when we use the dispatch_*() functions below
 */
#define THREAD_POOL_PARAM_T dispatch_context_t
```

```
#include <sys/iofunc.h>
#include <sys/dispatch.h>
static resmgr_connect_funcs_t connect_funcs;
static resmgr_io_funcs_t io_function io_fu
                                                                    io_funcs;
main(int argc, char **argv)
         /* declare variables we'll be using */
        thread_pool_attr_t pool_attr;
        resmgr_attr_t resmgr_attr;
dispatch_t *dpp;
        thread_pool_t *tpp;
        dispatch_context_t *ctp;
        int
                                                     id;
         /* initialize dispatch interface */
        if((dpp = dispatch create()) == NULL) {
                 fprintf(stderr, "%s: Unable to allocate dispatch handle.\n",
                                 argv[0]);
                 return EXIT FAILURE;
        }
        /* initialize resource manager attributes */
        memset(&resmgr attr, 0, sizeof resmgr attr);
        resmgr_attr.nparts_max = 1;
        resmgr attr.msg max size = 2048;
         /* initialize functions for handling messages */
         iofunc_func_init(_RESMGR_CONNECT_NFUNCS, &connect_funcs,
                                             _RESMGR_IO_NFUNCS, &io funcs);
         /* initialize attribute structure used by the device */
         iofunc_attr_init(&attr, S_IFNAM | 0666, 0, 0);
         /* attach our device name */
         id = resmgr attach(dpp,
                                                                                   /* dispatch handle
                                                 _FTYPE_ANY, /* open type
0, /* flags
                                                  0,
                                                  &connect funcs, /* connect routines
                                                                                                                                            */
                                                  &io_funcs, /* I/O routines
                                                                                 /* handle
                                                  &attr);
        if(id == -1) {
                 fprintf(stderr, "%s: Unable to attach name.\n", argv[0]);
                 return EXIT FAILURE;
         /* initialize thread pool attributes */
        memset(&pool_attr, 0, sizeof pool_attr);
        pool_attr.handle = dpp;
        pool_attr.context_alloc = dispatch context alloc;
        pool_attr.block_func = dispatch_block;
        pool_attr.unblock_func = dispatch_unblock;
        pool attr.handler func = dispatch handler;
        pool_attr.context_free = dispatch_context_free;
        pool attr.lo water = 2;
        pool_attr.hi_water = 4;
        pool attr.increment = 1;
        pool_attr.maximum = 50;
```

Most of the code is the same as in the single-threaded example, so we'll cover only those parts that aren't described above. Also, we'll go into more detail on multithreaded resource managers later in this guide, so we'll keep the details here to a minimum.

For this code sample, the threads are using the *dispatch\_\*()* functions (i.e. the dispatch layer) for their blocking loops.

### Define THREAD\_POOL\_PARAM T

```
/*
 * Define THREAD_POOL_PARAM_T such that we can avoid a compiler
 * warning when we use the dispatch_*() functions below
 */
#define THREAD_POOL_PARAM_T dispatch_context_t

#include <sys/iofunc.h>
#include <sys/dispatch.h>
```

The THREAD\_POOL\_PARAM\_T manifest tells the compiler what type of parameter is passed between the various blocking/handling functions that the threads will be using. This parameter should be the context structure used for passing context information between the functions. By default it's defined as a resmgr\_context\_t, but since this sample is using the dispatch layer, we need it to be a dispatch\_context\_t. We define it prior to the include directives above, since the header files refer to it.

#### Initialize thread pool attributes

```
/* initialize thread pool attributes */
memset(&pool_attr, 0, sizeof pool_attr);
pool_attr.handle = dpp;
pool_attr.context_alloc = dispatch_context_alloc;
pool_attr.block_func = dispatch_block;
pool_attr.unblock_func = dispatch_unblock;
pool_attr.handler_func = dispatch_handler;
pool_attr.context_free = dispatch_context_free;
pool_attr.lo_water = 2;
pool_attr.hi_water = 4;
pool_attr.increment = 1;
pool_attr.maximum = 50;
```

The thread pool attributes tell the threads which functions to use for their blocking loop and control how many threads should be in existence at any time. We'll go into more detail on these attributes when we talk about multithreaded resource managers in more detail later in this guide.

### Allocate a thread pool handle

The thread pool handle is used to control the thread pool. Among other things, it contains the given attributes and flags. The *thread\_pool\_create()* function allocates and fills in this handle.

### Start the threads

```
/* start the threads; will not return */
thread_pool_start(tpp);
```

The *thread\_pool\_start()* function starts up the thread pool. Each newly created thread allocates a context structure of the type defined by THREAD\_POOL\_PARAM\_T using the *context\_alloc* function we gave above in the attribute structure. They'll then block on the *block\_func* and when the *block\_func* returns, they'll call the *handler\_func*, both of which were also given through the attributes structure. Each thread essentially does the same thing that the single-threaded resource manager above does for its message loop.

From this point on, your resource manager is ready to handle messages. Since we gave the POOL\_FLAG\_EXIT\_SELF flag to *thread\_pool\_create()*, once the threads have been started up, *pthread\_exit()* will be called and this calling thread will exit.

## Using MsgSend() and MsgReply()

You don't have to use *read()* and *write()* to interact with a resource manager; you can use the path that a resource manager registers to get a connection ID (coid) that you can use with *MsgSend()* to send messages to the server.

This example consists of simple client and server programs that you can use as the starting point for any similar project. There are two source files: one for the server, and one for the client. Note that you must run server as **root** — a requirement in order to use the *resmgr* attach() function.

#### A bit of history

QNX Neutrino and our earlier QNX 4 RTOS both use a notion of Send/Receive/Reply for messaging. This IPC mechanism is (generally) used in a synchronous manner; the sending process waits for a reply from the receiver, and a receiver waits for a message to be sent. This provides a very easy call-response synchronization.

Under QNX 4, the *Send()* function needed only the process ID (pid) of the receiving process. QNX 4 also provided a very simple API for giving a process a name and, in turn, looking up that name to get a process ID. So you could name your server process, and then your client process could look up that name, get a process ID (pid), and then send the server some data and wait for a reply. This model worked well in a non-threaded environment.

Since QNX Neutrino includes proper thread support, the notion of having a single conduit into a process doesn't make a lot of sense, so a more flexible system was designed. To perform a *MsgSend()* under QNX Neutrino, you no longer need a pid, but rather a connection ID (coid).

This coid is obtained from opening a *connection* to a *channel*. Processes can create multiple channels and can have different threads service any (or all) of them. The issue now becomes: how does a client get a coid in the first place so it can open a connection to get the coid it needs to perform the *MsgSend()*?

There are many different ways this kind of information-sharing can occur, but the method that falls in line with the QNX Neutrino design ideals is for the server to also be a resource manager.

Under QNX Neutrino — and other POSIX systems — when you call *open()*, you get back a file descriptor (fd). But this fd is also a coid. So instead of registering a name, as in QNX 4, your server process registers a path in the filesystem, and the client opens that path to get the coid to talk to the server.

#### The server

Let's begin with the server:

```
* ResMgr and Message Server Process
#include <stdio.h>
#include <unistd.h>
#include <stdlib.h>
#include <errno.h>
#include <string.h>
#include <sys/neutrino.h>
#include <sys/iofunc.h>
#include <sys/dispatch.h>
resmgr connect funcs t ConnectFuncs;
resmgr_io_funcs_t IoFuncs;
iofunc_attr_t IoFuncAttr;
iofunc_attr_t
typedef struct
   uint16_t msg_no;
   char msg data[255];
} server msg t;
int message callback (message context t *ctp, int type, unsigned flags,
                     void *handle )
   server msg t *msg;
    int num;
    char msg reply[255];
    /* Cast a pointer to the message data */
   msg = (server_msg_t *)ctp->msg;
    /* Print some useful information about the message */
```

```
printf( "\n\nServer Got Message:\n" );
   printf( " type: %d\n" , type );
   printf( " data: %s\n\n", msg->msg_data );
   /* Build the reply message */
   num = type - IO MAX;
   snprintf( msg_reply, 254, "Server Got Message Code: _IO_MAX + %d", num );
    /* Send a reply to the waiting (blocked) client */
   MsgReply( ctp->rcvid, EOK, msg_reply, strlen( msg_reply ) + 1 );
   return 0;
}
int main ( int argc, char **argv )
   resmgr_attr_t
                      resmgr_attr;
   message_attr_t message_attr;
   dispatch t
                        *dpp;
   dispatch_context_t *ctp, *ctp_ret;
                        resmgr id, message id;
   /* Create the dispatch interface */
    dpp = dispatch_create();
   if( dpp == NULL )
   {
        fprintf( stderr, "dispatch create() failed: %s\n",
                 strerror( errno ) );
        return EXIT FAILURE;
   }
   memset( &resmgr attr, 0, sizeof( resmgr attr ) );
   resmgr_attr.nparts_max = 1;
   resmgr_attr.msg_max_size = 2048;
    /* Setup the default I/O functions to handle open/read/write/... */
    iofunc func init( RESMGR CONNECT NFUNCS, &ConnectFuncs,
                      RESMGR IO NFUNCS, & IoFuncs );
    /* Setup the attribute for the entry in the filesystem */
   iofunc attr init( &IoFuncAttr, S IFNAM | 0666, 0, 0 );
   resmgr id = resmgr attach( dpp, &resmgr attr, "serv", FTYPE ANY,
                              0, &ConnectFuncs, &IoFuncs, &IoFuncAttr );
   if( resmgr id == -1 )
        fprintf( stderr, "resmgr_attach() failed: %s\n", strerror( errno ) );
        return EXIT FAILURE;
   }
    /* Setup our message callback */
   memset( &message_attr, 0, sizeof( message_attr ) );
   message attr.nparts max = 1;
   message_attr.msg_max_size = 4096;
   /* Attach a callback (handler) for two message types */
   message_id = message_attach( dpp, &message_attr, _IO_MAX + 1,
                                _IO_MAX + 2, message_callback, NULL );
   if( message_id == -1 )
        fprintf( stderr, "message_attach() failed: %s\n", strerror( errno ) );
```

```
return EXIT FAILURE;
    }
    /* Setup a context for the dispatch layer to use */
    ctp = dispatch context alloc( dpp );
    if( ctp == NULL )
    {
        fprintf( stderr, "dispatch_context_alloc() failed: %s\n",
                 strerror( errno ) );
        return EXIT FAILURE;
    }
    /* The "Data Pump" - get and process messages */
    while(1)
        ctp ret = dispatch block( ctp );
        if( ctp ret )
            dispatch handler ( ctp );
        }
        else
            fprintf( stderr, "dispatch block() failed: %s\n",
                    strerror( errno ) );
            return EXIT FAILURE;
    }
    return EXIT SUCCESS;
}
```

The first thing the server does is create a dispatch handle (dpp) using <code>dispatch\_create()</code>. This handle will be used later when making other calls into the dispatch portion of the library. The dispatch layer takes care of receiving incoming messages and routing them to the appropriate layer (resmgr, message, pulse).

After the dispatch handle is created, the server sets up the variables needed to make a call into  $resmgr\_attach()$ . But since we're not using the resmgr functionality for anything more than getting a connection ID to use with MsgSend(), the server sets up everything to the defaults.

We don't need (or want) to worry about I/O and connection messages right now (like the messages that open(), close(), read(), write() and so on generate); we just want them to work and do the right thing. Luckily, there are defaults built into the C library to handle these types of messages for you, and  $iofunc\_func\_init()$  sets up these defaults. The call to  $iofunc\_attr\_init()$  sets up the attribute structure so that the entry in the filesystem has the specified attributes.

Finally, the call to <code>resmgr\_attach()</code> is made. For our purposes, the most important parameter is the third. In this case we're registering the filesystem entry <code>serv</code>. Since an absolute path wasn't given, the entry will appear in the same directory where the server was run. All of this gives us a filesystem entry that can be opened and closed, but generally behaves the same as <code>/dev/null</code>. But that's fine, since we want to be able to <code>MsgSend()</code> data to our server, not <code>write()</code> data to it.

Now that the resmgr portion of the setup is complete, we need to tell the dispatch layer that we'll be handling our own messages in addition to the standard I/O and connection messages handled by the resmgr layer. In order to let the dispatch layer know the general attributes of the messages we'll be receiving, we fill in the *message\_attr* structure. In this case we're telling it that the number of message parts we're going to receive is 1 with a maximum message size of 4096 bytes.

Once we have these attributes defined, we can register our intent to handle messages with the dispatch layer by invoking <code>message\_attach()</code>. With this call, we're setting up our <code>message\_callback()</code> routine to be the handler of messages of type <code>\_IO\_MAX + 1</code> up to and including messages of type <code>\_IO\_MAX + 2</code>. There's even the option of having a pointer to arbitrary data passed into the callback, but we don't need that so we're setting it to NULL.

You might now be asking, "Message type \_IO\_MAX + 1! I don't see anything in the <code>MsgSend()</code> docs for setting a message type!" This is true. However, in order to play nicely with the dispatch layer, all incoming messages must have a 32-bit integer at the start indicating the message type. Although this may seem restrictive to a new QNX developer, the reason it's in place is that most designs will end up using some sort of message identification anyway, and this just forces you into a particular style. This will become clearer when we look at the client. But now let's finish the server.

Now that we've registered both the resmgr and message handlers with the dispatch layer, we simply create a context for the dispatch layer to use while processing messages by calling <code>dispatch\_context\_alloc()</code>, and then start receiving and processing data. This is a two-step process:

- 1 The server calls *dispatch\_block()*, which waits for incoming messages and pulses.
- Once there's data available, we call into *dispatch\_handler()* to do the right thing based on the message data. It's inside the *dispatch\_handler()* call that our *message\_callback()* routing will be invoked, when messages of the proper type are received.

Finally, let's look at what our <code>message\_callback()</code> routine actually does when a proper message is received. When a message of type <code>\_IO\_MAX + 1</code> or <code>\_IO\_MAX + 2</code> is received, our callback is invoked. We get the message type passed in via the <code>type</code> parameter. The actual message data can be found in <code>ctp->msg</code>. When the message comes in, the server prints the message type and the string that was sent from the client. It then prints the offset from <code>\_IO\_MAX</code> of the message type, and then finally formats a reply string and sends the reply back to the client via <code>ctp->rcvid</code> using <code>MsgReply()</code>.

#### The client

The client is much simpler:

```
/*
 * Message Client Process
 */
```

```
#include <stdio.h>
#include <unistd.h>
#include <stdlib.h>
#include <fcntl.h>
#include <errno.h>
#include <string.h>
#include <sys/neutrino.h>
#include <sys/iofunc.h>
#include <sys/dispatch.h>
typedef struct
   uint16_t msg_no;
   char msg_data[255];
} client msg t;
int main( int argc, char **argv )
   int fd;
   int c;
   client_msg_t msg;
   int ret;
   int num;
   char msg_reply[255];
   num = 1;
   /* Process any command line arguments */
   while( ( c = getopt( argc, argv, "n:" ) ) != -1 )
       if( c == 'n' )
        {
           num = strtol( optarg, 0, 0 );
    /* Open a connection to the server (fd == coid) */
   fd = open( "serv", O_RDWR );
   if( fd == -1 )
   {
        fprintf( stderr, "Unable to open server connection: sn'",
           strerror( errno ) ):
        return EXIT FAILURE;
   }
   /* Clear the memory for the msg and the reply */
   memset( &msg, 0, sizeof( msg ) );
   memset( &msg reply, 0, sizeof( msg reply ) );
   /* Set up the message data to send to the server */
   msg.msg no = IO MAX + num;
   snprintf( msg.msg data, 254, "client %d requesting reply.", getpid() );
   printf( "client: msg_no: _IO_MAX + %d\n", num );
   fflush( stdout );
   /* Send the data to the server and get a reply */
   ret = MsgSend( fd, &msg, sizeof( msg ), msg_reply, 255 );
   if( ret == -1 )
   {
        fprintf( stderr, "Unable to MsgSend() to server: %s\n", strerror( errno ) );
        return EXIT FAILURE;
   }
```

```
/* Print out the reply data */
printf( "client: server replied: %s\n", msg_reply );

close( fd );

return EXIT_SUCCESS;
}
```



Remember that since the server registers a *relative* pathname, the client must be run from the same directory as the server.

The client uses the *open()* function to get a coid (the server's default resmgr setup takes care of all of this on the server side), and performs a *MsgSend()* to the server based on this coid, and then waits for the reply. When the reply comes back, the client prints the reply data.

You can give the client the command-line option -n# (where # is the offset from \_IO\_MAX) to use for the message. If you give anything over 2 as the offset, the <code>MsgSend()</code> will fail, since the server hasn't set up handlers for those messages.

This example is very basic, but it still covers a lot of ground. There are many other things you can do using this same basic framework:

- Register different message callbacks, based on different message types.
- Register to receive pulses, in addition to messages, using *pulse attach()*.
- Override the default I/O message handlers so that clients can also use read() and write() to interact with your server.
- Use a thread pool to make your server multithreaded.

Many of these topics are covered later in this guide.

# Chapter 3

# Fleshing Out the Skeleton

# In this chapter...

Message types 39
Setting resource manager attributes 46
Ways of adding functionality to the resource manager 48

It's time now to start adding some flesh to the basic bones of the resource manager.

# Message types

As we saw in the Bones of a Resource Manager chapter, your resource manager may need to handle these types of messages:

- connect messages
- I/O messages

We'll examine them in the sections and chapters that follow.



The *Getting Started with QNX Neutrino* guide includes a summary of the handlers for these messages; see "Alphabetical listing of connect and I/O functions" in its Resource Managers chapter.

### **Connect messages**

A connect message is issued by the client to perform an operation based on a pathname. This may be a message that establishes a longer term relationship between the client and the resource manager (e.g. open()), or it may be a message that is a "one-shot" event (e.g. rename()).

When you call resmgr\_attach(), you pass it a pointer to a resmgr\_connect\_funcs\_t structure that defines your connect functions. This structure is defined in sys/resmgr.h> as follows:

```
typedef struct resmgr connect funcs {
   unsigned nfuncs;
   int (*open)
                    (resmgr context t *ctp, io open t *msg,
                     RESMGR HANDLE T *handle, void *extra);
   int (*unlink)
                     (resmgr_context_t *ctp, io_unlink_t *msg,
                     RESMGR HANDLE T *handle, void *reserved);
   int (*rename)
                    (resmgr context t *ctp, io rename t *msg,
                     RESMGR HANDLE T *handle,
                     io_rename_extra_t *extra);
   int (*mknod)
                     (resmgr context t *ctp, io mknod t *msg,
                      RESMGR HANDLE T *handle, void *reserved);
   int (*readlink) (resmgr_context_t *ctp, io_readlink_t *msg,
                     RESMGR_HANDLE_T *handle, void *reserved);
   int (*link)
                     (resmgr context t *ctp, io link t *msg,
                     RESMGR HANDLE T *handle,
                     io_link_extra_t *extra);
   int (*unblock)
                     (resmgr_context_t *ctp, io_pulse_t *msg,
                      RESMGR HANDLE T *handle, void *reserved);
```

To initialize this structure, call <code>iofunc\_func\_init()</code> to fill it with pointers to the default handlers, and then override any that your resource manager needs to handle specifically.



The <code>resmgr\_attach()</code> function copies the <code>pointers</code> to the <code>resmgr\_connect\_funcs\_t</code> and <code>resmgr\_io\_funcs\_t</code> structures, not the structures themselves. You should allocate the structures, declare them to be static, or make them global variables. If your resource manager is for more than one device with different handlers, create separate structures that define the handlers.

The connect messages all have a type of \_IO\_CONNECT; the subtype further indicates what's happening. The entries are as follows:

The number of functions in the structure. This allows for future expansion.

Open Handles client calls to open(), fopen(), sopen(), and so on. The message subtype is \_IO\_CONNECT\_COMBINE, \_IO\_CONNECT\_COMBINE\_CLOSE, or \_IO\_CONNECT\_OPEN.

For more information about the io\_open handler, see "Ways of adding functionality to the resource manager," later in this chapter.

Unlink Handles client calls to unlink(). The message subtype is \_IO\_CONNECT\_UNLINK.

Tename Handles client calls to rename(). The message subtype is \_IO\_CONNECT\_RENAME.

*mknod* Handles client calls to *mkdir()*, *mkfifo()*, and *mknod()*. The message subtype is \_IO\_CONNECT\_MKNOD.

readlink Handles client calls to readlink(). The message subtype is IO CONNECT READLINK.

link Handles client calls to link(). The message subtype is \_IO\_CONNECT\_LINK.

unblock Handles requests from the kernel to unblock a client during the connect message phase. There's no corresponding message; the call is synthesized by the library.

For more information about the *io\_unblock* handler, see "Handling client unblocking due to signals or timeouts" in the Signals, Timeouts, and Interrupts chapter.

mount

Handles client calls to *mount()*. The message subtype is IO CONNECT MOUNT.

For more information about the *io\_mount* handler, see "Handling *mount()*" in the Handling Other Messages chapter.

If the message is the \_IO\_CONNECT message (and variants) corresponding with the <code>open()</code> outcall, then a <code>context</code> needs to be established for further I/O messages that will be processed later. This context is referred to as an <code>OCB (Open Control Block)</code>; it holds any information required between the connect message and subsequent I/O messages.

Basically, the OCB is a good place to keep information that needs to be stored on a per-open basis. An example of this would be the current position within a file. Each open file descriptor would have its own file position. The OCB is allocated on a per-open basis. During the open handling, you'd initialize the file position; during read and write handling, you'd advance the file position. For more information, see the section "The open control block (OCB) structure" in the POSIX-Layer Data Structures chapter of this guide.

## I/O messages

An I/O message is one that relies on an existing binding (e.g. OCB) between the client and the resource manager.

As an example, an \_IO\_READ (from the client's *read()* function) message depends on the client's having previously established an association (or *context*) with the resource manager by issuing an *open()* and getting back a file descriptor. This context, created by the *open()* call, is then used to process the subsequent I/O messages, like the \_IO\_READ.

There are good reasons for this design. It would be inefficient to pass the full pathname for each and every read() request, for example. The open() handler can also perform tasks that we want done only once (e.g. permission checks), rather than with each I/O message. Also, when the read() has read 4096 bytes from a disk file, there may be another 20 megabytes still waiting to be read. Therefore, the read() function would need to have some context information telling it the position within the file it's reading from, how much has been read, and so on.

The resmgr\_io\_funcs\_t structure (which you pass to resmgr\_attach() along with the connect functions) defines the functions to call for the I/O messages. The resmgr\_io\_funcs\_t structure is defined in <sys/resmgr.h> as follows:

```
RESMGR OCB T *ocb);
   int (*devctl)
                     (resmgr context t *ctp, io devctl t *msg,
                      RESMGR OCB T *ocb);
    int (*unblock)
                      (resmgr_context_t *ctp, io_pulse_t *msg,
                      RESMGR OCB T *ocb);
   int (*pathconf) (resmgr context t *ctp, io pathconf t *msg,
                      RESMGR OCB T *ocb);
    int (*lseek)
                     (resmgr_context_t *ctp, io_lseek_t *msg,
                      RESMGR OCB T *ocb);
    int (*chmod)
                     (resmgr_context_t *ctp, io_chmod_t *msg,
                      RESMGR OCB T *ocb);
    int (*chown)
                      (resmgr context t *ctp, io chown t *msg,
                      RESMGR OCB T *ocb);
    int (*utime)
                      (resmgr_context_t *ctp, io_utime_t *msg,
                      RESMGR OCB T *ocb);
    int (*openfd)
                     (resmgr context t *ctp, io openfd t *msg,
                      RESMGR OCB T *ocb);
    int (*fdinfo)
                     (resmgr context t *ctp, io fdinfo t *msg,
                      RESMGR OCB T *ocb);
    int (*lock)
                      (resmgr context t *ctp, io lock t *msg,
                      RESMGR OCB T *ocb);
    int (*space)
                      (resmgr_context_t *ctp, io_space_t *msg,
                      RESMGR OCB T *ocb);
    int (*shutdown) (resmgr_context_t *ctp, io_shutdown_t *msg,
                      RESMGR OCB T *ocb);
    int (*mmap)
                      (resmgr_context_t *ctp, io_mmap_t *msg,
                      RESMGR OCB T *ocb);
    int (*msq)
                     (resmgr_context_t *ctp, io_msg_t *msg,
                      RESMGR OCB T *ocb);
    int (*reserved)
                      (resmgr context t *ctp, void *msg,
                      RESMGR OCB T *ocb);
    int (*dup)
                      (resmgr_context_t *ctp, io_dup_t *msg,
                      RESMGR OCB T *ocb);
    int (*close dup) (resmgr context t *ctp, io close t *msg,
                      RESMGR OCB T *ocb);
    int (*lock_ocb) (resmgr_context_t *ctp, void *reserved,
                      RESMGR OCB T *ocb);
    int (*unlock_ocb) (resmgr_context_t *ctp, void *reserved,
                      RESMGR OCB T *ocb);
                      (resmgr_context_t *ctp, io_sync_t *msg,
    int (*sync)
                      RESMGR_OCB_T *ocb);
    int (*power)
                     (resmgr_context_t *ctp, io_power_t *msg,
                      RESMGR OCB T *ocb);
} resmgr io funcs t;
```

You initialize this structure in the same way as the <code>resmgr\_connect\_funcs\_t</code> structure: call <code>iofunc\_func\_init()</code> to fill it with pointers to the default handlers, and then override any that your resource manager needs to handle specifically. This structure also begins with an <code>nfuncs</code> member that indicates how many functions are in the structure, to allow for future expansion.



The <code>resmgr\_attach()</code> function copies the <code>pointers</code> to the <code>resmgr\_connect\_funcs\_t</code> and <code>resmgr\_io\_funcs\_t</code> structures, not the structures themselves. You should allocate the structures, declare them to be static, or make them global variables. If your resource manager is for more than one device with different handlers, create separate structures that define the handlers.

Notice that the I/O functions all have a common parameter list. The first entry is a resource manager context structure, the second is a message (the type of which matches the message being handled and contains parameters sent from the client), and the last is an OCB (containing what we bound when we handled the client's *open()* function).

You usually have to provide a handler for the following entries:

read Handles client calls to read() and readdir(). The message type is
 \_IO\_READ. For more information about the io\_read handler, see "Handling the \_IO\_READ message" in the Handling Read and Write Messages chapter.

write Handles client calls to write(), fwrite(), and so on. The message type is \_IO\_WRITE. For more information about the io\_write handler, see "Handling the \_IO\_WRITE message" in the Handling Read and Write Messages chapter.

devctl Handles client calls to devctl() and ioctl(). The message type is
 \_IO\_DEVCTL. For more information about the io\_devctl handler, see
 "Handling devctl() messages" in the Handling Other Messages chapter.

You typically use the default entry for the following:

close\_ocb Called by the library when the last close() has been received by a particular OCB. You can use this handler to clean up anything

associated with the OCB.

stat Handles client calls to stat(), lstat(), and fstat(). The message type is

\_IO\_STAT. For more information about the *io\_stat* handler, see "Handling *stat()*" in the Handling Other Messages chapter.

notify Handles client calls to select() and ionotify(). The message type is

\_IO\_NOTIFY. For more information about the *io\_notify* handler, see "Handling *ionotify()* and *select()*" in the Handling Other Messages

chapter.

unblock Handles requests from the kernel to unblock the client during the I/O

message phase. There's no message associated with this. For more information about the *io\_unblock* handler, see "Handling client unblocking due to signals or timeouts" in the Signals, Timeouts, and

Interrupts chapter.

pathconf Handles client calls to fpathconf() and pathconf(). The message type

is IO PATHCONF.

lseek Handles client calls to *lseek()*, *fseek()*, and *rewinddir()*. The message type is IO LSEEK. For more information about the io lseek handler, see "Handling *lseek()*" in the Handling Other Messages chapter. chmod Handles client calls to *chmod()* and *fchmod()*. The message type is IO CHMOD. chown Handles client calls to *chown()* and *fchown()*. The message type is IO CHOWN. utime Handles client calls to *utime()*. The message type is IO UTIME. Handles client calls to *openfd()*. The message type is IO OPENFD. openfd fdinfo Handles client calls to *iofdinfo()*. The message type is IO FDINFO. lock Handles client calls to fcntl(), lockf(), and flock(). The message type is \_IO\_LOCK. Handles client calls to *chsize()*, *fcntl()*, *ftruncate()*, and *ltrunc()*. The space message type is IO SPACE. Reserved for future use. shutdown ттар Handles client calls to mmap(), munmap(), mmap device io(), and mmap device memory(). The message type is IO MMAP. Handles messages that are manually assembled and sent via msg MsgSend(). The message type is IO MSG. For more information about the io msg handler, see "Handling out-of-band ( IO MSG) messages" in the Handling Other Messages chapter. reserved Reserved for future use. dup Handles client calls to dup(), dup2(), fcntl(), fork(), spawn\*(), and vfork(). The message type is IO DUP. For more information about the *io dup* handler, see "Handling *open()*, *dup()*, and *close()* messages" in the Handling Other Messages chapter. close dup Handles client calls to *close()* and *fclose()*. The message type is IO CLOSE DUP.



You'll almost never replace the default *close\_dup* handler because the library keeps track of multiple *open()*, *dup()*, and *close()* calls for an OCB. For more information, see "*open()*, *dup()*, and *close()*," below.

lock ocb

Locks the attributes structure pointed to by the OCB. This is done to ensure that only one thread at a time is operating on both the OCB and the corresponding attributes structure. The lock (and corresponding unlock) functions are synthesized by the resource manager library before and after completion of message handling.

unlock\_ocb Unlocks the attributes structure pointed to by the OCB.
 sync Handles client calls to fsync() and fdatasync(). The message type is \_IO\_SYNC.
 power Reserved for future use.

## **Default message handling**

Since a large number of the messages received by a resource manager deal with a common set of attributes, the OS provides an *iofunc\_\*()* shared library that lets a resource manager handle functions like stat(), chmod(), chown(), lseek(), and so on *automatically*, without your having to write additional code. As an added benefit, these  $iofunc_*()$  default handlers implement the POSIX semantics for the messages, offloading some work from you.

The library contains *iofunc* \*() default handlers for these client functions:

```
        chmod()
        lockf()

        chown()
        lseek()

        close()
        mmap()

        devctl()
        open()

        fpathconf()
        pathconf()

        fseek()
        stat()

        fstat()
        utime()
```

## open(), dup(), and close()

The resource manager shared library automatically handles dup() messages.

Suppose that the client program executed code that eventually ended up performing:

```
fd = open ("/dev/device", O_RDONLY);
...
fd2 = dup (fd);
...
fd3 = dup (fd);
...
close (fd3);
...
close (fd2);
...
close (fd);
```

The client generates an open connect message for the first open(), and then two \_IO\_DUP messages for the two dup() calls. Then, when the client executes the close() calls, it generates three close messages.

Since the dup() functions generate duplicates of the file descriptors, new context information shouldn't be allocated for each one. When the close messages arrive, because no new context has been allocated for each dup(), no release of the memory

by each close message should occur either! (If it did, the first close would wipe out the context.)

The resource manager shared library provides default handlers that keep track of the open(), dup(), and close() messages and perform work only for the last close (i.e. the third io close message in the example above).

# Setting resource manager attributes

In addition to the structures that define the connect and I/O functions, you pass a resmgr\_attr\_t structure to resmgr\_attach() to specify the attributes of the resource manager.

The resmgr attr t structure is defined as follows:

The members include:

flags

Lets you change the behavior of the resource manager interface. Set this to 0, or a combination of the following bits (defined in <sys/dispatch.h>):

- RESMGR\_FLAG\_ATTACH\_LOCAL set up the resource manager, but don't register its path with procnto. You can send messages to the resource manager's channel (if you know where to find it).
- RESMGR\_FLAG\_ATTACH\_OTHERFUNC the other\_func member of this structure points to a function for unhandled I/O messages.
- RESMGR\_FLAG\_CROSS\_ENDIAN the server handles cross-endian support. The framework handles all necessary conversions on the server's side; the client doesn't have to do anything.

If necessary, your resource manager can determine that a message came from a client of a different endian-ness by checking to see if the \_NTO\_MI\_ENDIAN\_DIFF bit is set in the <code>flags</code> member of the <code>\_msg\_info</code> structure that's included in the <code>resmgr\_context\_t</code> structure that's passed to the handler functions.

RESMGR\_FLAG\_NO\_DEFAULT\_FUNC — not implemented.



There are also some \_RESMGR\_FLAG\_\* bits (with a leading underscore), but you use them in the *flags* argument to *resmgr attach()*.

nparts max

The number of components that should be allocated to the IOV array.

msg max size

The size of the message buffer.

These members will be important when you start writing your own handler functions.

If you specify a value of zero for *nparts\_max*, the resource manager library will bump the value to the minimum usable by the library itself. Why would you want to set the size of the IOV array? As we'll see in the "Getting the resource manager library to do the reply" section of the Handling Read and Write Messages chapter, you can tell the resource manager library to do our replying for us. We may want to give it an IOV array that points to *N* buffers containing the reply data. But, since we'll ask the library to do the reply for us, we need to use its IOV array, which of course would need to be big enough to point to our *N* buffers.

other\_func

Lets you specify a routine to call in cases where the resource manager gets an I/O message that it doesn't understand.



In general, we don't recommend that you use this member. For private or custom messages, you should use \_IO\_DEVCTL or \_IO\_MSG handlers, as described in the Handling Other Messages chapter. If you want to receive pulses, use *pulse attach()*.

To attach an *other\_func*, you must set the RESMGR\_FLAG\_ATTACH\_OTHERFUNC bit in the *flags* member of this structure.

If the resource manager library gets an I/O message that it doesn't know how to handle, it'll call the routine specified by the *other\_func* member, if non-NULL. (If it's NULL, the resource manager library will return an ENOSYS to the client, effectively stating that it doesn't know what this message means.)

You might specify a non-NULL value for *other\_func* in the case where you've specified some form of custom messaging between clients and your resource manager, although the recommended approach for this is the *devctl()* function call (client) and the \_IO\_DEVCTL message handler (server) or a *MsgSend\*()* function call (client) and the \_IO\_MSG message handler (server).

For non-I/O message types, you should use the <code>message\_attach()</code> function, which attaches a message range for the dispatch handle. When a message with a type in that range is received, the <code>dispatch\_block()</code> function calls a user-supplied function that's

responsible for doing any specific work, such as replying to the client.

# Ways of adding functionality to the resource manager

You can add functionality to the resource manager you're writing in these fundamental ways:

- use the default functions encapsulated within your own
- use the helper functions within your own
- write the entire function yourself

The first two are almost identical, because the default functions really don't do that much by themselves — they rely on the POSIX helper functions. The third approach has advantages and disadvantages.

## Using the default functions

Since the default functions (e.g. *iofunc\_open\_default())* can be installed in the jump table directly, there's no reason you couldn't embed them within your own functions.

Here's an example of how you would do that with your own *io\_open* handler:

Obviously, this is just an incremental step that lets you gain control in your *io\_open* handler when the message arrives from the client. You may wish to do something before or after the default function does its thing:

```
{
   if (!accepting opens now) {
       return (EBUSY);
       at this point, we're okay to let the open happen,
       so let the default function do the "work".
   return (iofunc open default (ctp, msg, handle, extra));
Or:
/* example of doing something after */
int
io_open (resmgr_context_t *ctp, io_open_t *msg,
        RESMGR HANDLE T *handle, void *extra)
{
   int
            sts;
     * have the default function do the checking
     * and the work for us
   sts = iofunc open default (ctp, msg, handle, extra);
      if the default function says it's okay to let the open
     * happen, we want to log the request
   if (sts == EOK) \{
       log_open_request (ctp, msg);
   return (sts);
```

It goes without saying that you can do something before *and* after the standard default POSIX handler.

The principal advantage of this approach is that you can add to the functionality of the standard default POSIX handlers with very little effort.

# Using the helper functions

The default functions make use of *helper* functions — these functions can't be placed directly into the connect or I/O jump tables, but they do perform the bulk of the work.

Here's the source for the two functions *iofunc\_chmod\_default()* and *iofunc\_stat\_default()*:

Notice how the *iofunc\_chmod()* handler performs all the work for the *iofunc\_chmod\_default()* default handler. This is typical for the simple functions.

The more interesting case is the <code>iofunc\_stat\_default()</code> default handler, which calls two helper routines. First it calls <code>iofunc\_time\_update()</code> to ensure that all of the time fields (<code>atime</code>, <code>ctime</code> and <code>mtime</code>) are up to date. Then it calls <code>iofunc\_stat()</code>, which builds the reply. Finally, the default function builds a pointer in the <code>ctp</code> structure and returns it.

The most complicated handling is done by the *iofunc open default()* handler:

```
int
iofunc open default (resmgr context t *ctp, io open t *msg,
                    iofunc_attr_t *attr, void *extra)
   int status;
   iofunc_attr_lock (attr);
    if ((status = iofunc open (ctp, msg, attr, 0, 0)) != EOK) {
       iofunc attr unlock (attr);
       return (status):
   }
    if ((status = iofunc_ocb_attach (ctp, msg, 0, attr, 0))
       != EOK) {
       iofunc_attr_unlock (attr);
       return (status);
   iofunc attr unlock (attr);
   return (EOK);
}
```

This handler calls four helper functions:

- 1 It calls *iofunc\_attr\_lock()* to lock the attribute structure so that it has exclusive access to it (it's going to be updating things like the counters, so we need to make sure no one else is doing that at the same time).
- 2 It then calls the helper function *iofunc\_open()*, which does the actual verification of the permissions.
- 3 Next it calls *iofunc\_ocb\_attach()* to bind an OCB to this request, so that it will get automatically passed to all of the I/O functions later.
- **4** Finally, it calls *iofunc\_attr\_unlock()* to release the lock on the attribute structure.

## Writing the entire function yourself

Sometimes a default function will be of no help for your particular resource manager. For example, <code>iofunc\_read\_default()</code> and <code>iofunc\_write\_default()</code> functions implement <code>/dev/null</code>— they do all the work of returning 0 bytes (EOF) or swallowing all the message bytes (respectively).

You'll want to do something in those handlers (unless your resource manager doesn't support the \_IO\_READ or \_IO\_WRITE messages).

Note that even in such cases, there are still helper functions you can use:  $iofunc\_read\_verify()$  and  $iofunc\_write\_verify()$ .

# Chapter 4

# **POSIX-Layer Data Structures**

# In this chapter...

The iofunc\_ocb\_t (Open Control Block) structure 56
The iofunc\_attr\_t (attribute) structure 57
The optional iofunc\_mount\_t (mount) structure 61

The resource manager library defines several key structures that are related to the POSIX-layer support routines:

#### iofunc ocb t (Open Control Block) structure

Contains per-*open* data, such as the current position into a file (the *lseek()* offset).


#### iofunc attr t (attribute) structure

Since a resource manager may be responsible for more than one device (e.g. devc-ser\* may be responsible for /dev/ser1, /dev/ser2, /dev/ser3, etc.), the *attributes* structure holds data on a per-name basis. This structure contains such items as the user and group ID of the owner of the device, the last modification time, etc.

#### iofunc mount t (mount) structure


Contains per-mountpoint data items that are global to the entire mount device. Filesystem (block I/O device) managers use this structure; a resource manager for a device typically won't have a mount structure.

This picture may help explain their interrelationships:



A resource manager is responsible for three data structures.

If three clients open two paths associated with a resource manager, the data structures are linked like this:



Multiple clients with multiple OCBs, all linked to one mount structure.

# The iofunc ocb t (Open Control Block) structure

The Open Control Block (OCB) maintains the state information about a particular session involving a client and a resource manager. It's created during *open()* handling and exists until a *close()* is performed.

This structure is used by the iofunc layer helper functions. (In the Extending the POSIX-Layer Data Structures chapter, we'll show you how to extend this to include your own data).

The OCB structure contains at least the following:

```
typedef struct _iofunc_ocb {
    IOFUNC_ATTR_T *attr;
    int32_t ioflag;
    off_t offset;
    uint16_t sflag;
    uint16_t flags;
} iofunc_ocb_t;
```

where the values represent:

attr A pointer to the attribute structure (see below).

ioflag Contains the mode (e.g. reading, writing, blocking) that the resource was opened with. This information is inherited from the io connect t

structure that's available in the message passed to the *io\_open* handler. The open modes (as passed to *open()* on the client side) are converted to the *ioflag* values as follows:

### Open mode ioflag value

```
O_RDONLY _IO_FLAG_RD
O_RDWR _IO_FLAG_RD | _IO_FLAG_WR
O_WRONLY _IO_FLAG_WR
```

offset The read/write offset into the resource (e.g. our current *lseek()* position within a file). Your resource manager can modify this member.

sflag Defines the sharing mode. This information is inherited from the
io\_connect\_t structure that's available in the message passed to the
io open handler.

flags When the IOFUNC\_OCB\_PRIVILEGED bit is set, a privileged process (i.e. root) performed the *open()*. Additionally, you can use flags in the range IOFUNC\_OCB\_FLAGS\_PRIVATE (see <sys/iofunc.h>) for your own purposes. Your resource manager can modify this member.

# The iofunc attr t (attribute) structure

The iofunc\_attr\_t structure defines the characteristics of the device that you're supplying the resource manager for. This is used in conjunction with the OCB structure.

The attribute structure contains at least the following:

```
typedef struct iofunc attr {
   IOFUNC MOUNT_T
                             *mount;
   uint32 t
                            flags:
   int32 t
                            lock tid;
   uint16 t
                           lock count;
   uint16_t
                           count;
   uint16 t
                           rcount;
   uint16 t
                            wcount;
   uint16 t
                            rlocks;
   uint16 t
                             wlocks;
   struct _iofunc_mmap_list *mmap_list;
   struct _iofunc_lock_list *lock_list;
                             *list;
   uint32 t
                             list size;
   off t
                            nbytes;
   ino_t
                             inode:
   uid t
                             uid;
   gid t
                             gid;
   time t
                             mtime:
   time t
                             atime;
   time t
                             ctime;
   mode t
                             mode;
```

where the values represent:

mount

A pointer to the *mount structure* (see below).

flags

The bit-mapped *flags* member can contain the following flags:

IOFUNC ATTR ATIME

The access time is no longer valid. Typically set on a read from the resource.

IOFUNC ATTR CTIME

The change of status time is no longer valid. Typically set on a file info change.

IOFUNC ATTR DIRTY NLINK

The number of links has changed.

IOFUNC ATTR DIRTY MODE

The mode has changed.

IOFUNC\_ATTR\_DIRTY\_OWNER

The uid or the gid has changed.

IOFUNC ATTR DIRTY RDEV

The *rdev* member has changed, e.g. *mknod()*.

IOFUNC ATTR DIRTY SIZE

The size has changed.

IOFUNC ATTR DIRTY TIME

One or more of mtime, atime, or ctime has changed.

IOFUNC ATTR MTIME

The modification time is no longer valid. Typically set on a write to the resource.

Since your resource manager uses these flags, you can tell right away which fields of the attribute structure have been modified by the various iofunc-layer helper routines. That way, if you need to write the entries to some medium, you can write just those that have changed. The user-defined area for flags is IOFUNC\_ATTR\_PRIVATE (see <sys/iofunc.h>).

For details on updating your attribute structure, see the section on "Updating the time for reads and writes" in the Handling Read and Write Messages chapter.

lock\_tid and lock\_count

To support multiple threads in your resource manager, you'll need to lock the attribute structure so that only one thread at a time is allowed to change it. The resource manager layer automatically locks the attribute (using <code>iofunc\_attr\_lock()</code>) for you when certain handler functions are called (i.e. IO\_\*). The <code>lock\_tid</code> member holds the thread ID; the <code>lock\_count</code> member holds the number of times the thread has locked the attribute structure. For more information, see the <code>iofunc\_attr\_lock()</code> and <code>iofunc\_attr\_unlock()</code> functions in the QNX Neutrino <code>Library Reference</code>.)

count, rcount, wcount, rlocks and wlocks

Several counters are stored in the attribute structure and are incremented/decremented by some of the iofunc layer helper functions. Both the functionality and the actual contents of the message received from the client determine which specific members are affected.

#### This counter: Tracks the number of:

count	OCBs using this attribute in any manner. When this count goes to zero, it means that no one is using this attribute.
rcount	OCBs using this attribute for reading.
wcount	OCBs using this attribute for writing.
rlocks	read locks currently registered on the attribute.
wlocks	write locks currently registered on the attribute.

These counts aren't exclusive. For example, if an OCB has specified that the resource is opened for reading and writing, then *count*, *rcount*, and *wcount* will *all* be incremented. (See the *iofunc\_attr\_init()*, *iofunc\_lock\_default()*, *iofunc\_lock()*, *iofunc\_ocb\_attach()*, and *iofunc\_ocb\_detach()* functions.)

mmap list and lock list

To manage their particular functionality on the resource, the *mmap\_list* member is used by the *iofunc\_mmap()* and *iofunc\_mmap\_default()* functions; the *lock\_list* member is used by the *iofunc\_lock\_default()* function. Generally, you shouldn't need to modify or examine these members.

*list* Reserved for future use.

*list size* The size of the reserved *list* area; reserved for future use.

nbytes

The number of bytes in the resource. Your resource manager can modify this member. For a file, this would contain the file's size. For special devices (e.g. /dev/null) that don't support <code>lseek()</code> or have a radically different interpretation for <code>lseek()</code>, this field isn't used (because you wouldn't use any of the helper functions, but would supply your own instead.) In these cases, we recommend that you set this field to zero, unless there's a meaningful interpretation that you care to put to it.

inode

This is a mountpoint-specific inode that must be unique per mountpoint. You can specify your own value, or 0 to have the process manager fill it in for you. For filesystem resource managers, this may correspond to some on-disk structure. In any case, the interpretation of this field is up to you.

uid and gid

The user ID and group ID of the owner of this resource. These fields are updated automatically by the *chown()* helper functions (e.g. *iofunc\_chown\_default()*) and are referenced in conjunction with the *mode* member for access-granting purposes by the *open()* help functions (e.g. *iofunc\_open\_default()*).

mtime, atime, and ctime

The three POSIX time members:

- *mtime* modification time (*write*() updates this)
- atime access time (read() updates this)
- *ctime* change of status time (*write*(), *chmod*(), and *chown*() update this)



One or more of the time members may be *invalidated* as a result of calling an iofunc-layer function. This is to avoid having each and every I/O message handler go to the kernel and request the current time of day, just to fill in the attribute structure's time member(s).

POSIX states that these times must be *valid* when the *fstat()* is performed, but they don't have to reflect the *actual* time that the associated change occurred. Also, the times must change between *fstat()* invocations *if* the associated change occurred between *fstat()* invocations. If the associated change never occurred between *fstat()* invocations, then the time returned should be the same as returned last time. Furthermore, if the associated change occurred multiple times between *fstat()* invocations, then the time need only be different from the previously returned time.

There's a helper function that fills the members with the correct time; you may wish to call it in the appropriate handlers to keep the time up-to-date on the device — see the *iofunc\_time\_update()* function.

mode Contains the resource's mode (e.g. type, permissions). Valid modes may be selected from the S\_\* series of constants in sys/stat.h>.

nlink The number of links to this particular name. For names that represent

a directory, this value must be at least 2 (one for the directory itself, one for the ./ entry in it). Your resource manager can modify this

member.

rdev Contains the device number for a character special device and the

rdev number for a named special device.

## The optional iofunc mount t (mount) structure

The members of the mount structure, specifically the *conf* and *flags* members, modify the behavior of some of the iofunc layer functions. This optional structure contains at least the following:

The variables are:

flags

Contains one relevant bit (manifest constant IOFUNC\_MOUNT\_32BIT), which indicates that the offsets used by this resource manager are 32-bit (as opposed to the extended 64-bit offsets). The user-modifiable mount flags are defined as IOFUNC\_MOUNT\_FLAGS\_PRIVATE (see <sys/iofunc.h>).

*conf* Contains several bits:

```
IOFUNC_PC_CHOWN_RESTRICTED
```

Causes the default handler for the \_IO\_CHOWN message to behave in a manner defined by POSIX as "chown-restricted".

```
IOFUNC PC NO TRUNC
```

Has no effect on the iofunc layer libraries, but is returned by the iofunc layer's default \_IO\_PATHCONF handler.

```
IOFUNC_PC_SYNC_IO
```

If not set, causes the default iofunc layer \_IO\_OPEN handler to fail if the client specified any one of O\_DSYNC, O\_RSYNC, or O\_SYNC.

```
IOFUNC PC LINK DIR
```

Controls whether or not **root** is allowed to link and unlink directories.

Note that the options mentioned above for the *conf* member are returned by the iofunc layer \_IO\_PATHCONF default handler.

dev

Contains the device number for the filesystem. This number is returned to the client's *stat()* function in the **struct stat** *st\_dev* member.

blocksize

Contains the block size of the device. On filesystem types of resource managers, this indicates the native blocksize of the disk, e.g. 512 bytes.

funcs

Contains the following structure:

where:

*nfuncs* Indicates the number of functions present in the structure; it should be filled with the manifest constant

```
_IOFUNC_NFUNCS.
```

ocb\_calloc() and ocb\_free()

Allows you to override the OCBs on a per-mountpoint basis. (See the section titled "Extending the OCB and attribute structures" in the Extending the POSIX-Layer Data Structures chapter.) If these members are NULL, then the default library versions are used. You must specify either *both* or *neither* of these functions — they operate as a matched pair.

# Chapter 5

# **Handling Read and Write Messages**

# In this chapter...

Handling the \_IO\_READ message 65
Handling the \_IO\_WRITE message 68
Methods of returning and replying 71
Handling other read/write details 75
Updating the time for reads and writes 79

## Handling the IO READ message

The *io\_read* handler is responsible for returning data bytes to the client after receiving an \_IO\_READ message. Examples of functions that send this message are *read()*, *readdir()*, *fread()*, and *fgetc()*. Let's start by looking at the format of the message itself:

As with all resource manager messages, we've defined a union that contains the input (coming into the resource manager) structure and a reply or output (going back to the client) structure. The *io\_read* handler is prototyped with an argument of io\_read\_t \*msg — that's the pointer to the union containing the message.

Since this is a *read()*, the *type* member has the value \_IO\_READ. The items of interest in the input structure are:

combine\_len This field has meaning for a combine message — see the Combine Messages chapter.

*nbytes* How many bytes the client is expecting.

*xtype* A per-message override, if your resource manager supports it. Even if your resource manager doesn't support it, you should still examine

this member. More on the *xtype* later (see the "Handling the *xtype*"

member" section).

We'll create an *io\_read* handler that actually returns some data (the fixed string "Hello, world\n"). We'll use the OCB to keep track of our position within the buffer that we're returning to the client.

When we get the \_IO\_READ message, the *nbytes* member tells us exactly how many bytes the client wants to read. Suppose that the client issues:

```
read (fd, buf, 4096);
```

In this case, it's a simple matter to return our entire "Hello, world\n" string in the output buffer and tell the client that we're returning 13 bytes, i.e. the size of the string.

However, consider the case where the client is performing the following:

```
while (read (fd, &character, 1) != EOF) {
   printf ("Got a character \"%c\"\n", character);
}
```

Granted, this isn't a terribly efficient way for the client to perform reads! In this case, we would get msg->i.nbytes set to 1 (the size of the buffer that the client wants to get). We can't simply return the entire string all at once to the client — we have to hand it out one character at a time. This is where the OCB's offset member comes into play.

## Sample code for handling \_IO\_READ messages

Here's a complete io read handler that correctly handles these cases:

```
#include <errno.h>
#include <stdio.h>
#include <stddef.h>
#include <stdlib.h>
#include <unistd.h>
#include <sys/iofunc.h>
#include <sys/dispatch.h>
int io read (resmgr context t *ctp, io read t *msg, RESMGR OCB T *ocb);
static char
                               *buffer = "Hello world\n";
static resmgr_connect_funcs_t connect_funcs;
static resmgr_io_funcs_t
                               io_funcs;
static iofunc attr t
                               attr;
main(int argc, char **argv)
    /* declare variables we'll be using */
   resmgr_attr_t resmgr_attr;
   dispatch t
                        *dpp;
   dispatch_context_t *ctp;
                        id:
    /* initialize dispatch interface */
   if((dpp = dispatch_create()) == NULL) {
       fprintf(stderr, "%s: Unable to allocate dispatch handle.\n",
               argv[0]);
       return EXIT FAILURE;
   /* initialize resource manager attributes */
   memset(&resmgr_attr, 0, sizeof resmgr_attr);
   resmgr_attr.nparts_max = 1;
   resmgr attr.msg max size = 2048;
    /* initialize functions for handling messages */
   iofunc_func_init(_RESMGR_CONNECT_NFUNCS, &connect_funcs,
                    RESMGR_IO_NFUNCS, &io_funcs);
    io_funcs.read = io_read;
    /* initialize attribute structure used by the device */
   iofunc_attr_init(&attr, S_IFNAM | 0666, 0, 0);
    attr.nbytes = strlen(buffer)+1;
    /* attach our device name */
   if((id = resmgr_attach(dpp, &resmgr_attr, "/dev/sample", _FTYPE_ANY, 0,
                &connect funcs, &io funcs, &attr)) == -1) {
       fprintf(stderr, "%s: Unable to attach name.\n", argv[0]);
       return EXIT_FAILURE;
    /* allocate a context structure */
   ctp = dispatch context alloc(dpp);
   /* start the resource manager message loop */
   while(1) {
       if((ctp = dispatch_block(ctp)) == NULL) {
           fprintf(stderr, "block error\n");
           return EXIT_FAILURE;
       }
```

}

```
dispatch_handler(ctp);
io_read (resmgr_context_t *ctp, io_read_t *msg, RESMGR_OCB_T *ocb)
   int
               nleft;
   int
              nparts;
   int
               status;
   if ((status = iofunc_read_verify (ctp, msg, ocb, NULL)) != EOK)
       return (status);
   if ((msg->i.xtype & _IO_XTYPE_MASK) != _IO_XTYPE_NONE)
       return (ENOSYS);
    * On all reads (first and subsequent), calculate
    * how many bytes we can return to the client,
    * based upon the number of bytes available (nleft)
    * and the client's buffer size
   nleft = ocb->attr->nbytes - ocb->offset;
   nbytes = min (msg->i.nbytes, nleft);
   if (nbytes > 0) \{
       /* set up the return data IOV */
       SETIOV (ctp->iov, buffer + ocb->offset, nbytes);
       /* set up the number of bytes (returned by client's read()) */
       _IO_SET_READ_NBYTES (ctp, nbytes);
        * advance the offset by the number of bytes
         * returned to the client.
       ocb->offset += nbytes;
       nparts = 1;
   } else {
        * they've asked for zero bytes or they've already previously
        * read everything
       IO SET READ NBYTES (ctp, 0);
       nparts = 0:
    /* mark the access time as invalid (we just accessed it) */
   if (msg->i.nbytes > 0)
       ocb->attr->flags |= IOFUNC_ATTR_ATIME;
   return (_RESMGR_NPARTS (nparts));
```

The ocb maintains our context for us by storing the offset field, which gives us the position within the buffer, and by having a pointer to the attribute structure attr, which tells us how big the buffer actually is via its *nbytes* member.

Of course, we had to give the resource manager library the address of our io read handler so that it knew to call it. So the code in main() where we had called iofunc func init() became:

```
/* initialize functions for handling messages */
iofunc_func_init(_RESMGR_CONNECT_NFUNCS, &connect_funcs,
```

```
_RESMGR_IO_NFUNCS, &io_funcs);
io_funcs.read = io_read;
```

We also needed to add the following to the area above *main()*:

```
#include <errno.h>
#include <unistd.h>
int io_read (resmgr_context_t *ctp, io_read_t *msg, RESMGR_OCB_T *ocb);
static char *buffer = "Hello world\n";"
```

Where did the attribute structure's *nbytes* member get filled in? In *main()*, just after we did the *iofunc* attr init(). We modified *main()* slightly:

After this line:

```
iofunc_attr_init (&attr, s_IFNAM | 0666, 0, 0);
We added this one:
```

```
attr.nbytes = strlen (buffer) +1;
```

At this point, if you were to run the resource manager (our simple resource manager used the name /dev/sample), you could do:

```
# cat /dev/sample
Hello, world
```

The return line ( RESMGR NPARTS (nparts)) tells the resource manager library to:

- reply to the client for us
- reply with *nparts* IOVs

Where does it get the IOV array? It's using ctp->iov. That's why we first used the SETIOV() macro to make ctp->iov point to the data to reply with.

If we had no data, as would be the case of a read of zero bytes, then we'd do a return (\_RESMGR\_NPARTS(0)). But read() returns with the number of bytes successfully read. Where did we give it this information? That's what the

\_IO\_SET\_READ\_NBYTES() macro was for. It takes the *nbytes* that we give it and stores it in the context structure (*ctp*). Then when we return to the library, the library takes this *nbytes* and passes it as the second parameter to the *MsgReplyv()*. The second parameter tells the kernel what the *MsgSend()* should return. And since the *read()* function is calling *MsgSend()*, that's where it finds out how many bytes were read.

We also update the access time for this device in the read handler. For details on updating the access time, see the section on "Updating the time for reads and writes" below.

## Handling the IO WRITE message

The *io\_write* handler is responsible for writing data bytes to the media after receiving a client's \_IO\_WRITE message. Examples of functions that send this message are *write()* and *fflush()*. Here's the message:

As with the io\_read\_t, we have a union of an input and an output message, with the output message being empty (the number of bytes actually written is returned by the resource manager library directly to the client's MsgSend()).

The data being written by the client almost always follows the header message stored in **struct** \_io\_write. The exception is if the write was done using *pwrite()* or *pwrite64()*. More on this when we discuss the *xtype* member.

To access the data, we recommend that you reread it into your own buffer. Let's say you had a buffer called *inbuf* that was "big enough" to hold all the data you expected to read from the client (if it isn't big enough, you'll have to read the data piecemeal).

### Sample code for handling **IO\_WRITE** messages

The following is a code snippet that can be added to one of the simple resource manager examples. It prints out whatever it's given (making the assumption that it's given only character text):

```
io write (resmgr context t *ctp, io write t *msg, RESMGR OCB T *ocb)
   int
           status:
   char
           *buf;
   if ((status = iofunc write verify(ctp, msg, ocb, NULL)) != EOK)
       return (status);
   if ((msg->i.xtype & _IO_XTYPE_MASK) != _IO_XTYPE_NONE)
       return (ENOSYS);
   /* set up the number of bytes (returned by client's write()) */
    IO SET WRITE NBYTES (ctp, msg->i.nbytes);
   buf = (char *) malloc(msg->i.nbytes + 1);
   if (buf == NULL)
       return (ENOMEM);
    * Reread the data from the sender's message buffer.
    * We're not assuming that all of the data fit into the
      resource manager library's receive buffer.
   resmgr msgread(ctp, buf, msg->i.nbytes, sizeof(msg->i));
   buf [msg->i.nbytes] = '\0'; /* just in case the text is not NULL terminated */
   printf ("Received %d bytes = '%s'\n", msg -> i.nbytes, buf);
   free(buf);
   if (msg->i.nbytes > 0)
       ocb->attr->flags |= IOFUNC_ATTR_MTIME | IOFUNC_ATTR_CTIME;
```

```
return (_RESMGR_NPARTS (0));
```

Of course, we'll have to give the resource manager library the address of our *io\_write* handler so that it'll know to call it. In the code for *main()* where we called *iofunc\_func\_init()*, we'll add a line to register our *io\_write* handler:

You may also need to add the following prototype:

At this point, if you were to run the resource manager (our simple resource manager used the name /dev/sample), you could write to it by doing echo Hello > /dev/sample as follows:

```
# echo Hello > /dev/sample
Received 6 bytes = 'Hello'
```

Notice how we passed the last argument to *resmgr\_msgread()* (the *offset* argument) as the size of the input message buffer. This effectively skips over the header and gets to the data component.

If the buffer you supplied wasn't big enough to contain the entire message from the client (e.g. you had a 4 KB buffer and the client wanted to write 1 megabyte), you'd have to read the buffer in stages, using a for loop, advancing the offset passed to resmgr\_msgread() by the amount read each time.

Unlike the *io\_read* handler sample, this time we didn't do anything with ocb->offset. In this case there's no reason to. The ocb->offset would make more sense if we were managing things that had advancing positions such as a file position.

The reply is simpler than with the *io\_read* handler, since a *write()* call doesn't expect any data back. Instead, it just wants to know if the write succeeded and if so, how many bytes were written. To tell it how many bytes were written we used the \_*IO\_SET\_WRITE\_NBYTES()* macro. It takes the *nbytes* that we give it and stores it in the context structure (*ctp*). Then when we return to the library, the library takes this *nbytes* and passes it as the second parameter to the *MsgReplyv()*. The second parameter tells the kernel what the *MsgSend()* should return. And since the *write()* function is calling *MsgSend()*, that's where it finds out how many bytes were written.

Since we're writing to the device, we should also update the modification, and potentially, the creation time. For details on updating the modification and change of file status times, see the section on "Updating the time for reads and writes" below.

## Methods of returning and replying

You can return to the resource manager library from your handler functions in various ways. This is complicated by the fact that the resource manager library can reply for you if you want it to, but you must tell it to do so and put the information that it'll use in all the right places.

In this section, we'll discuss the following ways of returning to the resource manager library:

- returning with an error
- returning using an IOV array that points to your data
- returning with a single buffer containing data
- returning success but with no data
- getting the resource manager library to do the reply
- performing the reply in the server
- leaving the client blocked, replying later (a special case of performing the reply in the server)
- returning and telling the library to do the default action

### Returning with an error

To reply to the client such that the function the client is calling (e.g. *read()*) will return with an error, you simply return with an appropriate *errno* value (from <errno.h>).

```
return (ENOMEM);
```

In the case of a *read()*, this causes the read to return -1 with *errno* set to ENOMEM.



You might sometimes see this in the code for a resource manager:

```
_RESMGR_ERRNO (error_code)
```

but this is the same as simply returning the *error\_code* directly. The *\_RESMGR\_ERRNO()* macro is deprecated.

## Returning using an IOV array that points to your data

Sometimes you'll want to reply with a header followed by one of *N* buffers, where the buffer used will differ each time you reply. To do this, you can set up an IOV array whose elements point to the header and to a buffer.

The context structure already has an IOV array. If you want the resource manager library to do your reply for you, then you must use this array. But the array must contain enough elements for your needs. To ensure that this is the case, set the

*nparts\_max* member of the **resmgr\_attr\_t** structure that you passed to  $resmgr_attach()$  when you registered your name in the pathname space.

The following example assumes that the variable *i* contains the offset into the array of buffers of the desired buffer to reply with. The 2 in \_RESMGR\_NPARTS(2) tells the library how many elements in ctp->iov to reply with.

```
my_header_t header;
a_buffer_t buffers[N];
...

SETIOV(&ctp->iov[0], &header, sizeof(header));
SETIOV(&ctp->iov[1], &buffers[i], sizeof(buffers[i]));
return ( RESMGR NPARTS(2));
```

### Returning with a single buffer containing data

An example of this would be replying to a *read()* where all the data existed in a single buffer. You'll typically see this done in two ways:

```
return (_RESMGR_PTR(ctp, buffer, nbytes));
And:
SETIOV (ctp->iov, buffer, nbytes);
return ( RESMGR NPARTS(1));
```

The first method, using the \_RESMGR\_PTR() macro, is just a convenience for the second method where a single IOV is returned.

## Returning success but with no data

This can be done in a few ways. The most simple would be:

```
return (EOK);
But you'll often see:
return (_RESMGR_NPARTS(0));
```

Note that in neither case are you causing the *MsgSend()* to return with a 0. The value that the *MsgSend()* returns is the value passed to the *\_IO\_SET\_READ\_NBYTES()*, *\_IO\_SET\_WRITE\_NBYTES()*, and other similar macros. These two were used in the read and write samples above.

## Getting the resource manager library to do the reply

In this case, you give the client the data and get the resource manager library to do the reply for you. However, the reply data won't be valid by that time. For example, if the reply data was in a buffer that you wanted to free before returning, you could use the following:

```
resmgr_msgwrite (ctp, buffer, nbytes, 0);
free (buffer);
return (EOK);
```

The <code>resmgr\_msgwrite()</code> function copies the contents of buffer into the client's reply buffer immediately. Note that a reply is still required in order to unblock the client so it can examine the data. Next we free the buffer. Finally, we return to the resource manager library such that it does a reply with zero-length data. Since the reply is of zero length, it doesn't overwrite the data already written into the client's reply buffer. When the client returns from its send call, the data is there waiting for it.

## Performing the reply in the server

In all of the previous examples, it's the resource manager library that calls MsgReply\*() or MsgError() to unblock the client. In some cases, you may not want the library to reply for you. For instance, you might have already done the reply yourself, or you'll reply later. In either case, you'd return as follows:

```
return ( RESMGR NOREPLY);
```

## Leaving the client blocked, replying later

An example of a resource manager that would reply to clients later is a pipe resource manager. If the client is doing a read of your pipe but you have no data for the client, then you have a choice:

- You can reply with an error (EAGAIN).
   Or:
- You can leave the client blocked and later, when your write handler function is called, you can reply to the client with the new data.

Another example might be if the client wants you to write to some device but doesn't want to get a reply until the data has been fully written out. Here are the sequence of events that might follow:

- 1 Your resource manager does some I/O to the hardware to tell it that data is available.
- 2 The hardware generates an interrupt when it's ready for a packet of data.
- **3** You handle the interrupt by writing data out to the hardware.
- 4 Many interrupts may occur before all the data is written only then would you reply to the client.

The first issue, though, is whether the client wants to be left blocked. If the client doesn't want to be left blocked, then it opens with the O NONBLOCK flag:

```
fd = open("/dev/sample", O_RDWR | O_NONBLOCK);
```

The default is to allow you to block it.

One of the first things done in the read and write samples above was to call some POSIX verification functions: *iofunc\_read\_verify()* and *iofunc\_write\_verify()*. If we

pass the address of an int as the last parameter, then on return the functions will stuff that int with nonzero if the client doesn't want to be blocked (O\_NONBLOCK flag was set) or with zero if the client wants to be blocked.

When it then comes time to decide if we should reply with an error or reply later, we do:

```
if (nonblock) {
    /* client doesn't want to be blocked */
    return (EAGAIN);
} else {
    /*
    * The client is willing to be blocked.
    * Save at least the ctp->rcvid so that you can
    * reply to it later.
    */
    ...
    return (_RESMGR_NOREPLY);
}
```

The question remains: How do you do the reply yourself? The only detail to be aware of is that the *rcvid* to reply to is ctp->rcvid. If you're replying later, then you'd save ctp->rcvid and use the saved value in your reply:

```
MsgReply(saved_rcvid, 0, buffer, nbytes);
Or:
iov_t iov[2];
SETIOV(&iov[0], &header, sizeof(header));
SETIOV(&iov[1], &buffers[i], sizeof(buffers[i]));
MsgReplyv(saved rcvid, 0, iov, 2);
```

Note that you can fill up the client's reply buffer as data becomes available by using  $resmgr\_msgwrite()$  and  $resmgr\_msgwritev()$ . Just remember to do the MsgReply\*() at some time to unblock the client.



If you're replying to an \_IO\_READ or \_IO\_WRITE message, the *status* argument for *MsgReply\*()* must be the number of bytes read or written.

There's another way to resume the blocked operation, but it isn't as efficient as the other methods: you can call <code>resmgr\_msg\_again()</code>. This function restores the <code>resmgr\_context\_t</code> structure to the way it was when your resource manager received the message associated with the <code>rcvid</code>, and then processes the message again as if it had just been received.

### Returning and telling the library to do the default action

The default action in most cases is for the library to cause the client's function to fail with ENOSYS:

```
return ( RESMGR DEFAULT);
```

## Handling other read/write details

Topics in this session include:

- Handling the xtype member
- Handling *pread\*()* and *pwrite\*()*
- Handling *readcond()*.

## Handling the xtype member

The message structures passed to the *io\_read*, *io\_write*, and *io\_openfd* handlers contain a member called *xtype*. From struct io read:

Basically, the *xtype* contains extended type information that can be used to adjust the behavior of a standard I/O function. Most resource managers care about only a few values:

```
IO XTYPE NONE
```

No extended type information is being provided.

```
IO XTYPE OFFSET
```

If clients are calling pread(), pread64(), pwrite(), or pwrite64(), then they don't want you to use the offset in the OCB. Instead, they're providing a one-shot offset. That offset follows the struct \_io\_read or struct \_io\_write headers that reside at the beginning of the message buffers.

For example:

```
struct myread_offset {
    struct _io_read read;
    struct _xtype_offset offset;
}
```

Some resource managers can be sure that their clients will never call *pread\*()* or *pwrite\*()*. (For example, a resource manager that's controlling a robot arm probably wouldn't care.) In this case, you can treat this type of message as an error.

#### IO XTYPE READCOND

If a client is calling <code>readcond()</code>, they want to impose timing and return buffer size constraints on the read. Those constraints follow the <code>struct\_io\_read</code> or <code>struct\_io\_write</code> headers at the beginning of the message buffers. For example:

```
struct myreadcond {
    struct _io_read read;
    struct _xtype_readcond cond;
}
```

As with \_IO\_XTYPE\_OFFSET, if your resource manager isn't prepared to handle *readcond()*, you can treat this type of message as an error.

#### IO XFLAG DIR EXTRA HINT

This flag is valid only when reading from a directory. The filesystem should normally return extra directory information when it's easy to get. If this flag is set, it is a hint to the filesystem to try harder (possibly causing media lookups) to return the extra information. The most common use is to return \_DTYPE\_LSTAT information.

#### If you aren't expecting extended types (xtype)

The following code sample demonstrates how to handle the case where you're not expecting any extended types. In this case, if you get a message that contains an *xtype*, you should reply with ENOSYS. The example can be used in either an *io\_read* or *io\_write* handler.

## Handling pread\*() and pwrite\*()

Here are code examples that demonstrate how to handle an \_IO\_READ or \_IO\_WRITE message when a client calls:

- pread\*()
- *pwrite*\*()

#### Sample code for handling IO READ messages in pread\*()

The following sample code demonstrates how to handle \_IO\_READ for the case where the client calls one of the *pread\*()* functions.

```
/* we are defining io pread t here to make the code below
  simple */
typedef struct {
   struct _io_read
                         read;
   struct _xtype_offset offset;
} io pread t;
int
io_read (resmgr_context_t *ctp, io_read_t *msg,
        RESMGR_OCB_T *ocb)
   off64 t offset; /* where to read from */
   int status;
   if ((status = iofunc read verify(ctp, msg, ocb, NULL))
        ! = EOK) {
       return(status);
   switch(msg->i.xtype & _IO_XTYPE_MASK) {
   case IO XTYPE NONE:
       offset = ocb->offset;
       break:
   case IO XTYPE OFFSET:
        * io_pread_t is defined above.
        * Client is doing a one-shot read to this offset by
        * calling one of the pread*() functions
       offset = ((io_pread_t *) msg)->offset.offset;
       break;
   default:
       return (ENOSYS);
}
```

#### Sample code for handling IO WRITE messages in pwrite\*()

The following sample code demonstrates how to handle \_IO\_WRITE for the case where the client calls one of the <code>pwrite\*()</code> functions. Keep in mind that the <code>struct\_xtype\_offset</code> information follows the <code>struct\_io\_write</code> in the sender's message buffer. This means that the data to be written follows the <code>struct\_xtype\_offset</code> information (instead of the normal case where it follows the <code>struct\_io\_write</code>). So, you must take this into account when doing the <code>resmgr\_msgread()</code> call in order to get the data from the sender's message buffer.

```
io_write (resmgr_context_t *ctp, io_write_t *msg,
         RESMGR_OCB_T *ocb)
   off64 t offset; /* where to write */
   int status;
   size_t skip; /* offset into msg to where the data
                      resides */
   if ((status = iofunc_write_verify(ctp, msg, ocb, NULL))
        ! = EOK) {
        return(status);
   switch(msg->i.xtype & _IO_XTYPE_MASK) {
   case IO XTYPE NONE:
       offset = ocb->offset;
       skip = sizeof(io_write_t);
       break;
   case IO XTYPE OFFSET:
       /*
        * io_pwrite_t is defined above
        * client is doing a one-shot write to this offset by
         * calling one of the pwrite*() functions
        */
       offset = ((io pwrite t *) msg)->offset.offset;
       skip = sizeof(io_pwrite_t);
       break;
    default:
        return(ENOSYS);
    . . .
    * get the data from the sender's message buffer,
       skipping all possible header information
   resmgr msgreadv(ctp, iovs, niovs, skip);
}
```

## Handling readcond()

The same type of operation that was done to handle the *pread()/\_IO\_XTYPE\_OFFSET* case can be used for handling the client's *readcond()* call:

Then your manager has to properly interpret and deal with the arguments to *readcond()*. For more information, see the QNX Neutrino *Library Reference*.

## Updating the time for reads and writes

In the read sample above we did:

```
if (msg->i.nbytes > 0)
    ocb->attr->flags |= IOFUNC_ATTR_ATIME;
```

According to POSIX, if the read succeeds and the reader had asked for more than zero bytes, then the access time must be marked for update. But POSIX doesn't say that it must be updated right away. If you're doing many reads, you may not want to read the time from the kernel for every read. In the code above, we mark the time only as needing to be updated. When the next \_IO\_STAT or \_IO\_CLOSE\_OCB message is processed, the resource manager library will see that the time needs to be updated and will get it from the kernel then. This of course has the disadvantage that the time is not the time of the read.

Similarly for the write sample above, we did:

```
if (msg->i.nbytes > 0)
    ocb->attr->flags |= IOFUNC_ATTR_MTIME | IOFUNC_ATTR_CTIME;
```

so the same thing will happen.

If you *do* want to have the times represent the read or write times, then after setting the flags you need only call the *iofunc\_time\_update()* helper function. So the read lines become:

```
if (msg->i.nbytes > 0) {
    ocb->attr->flags |= IOFUNC_ATTR_ATIME;
    iofunc_time_update(ocb->attr);
}
and the write lines become:

if (msg->i.nbytes > 0) {
    ocb->attr->flags |= IOFUNC_ATTR_MTIME | IOFUNC_ATTR_CTIME;
    iofunc_time_update(ocb->attr);
}
```

You should call <code>iofunc\_time\_update()</code> before you flush out any cached attributes. As a result of changing the time fields, the attribute structure will have the <code>IOFUNC\_ATTR\_DIRTY\_TIME</code> bit set in the flags field, indicating that this field of the attribute must be updated when the attribute is flushed from the cache.

# Chapter 6

# **Combine Messages**

# In this chapter...

Where combine messages are used 83 The library's combine-message handling 84

## Where combine messages are used

In order to conserve network bandwidth and to provide support for atomic operations, *combine messages* are supported. A combine message is constructed by the client's C library and consists of a number of I/O and/or connect messages packaged together into one. Let's see how they're used.

### **Atomic operations**

Consider a case where two threads are executing the following code, trying to read from the same file descriptor:

```
a_thread ()
{
    char buf [BUFSIZ];

    lseek (fd, position, SEEK_SET);
    read (fd, buf, BUFSIZ);
    ...
}
```

The first thread performs the *lseek()* and then gets preempted by the second thread. When the first thread resumes executing, its offset into the file will be at the end of where the second thread read from, *not* the position that it had *lseek()*'d to.

This can be solved in one of three ways:

- The two threads can use a *mutex* to ensure that only one thread at a time is using the file descriptor.
- Each thread can open the file itself, thus generating a unique file descriptor that won't be affected by any other threads.
- The threads can use the *readblock()* function, which performs an atomic *lseek()* and *read()*.

Let's look at these three methods.

#### Using a mutex

In the first approach, if the two threads use a mutex between themselves, the following issue arises: every *read()*, *lseek()*, and *write()* operation *must* use the mutex.

If this practice isn't enforced, then you still have the exact same problem. For example, suppose one thread that's obeying the convention locks the mutex and does the <code>lseek()</code>, thinking that it's protected. However, another thread (that's not obeying the convention) can preempt it and move the offset to somewhere else. When the first thread resumes, we again encounter the problem where the offset is at a different (unexpected) location. Generally, using a mutex will be successful only in very tightly managed projects, where a code review will <code>ensure</code> that each and every thread's file functions obey the convention.

#### Per-thread files

The second approach — of using different file descriptors — is a good general-purpose solution, *unless* you explicitly wanted the file descriptor to be shared.

#### The readblock() function

In order for the *readblock()* function to be able to effect an atomic seek/read operation, it must ensure that the requests it sends to the resource manager will all be processed at the same time. This is done by combining the \_IO\_LSEEK and \_IO\_READ messages into one message. Thus, when the base layer performs the *MsgReceive()*, it will receive the entire *readblock()* request in one atomic message.

#### **Bandwidth considerations**

Another place where combine messages are useful is in the *stat()* function, which can be implemented by calling *open()*, *fstat()*, and *close()* in sequence.

Rather than generate three separate messages (one for each of the functions), the C library combines them into one contiguous message. This boosts performance, especially over a networked connection, and also simplifies the resource manager, because it's not forced to have a connect function to handle *stat()*.

## The library's combine-message handling

The resource manager library handles combine messages by presenting each component of the message to the appropriate handler routines. For example, if we get a combine message that has an <code>\_IO\_LSEEK</code> and <code>\_IO\_READ</code> in it (e.g. <code>readblock())</code>, the library will call our <code>io lseek</code> and <code>io read</code> handlers for us in turn.

But let's see what happens in the resource manager when it's handling these messages. With multiple threads, both of the client's threads may very well have sent in their "atomic" combine messages. Two threads in the resource manager will now attempt to service those two messages. We again run into the same synchronization problem as we originally had on the client end — one thread can be partway through processing the message and can then be preempted by the other thread.

The solution? The resource manager library provides callouts to lock the OCB while processing any message (except \_IO\_CLOSE and \_IO\_UNBLOCK —we'll return to these). As an example, when processing the <code>readblock()</code> combine message, the resource manager library performs callouts in this order:

- 1 *lock ocb* handler
- 2 IO LSEEK message handler
- **3** IO READ message handler
- 4 unlock ocb handler

Therefore, in our scenario, the two threads within the resource manager would be mutually exclusive to each other by virtue of the lock — the first thread to acquire the

lock would completely process the combine message, unlock the lock, and then the second thread would perform its processing.

Let's examine several of the issues that are associated with handling combine messages:

- Component responses
- Component data access
- Locking and unlocking the attribute structure
- Various styles of connect messages
- IO CONNECT COMBINE CLOSE
- \_IO\_CONNECT\_COMBINE

### **Component responses**

As we've seen, a combine message really consists of a number of "regular" resource manager messages combined into one large contiguous message. The resource manager library handles each component in the combine message separately by extracting the individual components and then out calling to the handlers you've specified in the connect and I/O function tables, as appropriate, for each component.

This generally doesn't present any new wrinkles for the message handlers themselves, except in one case. Consider the *readblock()* combine message:

Client call: readblock()

Message(s): \_IO\_LSEEK , \_IO\_READ

Callouts: io lock ocb

io\_lseek
io\_read
io\_unlock\_o

io\_unlock\_ocb

Ordinarily, after processing the \_IO\_LSEEK message, your handler would return the current position within the file. However, the next message (the \_IO\_READ) also returns data. By convention, only the last data-returning message within a combine message will actually return data. The intermediate messages are allowed to return only a pass/fail indication.

The impact of this is that the \_IO\_LSEEK message handler has to be aware of whether or not it's being invoked as part of combine message handling. If it is, it should only return either an EOK (indicating that the *lseek()* operation succeeded) or an error indication to indicate some form of failure.

But if the \_IO\_LSEEK handler isn't being invoked as part of combine message handling, it should return the EOK *and* the new offset (or, in case of error, an error indication only).

Here's a sample of the code for the default iofunc-layer *lseek()* handler:

The relevant decision is made in this statement:

```
if (msg -> i.combine len & IO COMBINE FLAG)
```

If the \_IO\_COMBINE\_FLAG bit is set in the *combine\_len* member, this indicates that the message is being processed as part of a combine message.

When the resource manager library is processing the individual components of the combine message, it looks at the error return from the individual message handlers. If a handler returns anything other than EOK, then processing of further combine message components is aborted. The error that was returned from the failing component's handler is returned to the client.

## **Component data access**

The second issue associated with handling combine messages is how to access the data area for subsequent message components.

For example, the *writeblock()* combine message format has an *lseek()* message first, followed by the *write()* message. This means that the data associated with the *write()* request is further in the received message buffer than would be the case for just a simple \_IO\_WRITE message:

This issue is easy to work around. There's a resource manager library function called *resmgr\_msgread()* that knows how to get the data corresponding to the correct

message component. Therefore, in the *io\_write* handler, if you used *resmgr\_msgread()* instead of *MsgRead()*, this would be transparent to you.



Resource managers should always use resmgr msg\*() cover functions.

For reference, here's the source for resmgr msgread():

As you can see,  $resmgr\_msgread()$  simply calls MsgRead() with the offset of the component message from the beginning of the combine message buffer. For completeness, there's also a  $resmgr\_msgwrite()$  that works in an identical manner to MsgWrite(), except that it dereferences the passed ctp to obtain the rcvid.

### Locking and unlocking the attribute structure

As mentioned above, another facet of the operation of the *readblock()* function from the client's perspective is that it's atomic. In order to process the requests for a particular OCB in an atomic manner, we must lock and unlock the attribute structure pointed to by the OCB, thus ensuring that only one resource manager thread has access to the OCB at a time.

The resource manager library provides two callouts for doing this:

- lock ocb
- unlock ocb

These are members of the I/O functions structure. The handlers that you provide for those callouts should lock and unlock the attribute structure pointed to by the OCB by calling <code>iofunc\_attr\_lock()</code> and <code>iofunc\_attr\_unlock()</code>. Therefore, if you're locking the attribute structure, there's a possibility that the <code>lock\_ocb</code> callout will block for a period of time. This is normal and expected behavior. Note also that the attributes structure is automatically locked for you when your I/O function is called.

## **Connect message types**

Let's take a look at the general case for the *io\_open* handler — it doesn't always correspond to the client's *open()* call!

For example, consider the *stat()* and *access()* client function calls.

### IO CONNECT COMBINE CLOSE

For a *stat()* client call, we essentially perform the sequence *open()/fstat()/close()*. Note that if we actually did that, three messages would be required. For performance reasons, we implement the *stat()* function as one single combine message:

Client call: stat()

Message(s): \_IO\_CONNECT\_COMBINE\_CLOSE, \_IO\_STAT

Callouts: io open

io\_lock\_ocb
io\_stat
io\_unlock\_ocb

io close

The \_IO\_CONNECT\_COMBINE\_CLOSE message causes the *io\_open* handler to be called. It then implicitly (at the end of processing for the combine message) causes the *io\_close\_ocb* handler to be called.

## **IO CONNECT COMBINE**

For the *access()* function, the client's C library will open a connection to the resource manager and perform a *stat()* call. Then, based on the results of the *stat()* call, the client's C library *access()* may perform an optional *devctl()* to get more information. In any event, because *access()* opened the device, it must also call *close()* to close it:

Client call: access()

Message(s): IO CONNECT COMBINE, IO STAT

IO DEVCTL (optional)

\_IO\_CLOSE

Callouts: io open

io\_lock\_ocb

io stat

io unlock ocb

io\_lock\_ocb (optional)
io devctl (optional)

io unlock ocb (optional)

io\_close

Notice how the *access()* function opened the pathname/device — it sent it an \_IO\_CONNECT\_COMBINE message along with the \_IO\_STAT message. This creates an OCB (when the *io\_open* handler is called), locks the associated attribute structure (via *io\_lock\_ocb*), performs the stat (*io\_stat*), and then unlocks the attributes structure (*io\_unlock\_ocb*). Note that we don't implicitly close the OCB — this is left for a later, explicit, message. Contrast this handling with that of the plain *stat()* above.

# Chapter 7

# **Extending the POSIX-Layer Data Structures**

# In this chapter...


Overview 91
Extending the OCB and attribute structures 91
Extending the mount structure 93

### **Overview**

The *iofunc\_\*()* default functions operate on the assumption that you've used the default definitions for the context block and the attributes structures. This is a safe assumption for two reasons:

- 1 The default context and attribute structures contain sufficient information for most applications.
- 2 If the default structures don't hold enough information, you can encapsulate them within the structures that you've defined.

The default structures must be the first members of their respective superstructures, so that the *iofunc* \*() default functions can access them:



Encapsulating the POSIX-layer data structures.

## **Extending the OCB and attribute structures**

In our /dev/sample example, we had a static buffer associated with the entire resource. Sometimes you may want to keep a pointer to a buffer associated with the resource, rather than in a global area. To maintain the pointer with the resource, we would have to store it in the iofunc\_attr\_t attribute structure. Since the attribute structure doesn't have any spare fields, we would have to extend it to contain that pointer.

Sometimes you may want to add extra entries to the standard *iofunc\_\*()* OCB (iofunc\_ocb\_t).

Let's see how we can extend both of these structures. The basic strategy used is to encapsulate the existing attributes and OCB structures within a newly defined superstructure that also contains our extensions. Here's the code (see the text following the listing for comments):

```
struct ocb
                            *next;
    struct ocb
                            **prev;
                                            /* see note 3 */
struct device {
                                            /* see note 2 */
                                            /* must always be first */
    iofunc_attr_t
                            attr;
    struct ocb
                            *list;
                                            /* waiting for write */
/* Prototypes, needed since we refer to them a few lines down */
struct ocb *ocb_calloc (resmgr_context_t *ctp, struct device *device);
void ocb_free (struct ocb *ocb);
iofunc_funcs_t ocb_funcs = { /* our ocb allocating & freeing functions */
    ocb_calloc,
    ocb_free
/* The mount structure. We have only one, so we statically declare it ^{\star}/
iofunc_mount_t
                       mountpoint = { 0, 0, 0, 0, &ocb_funcs };
/* One struct device per attached name (there's only one name in this
   example) */
struct device
                      deviceattr;
main()
     * deviceattr will indirectly contain the addresses
     * of the OCB allocating and freeing functions
    deviceattr.attr.mount = &mountpoint;
    resmgr_attach (..., &deviceattr);
}
 * ocb_calloc
 \boldsymbol{\ast} The purpose of this is to give us a place to allocate our own OCB.
 \mbox{\ensuremath{\star}} It is called as a result of the open being done
 * (e.g. iofunc open default causes it to be called). We
 * registered it through the mount structure.
IOFUNC OCB T
ocb_calloc (resmgr_context_t *ctp, IOFUNC_ATTR_T *device)
    struct ocb *ocb;
    if (!(ocb = calloc (1, sizeof (*ocb)))) {
        return 0;
    /* see note 3 */
    ocb -> prev = &device -> list;
    if (ocb -> next = device -> list) {
        device -> list -> prev = &ocb -> next;
    device -> list = ocb;
    return (ocb);
 * ocb_free
 * The purpose of this is to give us a place to free our OCB.
```

```
* It is called as a result of the close being done
* (e.g. iofunc_close_ocb_default causes it to be called). We
* registered it through the mount structure.
*/
void
ocb_free (IOFUNC_OCB_T *ocb)
{
    /* see note 3 */
    if (*ocb -> prev = ocb -> next) {
        ocb -> next -> prev = ocb -> prev;
    }
        free (ocb);
}
```

Here are the notes for the above code:

- We place the definitions for our enhanced structures *before* including the standard I/O functions header file. Because the standard I/O functions header file checks to see if the two manifest constants are already defined, this allows a convenient way for us to semantically override the structures.
- **2** Define our new enhanced data structures, being sure to place the encapsulated members first.
- The *ocb\_calloc()* and *ocb\_free()* sample functions shown here cause the newly allocated OCBs to be maintained in a linked list. Note the use of dual indirection on the struct ocb \*\*prev; member.
- 4 You **must always** place the **iofunc** structure that you're overriding as the first member of the new extended structure. This lets the common library work properly in the default cases.

## **Extending the mount structure**

You can also extend the iofunc\_mount\_t structure in the same manner as the attribute and OCB structures. In this case, you'd define:

# Chapter 8

## **Handling Other Messages**

## In this chapter...

Custom messages 97
Handling devctl() messages 98
Handling ionotify() and select() 103
Handling out-of-band (\_IO\_MSG) messages 113
Handling private messages and pulses 114
Handling open(), dup(), and close() messages 117
Handling mount() 118
Handling stat() 123
Handling lseek() 124

### **Custom messages**

Although most of the time your resource manager will handle messages from clients, there still could be times when you need to control the behavior of the resource manager itself. For example, if the resource manager is for a serial port, you'll likely need a way to change the baud rate, and so on.

There are various ways you could send control information to a resource manager:

- Stop the resource manager, and then restart it with new command-line options.
   This is an awkward method that leaves the device unavailable while the resource manager is restarting. It isn't a viable solution if the resource manager controls various devices and you need to set different options (at different times) for different devices.
- Accept write() messages that include control instructions. This lets you control the
  resource manager from the command line or a script; you can simply echo a
  command to a path that the resource manager has registered.
  - However, the *write()* messages might be broken into smaller messages, so your resource manager would have to be prepared to save the pieces, reassemble them, and then act on them. Your *io\_write* handler also has to parse the commands, in addition to handling *write()* messages from the clients.
- Send an IPC message, via *MsgSend()*, directly to the resource manager. This message would contain a data structure that includes the control instructions. This method is fast, simple, and flexible, but it isn't portable because *MsgSend()* isn't a POSIX function.
- Send control instructions via a *devctl()* command. Such messages won't conflict with any other messages sent to the resource manager, but this approach might not be portable because *devctl()* isn't a POSIX function (it was in a draft standard, but wasn't adopted). See "Handling *devctl()* messages," below.
- Set up a handler for "other" I/O messages when you call resmgr\_attach(). As described in "Initialize the resource manager attributes" in the Bones of a Resource Manager chapter, you have to set the RESMGR\_FLAG\_ATTACH\_OTHERFUNC bit in the flags member of the resmgr\_attr\_t structure, and set the other\_func member to point to the handler function. However, as we mentioned earlier, we don't recommend this approach.
- Use <code>message\_attach()</code> or <code>pulse\_attach()</code> to attach a specified message range or pulse code for the dispatch handle. When a message with a type in that range is received, the <code>dispatch\_block()</code> function calls the handler function that you specify. The message range must be outside the I/O range, and the messages or pulses aren't associated with an OCB. For more information, see "Handling private messages and pulses," later in this chapter.
- Use an out-of-band I/O message, \_IO\_MSG. This type of message *is* associated with an OCB, and is handled through the resource manager's framework. For more

information, see "Handling out-of-band (\_IO\_MSG) messages," later in this chapter.

### Handling devctl() messages

The *devctl()* function is a general-purpose mechanism for communicating with a resource manager. Clients can send data to, receive data from, or both send and receive data from a resource manager. The prototype of the client *devctl()* call is:

The following values (described in detail in the *devctl()* documentation in the QNX Neutrino *Library Reference*) map directly to the \_IO\_DEVCTL message itself:

```
struct io devctl {
       uint16 t
                                type;
       uint16 t
                               combine len;
       int32 t
                               dcmd;
       int32 t
                               nbytes;
       int32_t
                                zero;
       char
                                data[nbytes]; */
};
struct _io_devctl_reply {
       uint32_t
                               zero;
                              ret_val;
       int32 t
                              nbytes;
       int32 t
       int32 t
                               zero2;
                               data[nbytes]; */
       char
   } ;
typedef union {
      struct _io_devctl
                                i;
       struct _io_devctl_reply
} io devctl t;
```

As with most resource manager messages, we've defined a union that contains the input structure (coming into the resource manager), and a reply or output structure (going back to the client). The *io\_devctl* resource manager handler is prototyped with the argument:

```
io_devctl_t *msg
```

which is the pointer to the union containing the message.

The *type* member has the value IO DEVCTL.

The *combine\_len* field has meaning for a combine message; see the Combine Messages chapter.

The *nbytes* value is the *nbytes* that's passed to the *devctl()* function. The value contains the size of the data to be sent to the device driver, or the maximum size of the data to be received from the device driver.

The most interesting item of the input structure is the *dcmd* argument that's passed to the *devctl()* function. This command is formed using the macros defined in <devctl.h>:

```
#define POSIX_DEVDIR_NONE 0
#define POSIX_DEVDIR_TO 0x80000000
#define POSIX_DEVDIR_FROM 0x40000000
#define DIOF(class, cmd, data) ((sizeof(data)<<16) + ((class)<<8) + (cmd) + _POSIX_DEVDIR_FROM)
#define DIOT(class, cmd, data) ((sizeof(data)<<16) + ((class)<<8) + (cmd) + _POSIX_DEVDIR_TROM)
#define DIOT(class, cmd, data) ((sizeof(data)<<16) + ((class)<<8) + (cmd) + _POSIX_DEVDIR_TO)
#define DION(class, cmd) (((class)<<8) + (cmd) + _POSIX_DEVDIR_TOFROM)
```

It's important to understand how these macros pack data to create a command. An 8-bit class (defined in <devctl.h>) is combined with an 8-bit subtype that's manager-specific, and put together in the lower 16 bits of the integer.

The upper 16 bits contain the direction (TO, FROM) as well as a hint about the size of the data structure being passed. This size is only a hint put in to uniquely identify messages that may use the same class and code but pass different data structures.

In the following example, a command is generated to indicate that the client is sending data to the server (TO), but not receiving anything in return. The only bits that the library or the resource manager layer look at are the TO and FROM bits to determine which arguments are to be passed to MsgSend().

```
struct _my_devctl_msg {
    ...
}
#define MYDCMD __DIOT(_DCMD_MISC, 0x54, struct _my_devctl_msg)
```



The size of the structure that's passed as the last field to the  $\_DIO^*$  macros **must** be less than  $2^{14} == 16$  KB. Anything larger than this interferes with the upper two directional bits.

The data directly follows this message structure, as indicated by the /\* char data[nbytes] \*/ comment in the \_io\_devctl structure.

#### Sample code for handling \_IO\_DEVCTL messages

You can add the following code samples to either of the "/dev/null" examples provided in the "Simple device resource manager examples" section of the Bones of a Resource Manager chapter. Both of those code samples provided the name /dev/sample. With the changes indicated below, the client can use devctl() to set and retrieve a global value (an integer in this case) that's maintained in the resource manager.

The first addition defines what the *devctl()* commands are going to be. This is generally put in a common or shared header file:

```
#define MY_CMD_CODE 1
#define MY_DEVCTL_GETVAL __DIOF(_DCMD_MISC, MY_CMD_CODE + 0, int)
#define MY_DEVCTL_SETVAL __DIOT(_DCMD_MISC, MY_CMD_CODE + 1, int)
#define MY_DEVCTL_SETGET __DIOTF(_DCMD_MISC, MY_CMD_CODE + 2, union _my_devctl_msg)
```

In the above code, we defined three commands that the client can use:

```
MY DEVCTL SETVAL
```

Sets the server's global variable to the integer the client provides.

```
MY_DEVCTL_GETVAL
```

Gets the value of the server's global variable and puts it into the client's buffer.

```
MY_DEVCTL_SETGET
```

Sets the server's global variable to the integer that the client provides, and then returns the previous value of the server's global variable in the client's buffer.

Add this code to the *main()* function:

```
/* For handling _IO_DEVCTL, sent by devctl() */
io_funcs.devctl = io_devctl;
```

And the following code gets added before the *main()* function:

Now, you need to include the new handler function to handle the \_IO\_DEVCTL message (see the text following the listing for additional notes):

```
int io_devctl(resmgr_context_t *ctp, io_devctl_t *msg,
             RESMGR OCB T *ocb) {
           nbytes, status, previous;
   union { /* See note 1 */
       data_t data;
              data32;
       /* ... other devctl types you can receive */
   } *rx_data;
    Let common code handle DCMD ALL * cases.
    You can do this before or after you intercept devctls, depending
    on your intentions. Here we aren't using any predefined values,
    so let the system ones be handled first. See note 2.
   if ((status = iofunc devctl default(ctp, msg, ocb)) !=
        _RESMGR_DEFAULT) {
       return(status);
    }
    status = nbytes = 0;
    Note this assumes that you can fit the entire data portion of
```

```
the devctl into one message. In reality you should probably
perform a MsgReadv() once you know the type of message you
have received to get all of the data, rather than assume
it all fits in the message. We have set in our main routine
that we'll accept a total message size of up to 2 KB, so we
don't worry about it in this example where we deal with ints.
/* Get the data from the message. See Note 3. */
rx_data = _DEVCTL_DATA(msg->i);
Three examples of devctl operations:
SET: Set a value (int) in the server
GET: Get a value (int) from the server
SETGET: Set a new value and return the previous value
switch (msg->i.dcmd) {
case MY DEVCTL SETVAL:
   global_integer = rx_data->data32;
   nbytes = 0;
   break;
case MY DEVCTL GETVAL:
   rx data->data32 = global integer; /* See note 4 */
    nbytes = sizeof(rx_data->data32);
   break:
case MY DEVCTL SETGET:
    previous = global integer;
    global integer = rx data->data.tx;
    /* See note 4. The rx data overwrites the tx data
      for this command. */
    rx_data->data.rx = previous;
   nbytes = sizeof(rx data->data.rx);
   break;
default:
   return(ENOSYS);
/* Clear the return message. Note that we saved our data past
   this location in the message. */
memset(&msg->o, 0, sizeof(msg->o));
If you wanted to pass something different to the return
field of the devctl() you could do it through this member.
See note 5.
*/
msg->o.ret_val = status;
/* Indicate the number of bytes and return the message */
msg->o.nbytes = nbytes;
return(_RESMGR_PTR(ctp, &msg->o, sizeof(msg->o) + nbytes));
```

Here are the notes for the above code:

We define a union for all the possible types of received data. The MY\_DEVCTL\_SETVAL and MY\_DEVCTL\_GETVAL commands use the *data32* 

- member, and the MY\_DEVCTL\_SETGET uses the *data* member, of type data\_t, which is a union of the received and transmitted data.
- The default *devctl()* handler is called before we begin to service our messages. This allows normal system messages to be processed. If the message isn't handled by the default handler, then it returns \_RESMGR\_DEFAULT to indicate that the message might be a custom message. This means that we should check the incoming command against commands that our resource manager understands.
- The data to be passed follows directly after the io\_devctl\_t structure. You can get a pointer to this location by using the \_DEVCTL\_DATA (msg->i) macro defined in <devctl.h>. The argument to this macro must be the input message structure if it's the union message structure or a pointer to the input message structure, the pointer won't point to the right location.
  - For your convenience, we've defined a union of all of the messages that this server can receive. However, this won't work with large data messages. In this case, you'd use  $resmgr\_msgread()$  to read the message from the client. Our messages are never larger than <code>sizeof(int)</code> and this comfortably fits into the minimum receive buffer size.
- The data being returned to the client is placed at the end of the reply message. This is the same mechanism used for the input data, so we can use the \_\_DEVCTL\_DATA() function to get a pointer to this location. With large replies that wouldn't necessarily fit into the server's receive buffer, you should use one of the reply mechanisms described in the "Methods of returning and replying" section in the Handling Read and Write Messages chapter. Again, in this example, we're only returning an integer that fits into the receive buffer without any problem.
- The last argument to the *devctl()* function is a pointer to an integer. If this pointer is provided, then the integer is filled with the value stored in the msg->o.ret\_val reply message. This is a convenient way for a resource manager to return simple status information without affecting the core *devctl()* operation. It's not used in this example.

If you add the following handler code, a client should be able to open /dev/sample and subsequently set and retrieve the global integer value:

```
int main(int argc, char **argv) {
   int      fd, ret, val;
   data_t data;

if ((fd = open("/dev/sample", O_RDONLY)) == -1) {
      return(1);
   }

/* Find out what the value is set to initially */
   val = -1;
   ret = devctl(fd, MY_DEVCTL_GETVAL, &val, sizeof(val), NULL);
   printf("GET returned %d w/ server value %d \n", ret, val);
```

```
/* Set the value to something else */
   val = 25;
   ret = devctl(fd, MY DEVCTL SETVAL, &val, sizeof(val), NULL);
   printf("SET returned %d \n", ret);
   /* Verify we actually did set the value */
   ret = devctl(fd, MY DEVCTL GETVAL, &val, sizeof(val), NULL);
   printf("GET returned %d w/ server value %d == 25? \n", ret, val);
   /* Now do a set/get combination */
   memset(&data, 0, sizeof(data));
   data.tx = 50;
   ret = devctl(fd, MY DEVCTL SETGET, &data, sizeof(data), NULL);
   printf("SETGET returned with %d w/ server value %d == 25?\n",
          ret, data.rx);
    /* Check set/get worked */
   val = -1;
   ret = devctl(fd, MY DEVCTL GETVAL, &val, sizeof(val), NULL);
   printf("GET returned %d w/ server value %d == 50? \n", ret, val);
   return(0);
}
```

## Handling ionotify() and select()

A client uses *ionotify()* and *select()* to ask a resource manager about the status of certain conditions (e.g. whether input data is available). The conditions may or may not have been met. The resource manager can be asked to:

- check the status of the conditions immediately, and return if any have been met
- deliver an event later on when a condition is met (this is referred to as arming the resource manager)

The *select()* function differs from *ionotify()* in that most of the work is done in the library. For example, the client code would be unaware that any event is involved, nor would it be aware of the blocking function that waits for the event. This is all hidden in the library code for *select()*.

However, from a resource manager's point of view, there's no difference between *ionotify()* and *select()*; they're handled with the same code.

For more information on the *ionotify()* and *select()* functions, see the QNX Neutrino *Library Reference*.



If multiple threads in the same client perform simultaneous operations with *select()* and *ionotify()*, notification races may occur.

Since *ionotify()* and *select()* require the resource manager to do the same work, they both send the \_IO\_NOTIFY message to the resource manager. The *io\_notify* handler is

responsible for handling this message. Let's start by looking at the format of the message itself:

```
struct io notify {
   uint16 t
                              type;
   uint16_t
                              combine_len;
   int32 t
                              action;
   int32 t
                              flags;
   struct sigevent
                              event;
};
struct _io_notify_reply {
   uint32 t
                              flags;
typedef union {
   struct _io_notify
   struct io notify reply
} io_notify_t;
```



The code samples used in this chapter are not always POSIX-compliant.

As with all resource manager messages, we've defined a union that contains the input structure (coming into the resource manager), and a reply or output structure (going back to the client). The *io notify* handler is prototyped with the argument:

```
io_notify_t *msg
```

which is the pointer to the union containing the message. The items in the input structure are:

- type
- combine len
- action
- flags
- event

The *type* member has the value \_IO\_NOTIFY.

The *combine\_len* field has meaning for a combine message; see the Combine Messages chapter.

The *action* member is used by the *iofunc\_notify()* helper function to tell it whether it should:

- just check for conditions now
- check for conditions now, and if none are met, arm them
- just arm for transitions

Since *iofunc\_notify()* looks at this, you don't have to worry about it.

The *flags* member contains the conditions that the client is interested in and can be any mixture of the following:

#### NOTIFY COND INPUT

This condition is met when there are one or more units of input data available (i.e. clients can now issue reads). The number of units defaults to 1, but you can change it. The definition of a unit is up to you: for a character device such as a serial port, it would be a character; for a POSIX message queue, it would be a message. Each resource manager selects an appropriate object.

#### NOTIFY COND OUTPUT

This condition is met when there's room in the output buffer for one or more units of data (i.e. clients can now issue writes). The number of units defaults to 1, but you can change it. The definition of a unit is up to you — some resource managers may default to an empty output buffer while others may choose some percentage of the buffer empty.

#### NOTIFY COND OBAND

The condition is met when one or more units of out-of-band data are available. The number of units defaults to 1, but you can change it. The definition of out-of-band data is specific to the resource manager.

#### NOTIFY COND EXTEN

The conditions are defined with the following extended flags:

- \_NOTIFY\_CONDE\_RDNORM normal data is available; this is the same as NOTIFY\_COND\_INPUT.
- \_NOTIFY\_CONDE\_WRNORM room for normal data; this is the same as NOTIFY\_COND\_OUTPUT.
- \_NOTIFY\_CONDE\_RDBAND out-of-band data is available; this is the same as NOTIFY COND OBAND.
- NOTIFY CONDE PRI priority data is available.
- NOTIFY CONDE WRBAND room for OOB data.
- NOTIFY CONDE ERR an error occurred on the device or stream.
- NOTIFY CONDE HUP the device has been disconnected.
- \_NOTIFY\_CONDE\_NVAL the file descriptor is invalid.

The *event* member is what the resource manager delivers once a condition is met.

A resource manager needs to keep a list of clients that want to be notified as conditions are met, along with the events to use to do the notifying. When a condition is met, the resource manager must traverse the list to look for clients that are interested in that condition, and then deliver the appropriate event. As well, if a client closes its file descriptor, then any notification entries for that client must be removed from the list.

To make all this easier, the following structure and helper functions are provided for you to use in a resource manager:

#### iofunc notify tstructure

Contains the three notification lists, one for each possible condition. Each is a list of the clients to be notified for that condition.

iofunc\_notify()

Adds or removes notification entries; also polls for conditions. Call this function inside your *io notify* handler function.

iofunc notify trigger()

Sends notifications to queued clients. Call this function when one or more conditions have been met.

iofunc\_notify\_remove()

Removes notification entries from the list. Call this function when the client closes its file descriptor.



Don't return \_RESMGR\_NOREPLY from an *io\_notify* handler, as it may be called multiple times from a single message if handling multiple file descriptors from a client call to *select()* or *poll()*. This is handled for you if you're using *iofunc\_notify()*.

#### Sample code for handling IO NOTIFY messages

You can add the following code samples to either of the examples provided in the "Simple device resource manager examples" section of the Bones of a Resource Manager chapter. Both of those code samples provided the name <code>/dev/sample</code>. With the changes indicated below, clients can use writes to send it data, which it'll store as discrete messages. Other clients can use either <code>ionotify()</code> or <code>select()</code> to request notification when that data arrives. When clients receive notification, they can issue reads to get the data.

You'll need to replace this code that's located above the *main()* function:

```
#include <sys/iofunc.h>
#include <sys/dispatch.h>

static resmgr_connect_funcs_t connect_funcs;
static resmgr_io_funcs_t io_funcs;
static iofunc_attr_t attr;

with the following:

struct device_attr_s;
#define IOFUNC_ATTR_T struct device_attr_s

#include <sys/iofunc.h>
#include <sys/dispatch.h>
```

```
/*
* Define a structure and variables for storing the data that
* is received. When clients write data to us, we store it here.
* When clients do reads, we get the data from here. Result: a
* simple message queue.
typedef struct item s {
   struct item_s *next;
   char
                 *data;
} item t;
/* the extended attributes structure */
typedef struct device attr s {
   iofunc_attr_t attr;
   iofunc_notify_t notify[3]; /* notification list used by
                               iofunc notify*() */
   } device_attr_t;
/* We only have one device; device attr is its attribute structure */
static device attr t device attr;
int io_read( resmgr_context_t *ctp, io_read_t *msg,
           RESMGR OCB T *ocb);
int io write( resmgr context t *ctp, io write t *msg,
            RESMGR OCB T *ocb);
int io_notify( resmgr_context_t *ctp, io_notify_t *msg,
            RESMGR OCB T *ocb);
int io close ocb( resmgr context t *ctp, void *reserved,
                RESMGR_OCB_T *ocb);
static resmgr connect funcs t connect funcs;
static resmgr_io_funcs_t
                            io funcs;
```

We need a place to keep data that's specific to our device. A good place for this is in an attribute structure that we can associate with the name we registered:

/dev/sample. So, in the code above, we defined device\_attr\_t and IOFUNC\_ATTR\_T for this purpose. We talk more about this type of device-specific attribute structure in the Extending the POSIX-Layer Data Structures chapter.

We need two types of device-specific data:

- an array of three notification lists one for each possible condition that a client can ask to be notified about. In device\_attr\_t, we called this *notify*.
- a queue to keep the data that gets written to us, and that we use to reply to a client. For this, we defined item\_t; it's a type that contains data for a single item, as well as a pointer to the next item\_t. In device\_attr\_t we use firstitem (points to the first item in the queue), and nitems (number of items).

Note that we removed the definition of attr, since we use device attr instead.

Of course, we have to give the resource manager library the address of our handlers so that it'll know to call them. In the code for *main()* where we called *iofunc\_func\_init()*, we'll add the following code to register our handlers:

```
/* initialize functions for handling messages */
```

```
RESMGR IO NFUNCS, &io funcs);
/* For handling _IO_NOTIFY, sent as a result of client
   calls to ionotify() and select() */
io funcs.notify = io notify;
io_funcs.write = io_write;
io funcs.read = io read;
io_funcs.close_ocb = io_close_ocb;
And, since we're using device attr in place of attr, we need to change the code
wherever we use it in main(). So, you'll need to replace this code:
/* initialize attribute structure used by the device */
iofunc_attr_init(&attr, S_IFNAM | 0666, 0, 0);
/* attach our device name */
                              /* dispatch handle
id = resmgr attach(dpp,
                    &resmgr_attr, /* resource manager attrs */
"/dev/sample", /* device name */
                    _FTYPE_ANY, /* open type 0, /* flags
                    &connect_funcs, /* connect routines
                    &io_funcs, /* I/O routines
&attr); /* handle
with the following:
/* initialize attribute structure used by the device */
iofunc attr init(&device attr.attr, S IFNAM | 0666, 0, 0);
IOFUNC_NOTIFY_INIT(device_attr.notify);
device attr.firstitem = NULL;
device attr.nitems = 0;
/* attach our device name */
                   id = resmgr attach(dpp,
                   _FTYPE_ANY, /* open type
0, /* flags
&connect_funcs, /* connect routines
&io_funcs, /* I/O routines
&device_attr); /* handle
```

iofunc func init( RESMGR CONNECT NFUNCS, &connect funcs,

Note that we set up our device-specific data in *device\_attr*. And, in the call to  $resmgr\_attach()$ , we passed &device\_attr (instead of &attr) for the handle parameter.

Now, you need to include the new handler function to handle the \_IO\_NOTIFY message:

As stated above, our *io\_notify* handler will be called when a client calls *ionotify()* or *select()*. In our handler, we're expected to remember who those clients are, and what conditions they want to be notified about. We should also be able to respond immediately with conditions that are already true. The *iofunc\_notify()* helper function makes this easy.

The first thing we do is to figure out which of the conditions we handle have currently been met. In this example, we're always able to accept writes, so in the code above we set the \_NOTIFY\_COND\_OUTPUT bit in trig. We also check nitems to see if we have data and set the NOTIFY\_COND\_INPUT if we do.

We then call <code>iofunc\_notify()</code>, passing it the message that was received (<code>msg</code>), the notification lists (<code>notify()</code>), and which conditions have been met (<code>trig()</code>). If one of the conditions that the client is asking about has been met, and the client wants us to poll for the condition before arming, then <code>iofunc\_notify()</code> will return with a value that indicates what condition has been met and the condition will not be armed. Otherwise, the condition will be armed. In either case, we'll return from the handler with the return value from <code>iofunc\_notify()</code>.

Earlier, when we talked about the three possible conditions, we mentioned that if you specify \_NOTIFY\_COND\_INPUT, the client is notified when there's one or more units of input data available and that the number of units is up to you. We said a similar thing about \_NOTIFY\_COND\_OUTPUT and \_NOTIFY\_COND\_OBAND. In the code above, we let the number of units for all these default to 1. If you want to use something different, then you must declare an array such as:

```
int notifycounts[3] = \{10, 2, 1\};
```

This sets the units for: \_NOTIFY\_COND\_INPUT to 10; \_NOTIFY\_COND\_OUTPUT to 2; and \_NOTIFY\_COND\_OBAND to 1. We would pass *notifycounts* to *iofunc\_notify()* as the second to last parameter.

Then, as data arrives, we notify whichever clients have asked for notification. In this sample, data arrives through clients sending us \_IO\_WRITE messages and we handle it using an *io write* handler.

```
int
io write(resmgr context t *ctp, io write t *msg,
```

```
RESMGR_OCB_T *ocb)
{
   device_attr_t *dattr = (device_attr_t *) ocb->attr;
   char
                    *p;
   int
                   status:
   char
                   *buf;
                   *newitem;
   if ((status = iofunc_write_verify(ctp, msg, ocb, NULL))
        ! = EOK)
        return (status);
   if ((msg->i.xtype & _IO_XTYPE_MASK) != _IO_XTYPE_NONE)
       return (ENOSYS);
   if (msg->i.nbytes > 0) {
        /* Get and store the data */
        if ((newitem = malloc(sizeof(item t))) == NULL)
            return (errno);
        if ((newitem->data = malloc(msg->i.nbytes+1)) ==
           NULL) {
           free (newitem);
           return (errno);
        /* reread the data from the sender's message buffer */
        resmgr_msgread(ctp, newitem->data, msg->i.nbytes,
                      sizeof(msg->i));
       newitem->data[msg->i.nbytes] = NULL;
        if (dattr->firstitem)
           newitem->next = dattr->firstitem;
           newitem->next = NULL;
        dattr->firstitem = newitem;
       dattr->nitems++;
        * notify clients who may have asked to be notified
         * when there is data
        if (IOFUNC NOTIFY INPUT CHECK(dattr->notify,
            dattr->nitems, 0))
            iofunc_notify_trigger(dattr->notify, dattr->nitems,
                                  IOFUNC NOTIFY INPUT);
   }
    /* set up the number of bytes (returned by client's
   _IO_SET_WRITE_NBYTES(ctp, msg->i.nbytes);
   if (msg->i.nbytes > 0)
       ocb->attr->attr.flags |= IOFUNC_ATTR_MTIME
                                 IOFUNC_ATTR_CTIME;
   return (_RESMGR_NPARTS(0));
```

The important part of the above *io\_write* handler is the code within the following section:

```
if (msg->i.nbytes > 0) {
     ....
}
```

Here we first allocate space for the incoming data, and then use  $resmgr\_msgread()$  to copy the data from the client's send buffer into the allocated space. Then, we add the data to our queue.

Next, we pass the number of input units that are available to <code>IOFUNC\_NOTIFY\_INPUT\_CHECK()</code> to see if there are enough units to notify clients about. This is checked against the <code>notifycounts</code> that we mentioned above when talking about the <code>io\_notify</code> handler. If there are enough units available then we call <code>iofunc\_notify\_trigger()</code> telling it that <code>nitems</code> of data are available (IOFUNC\_NOTIFY\_INPUT means input is available). The <code>iofunc\_notify\_trigger()</code> function checks the lists of clients asking for notification (<code>notify</code>) and notifies any that asked about data being available.

Any client that gets notified will then perform a read to get the data. In our sample, we handle this with the following *io read* handler:

```
int
io read(resmgr context t *ctp, io read t *msg, RESMGR OCB T *ocb)
   device attr t  *dattr = (device attr t *) ocb->attr;
                   status;
   if ((status = iofunc read verify(ctp, msg, ocb, NULL)) != EOK)
       return (status);
   if ((msg->i.xtype & _IO_XTYPE_MASK) != _IO_XTYPE_NONE)
       return (ENOSYS);
   if (dattr->firstitem) {
        int nbytes;
        item t *item, *prev;
        /* get last item */
       item = dattr->firstitem;
       prev = NULL;
       while (item->next != NULL) {
           prev = item;
            item = item->next;
        }
         * figure out number of bytes to give, write the data to the
         * client's reply buffer, even if we have more bytes than they
         * are asking for, we remove the item from our list
       nbytes = min (strlen (item->data), msg->i.nbytes);
        /* set up the number of bytes (returned by client's read()) */
        IO SET READ NBYTES (ctp, nbytes);
         * write the bytes to the client's reply buffer now since we
```

```
* are about to free the data
        resmgr_msgwrite (ctp, item->data, nbytes, 0);
        /* remove the data from the queue */
        if (prev)
           prev->next = item->next;
            dattr->firstitem = NULL;
        free(item->data);
        free(item);
        dattr->nitems--;
    } else {
        /* the read() will return with 0 bytes */
        _IO_SET_READ_NBYTES (ctp, 0);
    /* mark the access time as invalid (we just accessed it) */
    if (msg->i.nbytes > 0)
        ocb->attr->attr.flags |= IOFUNC ATTR ATIME;
   return (EOK);
}
```

The important part of the above *io read* handler is the code within this section:

```
if (firstitem) {
    ....
}
```

We first walk through the queue looking for the oldest item. Then we use  $resmgr\_msgwrite()$  to write the data to the client's reply buffer. We do this now because the next step is to free the memory that we're using to store that data. We also remove the item from our queue.

Lastly, if a client closes its file descriptor, we must remove the client from our list. This is done using a *io close ocb* handler:

In the *io\_close\_ocb* handler, we called *iofunc\_notify\_remove()* and passed it *ctp* (contains the information that identifies the client) and *notify* (contains the list of clients) to remove the client from the lists.

### Handling out-of-band (\_IO\_MSG) messages

An \_IO\_MSG message lets a client send an "out-of-band" or control message to a resource manager, by way of a file descriptor. This interface is more general than an *ioctl()* or *devctl()*, but less portable.

The format of the message is specific to the resource manager, aside from the header, which we'll look at shortly. The client program sets up the message and uses *MsgSend()* to send it to the resource manager. The resource manager must set up an *io msg* handler in order to receive the message; there isn't a default handler.

The message header is defined in <sys/iomsg.h> and looks like this:

```
struct _io_msg {
    _Uint16t          type;
    _Uint16t          combine_len;
    _Uint16t          mgrid;
    _Uint16t          subtype;
};
```

The fields include:

```
type __IO_MSG

combine len Set this to sizeof (struct io msg).
```

mgrid

A unique ID for your resource manager. The <sys/iomgr.h>
header file defines some IDs that are reserved for various QNX
resource managers. If you're sure that your resource manager will
never get an \_IO\_MSG message that isn't intended for it (for
example, the resource manager will only run in an embedded
system), you can use an ID in the range from
\_IOMGR\_PRIVATE\_BASE through \_IOMGR\_PRIVATE\_MAX. If
your resource manager will be used in a more open system, contact

your resource manager will be used in a more open system, contact QNX Software Systems and reserve a manager ID or range of IDs.

subtype

Use this field to distinguish different types of \_IO\_MSG messages that you want your resource manager to handle.

Any data should follow this header. For example:

```
typedef struct {
    struct _io_msg hdr;
    /* Add any required data fields here. */
} my_msg_t;
The client program would then do something like this:
#define MY_MGR_ID (_IOMGR_PRIVATE_BASE + 22)
my_msg_t msg, my_reply;
int fd, status;
```

```
fd = open ("/dev/sample", O RDWR);
msg.hdr.type = _IO_MSG;
msg.hdr.combine len = sizeof( msg.hdr );
msg.hdr.mgrid = MY MGR ID;
msq.hdr.subtype = 0;
/* Fill in the additional fields as required. */
status = MsgSend( fd, &msg, sizeof( msg ), &my reply,
                  sizeof (my reply));
The resource manager registers a function to handle the IO MSG messages:
/* Initialize the functions for handling messages */
iofunc func init( RESMGR CONNECT NFUNCS, &connect funcs,
                 RESMGR IO NFUNCS, &io funcs);
io funcs.msg = my io msg;
This handler processes the message as appropriate. For example:
int my_io_msg (resmgr_context_t *ctp, io_msg_t *msg,
              RESMGR OCB T *ocb)
{
    my_msg_t my_msg;
    MsgRead (ctp->rcvid, &my msg, sizeof (my msg), 0);
    if (my_msg.hdr.mgrid != MY_MGR_ID)
        return (ENOSYS);
    /* Process the data as required. */
    /* Reply if necessary and tell the library that we've
       already replied. */
    MsgReply( ctp->rcvid, 0, &my_reply, sizeof(my_reply));
    return (_RESMGR_NOREPLY);
}
```

Note that the handler returns ENOSYS if the *mgrid* member of the header isn't the correct manager ID. This handler replies to the client, and then returns \_RESMGR\_NOREPLY to tell the library that there's no need for it to do the reply.

#### Handling private messages and pulses

A resource manager may need to receive and handle pulses, perhaps because an interrupt handler has returned a pulse or some other thread or process has sent a pulse.

The main issue with pulses is that they have to be received as a *message*. This means that a thread has to explicitly perform a *MsgReceive()* in order to get the pulse. But unless this pulse is sent to a different channel than the one that the resource manager is using for its main messaging interface, it will be received *by the library*. Therefore, we need to see how a resource manager can associate a pulse code with a handler routine and communicate that information to the library.

You can use the *pulse\_attach()* function to associate a pulse code with a handler function. When the dispatch layer receives a pulse, it will look up the pulse code and see which associated handler to call to handle the pulse message.

You may also want to define your own private message range to communicate with your resource manager. Note that the range 0x0 to 0x1FF is reserved for the OS. To attach a range, you use the *message\_attach()* function.

In this example, we create the same resource manager, but this time we also attach to a private message range and attach a pulse, which is then used as a timer event:

```
#include <stdio.h>
#include <stddef.h>
#include <stdlib.h>
#define THREAD POOL PARAM T
                              dispatch context t
#include <sys/iofunc.h>
#include <sys/dispatch.h>
static resmgr_connect_funcs_t connect_func;
static resmgr_io_funcs_t io_fustatic resmgr_io_funcs_t attr;
                               io func;
timer tick( message context t *ctp, int code, unsigned flags,
           void *handle)
                      value = ctp->msg->pulse.value;
    union sigval
    * Do some useful work on every timer firing
    printf("received timer event, value %d\n", value.sival int);
    return 0;
}
message handler (message context t *ctp, int code, unsigned flags,
                void *handle)
    printf("received private message, type %d\n", code);
    return 0;
}
int
main(int argc, char **argv) {
   thread_pool_attr_t pool_attr;
   resmgr_attr_t resmgr_attr;
struct sigevent event;
                        itime;
   struct itimer
   dispatch t
                         *dpp;
   thread_pool_t
                         *tpp;
   resmgr_context_t
                         *ctp;
    int
                          timer id;
    if((dpp = dispatch_create()) == NULL) {
        fprintf(stderr,
                "%s: Unable to allocate dispatch handle.\n",
                argv[0]);
```

```
return EXIT FAILURE;
}
memset(&pool_attr, 0, sizeof pool_attr);
pool attr.handle = dpp;
/* We are doing resmgr and pulse-type attaches.
 * If you're going to use custom messages or pulses with
 * the message_attach() or pulse_attach() functions,
 * then you MUST use the dispatch functions
   (i.e. dispatch_block(), dispatch_handler(), ...),
 * NOT the resmgr functions (resmgr block(), resmgr handler()).
pool_attr.context_alloc = dispatch_context_alloc;
pool_attr.block_func = dispatch_block;
pool attr.unblock func = dispatch unblock;
pool attr.handler func = dispatch handler;
pool attr.context free = dispatch context free;
pool_attr.lo_water = 2;
pool_attr.hi_water = 4;
pool attr.increment = 1;
pool attr.maximum = 50;
if((tpp = thread_pool_create(&pool_attr, POOL_FLAG EXIT SELF)) == NULL) {
    fprintf(stderr, "%s: Unable to initialize thread pool.\n",argv[0]);
    return EXIT_FAILURE;
}
iofunc_func_init(_RESMGR_CONNECT_NFUNCS, &connect_func, RESMGR IO NFUNCS,
                 &io func);
iofunc_attr_init(&attr, S_IFNAM | 0666, 0, 0);
memset(&resmgr attr, 0, sizeof resmgr attr);
resmgr attr.nparts max = 1;
resmgr_attr.msg_max_size = 2048;
if((id = resmgr_attach(dpp, &resmgr_attr, "/dev/sample", _FTYPE_ANY, 0,
             &connect func, &io func, &attr)) == -1) {
    fprintf(stderr, "%s: Unable to attach name.\n", argv[0]);
    return EXIT FAILURE;
}
/* We want to handle our own private messages, of type 0x5000 to 0x5fff */
if(message attach(dpp, NULL, 0x5000, 0x5fff, &message handler, NULL) == -1) {
    fprintf(stderr, "Unable to attach to private message range.\n");
     return EXIT_FAILURE;
}
/* Initialize an event structure, and attach a pulse to it */
if((event.sigev_code = pulse_attach(dpp, MSG_FLAG_ALLOC_PULSE, 0, &timer tick,
                                    NULL)) == -1) {
    fprintf(stderr, "Unable to attach timer pulse.\n");
     return EXIT FAILURE;
}
/* Connect to our channel */
if((event.sigev_coid = message_connect(dpp, MSG_FLAG_SIDE_CHANNEL)) == -1) {
    fprintf(stderr, "Unable to attach to channel.\n");
    return EXIT FAILURE;
}
event.sigev_notify = SIGEV_PULSE;
event.sigev_priority = -1;
```

```
/* We could create several timers and use different sigev values for each */
event.sigev_value.sival_int = 0;

if((timer_id = TimerCreate(CLOCK_REALTIME, &event)) == -1) {;
    fprintf(stderr, "Unable to attach channel and connection.\n");
    return EXIT_FAILURE;
}

/* And now set up our timer to fire every second */
itime.nsec = 1000000000;
itime.interval_nsec = 1000000000;
TimerSettime(timer_id, 0, &itime, NULL);

/* Never returns */
thread_pool_start(tpp);
}
```

We can either define our own pulse code (e.g. #define OurPulseCode 57), or we can ask the *pulse\_attach()* function to dynamically generate one for us (and return the pulse code value as the return code from *pulse\_attach()*) by specifying the pulse code as RESMGR PULSE ALLOC.

See the *pulse\_attach()*, *MsgSendPulse()*, *MsgDeliverEvent()*, and *MsgReceive()* functions in the QNX Neutrino *Library Reference* for more information on receiving and generating pulses.

## Handling open(), dup(), and close() messages

The resource manager library provides another convenient service for us: it knows how to handle dup() messages.

Suppose that the client executed code that eventually ended up performing:

```
fd = open ("/dev/sample", O_RDONLY);
...
fd2 = dup (fd);
...
fd3 = dup (fd);
...
close (fd3);
...
close (fd2);
...
close (fd);
```

Our resource manager would get an \_IO\_CONNECT message for the first *open()*, followed by two \_IO\_DUP messages for the two *dup()* calls. Then, when the client executed the *close()* calls, we would get three \_IO\_CLOSE messages.

Since the *dup()* functions generate duplicates of the file descriptors, we don't want to allocate new OCBs for each one. And since we're not allocating new OCBs for each *dup()*, we don't want to *release* the memory in each \_IO\_CLOSE message when the \_IO\_CLOSE messages arrive! If we did that, the first close would wipe out the OCB.

The resource manager library knows how to manage this for us; it keeps count of the number of \_IO\_DUP and \_IO\_CLOSE messages sent by the client. Only on the *last* 

\_IO\_CLOSE message will the library synthesize a call to our \_IO\_CLOSE\_OCB handler.



Most users of the library will want to have the default functions manage the \_IO\_DUP and IO CLOSE messages; you'll most likely *never* override the default actions.

### Handling mount()

Mount requests can provide a very convenient and flexible interface for programs that need to enable and disable components of their resource managers' systems.

The main areas to consider when using and building mount functionality into your resource manager are:

- mount utility
- mount() function call
- *mount()* callout in the resource manager

These components represent the stream of communication for the mount request. Let's start in the middle with the *mount()* function call and work our way out.

The *mount()* function call is at the bottom of the utility and represents a client's access point to the resource manager. The function is implemented in the C library, defined in <sys/mount.h>, and described in the QNX Neutrino *Library Reference*.

#### mount() function call

The prototype for *mount()* is as follows:

The argument that we need to consider here is the *flags* field.

To support the mounting of non-existent special devices (such as NFS devices) or arbitrary strings (such as the name of shared object or DLL), we need to massage the arguments to this function slightly because the mount utility has two methods (-T and -t) for specifying the mount type.

In the general case where *special\_device* is an actual device, a typical mount command may look like:

```
% mount -t qnx4 /dev/hd0t77 /mnt/fs
```

In this case the *special\_device* is /dev/hd0t77, the *mount\_directory* is /mnt/fs, and the mount type is qnx4. In this case, the mount request should be directed only to the process responsible for managing the *special\_device*. That is to say the resource

manager that has provided the /dev/hd0t77 path into the pathname space. In this type of scenario, the resource manager is given an OCB for the <code>special\_device</code> (/dev/hd0t77), rather than the string /dev/hd0t77. This simplifies the processing in the resource manager since having the OCB, which is an internal data pointer, for the special device implies that the server doesn't have to recursively communicate with itself to get a handle for the device.

A less frequently used, but very useful case, is where the *special\_device* isn't an actual device. For example:

```
% mount -T io-pkt /lib/dll/devn-i82544.so
```

Note that the mountpoint is missing from the command line. In this case, NULL (or /) acts as an implied <code>mount\_directory</code>, which causes the process handling the request (i.e. the currently running variant of <code>io-pkt</code>) to take the appropriate action when it receives the mount request. The special\_device is /lib/dll/devn-i82544.so and the type is <code>io-pkt</code>.

In this case, you want to avoid having the special device interpreted as being provided by the same process that will handle the mount request. So while the file <code>/lib/dll/devn-i82544.so</code> is probably handled by some filesystem process, we're actually interested in mounting a network interface that's managed by the <code>io-pkt</code> process. Ideally, the mount callout will receive only the special device string <code>/lib/dll/devn-i82544.so</code>, and not the OCB for the device.

The behavioral difference between the -t and -T options for the mount utility can be obtained by ORing in \_MFLAG\_OCB to the standard *mount() flags* parameter. If you don't want to use the OCB method of performing the mount request, use -T, which we translate to \_MFLAG\_OCB.

Mount requests are connection requests, which means they operate on a path in the same way that the *open()* or *unlink()* calls do. The requests are sent along the path specified by *dir*. When a resource manager receives a request to mount something, the information is already provided in the same way that it would be for an *open()* for creation request, namely in the *msg->connect.path* variable.

For more information on the name-resolution process, see the example "Using *MsgSend()* and *MsgReply()*" in the Bones of a Resource Manager chapter in this guide.

#### Mount in the resource manager

Your resource manager will be called upon to perform a mount request via the *mount* function callout in the resmgr connect funcs t structure, defined as:

The only field here that differs from the other connect functions is the io mount extra t structure. It's defined in <sys/iomsg.h> as:

```
typedef struct io mount extra {
```

```
uint32_t flags; /* _MOUNT_? or ST_? flags above */
   uint32 t nbytes; /* Size of entire structure */
   uint32_t datalen; /* Length of the data structure following */
   uint32_t zero[1];
   union { /* If EXTRA MOUNT PATHNAME these set*/
        struct { /* Sent from client to resmgr framework */
            struct _msg_info info; /* Special info on first mount,
                                      path info on remount */
        } cl;
        struct { /* Server receives this structure filled in */
           void * ocb; /* OCB to the special device */
           void * data; /* Server specific data of len datalen */
           char * type; /* Character string with type information */
           char * special; /* Optional special device info */
           void * zero[4]; /* Padding */
        } srv;
   } extra;
} io mount extra t;
```

This structure is provided with all of the pointers already resolved, so you can use it without doing any extra fiddling.

The members are:

flags Flag fields provided to the mount command containing the common mount flags defined in <sys/mount.h>.

*nbytes* Size of the entire mount-extra message:

```
sizeof(_io_mount_extra) + datalen + strlen(type)
+ 1 + strlen(special) + 1
```

datalen Size of the data pointer.

*info* Used by the resource manager layer.

ocb OCB of the special device if it was requested via the \_MOUNT\_OCB flag. NULL otherwise.

data Pointer to the user data of length datalen.

Null-terminated string containing the mount type, such as **nfs**, **cifs**, or **qnx4**.

special Null-terminated string containing the special device if it was requested via the MOUNT SPEC flag. NULL otherwise.

In order to receive mount requests, the resource manager should register a NULL path with an FTYPE of FTYPE MOUNT and with the flags

\_RESMGR\_FLAG\_FTYPEONLY. This would be done with code that looks something like:

Again, we're attaching at the root of the filesystem so that we'll be able to receive the full path of the new mount requests in the *msg->connect* structure.

Adding the \_RESMGR\_FLAG\_FTYPEONLY flag ensures that this request is used only when there's an \_FTYPE\_MOUNT-style of connection. Once this is done, the resource manager is ready to start receiving mount requests from users.

An outline of a sample mount handler would look something like this:

```
int io mount( ... ) {
   Do any sanity checks that you need to do.
   Check type against our type with strcmp(), since
   there may be no name for REMOUNT/UNMOUNT flags.
   Error with ENOENT out if no match.
   If no name, check the validity of the REMOUNT/UNMOUNT request.
   Parse arguments or set up your data structure.
   Check to see if we are remounting ( MOUNT REMOUNT)
      Change flags, etc., if you can remount.
      Return EOK.
   Check to see if we are unmounting MOUNT UNMOUNT
      Change flags, etc., if you can unmount.
      Return EOK.
   Create a new node and attach it at the msg->connect.path
   point (unless some other path is implied based on the
   input variables and the resource manager) with resmgr_attach().
   Return EOK.
```

What's important to notice here is that each resource manager that registers a mount handler will potentially get a chance to examine the request to see if it can handle it. This means that you have to be rigorous in your type- and error-checking to make sure that the request is indeed destined for your manager. If your manager returns anything other than ENOSYS or ENOENT, it's assumed that the request was valid for this manager, but there was some other sort of error. Only errors of ENOSYS or ENOENT cause the request to "fall through" to other resource managers.

When you unmount, you would perform any cleanup and integrity checks that you need, and then call  $resmgr\_detach()$  with the ctp->id field. In general, you should support umounted calls only on the root of a mounted filesystem.

#### mount utility

By covering the *mount()* library function and the operation in the resource manager, we've pretty well covered the **mount** utility. The usage for the utility is shown here for reference:

```
mount [-wreuv] -t type [-o options] [special] mntpoint
mount [-wreuv] -T type [-o options] special [mntpoint]
mount
```

The options are:

- -t Indicates the special device, if it's present, is generally a real device and the same server will handle the mountpoint.
- -T Indicates the special device isn't a real device but rather a key for the server. The server will automatically create an appropriate mountpoint if *mntpoint* isn't specified.
- -v Increases the verbosity.
- -w Mount read/write.
- **-r** Mount read-only.
- -u Mount for update (remount).

However, if you're writing a mount handler, there may be occasions when you want to do custom parsing of arguments and provide your own data structure to your server. This is why the mount command will always first try and call out to a separate program named mount\_XXX, where XXX is the type that you specified with the -t option. To see just what would be called (in terms of options, etc.), you can use the -v option, which should provide you with the command line that would be <code>exec()</code> ed.

In order to help with the argument parsing, there's a utility function, <code>mount\_parse\_generic\_args()</code>, that you can call to process the common options. The function is defined in <code><sys/mount.h></code> as:

```
char *mount_parse_generic_args(char *options, int *flags);
```

This function parses the given *options*, removes any options that it recognizes, and sets or clears the appropriate bits in the *flags*. It returns a pointer to the modified version of *options* containing any options that it didn't recognize, or NULL if it recognized all the options. You use *mount\_parse\_generic\_args()* like this:

For more information about the stripped options and the corresponding flags, see the entry for *mount parse generic args()*, in the QNX Neutrino *Library Reference*.

## Handling stat()

Your resource manager will receive an \_IO\_STAT message when a client calls *stat()*, *lstat()*, or *fstat()*. You usually don't need to provide your own handler for this message. The prototype for the *io\_stat* handler is as follows:

The default handler for the \_IO\_STAT message, <code>iofunc\_stat\_default()</code>, calls <code>iofunc\_time\_update()</code> to ensure that the time entries in the <code>ocb->attr</code> structure are current and valid, and then calls the <code>iofunc\_stat()</code> helper function to fill in the <code>stat</code> structure based on the information in the <code>ocb->attr</code> structure.

The io\_stat\_t structure holds the \_IO\_STAT message received by the resource manager:

As with all the I/O messages, this structure is a union of an input message (coming to the resource manager) and an output or reply message (going back to the client). The *i* member is a structure of type **io stat** that contains the following members:

```
type __IO_STAT.
```

combine\_len

If the message is a combine message, \_IO\_COMBINE\_FLAG is set in this member. For more information, see the Combine Messages chapter of this guide.

The *o* member is a structure of type **stat**; for more information, see the entry for *stat()* in the QNX Neutrino *Library Reference*.

If you write your own handler, it should return the status via the helper macro \_RESMGR\_STATUS() and the struct stat via message reply.

If your resource manager is for a filesystem, you might want to include the stat information in the reply for other messages. For more information, see "Returning directory entries from \_IO\_READ" in the Filesystem Resource Managers chapter of this guide.

### Handling Iseek()

Your resource manager will receive an \_IO\_LSEEK message when a client calls *lseek()*, *fseek()*, or *rewinddir()*.



A resource manager that handles directories will also need to interpret the \_IO\_LSEEK message for directory operations.

The prototype for the *io lseek* handler is as follows:

The default handler, *iofunc\_lseek\_default()*, simply calls the *iofunc\_lseek()* helper function.

The io\_lseek\_t structure is (once again), a union of an input message and an output message:

The *whence* and *offset* members are passed from the client's *lseek()* function. The routine should adjust the OCB's *offset* parameter after interpreting the *whence* and *offset* parameters from the message and should return the new offset or an error.

The handler should return the status via the helper macro \_RESMGR\_STATUS(), and optionally (if no error occurred, and if the message isn't part of a combine message) the current offset.

# Chapter 9

# Signals, Timeouts, and Interrupts

## In this chapter...

Handling client unblocking due to signals or timeouts 127 Handling interrupts 128

### Handling client unblocking due to signals or timeouts

Another convenient service that the resource manager library does for us is *unblocking*.

When a client issues a request (e.g. read()), this translates (via the client's C library) into a MsgSend() to our resource manager. The MsgSend() is a blocking call. If the client receives a signal during the time that the MsgSend() is outstanding, our resource manager needs to have some indication of this so that it can abort the request.

Because the library set the \_NTO\_CHF\_UNBLOCK flag when it called *ChannelCreate()*, we'll receive a pulse whenever the client tries to unblock from a *MsgSend()* that we have *MsgReceive()*'d.

As an aside, recall that in the Neutrino messaging model, the client can be in one of two states as a result of calling MsgSend(). If the server hasn't yet received the message (via the server's MsgReceive()), the client is in a SEND-blocked state — the client is waiting for the server to receive the message. When the server has actually received the message, the client transits to a REPLY-blocked state — the client is now waiting for the server to reply to the message (via MsgReply()).

When this happens and the pulse is generated, the resource manager library handles the pulse message and synthesizes an \_IO\_UNBLOCK message.

Looking through the resmgr\_io\_funcs\_t and the resmgr\_connect\_funcs\_t structures (see the QNX Neutrino *Library Reference*), you'll notice that there are actually *two* unblock message handlers: one in the I/O functions structure and one in the connect functions structure.

Why two? Because we may get an abort in one of two places. We can get the abort pulse right after the client has sent the \_IO\_OPEN message (but before we've replied to it), or we can get the abort during an I/O message.

Once we've performed the handling of the \_IO\_CONNECT message, the I/O functions' unblock member will be used to service an unblock pulse. Therefore, if you're supplying your own *io\_open* handler, be sure to set up all relevant fields in the OCB *before* you call *resmgr\_open\_bind()*; otherwise, your I/O functions' version of the unblock handler may get called with invalid data in the OCB. (Note that this issue of abort pulses "during" message processing arises only if there are multiple threads running in your resource manager. If there's only one thread, then the messages will be serialized by the library's *MsgReceive()* function.)

The effect of this is that if the client is SEND-blocked, the server doesn't need to know that the client is aborting the request, because the server hasn't yet received it.

Only in the case where the server has received the request and is performing processing on that request does the server need to know that the client now wishes to abort.

For more information on these states and their interactions, see the *MsgSend()*, *MsgReceive()*, *MsgReply()*, and *ChannelCreate()* functions in the QNX Neutrino

*Library Reference*; see also the chapter on Interprocess Communication in the *System Architecture* book.

If you're overriding the default unblock handler, *iofunc\_unblock\_default()*, you should always call the default handler to process any generic unblocking cases first (which it does by calling *iofunc\_unblock()*). For example:

```
if((status = iofunc_unblock_default(...)) != _RESMGR_DEFAULT) {
    return status;
}
```

This ensures that any client waiting on a resource manager list (such as an advisory lock list) will be unblocked if possible.

Then you'll need some way to walk your table of blocked client revids, looking for a match, and unblocking them. That is done by replying to them; you aren't replying to the unblock request as such, but to the original client call (so either partially read the data or give an EINTR error as appropriate).

The routine should confirm the unblock is still pending (to avoid the race condition where the client was replied to by the time you got the unblock pulse, and the revid now indicates another client), by calling <code>MsgInfo()</code> and then checking for the <code>\_NTO\_MI\_UNBLOCK\_REQ</code> flag. If you can't find a matching client, you can ignore the unblock request by returning <code>\_RESMGR\_NOREPLY</code>:

```
/* Check if rcvid is still valid and still has an unblock
  request pending. */
if (MsgInfo(ctp->rcvid, &info) == -1 ||
   !(info.flags & _NTO_MI_UNBLOCK_REQ)) {
  return _RESMGR_NOREPLY;
}
```

If you don't provide an unblock handler, having your client thread left REPLY-blocked on the server is expected behavior; the server has to be given a chance to clean up client data structures when a client terminates.

## Handling interrupts

Resource managers that manage an actual hardware resource will likely need to handle interrupts generated by the hardware. For a detailed discussion on strategies for interrupt handlers, see the chapter on Writing an Interrupt Handler in the QNX Neutrino *Programmer's Guide*.

How do interrupt handlers relate to resource managers? When a significant event happens within the interrupt handler, the handler needs to inform a thread in the resource manager. This is usually done via a pulse (discussed in the "Handling private messages and pulses" section of the Handling Other Messages chapter), but it can also be done with the SIGEV INTR event notification type. Let's look at this in more detail.

When the resource manager starts up, it transfers control to *thread\_pool\_start()*. This function may or may not return, depending on the flags passed to *thread\_pool\_create()* (if you don't pass any flags, the function returns after the thread

pool is created). This means that if you're going to set up an interrupt handler, you should do so *before* starting the thread pool, or use one of the strategies we discussed above (such as starting a thread for your entire resource manager).

However, if you're going to use the SIGEV\_INTR event notification type, there's a catch — the thread that *attaches* the interrupt (via *InterruptAttach()* or *InterruptAttachEvent()*) must be the same thread that calls *InterruptWait()*.

#### Sample code for handling interrupts

Here's an example that includes relevant portions of the interrupt service routine and the handling thread:

```
#define INTNUM 0
#include <stdio.h>
#include <stddef.h>
#include <stdlib.h>
#include <sys/iofunc.h>
#include <sys/dispatch.h>
#include <sys/neutrino.h>
static resmgr_connect_funcs_t connect_funcs;
static resmgr_io_funcs_t io_funcs;
static iofunc_attr_t attr;
interrupt thread (void * data)
    struct sigevent event;
                   id:
    /* fill in "event" structure */
    memset(&event, 0, sizeof(event));
    event.sigev_notify = SIGEV_INTR;
    /* Obtain I/O privileges */
    ThreadCtl( _NTO_TCTL_IO, 0 );
    /* intNum is the desired interrupt level */
    id = InterruptAttachEvent (INTNUM, &event, 0);
    /*... insert your code here ... */
    while (1) {
        InterruptWait (NULL, NULL);
        /* do something about the interrupt,
         * perhaps updating some shared
            structures in the resource manager
         * unmask the interrupt when done
        InterruptUnmask(INTNUM, id);
    }
}
main(int argc, char **argv) {
    thread_pool_attr_t pool_attr;
    resmgr_attr_t resmgr_attr;
dispatch_t *dpp;
```

```
thread_pool_t
                      *tpp;
                      id;
int
if((dpp = dispatch create()) == NULL) {
    fprintf(stderr,
           "%s: Unable to allocate dispatch handle.\n",
           argv[0]);
    return EXIT FAILURE;
}
memset(&pool attr, 0, sizeof pool attr);
pool attr.handle = dpp;
pool_attr.context_alloc = dispatch_context_alloc;
pool_attr.block_func = dispatch_block;
pool attr.unblock func = dispatch unblock;
pool attr.handler func = dispatch handler;
pool attr.context free = dispatch context free;
pool_attr.lo_water = 2;
pool_attr.hi_water = 4;
pool attr.increment = 1;
pool attr.maximum = 50;
if((tpp = thread_pool_create(&pool_attr,
                             POOL FLAG EXIT SELF)) == NULL) {
    fprintf(stderr, "%s: Unable to initialize thread pool.\n",
           argv[0]);
    return EXIT_FAILURE;
}
iofunc func init( RESMGR CONNECT NFUNCS, &connect funcs,
                 _RESMGR_IO_NFUNCS, &io_funcs);
iofunc attr init(&attr, S IFNAM | 0666, 0, 0);
memset(&resmgr_attr, 0, sizeof resmgr_attr);
resmgr_attr.nparts_max = 1;
resmgr_attr.msg_max_size = 2048;
if((id = resmgr attach(dpp, &resmgr attr, "/dev/sample",
                       FTYPE ANY, 0,
             &connect_funcs, &io_funcs, &attr)) == -1) {
    fprintf(stderr, "%s: Unable to attach name.\n", argv[0]);
    return EXIT FAILURE;
}
/* Start the thread that will handle interrupt events. */
pthread create (NULL, NULL, interrupt thread, NULL);
/* Never returns */
thread_pool_start(tpp);
```

Here the *interrupt\_thread()* function uses *InterruptAttachEvent()* to bind the interrupt source (*intNum*) to the event (passed in *event*), and then waits for the event to occur.

This approach has a major advantage over using a pulse. A pulse is delivered as a message to the resource manager, which means that if the resource manager's message-handling threads are busy processing requests, the pulse will be queued until a thread does a *MsgReceive()*.

}

With the *InterruptWait()* approach, if the thread that's executing the *InterruptWait()* is of sufficient priority, it unblocks and runs *immediately* after the SIGEV\_INTR is generated.

# Chapter 10

# **Multithreaded Resource Managers**

# In this chapter...

Multithreaded resource manager example 135 Thread pool attributes 136 Thread pool functions 138

# Multithreaded resource manager example

Let's look at our multithreaded resource manager example in more detail:

```
#include <errno.h>
#include <stdio.h>
#include <stddef.h>
#include <stdlib.h>
#include <unistd.h>
    define \mathtt{THREAD\_POOL\_PARAM\_T} such that we can avoid a compiler
 * warning when we use the dispatch *() functions below
#define THREAD_POOL_PARAM_T dispatch_context_t
#include <sys/iofunc.h>
#include <sys/dispatch.h>
static resmgr connect funcs t connect funcs;
static resmgr_io_funcs_t io_funcs;
static iofunc_attr_t
                                  attr;
main(int argc, char **argv)
    /* declare variables we'll be using */
    thread_pool_attr_t pool_attr;
   resmgr_attr_t resmgr_attr;
dispatch_t *dpp;
thread_pool_t *tpp;
    dispatch_context_t *ctp;
    /* initialize dispatch interface */
    if((dpp = dispatch create()) == NULL) {
        fprintf(stderr,
                 "%s: Unable to allocate dispatch handle.\n",
                 argv[0]);
        return EXIT FAILURE;
    }
    /* initialize resource manager attributes */
    memset(&resmgr_attr, 0, sizeof resmgr_attr);
    resmgr attr.nparts max = 1;
    resmgr attr.msg max size = 2048;
    /* initialize functions for handling messages */
    iofunc_func_init(_RESMGR_CONNECT_NFUNCS, &connect_funcs,
                      _RESMGR_IO_NFUNCS, &io funcs);
    /* initialize attribute structure used by the device */
    iofunc_attr_init(&attr, S_IFNAM | 0666, 0, 0);
    /* attach our device name */
    id = resmgr attach(
             dpp, /* dispatch handle */
&resmgr_attr, /* resource manager attrs */
"/dev/sample", /* device name */
            dpp,
             _FTYPE_ANY, /* open type
0, /* flags
            &connect_funcs, /* connect routines */
&io_funcs, /* I/O routines */
&attr); /* handle */
```

```
if(id == -1) {
   fprintf(stderr, "%s: Unable to attach name.\n", argv[0]);
    return EXIT FAILURE;
/* initialize thread pool attributes */
memset(&pool attr, 0, sizeof pool attr);
pool_attr.handle = dpp;
pool attr.context alloc = dispatch context alloc;
pool_attr.block_func = dispatch_block;
pool attr.unblock func = dispatch unblock;
pool attr.handler func = dispatch handler;
pool attr.context free = dispatch context free;
pool_attr.lo_water = 2;
pool_attr.hi_water = 4;
pool attr.increment = 1;
pool attr.maximum = 50;
/* allocate a thread pool handle */
if((tpp = thread_pool_create(&pool_attr,
                            POOL FLAG EXIT SELF)) == NULL) {
    fprintf(stderr, "%s: Unable to initialize thread pool.\n",
           argv[0]);
    return EXIT FAILURE;
}
/* start the threads, will not return */
thread_pool_start(tpp);
```

The thread pool attribute (*pool\_attr*) controls various aspects of the thread pool, such as which functions get called when a new thread is started or dies, the total number of worker threads, the minimum number, and so on.

# Thread pool attributes

Here's the thread pool attr structure:

```
typedef struct _thread_pool_attr {
 THREAD_POOL_HANDLE_T *handle;
 THREAD_POOL_PARAM_T *(*block_func)(THREAD_POOL_PARAM_T *ctp);
 void
                      (*unblock func) (THREAD POOL PARAM T *ctp);
                       (*handler_func)(THREAD_POOL_PARAM_T *ctp);
 THREAD POOL PARAM T *(*context alloc)(
                         THREAD POOL HANDLE T *handle);
 void
                     (*context free) (THREAD POOL PARAM T *ctp);
 pthread attr t
                    *attr;
 unsigned short
                     lo water;
 unsigned short
                     increment;
 unsigned short
                     hi water;
                      maximum;
 unsigned
                      reserved[8];
} thread_pool_attr_t;
```

The functions that you fill into the above structure can be taken from the dispatch layer (dispatch\_block(), ...), the resmgr layer (resmgr\_block(), ...) or they can be of your own making. If you're not using the resmgr layer functions, then you'll have to define THREAD\_POOL\_PARAM\_T to some sort of context structure for the library to pass between the various functions. By default, it's defined as a resmgr context t but

since this sample is using the dispatch layer, we needed it to be adispatch\_context\_t. We defined it prior to doing the includes above since the header files refer to it. THREAD POOL PARAM T

Part of the above structure contains information telling the resource manager library how you want it to handle multiple threads (if at all). During development, you should design your resource manager with multiple threads in mind. But during testing, you'll most likely have only one thread running (to simplify debugging). Later, after you've ensured that the base functionality of your resource manager is stable, you may wish to "turn on" multiple threads and revisit the debug cycle.

The following members control the number of threads that are running:

*lo\_water* Minimum number of blocked threads.

increment Number of thread to create at a time to achieve lo\_water.

hi water Maximum number of blocked threads.

maximum Total number of threads created at any time.

The important parameters specify the maximum thread count and the increment. The value for *maximum* should ensure that there's always a thread in a RECEIVE-blocked state. If you're at the number of maximum threads, then your clients will block until a free thread is ready to receive data. The value you specify for *increment* will cut down on the number of times your driver needs to create threads. It's probably wise to err on the side of creating more threads and leaving them around rather than have them being created/destroyed all the time.

You determine the number of threads you want to be RECEIVE-blocked on the MsgReceive() at any time by filling in the lowater parameter.

If you ever have fewer than *lo\_water* threads RECEIVE-blocked, the *increment* parameter specifies how many threads should be created at once, so that at least *lo water* number of threads are once again RECEIVE-blocked.

Once the threads are done their processing, they will return to the block function. The *hi\_water* variable specifies an upper limit to the number of threads that are RECEIVE-blocked. Once this limit is reached, the threads will destroy themselves to ensure that no more than *hi\_water* number of threads are RECEIVE-blocked.

To prevent the number of threads from increasing without bounds, the *maximum* parameter limits the absolute maximum number of threads that will ever run simultaneously.

When threads are created by the resource manager library, they'll have a stack size as specified by the *thread\_stack\_size* parameter. If you want to specify stack size or priority, fill in *pool\_attr.attr* with a proper *pthread\_attr\_t* pointer.

The thread pool attr t structure contains pointers to several functions:

block_func()	Called by the worker thread when it needs to block waiting for some message.
handler_func()	Called by the thread when it has unblocked because it received a message. This function processes the message.
context_alloc()	Called when a new thread is created. Returns a context that this thread uses to do its work.
context_free()	Free the context when the worker thread exits.
unblock_func()	Called by the library to shutdown the thread pool or change the number of running threads.

# Thread pool functions

The library provides the following thread pool functions:

thread\_pool\_create()

Initializes the pool context. Returns a thread pool handle (*tpp*) that's used to start the thread pool.

thread\_pool\_start()

Start the thread pool. This function may or may not return, depending on the flags passed to *thread\_pool\_create()*.

thread pool destroy()

Destroy a thread pool.

thread\_pool\_control()

Control the number of threads.



In the example provided in the multithreaded resource managers section, thread\_pool\_start(tpp) never returns because we set the POOL\_FLAG\_EXIT\_SELF bit. Also, the POOL\_FLAG\_USE\_SELF flag itself never returns, but the current thread becomes part of the thread pool.

If no flags are passed (i.e. 0 instead of any flags), the function returns after the thread pool is created.

# Chapter 11

# **Filesystem Resource Managers**

# In this chapter...

Considerations for filesystem resource managers 141 Taking over more than one device 141 Handling directories 142

# Considerations for filesystem resource managers

Since a filesystem resource manager may potentially receive long pathnames, it must be able to parse and handle each component of the path properly.

Let's say that a resource manager registers the mountpoint /mount/, and a user types:

```
ls -1 /mount/home
where /mount/home is a directory on the device.
ls does the following:
d = opendir("/mount/home");
while (...) {
    dirent = readdir(d);
    ...
}
```

# Taking over more than one device

If we wanted our resource manager to handle multiple devices, the change is really quite simple. We would call  $resmgr\_attach()$  for each device name we wanted to register. We would also pass in an attributes structure that was unique to each registered device, so that functions such as chmod() would be able to modify the attributes associated with the correct resource.

Here are the modifications necessary to handle both /dev/sample1 and /dev/sample2:

```
* MOD [1]: allocate multiple attribute structures,
            and fill in a names array (convenience)
*/
#define NumDevices 2
"/dev/sample1",
   "/dev/sample2"
};
main ()
      MOD [2]: fill in the attribute structure for each device
    *
               and call resmgr attach for each device
    */
   for (i = 0; i < NumDevices; i++) {
       iofunc_attr_init (&sample_attrs [i],
                       S IFCHR | 0666, NULL, NULL);
       pathID = resmgr attach (dpp, &resmgr attr, name[i],
                              FTYPE ANY, 0,
                              &my_connect_funcs,
                              &my io funcs,
```

```
&sample_attrs [i]);
}
...
}
```

The first modification simply declares an array of attributes, so that each device has its own attributes structure. As a convenience, we've also declared an array of names to simplify passing the name of the device in the *for* loop. Some resource managers (such as devc-ser8250) construct the device names on the fly or fetch them from the command line.

The second modification initializes the array of attribute structures and then calls  $resmgr\_attach()$  multiple times, once for each device, passing in a unique name and a unique attribute structure.

Those are all the changes required. Nothing in our *io\_read* or *io\_write* handlers has to change — the iofunc-layer default functions will gracefully handle the multiple devices.

# Handling directories

Up until this point, our discussion has focused on resource managers that associate each device name via discrete calls to  $resmgr\_attach()$ . We've shown how to "take over" a single pathname. (Our examples have used pathnames under /dev, but there's no reason you couldn't take over any other pathnames, e.g. /MyDevice.)

A typical resource manager can take over any number of pathnames. A practical limit, however, is on the order of a hundred — the real limit is a function of memory size and lookup speed in the process manager.

What if you wanted to take over thousands or even millions of pathnames?

The most straightforward method of doing this is to take over a *pathname prefix* and manage a directory structure below that prefix (or *mountpoint*).

Here are some examples of resource managers that may wish to do this:

- A CD-ROM filesystem might take over the pathname prefix /cdrom, and then
  handle any requests for files below that pathname by going out to the CD-ROM
  device.
- A filesystem for managing compressed files might take over a pathname prefix of /uncompressed, and then uncompress disk files on the fly as read requests arrive.
- A network filesystem could present the directory structure of a remote machine
  called "flipper" under the pathname prefix of /mount/flipper and allow the user
  to access flipper's files as if they were local to the current machine.

And those are just the most obvious ones. The reasons (and possibilities) are almost endless.

The common characteristic of these resource managers is that they all implement *filesystems*. A filesystem resource manager differs from the "device" resource managers (that we have shown so far) in the following key areas:

- 1 The \_RESMGR\_FLAG\_DIR bit in the *flags* argument to *resmgr\_attach()* informs the library that the resource manager will accept matches *at or below* the defined mountpoint.
- The \_IO\_CONNECT logic has to check the individual pathname components against permissions and access authorizations. It must also ensure that the proper attribute is bound when a particular filename is accessed.
- The \_IO\_READ logic has to return the data for either the "file" or "directory" specified by the pathname.

Let's look at these points in turn.

# Matching at or below a mountpoint

When we specified the *flags* argument to *resmgr\_attach()* for our sample resource manager, we specified a 0, implying that the library should "use the defaults."

If we specified the value \_RESMGR\_FLAG\_DIR instead of 0, the library would allow the resolution of pathnames at or below the specified mountpoint.

# The IO OPEN message for filesystems

Once we've specified a mountpoint, it would then be up to the resource manager to determine a suitable response to an open request. Let's assume that we've defined a mountpoint of /sample fsys for our resource manager:

Now when the client performs a call like this:

```
fopen ("/sample_fsys/spud", "r");
```

we receive an \_IO\_CONNECT message, and our *io\_open* handler will be called. Since we haven't yet looked at the IO CONNECT message in depth, let's take a look now:

```
unsigned short path_len;
unsigned char eflag;  /* _IO_CONNECT_EFLAG_* */
unsigned char extra_type; /* _IO_EXTRA_* */
unsigned short extra_len;
unsigned char path[1]; /* path_len, null, extra_len */
};
```

Looking at the relevant fields, we see *ioflag*, *mode*, *sflag*, and *access*, which tell us how the resource was opened.

The <code>path\_len</code> parameter tells us how many bytes the pathname takes; the actual pathname appears in the <code>path</code> parameter. Note that the pathname that appears is <code>not/sample\_fsys/spud</code>, as you might expect, but instead is just <code>spud</code>— the message contains only the pathname relative to the resource manager's mountpoint. This simplifies coding because you don't have to skip past the mountpoint name each time, the code doesn't have to know what the mountpoint is, and the messages will be a little bit shorter.

Note also that the pathname will *never* have relative (. and ..) path components, nor redundant slashes (e.g. <code>spud//stuff</code>) in it — these are all resolved and removed by the time the message is sent to the resource manager.

When writing filesystem resource managers, we encounter additional complexity when dealing with the pathnames. For verification of access, we need to break apart the passed pathname and check each component. You can use strtok() and friends to break apart the string, and then there's  $iofunc\_check\_access()$ , a convenient iofunc-layer call that performs the access verification of pathname components leading up to the target. (See the QNX Neutrino  $Library\ Reference$  page for the  $iofunc\_open()$  for information detailing the steps needed for this level of checking.)



The binding that takes place after the name is validated requires that every path that's handled has its own attribute structure passed to *iofunc\_open\_default()*. Unexpected behavior will result if the wrong attribute is bound to the pathname that's provided.

# Returning directory entries from \_IO\_READ

When the \_IO\_READ handler is called, it may need to return data for either a file (if S\_ISDIR (ocb->attr->mode) is false) or a directory (if S\_ISDIR (ocb->attr->mode) is true). We've seen the algorithm for returning data, especially the method for matching the returned data's size to the smaller of the data available or the client's buffer size.

A similar constraint is in effect for returning directory data to a client, except we have the added issue of returning block-integral data. What this means is that instead of returning a stream of bytes, where we can arbitrarily package the data, we're actually returning a number of struct dirent structures. (In other words, we can't return 1.5 of those structures; we always have to return an integral number.) The dirent structures must be aligned on 4-byte boundaries in the reply.

A struct dirent looks like this:

```
struct dirent {
```

```
#if _FILE_OFFSET_BITS - 0 == 64
   ino_t d_ino;
off_t d_offset;
                                  /* File serial number. */
#elif !defined(_FILE_OFFSET_BITS) | _FILE_OFFSET_BITS == 32
#if defined(__LITTLEENDIAN__)
   ino_t d_ino;
ino_t d_ino_hi;
off_t d_offset;
off_t d_offset_hi;
                                   /* File serial number. */
#elif defined(__BIGENDIAN__)
   /* File serial number. */
#else
#error endian not configured for system
#endif
#else
#error _FILE_OFFSET_BITS value is unsupported
   _Int16t
_Int16t
char
                      d_reclen;
d_namelen;
                       d name[1];
};
```

The *d\_ino* member contains a mountpoint-unique file serial number. This serial number is often used in various disk-checking utilities for such operations as determining infinite-loop directory links. (Note that the inode value cannot be zero, which would indicate that the inode represents an *unused* entry.)

In some filesystems, the  $d_{offset}$  member is used to identify the directory entry itself; in others, it's the offset of the *next* directory entry. For a disk-based filesystem, this value might be the actual offset into the on-disk directory structure.

The <u>d\_reclen</u> member contains the size of this directory entry <u>and any other</u> associated information (such as an optional struct stat structure appended to the struct direct entry; see below).

The  $d_namelen$  parameter indicates the size of the  $d_name$  parameter, which holds the actual name of that directory entry. (Since the size is calculated using strlen(), the  $\0$  string terminator, which must be present, is not counted.)



The dirent structure includes space only for the first four bytes of the name; your \_IO\_READ handler needs to return the name and the struct dirent as a bigger structure:

So in our *io\_read* handler, we need to generate a number of **struct dirent** entries and return them to the client.

If we have a cache of directory entries that we maintain in our resource manager, it's a simple matter to construct a set of IOVs to point to those entries. If we don't have a cache, then we must manually assemble the directory entries into a buffer and then return an IOV that points to that.

## Returning information associated with a directory structure

Instead of returning just the struct dirent in the \_IO\_READ message, you can also return a struct stat. Although this will improve efficiency, returning the struct stat is entirely optional. If you don't return one, the users of your device will then have to call stat() or lstat() to get that information. (This is basically a usage question. If your device is typically used in such a way that readdir() is called, and then stat() is called, it will be more efficient to return both. See the documentation for readdir() in the QNX Neutrino Library Reference for more information.)

The client can set the *xtype* member of the message to


\_IO\_XFLAG\_DIR\_EXTRA\_HINT to send a hint to the filesystem to return the extra information, however the filesystem isn't guaranteed to do so. If the resource manager provides the information, it must put it in a struct dirent\_extra\_stat, which is defined as follows:

The resource manager must set  $d_{type}$  to \_DTYPE\_LSTAT or \_DTYPE\_STAT, depending on whether or not it resolves symbolic links. For example:

```
if(msg->i.xtype & _IO_XFLAG_DIR_EXTRA_HINT) {
    struct dirent_extra_stat extra;
    extra.d datalen = sizeof extra.d stat;
```

```
extra.d_type = _DTYPE_LSTAT;
extra.d_reserved = 0;
iofunc_stat(ctp, &attr, &extra.d_stat);
...
}
```

There's a dirent\_extra\_stat after each directory entry:



Returning the optional struct dirent\_extra\_stat along with the struct dirent entry can improve efficiency.



The dirent structures must be aligned on 4-byte boundaries, and the dirent\_extra\_stat structures on 8-byte boundaries. The d\_reclen member of the struct dirent must contain the size of both structures, including any space necessary for the pathname and alignment. There must be no more than seven bytes of alignment filler.

The client has to check for extra data by using the \_DEXTRA\_\*() macros (see the entry for readdir() in the QNX Neutrino Library Reference.) If this check fails, the client will need to call lstat() or stat() explicitly. For example, ls -l checks for extra \_DTYPE\_LSTAT information; if it isn't present, ls calls lstat(). The ls -L command checks for extra \_DTYPE\_STAT information; if it isn't present, ls calls stat().

# Glossary

### administrator

See superuser.

#### alias

A shell feature that lets you create new commands or specify your favorite options. For example, alias my\_ls='ls -F' creates an alias called my\_ls that the shell replaces with ls -F.

#### atomic

Of or relating to atoms. :-)

In operating systems, this refers to the requirement that an operation, or sequence of operations, be considered *indivisible*. For example, a thread may need to move a file position to a given location and read data. These operations must be performed in an atomic manner; otherwise, another thread could preempt the original thread and move the file position to a different location, thus causing the original thread to read data from the second thread's position.

## **BIOS/ROM Monitor extension signature**

A certain sequence of bytes indicating to the BIOS or ROM Monitor that the device is to be considered an "extension" to the BIOS or ROM Monitor — control is to be transferred to the device by the BIOS or ROM Monitor, with the expectation that the device will perform additional initializations.

On the x86 architecture, the two bytes 0x55 and 0xAA must be present (in that order) as the first two bytes in the device, with control being transferred to offset 0x0003.

#### budget

In **sporadic** scheduling, the amount of time a thread is permitted to execute at its normal priority before being dropped to its low priority.

#### buildfile

A text file containing instructions for mkifs specifying the contents and other details of an image, or for mkefs specifying the contents and other details of an embedded filesystem image.

#### canonical mode

Also called edited mode or "cooked" mode. In this mode the character device library performs line-editing operations on each received character. Only when a line is "completely entered" — typically when a carriage return (CR) is received — will the line of data be made available to application processes. Contrast **raw mode**.

#### channel

A kernel object used with message passing.

In Neutrino, message passing is directed towards a **connection** (made to a channel); threads can receive messages from channels. A thread that wishes to receive messages creates a channel (using *ChannelCreate()*), and then receives messages from that channel (using *MsgReceive()*). Another thread that wishes to send a message to the first thread must make a connection to that channel by "attaching" to the channel (using *ConnectAttach()*) and then sending data (using *MsgSend()*).

## **CIFS**

Common Internet File System (aka SMB) — a protocol that allows a client workstation to perform transparent file access over a network to a Windows server. Client file access calls are converted to CIFS protocol requests and are sent to the server over the network. The server receives the request, performs the actual filesystem operation, and sends a response back to the client.

#### CIS

Card Information Structure.

## command completion

A shell feature that saves typing; type enough of the command's name to identify it uniquely, and then press Esc twice. If possible, the shell fills in the rest of the name.

#### command interpreter

A process that parses what you type on the command line; also known as a **shell**.

#### compound command

A command that includes a shell's reserved words, grouping constructs, and function definitions (e.g. ls -al | less). Contrast simple command.

## configurable limit

A special variable that stores system information. Some (e.g. \_PC\_NAME\_MAX) depend on the filesystem and are associated with a path; others (e.g. \_SC\_ARG\_MAX) are independent of paths.

#### configuration string

A system variable that's like an environment variable, but is more dynamic. When you set an environment variable, the new value affects only the current instance of the shell and any of its children that you create after setting the variable; when you set a configuration string, its new value is immediately available to the entire system.

#### connection

A kernel object used with message passing.

Connections are created by client threads to "connect" to the channels made available by servers. Once connections are established, clients can *MsgSend()* messages over them.

#### console

The display adapter, the screen, and the system keyboard are collectively referred to as the **physical console**. A **virtual console** emulates a physical console and lets you run more than one terminal session at a time on a machine.

#### cooked mode

See canonical mode.

#### core dump

A file describing the state of a process that terminated abnormally.

#### critical section

A code passage that *must* be executed "serially" (i.e. by only one thread at a time). The simplest from of critical section enforcement is via a **mutex**.

#### device driver

A process that allows the OS and application programs to make use of the underlying hardware in a generic way (e.g. a disk drive, a network interface). Unlike OSs that require device drivers to be tightly bound into the OS itself, device drivers for Neutrino are standard processes that can be started and stopped dynamically. As a result, adding device drivers doesn't affect any other part of the OS — drivers can be developed and debugged like any other application. Also, device drivers are in their own protected address space, so a bug in a device driver won't cause the entire OS to shut down.

#### **DNS**

Domain Name Service — an Internet protocol used to convert ASCII domain names into IP addresses. In QNX native networking, dns is one of **Qnet's** builtin resolvers.

# edge-sensitive

One of two ways in which a **PIC** (Programmable Interrupt Controller) can be programmed to respond to interrupts. In edge-sensitive mode, the interrupt is "noticed" upon a transition to/from the rising/falling edge of a pulse. Contrast **level-sensitive**.

#### edited mode

See canonical mode.

#### **EPROM**

Erasable Programmable Read-Only Memory — a memory technology that allows the device to be programmed (typically with higher-than-operating voltages, e.g. 12V), with the characteristic that any bit (or bits) may be individually programmed from a 1 state to a 0 state. To change a bit from a 0 state into a 1 state can only be accomplished by erasing the *entire* device, setting *all* of the bits to a 1 state. Erasing is accomplished by shining an ultraviolet light through the erase window of the device for a fixed period of time (typically 10-20 minutes). The device is further characterized by having a limited number of erase cycles (typically 10e5 - 10e6). Contrast **EEPROM**, **flash**, and **RAM**.

#### **EEPROM**

Electrically Erasable Programmable Read-Only Memory — a memory technology that's similar to **EPROM**, but you can erase the entire device electrically instead of via ultraviolet light. Contrast **flash** and **RAM**.

#### event

A notification scheme used to inform a thread that a particular condition has occurred. Events can be signals or pulses in the general case; they can also be unblocking events or interrupt events in the case of kernel timeouts and interrupt service routines. An event is delivered by a thread, a timer, the kernel, or an interrupt service routine when appropriate to the requester of the event.

#### extent

A contiguous sequence of blocks on a disk.

#### fd

File Descriptor — a client must open a file descriptor to a resource manager via the *open()* function call. The file descriptor then serves as a handle for the client to use in subsequent messages.

#### **FIFO**

First In First Out — a scheduling policy whereby a thread is able to consume CPU at its priority level without bounds. See also **round robin** and **sporadic**.

#### filename completion

A shell feature that saves typing; type enough of the file's name to identify it uniquely, and then press Esc twice. If possible, the shell fills in the rest of the name.

#### filter

A program that reads from standard input and writes to standard output, such as grep, sort, and wc. You can use a pipe (|) to combine filters.

### flash memory

A memory technology similar in characteristics to **EEPROM** memory, with the exception that erasing is performed electrically, and, depending upon the organization of the flash memory device, erasing may be accomplished in blocks (typically 64 KB bytes at a time) instead of the entire device. Contrast **EPROM** and **RAM**.

#### **FQNN**

Fully Qualified Node Name — a unique name that identifies a Neutrino node on a network. The FQNN consists of the nodename plus the node domain tacked together.

## garbage collection

The process whereby a filesystem manager recovers the space occupied by deleted files and directories. Also known as space reclamation.

#### group

A collection of users who share similar file permissions.

## HA

High Availability — in telecommunications and other industries, HA describes a system's ability to remain up and running without interruption for extended periods of time.

## hard link

See link.

#### hidden file

A file whose name starts with a dot (.), such as .profile. Commands such as ls don't operate on hidden files unless you explicitly say to.

#### image

In the context of embedded Neutrino systems, an "image" can mean either a structure that contains files (i.e. an OS image) or a structure that can be used in a read-only, read/write, or read/write/reclaim filesystem (i.e. a flash filesystem image).

#### inode

Information node — a storage table that holds information about files, other than the files' names. In order to support links for each file, the filename is separated from the other information that describes a file.

#### interrupt

An event (usually caused by hardware) that interrupts whatever the processor was doing and asks it do something else. The hardware will generate an interrupt whenever it has reached some state where software intervention is required.

## interrupt latency

The amount of elapsed time between the generation of a hardware interrupt and the first instruction executed by the relevant interrupt service routine. Also designated as "T<sub>il</sub>". Contrast **scheduling latency**.

**IPC** 

Interprocess Communication — the ability for two processes (or threads) to communicate. Neutrino offers several forms of IPC, most notably native messaging (synchronous, client/server relationship), POSIX message queues and pipes (asynchronous), as well as signals.

**IPL** 

Initial Program Loader — the software component that either takes control at the processor's reset vector (e.g. location <code>0xffffffff0</code> on the x86), or is a BIOS extension. This component is responsible for setting up the machine into a usable state, such that the startup program can then perform further initializations. The IPL is written in assembler and C. See also <code>BIOS/ROM Monitor extension signature</code> and <code>startup code</code>.

**IRQ** 

Interrupt Request — a hardware request line asserted by a peripheral to indicate that it requires servicing by software. The IRQ is handled by the **PIC**, which then interrupts the processor, usually causing the processor to execute an **Interrupt Service Routine** (**ISR**).

**ISR** 

Interrupt Service Routine — a routine responsible for servicing hardware (e.g. reading and/or writing some device ports), for updating some data structures shared between the ISR and the thread(s) running in the application, and for signalling the thread that some kind of event has occurred.

kernel

See microkernel.

## level-sensitive

One of two ways in which a **PIC** (Programmable Interrupt Controller) can be programmed to respond to interrupts. If the PIC is operating in level-sensitive mode, the IRQ is considered active whenever the corresponding hardware line is active. Contrast **edge-sensitive**.

link

A filename; a pointer to the file's contents. Contrast symbolic link.

## message

A parcel of bytes passed from one process to another. The OS attaches no special meaning to the content of a message — the data in a message has meaning for the sender of the message and for its receiver, but for no one else.

Message passing not only allows processes to pass data to each other, but also provides a means of synchronizing the execution of several processes. As they send, receive, and reply to messages, processes undergo various "changes of state" that affect when, and for how long, they may run.

#### metadata

Data about data; for a filesystem, metadata includes all the overhead and attributes involved in storing the user data itself, such as the name of a file, the physical blocks it uses, modification and access timestamps, and so on.

#### microkernel

A part of the operating system that provides the minimal services used by a team of optional cooperating processes, which in turn provide the higher-level OS functionality. The microkernel itself lacks filesystems and many other services normally expected of an OS; those services are provided by optional processes.

## mountpoint

The location in the pathname space where a resource manager has "registered" itself. For example, a CD-ROM filesystem may register a single mountpoint of /cdrom.

#### mutex

Mutual exclusion lock, a simple synchronization service used to ensure exclusive access to data shared between threads. It is typically acquired (*pthread\_mutex\_lock()*) and released (*pthread\_mutex\_unlock()*) around the code that accesses the shared data (usually a **critical section**).

#### name resolution

In a Neutrino network, the process by which the **Qnet** network manager converts an **FQNN** to a list of destination addresses that the transport layer knows how to get to.

# name resolver

Program code that attempts to convert an **FQNN** to a destination address.

#### **NDP**

Node Discovery Protocol — proprietary QNX Software Systems protocol for broadcasting name resolution requests on a Neutrino LAN.

### network directory

A directory in the pathname space that's implemented by the **Qnet** network manager.

#### **Neutrino**

Product name of the RTOS developed by QNX Software Systems.

#### **NFS**

Network FileSystem — a TCP/IP application that lets you graft remote filesystems (or portions of them) onto your local namespace. Directories on the remote systems appear as part of your local filesystem and all the utilities you use for listing and managing files (e.g. 1s, cp, mv) operate on the remote files exactly as they do on your local files.

## **Node Discovery Protocol**

See NDP.

#### node domain

A character string that the **Qnet** network manager tacks onto the nodename to form an **FQNN**.

#### nodename

A unique name consisting of a character string that identifies a node on a network.

#### package

A directory tree of files laid out in a structure that matches where they would be if they were transported to the root of some filesystem.

## package filesystem

A virtual filesystem manager that presents a customized view of a set of files and directories to a client. The "real" files are present on some media; the package filesystem presents a virtual view of selected files to the client.



Neutrino doesn't start the package filesystem by default.

## pathname prefix

See mountpoint.

## pathname-space mapping

The process whereby the Process Manager maintains an association between resource managers and entries in the pathname space.

### persistent

When applied to storage media, the ability for the media to retain information across a power-cycle. For example, a hard disk is a persistent storage media, whereas a ramdisk is not, because the data is lost when power is lost.

#### Photon microGUI

The proprietary graphical user interface built by QNX Software Systems.

**PIC** 

Programmable Interrupt Controller — a hardware component that handles IRQs.

**PID** 

Process ID. Also often *pid* (e.g. as an argument in a function call). See also **process ID**.

**POSIX** 

An IEEE/ISO standard. The term is an acronym (of sorts) for Portable Operating System Interface — the "X" alludes to "UNIX", on which the interface is based.

### preemption

The act of suspending the execution of one thread and starting (or resuming) another. The suspended thread is said to have been "preempted" by the new thread. Whenever a lower-priority thread is actively consuming the CPU, and a higher-priority thread becomes READY, the lower-priority thread is immediately preempted by the higher-priority thread.

#### prefix tree

The internal representation used by the Process Manager to store the pathname table.

#### priority inheritance

The characteristic of a thread that causes its priority to be raised or lowered to that of the thread that sent it a message. Also used with mutexes. Priority inheritance is a method used to prevent **priority inversion**.

# priority inversion

A condition that can occur when a low-priority thread consumes CPU at a higher priority than it should. This can be caused by not supporting priority inheritance, such that when the lower-priority thread sends a message to a higher-priority thread, the higher-priority thread consumes CPU *on behalf of* the lower-priority thread. This is solved by having the higher-priority thread inherit the priority of the thread on whose behalf it's working.

## process

A nonschedulable entity, which defines the address space and a few data areas. A process must have at least one **thread** running in it.

## process group

A collection of processes that permits the signalling of related processes. Each process in the system is a member of a process group identified by a process group ID. A newly created process joins the process group of its creator.

## process group ID

The unique identifier representing a process group during its lifetime. A process group ID is a positive integer. The system may reuse a process group ID after the process group dies.

### process group leader

A process whose ID is the same as its process group ID.

#### process ID (PID)

The unique identifier representing a process. A PID is a positive integer. The system may reuse a process ID after the process dies, provided no existing process group has the same ID. Only the Process Manager can have a process ID of 1.

# pty

Pseudo-TTY — a character-based device that has two "ends": a master end and a slave end. Data written to the master end shows up on the slave end, and vice versa. You typically use these devices when a program requires a terminal for standard input and output, and one doesn't exist, for example as with sockets.

#### **Qnet**

The native network manager in Neutrino.

#### QNX

Name of an earlier-generation RTOS created by QNX Software Systems. Also, short form of the company's name.

## QoS

Quality of Service — a policy (e.g. loadbalance) used to connect nodes in a network in order to ensure highly dependable transmission. QoS is an issue that often arises in high-availability (HA) networks as well as realtime control systems.

#### **QSS**

QNX Software Systems.

### quoting

A method of forcing a shell's special characters to be treated as simple characters instead of being interpreted in a special way by the shell. For example, less "my file name" escapes the special meaning of the spaces in a filename.

#### **RAM**

Random Access Memory — a memory technology characterized by the ability to read and write any location in the device without limitation. Contrast **flash**, **EPROM**, and **EEPROM**.

#### raw mode

In raw input mode, the character device library performs no editing on received characters. This reduces the processing done on each character to a minimum and provides the highest performance interface for reading data. Also, raw mode is used with devices that typically generate binary data — you don't want any translations of the raw binary stream between the device and the application. Contrast **canonical mode**.

#### remote execution

Running commands on a machine other than your own over a network.

#### replenishment

In **sporadic** scheduling, the period of time during which a thread is allowed to consume its execution **budget**.

#### reset vector

The address at which the processor begins executing instructions after the processor's reset line has been activated. On the x86, for example, this is the address 0xFFFFFFF0.

#### resource manager

A user-level server program that accepts messages from other programs and, optionally, communicates with hardware. Neutrino resource managers are responsible for presenting an interface to various types of devices, whether actual (e.g. serial ports, parallel ports, network cards, disk drives) or virtual (e.g. /dev/null, a network filesystem, and pseudo-ttys).

In other operating systems, this functionality is traditionally associated with **device drivers**. But unlike device drivers, Neutrino resource managers don't require any special arrangements with the kernel. In fact, a resource manager looks just like any other user-level program. See also **device driver**.

#### root

The superuser, which can do anything on your system. The superuser has what Windows calls administrator's rights.

#### round robin

A scheduling policy whereby a thread is given a certain period of time (the **timeslice**) to run. Should the thread consume CPU for the entire period of its timeslice, the thread will be placed at the end of the ready queue for its priority, and the next available thread will be made READY. If a thread is the only thread READY at its priority level, it will be able to consume CPU again immediately. See also **FIFO** and **sporadic**.

#### **RTOS**

Realtime operating system.

### runtime loading

The process whereby a program decides *while it's actually running* that it wishes to load a particular function from a library. Contrast **static linking**.

### scheduling latency

The amount of time that elapses between the point when one thread makes another thread READY and when the other thread actually gets some CPU time. Note that this latency is almost always at the control of the system designer.

Also designated as "T<sub>sl</sub>". Contrast **interrupt latency**.

#### session

A collection of process groups established for job-control purposes. Each process group is a member of a session. A process belongs to the session that its process group belongs to. A newly created process joins the session of its creator. A process can alter its session membership via *setsid()*. A session can contain multiple process groups.

#### session leader

A process whose death causes all processes within its process group to receive a SIGHUP signal.

### shell

A process that parses what you type on the command line; also known as a **command interpreter**.

#### shell script

A file that contains shell commands.

### simple command

A command line that contains a single command, usually a program that you want to run (e.g. less my file). Contrast compound command.

#### socket

A logical drive in a flash filesystem, consisting of a contiguous and homogeneous region of flash memory.

#### socket

In TCP/IP, a combination of an IP address and a port number that uniquely identifies a single network process.

### software interrupt

Similar to a hardware interrupt (see **interrupt**), except that the source of the interrupt is software.

## spilling

What happens when you try to change a file that the package filesystem manages (if you're using it): a copy of the file is transferred to the spill directory.

## sporadic

A scheduling policy whereby a thread's priority can oscillate dynamically between a "foreground" or normal priority and a "background" or low priority. A thread is given an execution **budget** of time to be consumed within a certain **replenishment** period. See also **FIFO** and **round robin**.

#### startup code

The software component that gains control after the IPL code has performed the minimum necessary amount of initialization. After gathering information about the system, the startup code transfers control to the OS.

#### static linking

The process whereby you combine your programs with the modules from the library to form a single executable that's entirely self-contained. The word "static" implies that it's not going to change — *all* the required modules are already combined into one. Contrast runtime loading.

#### superuser

The root user, which can do anything on your system. The superuser has what Windows calls administrator's rights.

## symbolic link

A special file that usually has a pathname as its data. Symbolic links are a flexible means of pathname indirection and are often used to provide multiple paths to a single file. Unlike hard links, symbolic links can cross filesystems and can also create links to directories.

### system page area

An area in the kernel that is filled by the startup code and contains information about the system (number of bytes of memory, location of serial ports, etc.) This is also called the SYSPAGE area.

#### thread

The schedulable entity under Neutrino. A thread is a flow of execution; it exists within the context of a **process**.

#### timer

A kernel object used in conjunction with time-based functions. A timer is created via *timer\_create()* and armed via *timer\_settime()*. A timer can then deliver an **event**, either periodically or on a one-shot basis.

#### timeslice

A period of time assigned to a **round-robin** scheduled thread. This period of time is small (four times the clock period in Neutrino); programs shouldn't rely on the actual value (doing so is considered bad design).

!	_IO_MSG 44, 47, 113
	_io_msg structure 113
/dev/null 22	_IO_NOTIFY 43, 108
_DEVCTL_DATA() 102	_IO_OPEN 61, 127, 143
_DEXTRA_*() 147	_IO_OPENFD 44
_DTYPE_LSTAT 76, 146	_IO_PATHCONF 43, 61, 62
_DTYPE_STAT 146	_IO_READ 17, 18, 27, 41, 43, 51, 65, 66, 76,
_FTYPE_ANY 16, 26	84, 85, 143, 144, 146
_FTYPE_MOUNT 120	_IO_SET_READ_NBYTES() 72
_FTYPE_MQUEUE 26	_IO_SET_WRITE_NBYTES() 72
_IO_CHMOD 44	IO SPACE 44
_IO_CHOWN 44, 61	IO STAT 5, 43, 79, 88, 123
_IO_CLOSE 84, 88, 117, 118	IO SYNC 45
_IO_CLOSE_DUP 17, 44	IO UNBLOCK 84, 127
_IO_CLOSE_OCB 79, 118	_IO_UTIME 44
_IO_COMBINE_FLAG 86, 123	IO WRITE 17, 43, 51, 76, 86
_IO_CONNECT 17, 27, 41, 117, 127, 143	
_IO_CONNECT_COMBINE 40, 88	_IO_XTYPE_NONE 75
_IO_CONNECT_COMBINE_CLOSE 40, 88	O_XTYPE_OFFSET 75, 76
_IO_CONNECT_LINK 40	IO XTYPE READCOND 78
_IO_CONNECT_MKNOD 40	IOFUNC NFUNCS 62
_IO_CONNECT_MOUNT 41	IOMGR PRIVATE BASE 113
_IO_CONNECT_OPEN 40	IOMGR PRIVATE MAX 113
_IO_CONNECT_READLINK 40	MOUNT OCB 120
_IO_CONNECT_RENAME 40	MOUNT SPEC 120
_IO_CONNECT_UNLINK 40	_msg_info 46
_IO_DEVCTL 43, 47, 88, 98–100	NOTIFY_COND_INPUT 105
_IO_DUP 44, 117, 118	NOTIFY_COND_OBAND 105
_IO_FDINFO 44	NOTIFY_COND_OUTPUT 105
_IO_FLAG_RD 57	NOTIFY_CONDE_ERR 105
_IO_FLAG_WR 57	_NOTIFY_CONDE_HUP 105
_IO_LOCK 44	NOTIFY_CONDE_NVAL 105
_IO_LSEEK 44, 84–86, 124	NOTIFY CONDE PRI 105
_IO_MAX 34	NOTIFY CONDE RDBAND 105
_IO_MMAP 44	NOTIFY_CONDE_RDNORM 105

May 10, 2010 Index **165** 

_NOTIFY_CONDE_WRBAND 105	chsize() 44
NOTIFY_CONDE_WRNORM 105	clients
NTO CHF UNBLOCK 127	blocking 73
NTO_MI_ENDIAN_DIFF 46	nonblocking 73
NTO MI UNBLOCK REQ 128	replying to 71
NTO SIDE CHANNEL 17	unblocking 127
RESMGR DEFAULT 75, 102	close() 43–45, 84, 88, 117
RESMGR ERRNO() macro (deprecated) 71	combine messages 83
RESMGR FLAG BEFORE 26	connect functions table 24
RESMGR FLAG DIR 120, 143	connect messages 39
_RESMGR_FLAG_FTYPEONLY 120	ConnectAttach()
RESMGR NOREPLY 73, 128	side channels 17
don't return it from anio notify handler	connection ID (coid) 17, 30, 36
106	connections 31
RESMGR NPARTS() 72	control messages 113
_RESMGR_PTR() 72	conventions
RESMGR PULSE ALLOC 117	typographical xi
RESMGR STATUS() 124	counters
_RESMOR_STATOS() 124	in attribute structure of resource managers
	59
	cross-endian support 46
A	cross-endrair support 40
access() 87, 88	
architecture 19	D
atomic operations 83	_
attribute structure 57	database example 10
counters 59	devctl() 43, 45, 47, 88, 98
extending 91	device drivers 3
time members 60	device resource managers 5
	differences from filesystem resource
	managers 142
	directory information, returning 76
В	dirent extra stat 146
	dispatch block() 26, 34
blocking	dispatch context, reallocating 27
clients 73	dispatch context alloc() 34
	dispatch create() 24, 33
	dispatch handler() 34
	dispatch t 24
C	dispatch layer 24
Cl. 1C + () 127	context 34
ChannelCreate() 127	reallocated by dispatch block() 27
channels 31	dup() 44, 45, 117
side 17	dup2() 44
<i>chmod()</i> 22, 44, 45, 60	$uup \omega()$ $\tau \tau$
<i>chown()</i> 22, 44, 45, 60	

**166** Index May 10, 2010

E	G
EAGAIN 73	GPS devices 8
EINTR 128	
endian-ness 46	
ENOENT 121	
ENOSYS 22, 47, 75, 76, 114, 121	Н
EOF 51	
EOK 85	helper functions 49
errno values, returning 71	
examples	
database 10	1
GPS devices 8	•
handling_IO_DEVCTL messages 99	I/O
I2C (Inter-Integrated Circuit) driver 11	functions table 24
in the IDE 22	messages 41
multithreaded 27	I2C (Inter-Integrated Circuit) driver 11
robot arm 8	IDE, sample resource manager in 22
single-threaded 23	interprocess communication (IPC) 30
Transparent Distributed Processing (Qnet)	InterruptAttach() 129
statistics 7	InterruptAttachEvent() 129
extended type information 75	InterruptWait() 129, 131
	io close handler 88
	io devetl handler 88
_	io lock och handler 87, 88
F	io lseek t 124
	io lseek handler 87, 124
fchmod() 44	io mount extra t 119
fchown() 44	io notify handler 103, 104
fclose() 44	don't return RESMGR NOREPLY from
fcntl() 44	106
fdatasync() 45	<i>io open</i> handler 17, 48, 87, 88, 127, 143
fgetc() 65	<i>io read</i> handler 17–19, 65, 66, 142, 146
filesystem resource managers 5	io read structure 65
differences from device resource managers	io stat t 123
142	io stat handler 88, 123
flock() 44	io unlock och handler 87, 88
fopen() 40	<i>io write</i> handler 17, 68, 69, 87, 109, 142
fork() 44	ioctl() 43
fpathconf() 43, 45	iofdinfo() 44
fread() 65	iofunc *() shared library 45
fseek() 44, 45, 124	IOFUNC ATTR ATIME 58,79
fstat() 43, 45, 60, 84, 88, 123	IOFUNC ATTR CTIME 58, 79
fsync() 45	IOFUNC ATTR DIRTY MODE 58
ftruncate() 44	IOFUNC ATTR DIRTY MTIME 58
fwrite() 43	IOFUNC ATTR DIRTY NLINK 58

May 10, 2010 Index **167** 

OFUNC ATTR DIRTY OWNER 58	<i>iofunc stat()</i> 50, 123
IOFUNC ATTR DIRTY RDEV 58	iofunc_time_update() 50, 60, 79, 123
IOFUNC ATTR DIRTY SIZE 58	iofunc unblock default() 128
IOFUNC ATTR DIRTY TIME 58, 79	iofunc unblock() 128
iofunc attr init() 33,59	iofunc write default() 51
iofunc attr lock() 50, 59, 87	iofunc write verify() 51
IOFUNC ATTR MTIME 79	indicating nonblocking 73
IOFUNC ATTR PRIVATE 58	ionotify() 43
IOFUNC ATTR T 91	IOV 146
iofunc attr t 57	IOV array
extending 91	returning data with 71
iofunc attr unlock() 50, 59, 87	size of, setting 24
iofunc check access() 144	IPC (interprocess communication) 6, 30
iofunc chmod default() 49,50	11 0 (morprocess communication) 0,000
iofunc chmod() 50	
iofunc chown default() 60	
iofunc func init() 25, 33, 40, 42	L
iofunc lock default() 59	
iofunc lock() 59	layers 19
iofunc lseek default() 124	link() 40
iofunc lseek() 124	lockf() 44, 45
iofunc mmap default() 59	lseek() 22, 44, 45, 57, 60, 83, 85, 86, 124
iofunc_mmap() 59	<i>lstat()</i> 43, 123, 146
IOFUNC MOUNT 32BIT 61	ltrunc() 44
IOFUNC MOUNT FLAGS PRIVATE 61	
IOFUNC MOUNT T 93	
iofunc mount t 61	
extending 93	M
iofunc och attach() 50, 59	TD 112
iofunc och calloc() 91	manager IDs 113
iofunc och detach() 59	message_attach() 34, 97, 115
iofunc och free() 91	messages
IOFUNC OCB PRIVILEGED 57	associating with a handler 115
IOFUNC OCB T 91	combine 83
iofunc ocb t 56	connect 39
extending 91	I/O 41
iofunc open default() 48, 50, 60	types 34, 39, 47
iofunc open() 50	mkdir() 40
IOFUNC PC CHOWN RESTRICTED 61	mkfifo() 40
IOFUNC PC LINK DIR 61	mknod() 40, 58
IOFUNC PC NO TRUNC 61	mmap_device_io() 44
IOFUNC PC SYNC IO 61	mmap_device_memory() 44
iofunc read default() 51	mmap() 44, 45
iofunc_read_uejaun() 51 iofunc_read_verify() 51	mount_parse_generic_args() 122
indicating nonblocking 73	mount structure 61
iofunc stat default() 49, 50, 123	extending 93
-5/mic_5/m_ucjumi() +7, 50, 125	mount() 41, 118

**168** Index May 10, 2010

MsgDeliverEvent() 117 MsgInfo() 128 MsgRead() 87 MsgReceive() 114, 117, 127, 130, 137	checking for availability 105 handling messages 113
MsgReply() 30, 74, 127 MsgReplyv() 74	Р
MsgSend() 30, 36, 44, 69, 127  MsgSendPulse() 117  MsgWrite() 87  multithreaded resource managers 22, 27, 135  munmap() 44  mutex 83  MY_DEVCTL_GETVAL 100  MY_DEVCTL_SETGET 100  MY_DEVCTL_SETVAL 100	pathconf() 43, 45 pathname can be taken over by resource manager prefix 142 pathname delimiter in QNX documentation xii POOL_FLAG_EXIT_SELF 30, 138 POOL_FLAG_USE_SELF 138 pread(), pread64() 75, 77 privileged processes 57 process ID (pid) 30
N	<pre>procnto 3 pulse_attach() 36, 97, 115, 117 pulses</pre>
native IPC messaging 6 network transparency 6 nonblocking, indicating 73	and library 114 associating with a handler 115 why used by resource managers 114 pwrite(), pwrite64() 75, 77
0	Q
O_DSYNC 61 O_NONBLOCK 73 O_RDONLY 57 O_RDWR 57	Qnet statistics 7 QNX 4 interprocess communication 30
O_RSYNC 61 O_SYNC 61	R
O_WRONLY 57  OCB (Open Control Block) 56 cleaning up 43 extending 91 locking and unlocking 44 multiple open(), dup(), and close() calls 44, 45	read() 18, 22, 26, 41, 43, 60, 65, 83, 127 nonblocking 73 readblock() 83–85, 87 readcond() 76, 78 readdir() 43, 65, 146 readlink() 40 receive buffer, specifying the minimum size 24
open() 22, 26, 36, 39–41, 43, 45, 55, 84, 87, 88, 117 performed by root 57	rename() 40 REPLY-blocked 127
openfd() 44 out-of-band (OOB) data	resmgr_attach() 24, 33, 39, 91, 97, 141–143 copies the pointer to the table of handler functions 40, 42

May 10, 2010 Index **169** 

7

IOV array 71 time members resmgr attr t 24, 46, 97in attribute structure of resource managers 39, 119, 127 resmgr connect funcs t resmgr context t Transparent Distributed Processing statistics RESMGR FLAG ATTACH LOCAL typographical conventions xi RESMGR\_FLAG\_ATTACH\_OTHERFUNC 46, 47, 97 RESMGR\_FLAG\_CROSS\_ENDIAN U RESMGR FLAG NO DEFAULT FUNC (not implemented) 46 unblocking 127 41, 127 resmgr io funcs t unlink() 40 resmgr msg again() utime() 44, 45 70, 77, 87, 102, 111 resmgr msgread() resmgr msgwrite() 73, 74, 87 resmgr\_msgwritev() 74 resmgr open bind() 127 V *rewinddir()* 44, 124 robot arm example 8 vfork() 44

# S

sample code 22

select() 43

Send() (QNX 4) 30

SEND-blocked 127

side channels 17

SIGEV\_INTR 128, 131

signals 127

causing dispatch\_block() to returnNULL 27

sopen() 40

spawn\*() 44

stat structure 123

stat() 43, 45, 84, 87, 88, 123, 146

stat.h 61

strtok() 144

support, technical xiii

## Т

technical support xiii
THREAD\_POOL\_PARAM\_T 29
threads 22, 27, 137
locking the attribute structure 59

# W

write() 22, 26, 43, 60, 83, 86 nonblocking 73 writeblock() 86

# X

xtype 75

**170** Index May 10, 2010