QNX® Software Development Platform

High Availability Framework Developer's Guide

For QNX[®] Neutrino[®] 6.4.0

 $\ @$ 2001–2009, QNX Software Systems GmbH & Co. KG. All rights reserved.

Published under license by:

QNX Software Systems International Corporation

175 Terence Matthews Crescent Kanata, Ontario K2M 1W8 Canada Voice: +1 613 591-0931

Fax: +1 613 591-3579
Email: info@qnx.com
Web: http://www.qnx.com/
Electronic edition published 2009.

QNX, Neutrino, Photon, Photon microGUI, Momentics, and Aviage are trademarks, registered in certain jurisdictions, of QNX Software Systems GmbH & Co. KG. and are used under license by QNX Software Systems International Corporation. All other trademarks belong to their respective owners.

Note to Windows users x Technical support x 1 Introduction 1 Where's the problem? 3 A software foundation for HA 3 2 What's in the High Availability Framework What you get 7 3 The QNX Approach to HA 9 The reset "solution" 11 Traditional RTOS architecture 11 Modularity means granularity 12 Intrinsic HA 12 4 Using the High Availability Manager 15 Introduction 17 HAM hierarchy 17 Entities 18 Conditions 19 Actions 20 Action Fail actions 22 Multistaged recovery 23 State of the HAM 23	
 Introduction 1 Where's the problem? 3 A software foundation for HA 3 What's in the High Availability Framework What you get 7 The QNX Approach to HA 9 The reset "solution" 11 Traditional RTOS architecture 11 Modularity means granularity 12 Intrinsic HA 12 Using the High Availability Manager 15 Introduction 17 HAM hierarchy 17 Entities 18 Conditions 19 Actions 20 Action Fail actions 22 Multistaged recovery 23 	
Where's the problem? 3 A software foundation for HA 3 What's in the High Availability Framework What you get 7 The QNX Approach to HA 9 The reset "solution" 11 Traditional RTOS architecture 11 Modularity means granularity 12 Intrinsic HA 12 Using the High Availability Manager 15 Introduction 17 HAM hierarchy 17 Entities 18 Conditions 19 Actions 20 Action Fail actions 22 Multistaged recovery 23	
2 What's in the High Availability Framework What you get 7 3 The QNX Approach to HA 9 The reset "solution" 11 Traditional RTOS architecture 11 Modularity means granularity 12 Intrinsic HA 12 4 Using the High Availability Manager 15 Introduction 17 HAM hierarchy 17 Entities 18 Conditions 19 Actions 20 Action Fail actions 22 Multistaged recovery 23	
 What's in the High Availability Framework What you get 7 The QNX Approach to HA 9 The reset "solution" 11 Traditional RTOS architecture 11 Modularity means granularity 12 Intrinsic HA 12 Using the High Availability Manager 15 Introduction 17 HAM hierarchy 17 Entities 18 Conditions 19 Actions 20 Action Fail actions 22 Multistaged recovery 23 	
What you get 7 The QNX Approach to HA 9 The reset "solution" 11 Traditional RTOS architecture 11 Modularity means granularity 12 Intrinsic HA 12 Using the High Availability Manager 15 Introduction 17 HAM hierarchy 17 Entities 18 Conditions 19 Actions 20 Action Fail actions 22 Multistaged recovery 23	
The QNX Approach to HA The reset "solution" 11 Traditional RTOS architecture 11 Modularity means granularity 12 Intrinsic HA 12 Using the High Availability Manager 15 Introduction 17 HAM hierarchy 17 Entities 18 Conditions 19 Actions 20 Action Fail actions 22 Multistaged recovery 23	? 5
The reset "solution" 11 Traditional RTOS architecture 11 Modularity means granularity 12 Intrinsic HA 12 4 Using the High Availability Manager 15 Introduction 17 HAM hierarchy 17 Entities 18 Conditions 19 Actions 20 Action Fail actions 22 Multistaged recovery 23	
Traditional RTOS architecture 11 Modularity means granularity 12 Intrinsic HA 12 4 Using the High Availability Manager 15 Introduction 17 HAM hierarchy 17 Entities 18 Conditions 19 Actions 20 Action Fail actions 22 Multistaged recovery 23	
Modularity means granularity 12 Intrinsic HA 12 4 Using the High Availability Manager 15 Introduction 17 HAM hierarchy 17 Entities 18 Conditions 19 Actions 20 Action Fail actions 22 Multistaged recovery 23	
Intrinsic HA 12 4 Using the High Availability Manager 15 Introduction 17 HAM hierarchy 17 Entities 18 Conditions 19 Actions 20 Action Fail actions 22 Multistaged recovery 23	
4 Using the High Availability Manager Introduction 17 HAM hierarchy 17 Entities 18 Conditions 19 Actions 20 Action Fail actions 22 Multistaged recovery 23	
Introduction 17 HAM hierarchy 17 Entities 18 Conditions 19 Actions 20 Action Fail actions 22 Multistaged recovery 23	
Entities 18 Conditions 19 Actions 20 Action Fail actions 22 Multistaged recovery 23	
Entities 18 Conditions 19 Actions 20 Action Fail actions 22 Multistaged recovery 23	
Actions 20 Action Fail actions 22 Multistaged recovery 23	
Action Fail actions 22 Multistaged recovery 23	
Multistaged recovery 23	
·	
State of the HAM 23	
Example of the view shown in /proc/ham 24	
HAM API 26	
Connect/disconnect functions 26	
Attach/detach functions 27	
Entity functions 30	

vii

About This Guide

What you'll find in this guide

April 20, 2009 Contents iii

```
Condition functions
                          30
                       33
   Action functions
   Action fail functions
                           35
   Functions to operate on handles
                                     37
A client example
                    37
Starting and stopping a HAM
                               40
   Stopping a HAM
                       41
   Control functions
                        41
   Verbosity control
                       42
   Publishing autonomously detected conditions
                                                  42
   Publish state transitions
                             43
   Publish other conditions
                              43
   Subscribing to autonomously published conditions
                                                      43
   Trigger based on state transitions
   Trigger based on specific published condition
                                                  44
Using the Client Recovery Library
                                                   45
Introduction
               47
MsgSend*() functions
                        47
Other covers and convenience functions
                                         48
   HA-awareness functions
                              48
   I/O covers
   Convenience functions
                             50
A simple example
                               52
State-reconstruction example
HAM API Reference
                               55
ham action control()
ham action execute()
ham_action_fail_execute()
                             65
ham action fail log()
                          67
                                                                       69
ham action fail notify pulse(), ham action fail notify pulse node()
                                                                         71
ham action fail notify signal(), ham action fail notify signal node()
ham action fail waitfor()
                             73
ham_action_handle(), ham_action_handle_node()
                                                    75
ham action handle free()
                                   79
ham action heartbeat healthy()
ham action log()
                     81
                                                              83
ham action notify pulse(), ham action notify pulse node()
ham_action_notify_signal(), ham_action_notify_signal_node()
                                                                86
ham action remove()
```

5

6

iV Contents April 20, 2009

7

ha dup()

ha fclose()

ha fopen()

ha reopen()

160

ha open(), ha open64()

ha ReConnectAttach()

162

169

```
ham action restart()
                      91
ham action waitfor()
                       94
                                 96
ham attach(), ham attach node()
ham attach self()
                    99
ham condition()
ham entity control()
                     104
ham condition handle(), ham condition handle node()
                                                     106
ham condition handle free()
                            108
ham condition raise()
ham condition remove()
ham condition state() 114
ham connect(), ham connect nd(), ham connect node()
                                                     117
ham detach() 119
ham detach name(), ham detach name node()
ham detach self() 123
ham disconnect(), ham disconnect nd(), ham disconnect node()
ham entity(), ham entity node() 127
ham entity condition raise()
                             129
ham entity condition state()
                            131
ham entity control() 133
ham entity handle(), ham entity handle node()
ham entity handle free()
                         137
ham heartbeat() 139
ham stop(), ham stop nd(), ham stop node()
ham verbose() 143
Client Recovery Library Reference 145
ha attach()
             148
ha close()
            150
ha connection ctrl() 151
ha ConnectAttach(), ha ConnectAttach r()
ha_ConnectDetach(), ha_ConnectDetach_r()
                                          155
ha creat(), ha creat64() 157
ha detach()
            159
```

April 20, 2009 Contents V

165

167

A Examples 171

Simple restart 173

Compound restart 174

Death/condition notification 175

Heartbeating clients (liveness detection) 178

The process is made to heartbeat 182

Process starvation 183

Thread 2 is made to heartbeat 186

Glossary 189

Index 193

vi Contents April 20, 2009

About This Guide

April 20, 2009 About This Guide **vii**

What you'll find in this guide

The QNX High Availability Framework *Developer's Guide* describes how to build robust high-availability software running on the QNX Neutrino realtime operating system.

The following table may help you find information quickly in this guide:

If you want to:	Go to:
Find the introduction	Introduction
Learn about the main components	What's in the High Availability Framework?
Understand the benefits of a software-oriented approach to High Availability	The QNX Approach to HA
Get an overview of the HAM and Guardian "watchdogs"	Using the High Availability Manager
Find out which standard QNX library functions have HA covers	Using the Client Recovery Library
Look up a convenience function (e.g. $ha_recover()$)	Client Recovery Library Reference
Look up a HAM API function (e.g. ham_attach())	HAM API Reference
See sample code listings for handling various HA scenarios	The Examples appendix
Look up a special term used in this guide	Glossary



For an overview of the QNX Neutrino RTOS, see the *System Architecture* manual in the OS documentation set.

Typographical conventions

Throughout this manual, we use certain typographical conventions to distinguish technical terms. In general, the conventions we use conform to those found in IEEE POSIX publications. The following table summarizes our conventions:

Reference	Example
Code examples	<pre>if(stream == NULL)</pre>
Command options	-1R
Commands	make
Environment variables	PATH

continued...

April 20, 2009 About This Guide ix

Reference	Example
File and pathnames	/dev/null
Function names	exit()
Keyboard chords	Ctrl-Alt-Delete
Keyboard input	something you type
Keyboard keys	Enter
Program output	login:
Programming constants	NULL
Programming data types	unsigned short
Programming literals	0xFF, "message string"
Variable names	stdin
User-interface components	Cancel

We use an arrow (\rightarrow) in directions for accessing menu items, like this:

You'll find the **Other...** menu item under **Perspective** \rightarrow **Show View**.

We use notes, cautions, and warnings to highlight important messages:



Notes point out something important or useful.



CAUTION: Cautions tell you about commands or procedures that may have unwanted or undesirable side effects.



WARNING: Warnings tell you about commands or procedures that could be dangerous to your files, your hardware, or even yourself.

Note to Windows users

In our documentation, we use a forward slash (/) as a delimiter in *all* pathnames, including those pointing to Windows files.

We also generally follow POSIX/UNIX filesystem conventions.

Technical support

To obtain technical support for any QNX product, visit the **Support** + **Services** area on our website (www.qnx.com). You'll find a wide range of support options, including community forums.

X About This Guide April 20, 2009

Chapter 1

Introduction

In this chapter...

Where's the problem? 3 A software foundation for HA

April 20, 2009 Chapter 1 ● Introduction 1

Where's the problem?

The ideal High Availability (HA) system is one that remains up and running *continuously*, uninterrupted for an indefinite period of time. In practical terms, HA systems strive for "five nines" availability, a metric referring to the percentage of uptime a system can sustain in a year — 99.999% uptime amounts to about five minutes downtime per year.

Obviously, systems fail. For one reason or another, systems aren't as available for use as their users and designers would like them to be. Of all the possible causes of system failure — power outages, component breakdowns, operator errors, software faults, etc. — the lion's share belongs to software faults.

Many HA systems try to address the problem of system failure by turning to *hardware* solutions such as:

- rugged hardware
- redundant systems/components
- hot-swap CompactPCI components
- clustering

But if so many system crashes are caused by *software* faults, then throwing more hardware at the problem may not solve it at all. What if the system's memory state isn't properly restored after recovery? What if yours is an HA system (e.g. a consumer appliance) where redundant hardware simply isn't an option? Or what if your particular HA system is based on a custom chassis for which a PCI-based HA "solution" would be pointless?

A software foundation for HA

Most system designers wouldn't think of using a "standard" desktop PC as the foundation for an effective HA system. Apart from the reliability issues arising from the hardware itself, the *underlying software* isn't meant for continuous operation. When desktop operating systems and applications need to be patched or upgraded, most users expect to reboot their machines. Unfortunately, they might also have become accustomed to rebooting as part of their daily operations!

But in an HA system, various software components may need to be upgraded *on a live system*. Individual modules should be readily accessible for analysis and repair, without jeopardizing the availability of the system itself.

In our view, effective HA systems must address the main problem — software faults — through a modular approach to system design and implementation. Based on a microkernel architecture, the QNX Neutrino RTOS not only helps isolate problem areas throughout the system, but also ensures complete independence of system components. Each component enjoys full MMU-based memory protection. And system-level modules such as device drivers benefit from the same isolation and protection as any other process. You can start and stop a driver, networking protocol,

filesystem, etc., without touching the kernel. A microkernel RTOS inherently keeps the *single point of failure* (SPOF) number as low as possible.

QNX High Availability Framework provides a reliable software infrastructure on which to build highly effective HA systems. In addition to support for hardware-oriented HA solutions (e.g. CompactPCI as well as custom hardware), you also have the tools to isolate and even repair software faults before they occur throughout your entire system.

For example, suppose a device driver crashes because it tried to write to memory that was allocated to another process. The MMU will alert the QNX Neutrino microkernel, which in turn will alert the High Availability Manager (HAM). A HAM can then restart the driver. In addition, a dump file can be generated for postmortem analysis.

Viewing this dump file, you can immediately determine which line of code is the culprit and then prepare a fix that you can download to all other units in the field before they run into the same bug. With a conventional OS, a rogue driver may run for days before the system becomes corrupted enough to fail — and then it's too late to identify the problem, let alone dynamically install an upgraded driver!

A HAM can perform a multistage recovery, executing several actions in a certain order. This technique is useful whenever strict dependencies exist between various actions in a sequence, so that the system can restore itself to the state it was in before a failure.

Equipped with the QNX Neutrino RTOS itself, as well as the special tools and API in the High Availability Framework, you should be able to anticipate the kinds of problems that are likely to happen, isolate them, and then plan accordingly. In other words, assuming that failure will occur, you can now design for it and build systems that can recover intelligently.

Chapter 1 ● Introduction April 20, 2009

What's in the High Availability Framework?

In this chapter...

What you get

What you get

QNX High Availability Framework consists of the following main components:

QNX Neutrino realtime operating system

We're not just trying to be thorough by listing the OS itself here! And it's first in the list for good reason — the QNX Neutrino microkernel architecture inherently provides a robust environment for building highly reliable applications. Many of the particular features required in an HA application — system stability, isolation of software modules, dynamic upgrading of software components, etc. — are already included in the OS.

The QNX Neutrino microkernel provides system-wide stability by offering full memory protection to all processes. And there's very little code running in kernel mode that could cause the microkernel itself to fail. All individual processes, whether applications or OS services — including device drivers — can be started and stopped dynamically, without jeopardizing system uptime.

For more on the suitability of the QNX Neutrino RTOS for HA, see the next chapter in this guide.

High Availability Manager (HAM)

A HAM is a "smart watchdog" — a highly resilient manager process that can monitor your system and perform multistage recovery whenever system services or processes fail or no longer respond.

As a self-monitoring manager, a HAM is resilient to internal failures. If, for whatever reason, the HAM itself is stopped abnormally, it can immediately and completely *reconstruct its own state* by handing over to a mirror process called the Guardian.

For details on the HAM, see the chapter Using the High Availability Manager in this guide.

HAM API

The HAM API library of more than 35 ham_*() functions gives you a simple mechanism to talk to a HAM. This API is implemented as a thread-safe library you can link against.

You use the API to interact with a HAM in order to begin monitoring processes and to set up the various conditions (e.g. the death of a server) that will trigger certain recovery actions.

For descriptions of the functions in the HAM API, see the HAM API Reference chapter in this guide.

Client Recovery Library

The client recovery library provides a drop-in enhancement solution for many standard libe I/O operations. The HA library's cover functions

provide automatic recovery mechanisms for failed connections that can be recovered from in an HA scenario.

For descriptions of the client library functions, see the Client Recovery Library Reference chapter in this guide.

Examples

You'll find several sample code listings (and source) that illustrate such tasks as restarting, heartbeating, and more. Since the examples deal with some typical fault-recovery scenarios, you may be able to easily tailor this source for your HA applications.

For details, see the Examples appendix in this guide.

Chapter 3

The QNX Approach to HA

In this chapter...

The reset "solution" Modularity means granularity 12

The reset "solution"

Traditional approaches to dealing with software malfunctions have included such mechanisms as:

Hardware/software watchdog

This is a piece of hardware that's known to be fault-free. It triggers code to check the sanity of the system. This sanity check usually involves examining a set of registers that are continuously updated by properly functioning software components. But when one of the components isn't working properly, the system is reset.

Manual operator intervention

Many systems aren't designed to include an automatic fault detection, but rely instead on a manual approach — an operator who monitors the health of the system. If the system state is deemed invalid, then the operator takes the appropriate action, which usually includes a system reset.

Memory constraint faulting

Several operating systems (and hardware platforms) include features that let you generate a fault when a program accesses memory that isn't yours. Once this occurs, the program becomes unreliable. With most realtime executives, the result is that the system must be reset in order to return to a sane operating state.

All of these approaches are relatively successful at detecting a software fault. But the net result of this detection, especially when faced with a multitude of faults in several potentially separate software components, is the rather drastic action of a system reset.

Traditional RTOS architecture

One of the principal reasons for this lack of graceful recovery is the monolithic architecture of a traditional realtime embedded system. At the heart of most of these systems lies a *realtime executive* — a single memory image consisting of the RTOS itself and often numerous tasks.

Since all tasks — including critical system-level services — share the very same address space, when the integrity of one task is called into question, the integrity of the entire system is at risk. If a single component such as a device driver fails, the RTOS itself could fail. In HA terms, each software component becomes a single point of failure (SPOF).

The only sure recovery mechanism in such an environment is to reset the system and start from scratch.

Such realtime systems present a very low granularity of fault recovery, making the HA procedure of planning for and dealing with failure seemingly straightforward (a system reset), yet often very costly (in terms of downtime, system restoration, etc.). For some embedded applications, a reset may involve a specialized, time-consuming procedure in order to restore the system to full operation in the field.

Modularity means granularity

What is really needed here is a more modular approach. System architects often de-couple and modularize their systems from a design/implementation point of view. Ideally, these modules would be the focus not only of the design, but also of the fault-recovery process, so that if one module malfunctions, then only that module would require a reset — the integrity of the rest of the system would remain intact. In other words, that particular module wouldn't be a SPOF.

This modular approach would also help us address the fact that the mean time to repair (MTTR) for a system reboot is a magnitude larger than the MTTR for replacing a single running task.

This type of increased granularity on the recovery of individual tasks is precisely what the QNX Neutrino microkernel offers. The architecture of the QNX Neutrino realtime operating system itself provides so many intrinsic HA features that many QNX users take them for granted and often design recoverability into their systems without giving it a second thought.

Let's look briefly at the key features of the QNX Neutrino RTOS and see how system designers can easily make use of these builtin HA-ready features to build effective HA systems.

Intrinsic HA

Three key factors of the QNX Neutrino architecture contribute directly to intrinsic HA:

QNX Neutrino microkernel

Only a few essential services are provided (e.g. message passing and realtime scheduling). The result is a robust, dependable system — fewer lines of code in the kernel reduce the probability of OS errors.

Also, the kernel's fixed-priority preemptive scheduler ensures a *predictable* system — there are fewer HA software paths to analyze and deal with separately.

POSIX process model

This means full MMU-supported memory protection between system processes, making it easy to isolate and protect individual tasks.

The process model also offers *dynamic* process creation and destruction, which is especially important for HA systems, because you can more readily perform fault detection, recovery, and live upgrades in the field.

The POSIX API provides a standard programming environment and can help achieve system simplification, validation, and verification.

In addition, the process model lets you easily monitor external tasks, which not only aids in fault detection and diagnosis, but also in service distribution.

Message passing

In the QNX Neutrino realtime operating system, all interprocess communication happens through standard message passing. For HA systems, this facilitates task decoupling, task simplification, and service distribution.

Local and network-remote messaging is *identical* and practically transparent for the application. In a network-distributed HA system, the QNX message-based approach fosters replication, redundancy, and system simplification.

These represent some of the more prominent HA-oriented features that become readily apparent when the QNX Neutrino RTOS forms the basis of an HA design.

Chapter 4

Using the High Availability Manager

In this chapter...

Introduction 17
HAM hierarchy 17
State of the HAM 23
HAM API 26
A client example 37
Starting and stopping a HAM 40

Introduction

The High Availability Manager (HAM) provides a mechanism for monitoring processes and services on your system. The goal is to provide a resilient manager (or "smart watchdog") that can perform multistage recovery when system services or processes fail, do not respond, or provide an unacceptable level of service. The HA framework, including the HAM, uses a simple publish/subscribe mechanism to communicate interesting system events between interested components in the system. By automatically integrating into the native networking mechanism (QNET), this framework transparently extends a local monitoring mechanism to a network.

The HAM acts as a conduit through which the rest of the system can both obtain and deliver information regarding the state of the system as a whole. The system could be a single node or a collection of nodes connected via QNET. The HAM can monitor specific processes and can control the behavior of the system when specific components fail and need to be recovered. The HAM also permits external detectors to report interesting events to the system, and can associate actions with the occurrence of these events.

In many HA systems, single points of failure (SPOFs) must be identified and dealt with carefully. Since the HAM maintains information about the health of the system and also provides the basic recovery framework, the HAM itself must never become a SPOF.

As a self-monitoring manager, the HAM is resilient to internal failures. If, for whatever reason, the HAM itself is stopped abnormally, it can immediately and completely reconstruct its own state. A mirror process called the Guardian perpetually stands ready and waiting to take over the HAM's role. Since all state information is maintained in shared memory, the Guardian can assume the exact same state that the original HAM was in before the failure.

But what happens if the Guardian terminates abnormally? The Guardian (now the new HAM) creates a new Guardian for itself *before taking the place of the original HAM*. Practically speaking, therefore, one can't exist without the other.

Since the HAM/Guardian pair monitor each other, the failure of either one can be completely recovered from. The only way to stop HAM is to explicitly instruct it to terminate the Guardian and then to terminate itself.

HAM hierarchy

HAM consists of three main components:

- Entities
- Conditions
- Actions

Entities

Entities are the fundamental units of observation/monitoring in the system. Essentially, an entity is a process (pid). As processes, all entities are uniquely identifiable by their pids. Associated with each entity is a symbolic name that can be used to refer to that specific entity. Again, the names associated with entities are unique across the system. Managers are currently associated with a node, so uniqueness rules apply to a node. As we'll see later, this uniqueness requirement is very similar to the naming scheme used in a hierarchical filesystem.

There are three basic entity types:

- Self-attached
- Externally attached
- Global

Self-attached entities

These are processes that explicitly choose to be HA-aware. These processes use the <code>ham_attach_self()</code> and <code>ham_detach_self()</code> functions to connect to and disconnect from a HAM. Self-attached processes are compiled against the HAM API library, and the lifetime of the monitoring is from the time of the <code>ham_attach_self()</code> call to the time of the <code>ham_detach_self()</code> call.

Self-attached entities can also choose to send heartbeats to a HAM, which will then monitor them for failure. Since arbitrary processes on the system aren't necessarily "trackable" for failure (i.e. they're not in session 1, not child processes, etc.), you can use this heartbeat mechanism to monitor such processes.

Self-attached entities can, on their own, decide at exactly what point in their lifespan they want to be monitored, what conditions they want acted upon, and when they want to stop the monitoring. In other words, this is a situation where a process says, "Do the following if I die."

Externally attached entities

These are generic processes in the system that are being monitored. These could be arbitrary daemons/service providers whose health is deemed important. This method is useful for the case where Process A says, "Tell me when Process B dies" but Process B needn't know about this at all.

Global entity

A global entity is really just a place holder for matching any entity. It can be used to associate actions that will be triggered when an interesting event is detected with respect to any entity on the system. The term global refers to the set of entities being monitored in the system. This permits one to say things like "when any process dies

or when any process misses a heartbeat, do the following". The global entity is never added or removed, but is only referred to. Conditions can be added/removed to the global entity as usual, and actions added/removed from any of the conditions.

The dumper process is normally used to obtain core images of processes that terminate abnormally as a result of performing any illegal operations. A HAM receives notification of such terminations from dumper. In addition the HAM also receives notification, from the system, of the termination of any process that is in session 1. This includes daemon processes that call $procmgr_daemon()$, thereby detaching themselves from their controlling terminal.

Conditions

Conditions are associated with entities. These conditions represent the state of the entity. Here are some examples of conditions:

Condition	Description
CONDDEATH	The entity has died.
CONDABNORMALDEATH	The entity has died an abnormal death. This condition is triggered whenever an entity dies by a mechanism that results in the generation of a core file (see dumper in the <i>Utilities Reference</i> for details).
CONDDETACH	The entity that was being monitored is detaching. This ends HAM's monitoring of that entity.
CONDATTACH	An entity for whom a place holder was previously created (someone has subscribed to events relating to this entity), has joined the system. This is also the start of the monitoring of the entity by a HAM.
CONDHBEATMISSEDHIGH	The entity missed sending a heartbeat message specified for a condition of "high" severity.
CONDHBEATMISSEDLOW	The entity missed sending a heartbeat message specified for a condition of "low" severity.
CONDRESTART	The entity was restarted. This condition is true <i>after</i> the entity is successfully restarted.
CONDRAISE	An externally detected condition is reported to a HAM. Subscribers can associate actions with these externally detected conditions.
CONDSTATE	An entity reports a state transition to a HAM. Subscribers can associate actions with specific state transitions.

continued...

Condition	Description
CONDANY	This condition type matches any condition type. It can be used to associate the same actions with one of many conditions.

The conditions described above with the exception of CONDSTATE, CONDRAISE and CONDANY are automatically detected and/or triggered by a HAM (i.e. the HAM is the publisher of the conditions). The CONDSTATE and CONDRAISE conditions are published to a HAM by external detectors. For all conditions, subscribers can associate with lists of actions that will be performed in sequence when the condition is triggered. Both the CONDSTATE and CONDRAISE conditions provide filtering capabilities so the subscribers can selectively associate actions with individual conditions, based on the information published.

Conditions are also associated with symbolic names, which also need to be unique within an entity.



The HAM architecture is *extensible*. Several conditions are automatically detected by a HAM. Also, by using the *Condition Raise* mechanism other components in the system can notify a HAM of interesting events in the system. These conditions can be fully customized. Also, by studying the source code, it is possible to add the capability of detecting other conditions into the HAM (e.g. low memory, high CPU utilization, low disk space, etc.) to suit your HA application.

Actions

Actions are associated with conditions. A condition can contain multiple actions. The actions are executed whenever the corresponding condition is true. Actions within a condition execute in FIFO order (the order in which they were added into the condition). Multiple conditions that are true are triggered simultaneously in an arbitrary order. Conditions specified as HCONDINDEPENDENT will execute in a separate thread of execution, in parallel with other conditions. (See the section Condition functions in this chapter.)

The HAM API includes several functions for different kinds of actions:

Action	Description
ham_action_restart()	This action restarts the entity.
ham_action_execute()	Executes an arbitrary command (e.g. to start a process).

continued...

Action	Description
ham_action_notify_pulse()	Notifies some process that this condition has occurred. This notification is sent using a specific <i>pulse</i> with a value specified by the process that wished to receive this notify message. Pulses can be delivered to remote nodes, by specifying the appropriate node specifier.
ham_action_notify_signal()	Notifies some process that this condition has occurred. This notification is sent using a specific <i>realtime signal</i> with a value specified by the process that wished to receive this notify message. Signals can be delivered to remote nodes, by specifying the appropriate node specifier.
ham_action_notify_pulse_node()	This is the same as the <code>ham_action_notify_pulse()</code> described above, except that the node name specified for the recipient of the pulse can be given using the fully qualified node name instead of the node identifier.
ham_action_notify_signal_node()	This is the same as the <code>ham_action_notify_signal()</code> described above, except that the node name specified for the recipient of the signal can be given using the fully qualified node name instead of the node identifier.
ham_action_waitfor()	This action lets you insert delays between consecutive actions in a sequence. You can also wait for certain names to appear in the namespace.
ham_action_heartbeat_healthy()	Resets the heartbeat mechanism for an entity that had previously missed sending heartbeats, and had triggered a missed heartbeat condition, but has now recovered.
ham_action_log()	This allows one to insert a customizable verbosity message into the activity log maintained by a HAM.

Actions are also associated with symbolic names, which are unique within a specific condition.



Again, the HAM architecture is extensible, so you may add your own action functions as you see fit.

Action Fail actions

When an action in a list of actions fails, one can specify an alternate list of actions that will be performed to recover from the failure of the given action. These actions are referred to as *action_fail* actions, and are associated with each individual action. The action_fail actions are essentially the same set of actions that would normally be executed with the exception of *ham_action_restart()* and *ham action heartbeat healthy()*). Here's the list of action fail actions:

Action	Description
ham_action_fail_execute()	Executes an arbitrary command (e.g. to start a process).
ham_action_fail_notify_pulse()	Notifies some process that this condition has occurred. This notification is sent using a specific pulse with a value specified by the process that wished to receive this notify message. Pulses can be delivered to remote nodes by specifying the appropriate node specifier.
ham_action_fail_notify_signal()	Notifies some process that this condition has occurred. This notification is sent using a specific realtime signal with a value specified by the process that wished to receive this notify message. Signals can be delivered to remote nodes by specifying the appropriate node specifier.
ham_action_fail_notify_pulse_node()	This is the same as the ham_action_fail_notify_pulse() described above, except that the node name specified for the recipient of the pulse can be given using the fully qualified node name instead of the node identifier.

continued...

Action	Description
ham_action_fail_notify_signal_node()	This is the same as the ham_action_fail_notify_signal() described above, except that the node name specified for the recipient of the signal can be given using the fully qualified node name instead of the node identifier.
ham_action_fail_waitfor()	This action lets you insert delays between consecutive actions in a sequence. You can also wait for certain names to appear in the namespace.
ham_action_fail_log()	This allows one to insert a customizable verbosity message into the activity log maintained by a HAM.

Multistaged recovery

This complete mechanism allows us to perform recovery of a failure of a single service or process in a multi-staged fashion.

For example, suppose you've started fs-nfs2 (the NFS filesystem) and then mounted a few directories from multiple sources. You can instruct HAM to restart fs-nfs2 upon failure, and also to remount the appropriate directories as required after restarting the NFS process. And if during the lifespan of fs-nfs2 some directories are unmounted, you can remove those particular actions from the set of actions to be performed.

As another example, suppose io-pkt* (network I/O manager) were to die. We can tell a HAM to restart it and also to load the appropriate network drivers (and maybe a few more services that essentially depend on network services in order to function).

State of the HAM

Effectively, a HAM's internal state is like a hierarchical filesystem, where entities are like directories, conditions associated with those entities are like subdirectories, and actions inside those conditions are like leaf nodes of this tree structure.

A HAM also presents this state as a read-only filesystem under /proc/ham. As a result, arbitrary processes can also view the current state (e.g. you can do ls /proc/ham).

Besides presenting a view of the state as a filesystem, for each item (entity/condition/action) a HAM can also display statistics and information relating to it in a corresponding .info file at each level in a HAM filesystem under /proc/ham.

Example of the view shown in /proc/ham

Consider the following simple example where a HAM is monitoring inetd and restarts it when it dies:

```
# ls -al /proc/ham
total 2
-r----- 1 root root 175 Aug 30 23:05 .info
dr-x---- 1 root root 1 Aug 30 23:06 inetd
```

The .info file at the highest level provides information about the HAM and the Guardian, as well as an overview of the entities and other objects in the system:

```
# cat /proc/ham/.info
Ham Pid : 10993674
Guardian Pid : 10997782
Ham Failures : 0
Guardian Failures : 0
Num Entities : 1
Num Conditions : 1
```

In this case the only entity being monitored is **inetd**, which appears as a directory at the top level under /proc/ham:

```
# ls -al /proc/ham/inetd
total 2
-r------ 1 root root 173 Aug 30 23:06 .info
dr-x----- 1 root root 1 Aug 30 23:06 death

# cat /proc/ham/inetd/.info
Path : inetd
Entity Pid : 11014167
Num conditions : 1
Entity type : ATTACHED
Stats:
Created : 2001/08/30 23:04:49:930148650
Num Restarts : 0
```

As you can see, the .info provides information and statistics relating to the inetd entity that is being monitored. The information is generated dynamically and contains up-to-date data for each entity.

The inetd entity has associated with it only one *condition* (i.e. death), which is triggered when the entity dies.

```
# ls -al /proc/ham/inetd/death
total 2
-r----- 1 root root 126 Aug 30 23:07 .info
-r---- 1 root root 108 Aug 30 23:07 restart

# cat /proc/ham/inetd/death/.info
Path : inetd/death
Entity Pid : 11014167
Num Actions : 1
Condition ReArm : ON
Condition type : CONDDEATH
```

Similarly, there's only one *action* associated with this death condition: the *restart* mechanism. Each action under the condition appears as a file under the appropriate condition directory. The file contains details about the action that will be performed when the condition is triggered.

cat /proc/ham/inetd/death/restart Path : inetd/death/restart Entity Pid : 11014167

Action ReArm : ON

Restart Line : /usr/sbin/inetd -D



You need to specify the -D option to inetd, to force inetd to daemonize by calling procmgr daemon() instead of by calling daemon(). The HAM can see death messages only from tasks that are running in session 1, and the call to daemon() doesn't put the caller into that session.

When inetd dies, all the actions associated with a death condition under it are executed:

slay inetd

```
# cat /proc/ham/inetd/.info
Path : inetd
Entity Pid : 11071511 <- new pid of entity
Num conditions : 1
Entity type
                   : ATTACHED
Stats:
Created : 2001/08/30 23:04:49:930148650 - 2001/08/30 23:10:31:889820814
Restarted : 2001/08/30 23:10:31:889820814
Num Restarts : 1
Last Death : 2001/08/30 23:10:31:889820814
Restarted : 2001/08/30 23:10:31:904818519
```

As you can see, the statistics relating to the entity inetd are updated.

Similarly, if a HAM itself is terminated, the Guardian takes over as the new HAM, and creates a Guardian for itself.

```
# cat /proc/ham/.info
             : 10993674 <---- This is the HAM
Ham Pid
Guardian Pid : 10997782 <---- This is the Guardian Ham Failures : 0
Guardian Failures : 0
Num Entities
               : 1
Num Conditions : 1
Num Actions : 1
... Kill the ham ....
# /bin/kill -9 10993674
                          <---- Simulate failure
... re-read the stats ...
# cat /proc/ham/.info
Ham Pid : 10997782 <---- This is the new HAM
            : 11124746 <---- This is the Guardian
Guardian Pid
Ham Failures
                : 1
Guardian Failures : 0
Num Entities
                : 1
Num Conditions
                : 1
```

As you can see, the old Guardian is now the new HAM, and a new Guardian has been created. All entities and conditions remain as before; the monitoring continues as usual. The HAM and the Guardian ignore all signals that they can.

HAM API

A HAM provides an API for you to use in order to interact with it. This API provides a collection of functions to:

- connect to and disconnect from a HAM
- add entities/conditions/actions to (and remove them from) the set of things currently being monitored.

The API is implemented as a library that you can link against. The library is thread-safe and also cancellation-safe.

Connect/disconnect functions

The HAM API library maintains only one connection to the HAM. The library itself is thread-safe, and multiple connections (from different threads) or the same thread are multiplexed on the same single connection to a HAM. The library maintains reference counts.

Here are the basic connect functions:

```
/* Basic connect functions
   return success (0) or failure (-1, with errno set) */
int ham_connect(unsigned flags);
int ham_connect_nd(int nd, unsigned flags);
int ham_connect_node(const char *nodename, unsigned flags);
int ham_disconnect(unsigned flags);
int ham_disconnect_nd(int nd, unsigned flags);
int ham_disconnect_node(const char *nodename, unsigned flags);
```

These functions are used to open or close connections to a HAM. The first call to $ham_connect*()$ will open the fd, while subsequent calls will increment the reference count.

Similarly, $ham_disconnect()$ will decrement the count until zero; the call that makes the count zero will close the fd. The functions return -1 on error, and 0 on success. Similarly $ham_disconnect*()$ will decrement the reference count until zero, with the call that makes the count zero closing the fd. The functions return -1 on error with errno set, and 0 on success.

In a multithreaded situation, there will exist only one open connection to a given HAM at any given time, even if multiple threads were to perform *ham connect*()/ham disconnect*()* calls.

The ham_*_nd() and ham_*_node() versions of the calls are used to open a connection to a remote HAM across QNET. The nd that is passed to the function is the node identifier that refers to the remote host at the instant the call is made. Since node identifiers are transient values, it is essential that the node identifier is obtained just prior to the call. The other option is to use the fully qualified node name (FQNN) of the host and to pass this as the nodename parameter. An nd of ND_LOCAL_NODE (a

constant defined in sys/netmgr.h) or a *nodename* of NULL (or the empty string) are equivalent, and refer to the current node. (This is also the same as calling <code>ham_connect()</code> or <code>ham_disconnect()</code> directly).

Calls to <code>ham_connect()</code>, <code>ham_connect_nd()</code>, and <code>ham_connect_node()</code> can be freely mixed, as long as the number of connect calls equals the number of disconnect calls for each connection to a specific (local or remote) HAM before the connection (<code>fd</code>) is closed.

Attach/detach functions

For self-attached entities

You use these two functions to attach/detach a process to/from a HAM as a self-attached entity.

The *ename* argument represents the symbolic name for this entity, which needs to be unique in the system (of all monitored entities at the instant the call is made).

The *hp* argument represents time values in nanoseconds for the *heartbeat period*. Heartbeating can be used to ensure "liveness" of the monitored entity. Liveness is a property that describes a component's useful progress. In many cases, the availability of a system component is compromised not because the component has necessarily died, but because it isn't responding or making any progress. The heartbeating mechanism lets you specify that a component will issue a heartbeat at a given interval, and if it misses a certain number of heartbeats, then that would constitute a heartbeat-missed condition.

The *hpdl* and *hpdh* represent the number of heartbeats that can be missed before the conditions *heartbeatmissedlow* and *heartbeatmissedhigh* are triggered. The HAM API library registers this request with a HAM and also creates a thread that keeps the connection to a HAM open. If the entity were to abnormally terminate, the connection to the HAM is closed, and the HAM will know that this is an abnormal termination (since *ham_detach_self()* wasn't called first).

On the other hand, if a HAM were to abnormally fail (extremely unlikely) and the Guardian takes over as the new HAM, the connection to the old HAM will have gone stale. In that case, the Guardian notifies all self-attached entities to reattach. The extra thread mentioned above handles this reattach transparently.

If a connection to a HAM is already open, then <code>ham_attach_self()</code> uses the same connection, but increments the reference count of connections opened by this client. A client that indicates that it will heartbeat at a certain period must call <code>ham_heartbeat()</code> to actually transmit a heartbeat to the HAM.

The library also verifies whether the *ename* provided by the caller is unique. If it doesn't already exist, then this request is forwarded to a HAM, which also checks it again to avoid any race conditions in creating new entities. The *ham_attach_self()* returns a generic handle, which can be used to detach the process from the HAM later.

Note that this handle is an opaque pointer that's also used to add conditions and actions as shown below.

The <code>ham_detach_self()</code> function is used to close the connection to a HAM. From this point on, the HAM will no longer monitor this process as a self-attached entity. The extra thread is canceled. The <code>ham_detach_self()</code> function takes as an argument the handle returned by <code>ham_attach_self()</code>.

Code snippet using self-attach/detach calls

The following snippet of code uses the ham attach | detach | self() functions:

```
ham_entity_t *ehdl; /* The entity Handle */
int status;

/*
  connects to a HAM with a heartbeat of 5 seconds
  and an entity name of "client1", and no flags
  it also specifies hpdh = 4, and hpdh = 8

*/
ehdl = ham_attach_self("client1", 5000000000, 4, 8, 0);
if (ehdl == NULL) {
   printf("Could not attach to Ham\n");
   exit(-1);
}
/* Detach from a HAM using the original handle */
status = ham_detach_self(ehdl,0);
...
```

For attaching/detaching all other entities

These attach/detach/detach-name functions are very similar to the *_self() functions above, except here the calling process asks a HAM to monitor a different process.

This mechanism allows for arbitrary monitoring of entities that already exist and aren't compiled against the HAM API library. In fact, the entities that are being monitored needn't even be aware that they're being monitored.

You can use the *ham attach()* call either to:

- start an entity and continue to monitor it or:
- begin monitoring an entity that's already running.

In the *ham_attach()* call, if *pid* is -1, then we assume that the entity isn't running. The entity is started now using *line* as the startup command line for it. But if *pid* is greater

than 0, then *line* is ignored and the *pid* given is attached to as an entity. Again *ename* needs to be unique across all entities currently registered.

The nd specifier in ham_attach() and ham_detach_name(), and the nodename specifier in the ham_attach_node() and ham_detach_name_node() versions of the calls are used to refer to a remote HAM across Qnet. The nd that is passed to the function is the node identifier that refers to the remote host at the instant the call is made. Since node identifiers are transient values, it is essential that the node identifier is obtained just prior to the call. The other option is to use the fully qualified node name (FQNN) of the host and to pass this as the nodename parameter. An nd of ND_LOCAL_NODE (a constant defined in sys/netmgr.h or a nodename of NULL (or the empty string) are equivalent, and refer to the current node.

The <code>ham_detach*()</code> functions stop monitoring a given entity. The <code>ham_detach()</code> call takes as an argument the original handle returned by <code>ham_attach()</code>. You can also call <code>ham_detach_name()</code>, which uses the entity's name instead of the handle.

Note that the entity handle can also be used later to add *conditions* to the entity (described below).

Code snippet using attach/detach calls

```
...
ham_entity_t *ehdl;
int status;
ehdl = ham_attach("inetd", 0, -1, "/usr/sbin/inetd -D", 0);
/* inetd is started, running and monitored now */
...
status = ham_detach(ehdl,0);
...
```

Of course the attach and detach needn't necessarily be performed by the same caller:

```
ham_entity_t *ehdl;
int status;
/* starts and begins monitoring inetd */
ehdl = ham_attach("inetd", 0, -1, "/usr/sbin/inetd -D", 0);
...
/* disconnect from Ham (monitoring still continues) */
exit(0);
And to detach inetd:
...
int status;
/* stops monitoring inetd. */
status = ham_detach_name(0, "inetd", 0);
...
exit(0);
```

If inetd were already running, say with *pid* 105328676, then we can write the attach/detach code as follows:

```
ham_entity_t *ehdl;
int status;
```

```
ehdl = ham_attach("inetd", 0, 105328676, NULL, 0);
...
...
status = ham_detach(ehdl,0);
/* status = ham_detach_name(0, "inetd",0); */
...
exit(0);
```

For convenience, the *ham_attach()* and *ham_detach()* functions connect to a HAM if such a connection doesn't already exist. We do this only to make the use of the functions easier.

The connections to a HAM persist only for the duration of the attach/detach calls; any subsequent requests to the HAM must be preceded by the appropriate <code>ham_connect()</code> calls.

The best way to perform a large sequence of requests to a HAM is to:

- 1 Call ham connect() before the first request.
- **2** Call *ham disconnect()* after the last request.

This is the most efficient method, because it guarantees that there's always the same connection open to the HAM.

Entity functions

The *ham_attach_*()* functions are normally used when an entity is either already running or will be started by a HAM, and monitoring begins with the invocation of the *ham_attach*()* call. The HAM API also provides two functions that allow users to create placeholders for entities that are not yet running and that might be started in the future. This allows subscribers of interesting events to indicate their interest in these events, without necessarily waiting for a publisher (other entity/HAM) to create the entity.

These functions create entity place holders with the name specified *ename*, on the corresponding node described by either the node identifier *nd* or the nodename given by *nodename*. Once created, these placeholders can be used to add conditions and actions to their associated entities. When a subsequent *ham_attach*()* call is made that references the same *ename*, it will fill the entity place holder with the appropriate process ID. From that time onwards, the entity is monitored normally.

Condition functions

Each entity can be associated with various conditions. And for each of these conditions there's a set of actions that will be performed in sequence when the

condition is true. If an entity has multiple conditions that are true simultaneously with different sets of actions associated with each condition, then all the actions are performed for each condition, in sequence.

This mechanism lets you combine actions together into sets and choose to remove/control them as a single "group" instead of as individual items.

Since conditions are associated with entities, an entity handle must be available in order to add conditions. The ham condition*() functions return an opaque pointer that is a condition handle, which you can use later to either remove a condition or add actions to the condition.

Condition types

You can specify any of the following for *type*:

CONDDEATH The entity has died.

CONDABNORMALDEATH

The entity has died an abnormal death. This condition is triggered whenever an entity dies by a mechanism that results in the generation of a core file (see dumper in the *Utilities* Reference for details).

CONDDETACH

The entity that was being monitored is detaching. This ends

HAM's monitoring of that entity.

CONDATTACH

An entity for whom a place holder was previously created (someone has subscribed to events relating to this entity), has joined the system. This is also the start of the monitoring of the

entity by a HAM.

CONDHBEATMISSEDHIGH

The entity missed sending a heartbeat message specified for a condition of "high" severity.

CONDHBEATMISSEDLOW

The entity missed sending a heartbeat message specified for a condition of "low" severity.

CONDRESTART

The entity was restarted. This condition is true *after* the entity is

successfully restarted.

CONDANY

This condition type matches any condition type. It can be used to

associate the same actions with one of many conditions.

The CONDATTACH, CONDDETACH and CONDRESTART conditions are triggered by the HAM, when entities attach, detach, or restart respectively. The CONDHBEATMISSEDHIGH and CONDHBEATMISSEDLOW conditions are triggered

internally by the HAM when it detects the missed heartbeat conditions, as defined by the entities when they indicated their original intent to heartbeat.

CONDDEATH is triggered whenever an entity dies. CONDABNORMALDEATH is triggered only when an abnormal death takes place, but such an abnormal death also triggers a CONDDEATH condition.

You use the *detach* condition to perform some actions whenever a monitored entity properly detaches from a HAM. After this point, the HAM will no longer monitor the entity. In effect, you can use this to "notify" interested clients when the HAM can no longer provide any more information about the detaching entity.

The *restart* condition is asserted and triggered by a HAM automatically if an entity dies and is restarted.

Condition flags

HCONDNOWAIT

Guarantees that there can be no "waitfor" statements in the list of actions in this condition. All conditions that are flagged HCONDNOWAIT are handled in a separate thread, and thus aren't delayed in any way by the nature of the actions in other conditions.

HCONDINDEPENDENT

If this flag is set, then all actions in this condition are executed in a separate thread. This lets you insert delays into a condition, without incurring any delays in other conditions.

If a condition is flagged with both HCONDINDEPENDENT and HCONDNOWAIT, then HCONDNOWAIT takes precedence, and all actions in this condition are executed in the same thread as *all* other conditions that are also flagged as HCONDNOWAIT. This is because all HCONDNOWAIT conditions are guaranteed to have minimal delays already.

If a condition is flagged with neither HCONDNOWAIT nor HCONDINDEPENDENT, it is treated as an OTHER condition, implying that it will be executed in the FIFO order among all conditions that are true.

To sum up:

- Whenever a condition (e.g. CONDDEATH, CONDDETACH, etc.) occurs, all conditions flagged HCONDNOWAIT are executed in FIFO order in a single thread.
- **2** All conditions flagged HCONDINDEPENDENT (but not HCONDNOWAIT) are executed each in a separate thread.
- **3** All other conditions are executed in FIFO order in one single thread.

This limits the number of threads in all to be at most:

 $(number\ of\ HCONDINDEPENDENT\ conditions)+2$

That is, one for all the conditions flagged HCONDNOWAIT, and one for all OTHER conditions.

In addition, within a condition, all actions are also executed in FIFO order. This is true irrespective of whether the conditions are HCONDNOWAIT or HCONDINDEPENDENT.

Action functions

```
/* action operations
ham_action_t *ham_action_restart(ham_condition_t *chdl, const char *aname,
             const char *path, unsigned flags);
ham_action_t *ham_action_execute(ham_condition_t *chdl, const char *aname,
             const char *path, unsigned flags);
ham_action_t *ham_action_waitfor(ham_condition_t *chdl, const char *aname,
             const char *path, int delay, unsigned flags);
ham_action_t *ham_action_notify_pulse(ham_condition_t *chdl, const char *aname,
             int nd, int topid, int chid, int pulsecode, int value,
             unsigned flags);
ham_action_t *ham_action_notify_signal(ham_condition_t *chdl, const char *aname,
             int nd, pid t topid, int signum, int code, int value,
              unsigned flags);
ham action t *ham action notify pulse node(ham condition t *chdl,
             const char *aname, const char *nodename, int topid, int chid,
             int pulsecode, int value, unsigned flags);
ham_action_t *ham_action_notify_signal_node(ham_condition_t *chdl,
             const char *aname, const char *nodename, pid_t topid,
             int signum, int code, int value, unsigned flags);
ham_action_t *ham_action_heartbeat_healthy(ham_condition_t *chdl,
             const char *aname, unsigned flags);
ham action t *ham action log(ham condition t *chdl, const char *aname,
             const char *msg, unsigned attachprefix, int verbosity,
              unsigned flags);
/* remove an action
int ham_action_remove(ham_action_t *ahdl, unsigned flags);
```

As mentioned earlier, a HAM currently supports several different types of *action functions*, but note that you can add your own action functions to suit your particular HA application.

```
ham action restart()
```

Provides a restart mechanism for the entity in the event that a *death* condition has occurred. This implies that the entity in question has terminated; the *restart* action will restart the entity and also keep track of the new *pid* that the entity will now be associated with.



Restart actions can be associated only with *death* conditions. And across all conditions of type *death*, there can be only a single *restart* action at any time. This ensures that the entity is restarted only if it terminates, and only once. (Conditions of type *death* include conditions of the types CONDDEATH and CONDABNORMALDEATH.

```
ham_action_execute()
```

Executes an arbitrary command in the event that the condition is true. This could be any executable command line. When the condition in question is true, the list of actions is traversed and executed in sequence.

This executes a command line as specified in the parameters. The command line must contain the FULL path to the executable along with all parameters to be

passed to it. The command line is in turn passed onto a *spawn* command by a HAM to create a new process that will execute the command.

You'll find *execute* actions useful when you need to set up a multistage recovery. For example, if fs-nfs2 dies and is restarted, the *ham_action_execute()* function lets you remount any directories that are required after fs-nfs2 is restarted.

You can have an *execute* action take place immediately by setting the HACTIONDONOW flag. Again, this is useful in startup situations when an entity is created in many stages.

Note that HACTIONDONOW is ignored for *waitfor* actions. So in order to insert delays into a sequence of actions flagged HACTIONDONOW, you'll need to insert the delays in the client program (between calls to *ham action*()*).

ham action waitfor()

Given a sequence of actions in a condition that will execute in FIFO order, you can insert delays into the execution sequence by using *ham_action_waitfor()* (as long as the condition permits it — see the section Condition functions in this chapter). The delay specified is in multiples of 100 msecs.

The ham_action_waitfor() call takes as an argument a path component, which can be used to wait for a specific name to appear in the name space. If path is NULL, the waitfor is for exactly delay msecs. But if path is specified, the waitfor is for either delay msecs or until path appears in the namespace, whichever occurs earlier. Note that the delay when a pathname is specified is in integral multiples of 100 msecs.

If a pathname is specified, the delays will be the closest integral multiple of 100 msecs, rounding up. A delay of 0 effectively disables the waitfor, making the *pathname* specification redundant.

ham action notify pulse(), ham action notify signal()

The *ham_action_notify_pulse()* function sends the appropriate pulse to the given *nd/pid/chid*.

The *action_notify_signal()* sends an appropriate realtime signal with a value to the *pid* that requests it.

Actions can persist across a restart if the entity is restarted. Similarly, conditions can also be set to persist (i.e. you can rearm them) after a restart of the entity. You can do this by ORing HREARMAFTERRESTART into the flags argument to either the *ham condition()* call or to the appropriate action statement.

If a condition persists when an entity is restarted, each individual action is checked to see if it also persists. Actions that needn't be rearmed are performed once and removed. Any actions that fail are also removed, even if they're set to be rearmed.

If a condition isn't marked as *rearmed*, then all actions under it are automatically removed, since the actions are associated only with the condition and can't be retained if the condition no longer exists.

The persistence of conditions and actions across a restart depends on the restart of the entity itself. So if the entity isn't restarted (i.e. there's no ACTIONRESTART or the ACTIONRESTART fails for some reason), then the entity is removed, along with all conditions and actions associated with the entity as well.

```
ham action notify pulse node()
```

This is the same as the *ham_action_notify_pulse()* above, except that the node name specified for the recipient of the pulse can be given using the fully qualified node name instead of the node identifier (*nd*).

```
ham action notify signal node()
```

This is the same as the *ham_action_notify_signal()* above, except that the node name specified for the recipient of the signal can be given using the fully qualified node name instead of the node identifier (*nd*).

Action fail functions

```
/* action fail operations
int ham_action_fail_execute(ham_action_t *ahdl, const char *aname,
    const char *path, unsigned flags);
int ham_action_fail_waitfor(ham_action_t *ahdl, const char *aname,
   const char *path, int delay, unsigned flags);
int ham_action_fail_notify_pulse(ham_action_t *ahdl, const char *aname,
   int nd, int topid, int chid, int pulsecode, int value, unsigned flags);
int ham_action_fail_notify_signal(ham_action_t *ahdl, const char *aname
   int nd, pid_t topid, int signum, int code, int value, unsigned flags);
int ham_action_fail_notify_pulse_node(ham_action_t *ahdl, const char *aname,
   const char *nodename, int topid, int chid, int pulsecode, int value,
   unsigned flags);
int ham_action_fail_notify_signal_node(ham_action_t *ahdl, const char *aname,
   const char *nodename, pid_t topid, int signum, int code, int value,
   unsigned flags);
int ham_action_fail_log(ham_action_t *ahdl, const char *aname,
   const char *message, unsigned attachprefix, int verbosity, unsigned flags);
/* remove an action fail operation */
int ham_action_fail_remove(ham_action_t *ahdl, const char *aname,
   unsigned flags):
```

These actions are used to associate a list of actions that will be executed when an action in a condition fails. These functions are similar to the corresponding action functions described in the previous section, the primary difference being the first parameter, which in the case of these functions is a handle to an action (as opposed to a handle to a condition).

Example to monitor inetd

The following code snippet shows how to begin monitoring the inetd process:

```
#include <stdio.h>
#include <string.h>
#include <stdlib.h>
#include <unistd.h>
#include <cys/stat.h>
#include <sys/netmgr.h>
#include <fcntl.h>
#include <ha/ham.h>
int main(int argc, char *argv[])
```

```
char *inetdpath;
 ham_entity_t *ehdl;
 ham condition t *chdl;
 ham_action_t *ahdl;
 int inetdpid;
  inetdpath = strdup("/usr/sbin/inetd -D");
 inetdpid = -1;
 ham connect(0);
  ehdl = ham_attach("inetd", ND_LOCAL_NODE, inetdpid, inetdpath, 0);
  if (ehdl != NULL)
    chdl = ham_condition(ehdl,CONDDEATH, "death", HREARMAFTERRESTART);
  if (chdl != NULL) {
      ahdl = ham_action_restart(chdl, "restart", inetdpath,
                           HREARMAFTERRESTART);
        if (ahdl == NULL)
            printf("add action failed\n");
      }
         printf("add condition failed\n");
 else
     printf("add entity failed\n");
 ham disconnect(0);
  exit(0);
```

Example to monitor fs-nfs2

The following code snippet shows how to begin monitoring the fs-nfs2 process:

```
#include <stdio.h>
#include <string.h>
#include <stdlib.h>
#include <unistd.h>
#include <sys/stat.h>
#include <sys/netmgr.h>
#include <fcntl.h>
#include <ha/ham.h>
int main(int argc, char *argv[])
  int status;
   ham_entity_t *ehdl;
   ham_condition_t *chdl;
   ham_action_t *ahdl;
   char *fsnfspath;
   int fsnfs2pid;
   fsnfspath = strdup("/usr/sbin/fs-nfs2");
   fsnfs2pid = -1;
   ham_connect(0);
    ehdl = ham_attach("Fs-nfs2", ND_LOCAL_NODE, fsnfs2pid, fsnfspath, 0);
    if (ehdl != NULL)
    {
     chdl = ham condition(ehdl,CONDDEATH, "Death", HREARMAFTERRESTART);
    if (chdl != NULL) {
        ahdl = ham_action_restart(chdl, "Restart", fsnfspath,
                              HREARMAFTERRESTART);
          if (ahdl == NULL)
             printf("add action failed\n");
            else {
          ahd1 = ham_action_waitfor(chd1, "Delay1", NULL, 2000,
                                 HREARMAFTERRESTART);
            if (ahdl == NULL)
               printf("add action failed\n");
          ahdl = ham_action_execute(chdl, "MountDirl",
```

```
"/bin/mount -t nfs a.b.c.d:/dir1 /dir1",
                 HREARMAFTERRESTART | HACTIONDONOW));
        if (ahdl == NULL)
           printf("add action failed\n");
      ahdl = ham action waitfor(chdl, "Delay2", NULL, 2000,
               HREARMAFTERRESTART);
        if (ahdl == NULL)
           printf("add action failed\n");
      ahdl = ham_action_execute(chdl, "Mountdir2",
                              "/bin/mount -t nfs a.b.c.d:/dir2 /dir2",
                              HREARMAFTERRESTART | HACTIONDONOW);
        if (ahdl == NULL)
            printf("add action failed\n");
        printf("add condition failed\n");
}
else
   printf("add entity failed\n");
ham_disconnect(0);
exit(0);
```

Functions to operate on handles

You use the handle functions to get/free handles based on entity, condition, and action names. You can then use these handles later to add or remove conditions and actions. As for all the other functions the *_node*() variations are used to refer to a HAM that is not necessarily local, using a fully qualified node name (FQNN).

A client example

Here's an example of a client that obtains notifications via pulses and signals about significant events from a HAM. It registers a pulse-notification scheme in the event that inetd dies or detaches. It also registers a signal-notification mechanism for the death of fs-nfs2.

This example also demonstrates how the delayed notification occurs, and shows how to overcome this using an HCONDINDEPENDENT condition.

```
#include <stdio.h>
#include <string.h>
#include <stdlib.h>
#include <unistd.h>
#include <sys/stat.h>
#include <fcntl.h>
#include <fcrtl.h>
#include <errno.h>
```

```
#include <sys/neutrino.h>
#include <sys/iomsg.h>
#include <sys/netmgr.h>
#include <signal.h>
#include <ha/ham.h>
#define PCODEINETDDEATH
                              _PULSE_CODE_MINAVAIL+1
                             _PULSE_CODE_MINAVAIL+2
#define PCODEINETDDETACH
#define PCODENFSDELAYED PULSE_CODE_MINAVAIL+3
#define PCODEINETDRESTART1 PULSE_CODE_MINAVAIL+4
#define PCODEINETDRESTART3
#define PCODEINETDRESTART2
                              PULSE CODE MINAVAIL+5
#define MYSTG STGRTMIN+1
int fsnfs_value;
/* Signal handler to handle the death notify of fs-nfs2 */
void MySigHandler(int signo, siginfo_t *info, void *extra)
  printf("Received signal %d, with code = %d, value %d\n",
        signo, info->si_code, info->si_value.sival_int);
  if (info->si value.sival int == fsnfs value)
   printf("FS-nfs2 died, this is the notify signal\n");
  return;
}
int main(int argc, char *argv[])
  int chid, coid, rcvid;
  struct pulse pulse;
  pid t pid;
  int status;
  int value:
  ham_entity_t *ehdl;
  ham_condition_t *chdl;
  ham_action_t *ahdl;
  struct sigaction sa;
  int scode;
  int svalue;
  /* we need a channel to receive the pulse notification on */
  chid = ChannelCreate( 0 );
  /* and we need a connection to that channel for the pulse to be
    delivered on */
  coid = ConnectAttach( 0, 0, chid, _NTO_SIDE_CHANNEL, 0 );
  /* fill in the event structure for a pulse */
  pid = getpid();
  value = 13;
  ham connect(0);
  /\ast Assumes there is already an entity by the name "inetd" \ast/
  chdl = ham_condition_handle(ND_LOCAL_NODE, "inetd", "death", 0);
  ahdl = ham_action_notify_pulse(chdl, "notifypulsedeath",ND_LOCAL_NODE, pid,
             chid, PCODEINETDDEATH, value, HREARMAFTERRESTART);
  ham_action_handle_free(ahdl);
  ham condition handle free(chdl);
  ehdl = ham_entity_handle(ND_LOCAL_NODE, "inetd", 0);
  chdl = ham_condition(ehdl, CONDDETACH, "detach", HREARMAFTERRESTART);
  ahdl = ham_action_notify_pulse(chdl, "notifypulsedetach", ND_LOCAL_NODE, pid,
           chid, PCODEINETDDETACH, value, HREARMAFTERRESTART);
  ham action handle free(ahdl);
  ham condition handle free(chdl);
  ham_entity_handle_free(ehdl);
  fsnfs_value = 18; /* value we expect when fs-nfs dies */
  scode = 0;
  svalue = fsnfs_value;
  sa.sa sigaction = MySigHandler;
  sigemptyset(&sa.sa mask);
  sa.sa_flags = SA_SIGINFO;
  sigaction(MYSIG, &sa, NULL);
```

```
Assumes there is an entity by the name "Fs-nfs2".
We use "Fs-nfs2" to symbolically represent the entity
fs-nfs2. Any name can be used to represent the
entity, but it's best to use a readable and meaningful name.
ehd1 = ham_entity_handle(ND_LOCAL_NODE, "Fs-nfs2", 0);
Add a new condition, which will be an "independent" condition.
This means that notifications/actions inside this condition
are not affected by "waitfor" delays in other action
sequence threads
chdl = ham_condition(ehdl,CONDDEATH, "DeathSep",
                 HCONDINDEPENDENT | HREARMAFTERRESTART);
ahdl = ham_action_notify_signal(chdl, "notifysignaldeath", ND_LOCAL_NODE,
                 pid, MYSIG, scode, svalue, HREARMAFTERRESTART);
ham_action_handle_free(ahdl);
ham_condition_handle_free(chdl);
ham_entity_handle_free(ehdl);
chdl = ham_condition_handle(ND_LOCAL_NODE, "Fs-nfs2", "Death", 0);
This action is added to a condition that does not
have an HCONDNOWAIT. Since we are unaware what the condition
already contains, we might end up getting a delayed notification
since the action sequence might have "arbitrary" delays and
ahdl = ham_action_notify_pulse(chdl, "delayednfsdeathpulse", ND_LOCAL_NODE,
          pid, chid, PCODENFSDELAYED, value, HREARMAFTERRESTART);
ham_action_handle_free(ahdl);
ham_condition_handle_free(chdl);
ehdl = ham_entity_handle(ND_LOCAL_NODE, "inetd", 0);
/* We force this condition to be independent of all others. */
chdl = ham_condition(ehdl, CONDRESTART, "restart",
                           HREARMAFTERRESTART | HCONDINDEPENDENT);
ahdl = ham_action_notify_pulse(chdl, "notifyrestart_imm", ND_LOCAL_NODE,
                pid, chid, PCODEINETDRESTART1, value, HREARMAFTERRESTART);
ham action handle free(ahdl);
ahdl = ham action waitfor(chdl, "delay", NULL, 6532, HREARMAFTERRESTART);
ham_action_handle_free(ahdl);
ahdl = ham_action_notify_pulse(chdl, "notifyrestart_delayed", ND_LOCAL_NODE,
                 pid, chid, PCODEINETDRESTART2, value, HREARMAFTERRESTART);
ham action handle free(ahdl);
ham condition handle free(chdl);
ham entity handle free(ehdl);
while (1) {
 rcvid = MsgReceivePulse( chid, &pulse, sizeof( pulse ), NULL );
  if (rcvid < 0) {
   if (errno != EINTR) {
     exit(-1);
   }
 }
 else {
          switch (pulse.code) {
             case PCODEINETDDEATH:
                   printf("Inetd Death Pulse\n");
                 break;
             case PCODENFSDELAYED:
                   printf("Fs-nfs2 died: this is the possibly delayed pulse\n");
                   break;
             case PCODEINETDDETACH:
                   printf("Inetd detached, so quitting\n");
                   goto the end;
             case PCODEINETDRESTART1:
                   printf("Inetd Restart Pulse: Immediate\n");
                 break;
              case PCODEINETDRESTART2:
```



Note that the HAM API has certain restrictions:

- The names of entities, conditions, and actions (*ename*, *cname*, and *aname*) must not contain a "/" character.
- All names are subject to the length restriction imposed by _POSIX_PATH_MAX (as defined in limits.h>). Since the names are manifested inside the namespace, the effective length of a name is the maximum length of the name as a path component. In other words, the *combined length* of an entity/condition/action name including the /proc/ham prefix must not exceed _POSIX_PATH_MAX.

Starting and stopping a HAM

You start a HAM by running the ham utility at the command line:

ham

The ham utility has these command-line options:

- -? | h Display usage message
- -d Disable internal verbosity.
- -f Log verbose output to a file (default is *stderr*).
- -t none relative absolute shortabs

Specify the timestamping method. The default is relative.

- -v Set verbosity level extra -v's increase verbosity.
- -vn Set verbosity level use a number to specify the level (e.g. -v3).

When a HAM starts, it also starts the Guardian process for itself.



You must start ham with its full path or with the **PATH** variable set to include the path to ham as a component.

You must be **root** in order to start or stop a HAM.

Stopping a HAM

To stop the HAM, you must use either the <code>ham_stop()</code> function or the <code>hamctrl</code> command-line utility. These are the only correct (and the only guaranteed) ways to stop the HAM.

The ham_stop() function or the hamctrl utility instructs a HAM to terminate. The HAM in turn first instructs the Guardian to terminate, and then terminates itself. To stop the HAM from the command line, use the hamctrl utility:

```
hamctrl -stop
```

To stop a remote HAM, use the -node option to the hamctrl utility:

```
hamctrl -node "nodename" -stop
```

To stop the HAM programmatically using the API, use the following functions:

Control functions

The following set of functions have been provided to permit control of entities, conditions, and actions that are currently configured.

The permitted operations (commands) are:

```
HENABLE
                       /* enable item
                                              */
                      /* disable item
HDISABLE
                                              */
HADDFLAGS
                      /* add flag
                                              */
                                              */
HREMOVEFLAGS
                      /* remove flag
HSETFLAGS
                       /* set flag to specific */
HGETFLAGS
                       /* get flag
                                              * /
```

The "enable" and "disable" commands can be used to temporarily unhide/hide an entity, condition, or action.

An entity that is hidden is not removed, but will not be monitored for any conditions. Similarly, a condition that is hidden will never be triggered, while actions that are hidden will not be executed. By default the enable and disable operations do not

operate recursively (although the disabling of an entity, will prevent the triggering of any conditions below it, and the disabling of a condition will prevent the execution of the actions in it).

To understand the finer distinctions of the recursive operation of the the control functions refer to the API descriptions for:

- ham entity control()
- ham condition control()
- ham_action_control()

The "addflags", "removeflags", "setflags", and "getflags" commands can be used to obtain or modify the flags associated with any of the entities, conditions, or actions. For more details, refer to the API descriptions of the <code>ham_*_control_*()</code> functions.

Verbosity control

You can use the *ham_verbose()* function to programmatically get or set (increase or decrease) the verbosity:

```
int ham verbose(const char *nodename, int op, int value);
```

You can also use the hamctrl utility to interactively control the verbosity:

```
hamctrl -verbose /* increase verbosity */
hamctrl +verbose /* decrease verbosity */
hamctrl =verbose /* get current verbosity */
```

To operate on a remote HAM, use the hamctrl utility with the -node option:

```
hamctrl -node "nodename" -verbose /* increase verbosity */
hamctrl -node "nodename" +verbose /* decrease verbosity */
hamctrl -node "nodename" =verbose /* get current verbosity */
```

where *nodename* is a valid name that represents a remote (or local) node.

Publishing autonomously detected conditions

Entities or other components on the system can publish conditions that they deem interesting to a HAM, and the HAM can in turn deliver these to other components in the system that have expressed interest and subscribed to them. This allows arbitrary system components that are capable of detecting error conditions or potentially erroneous conditions, to report these to the HAM, which in turn can notify other components to start corrective procedures and/or take preventive action.

There are currently two different ways of publishing information to a HAM. Both of these are designed to be general enough to permit clients to build more complex information exchange mechanisms using them.

Publish state transitions

An entity can report its state transitions to a HAM. The HAM maintains the current state of every entity (as reported by the entity). The HAM does not interpret the meaning of the state value itself, neither does it try to validate the state transitions, but can generate events based on transitions from one state to another.

Components can publish transitions that they want the external world to know. These states need not necessarily represent a *specific* state the application uses internally for decision making.

The following function can be used to notify a HAM of a state transition. Since the HAM is only interested in the *next* state in the transition, this is the only information that is transmitted to the HAM. The HAM then triggers a condition state change event internally, which other components can subscribe to, using the *ham_condition_state()* API call described below.

```
/* report a state transition */
int ham_entity_condition_state(ham_entity_t *ehdl, unsigned tostate,
    unsigned flags);
```

Publish other conditions

In addition to the above, components on the system can also publish autonomously detected conditions by using the <code>ham_entity_condition_raise()</code> API call. The component raising the condition can also specify a type, class, and severity of its choice, to allow subscribers further granularity in filtering out specific conditions to subscribe to. This call results in the HAM triggering a condition-raise event internally, which other components can subscribe to using the <code>ham_condition_raise()</code> API call described below.

```
/* publish autonomously detected condition */
int ham_entity_condition_raise(ham_entity_t *ehdl, unsigned rtype,
    unsigned rclass, unsigned severity, unsigned flags);
```

Subscribing to autonomously published conditions

Subscribers can express their interest in events published by other components by using the following API calls:

- ham condition state()
- ham condition raise()

These calls are similar to the *ham_condition()* API call, and return a handle to a condition, but allow the subscriber customize which of several possible published conditions they are interested in.

Trigger based on state transitions

When an entity publishes a state transition, a state transition condition is raised for that entity, based on the two states involved in the transition (the *from* state and the *to* state). Subscribers indicate which states they are interested in by specifying values for the *fromstate* and *tostate* parameters in the API call.

For more details, refer to the API reference documentation for *ham_condition_state()*.

Trigger based on specific published condition

Subscribers can express interest in conditions raised by entities by using *ham_condition_raise()*, indicating as parameters to the call what sort of conditions they are interested in.

For more information, refer to the API documentation for ham condition raise().

Chapter 5

Using the Client Recovery Library

In this chapter...

Introduction 47

MsgSend*() functions 47

Other covers and convenience functions 48

A simple example 50

State-reconstruction example 52

Introduction

The client recovery library provides a drop-in enhancement solution for many standard libc I/O operations. The HA library's cover functions provide automatic recovery mechanisms for failed connections that can be recovered from in an HA scenario.

The goal is to provide an API for high availability I/O that can transparently provide recovery to clients, especially in an environment where the servers must also be highly available. The recovery is configurable to tailor specific client needs; we provide examples of ways to develop more complicated recovery mechanisms.

The main principle of the HA library is to provide drop-in replacements for all the "transmission" functions (e.g. MsgSend*()). The API lets a client choose specific connections that it would like to make $highly\ available\ —$ all other connections will operate as ordinary connections.

Normally, when a server that the client is talking to fails, or if there's a transient network fault, the *MsgSend*()* functions return an error indicating that the connection ID (or file descriptor) is stale or invalid (EBADF).

In an HA-aware scenario, these transient faults are often recovered from almost immediately (on the server end), thus making the services available again. Unfortunately, clients using a standard I/O offering might not be available to benefit from this to the maximum unless they provide mechanisms to recover from these errors, and then retransmit the information/data, which often might involve a nontrivial rework of client programs.

By providing/achieving recovery inside the HA library itself, we can automatically take advantage of the HA-aware services that restart themselves or are automatically restarted or of the services that are provided in a transparent cluster/redundant way.

Since recovery itself is a connection-specific task, we allow clients to provide recovery mechanisms that will be used to restore connections when they fail. Irrecoverable errors are propagated back reliably so that any client that doesn't wish to recover will get the I/O library semantics that it expects.

The recovery mechanism can be anything ranging from a simple reopen of the connection to a more complex scenario that includes the retransmission/renegotiation of connection-specific information.

MsgSend*() functions

Normally, the *MsgSend*()* functions return EBADF/ESRCH when a connection is stale or closed on the server end (e.g. because the server dies). In many cases, the servers themselves return (e.g. they're restarted) and begin to offer the services properly almost immediately (in an HA scenario). Rather than merely terminate the message transmission with an error, in some cases it might be possible to perform recovery and continue with the message transmission.

The HA library functions that "cover" all the MsgSend*() varieties are designed to do exactly this. When a specific invocation of one of the MsgSend*() functions fails, a

client-provided recovery function is called. This recovery function can attempt to reestablish the connection and return control to the HA library's MsgSend*() function. As long as the connection ID returned by the recovery function is the same as the old connection ID (which in many cases is easy to ensure via close/open/dup2() sequences), then the MsgSend*() functions can now attempt to retransmit the data.

If at any point the errors returned by MsgSend*() are anything other than EBADF/ESRCH, these errors are propagated back to the client. Note also that if the connection ID isn't an HA-aware connection ID, or if the client hasn't provided a recovery function or that function can't re-obtain the same connection ID, then the error is allowed to propagate back to the client to handle in whatever way it likes.

Clients can change their recovery functions. And since clients can also pass around "recovery/connection" information (which in turn is passed by the HA library to the recovery function), clients can construct complex recovery mechanisms that can be modified dynamically.

The client-side recovery library lets clients reconstruct the state required to continue the message transmission after reconnecting to either the same server or to a different server. The client is responsible for determining what constitutes the state that must be reconstructed and for performing this appropriately while the recovery function is called.

Other covers and convenience functions

In addition to the cover functions for the standard *MsgSend*()* calls, the HA library provides clients with two "HA-awareness" functions that let you designate a connection as being HA-aware or similarly remove such a designation for an already HA-aware connection:

HA-awareness functions

ha_attach() Associate a recovery function with a connection to make it

HA-aware.

ha detach() Remove a previously specified association between a recovery

function and a connection. This makes the connection no longer

HA-aware.

ha connection ctrl()

Control the operation of a HA-aware connection.

I/O covers

The HA library also provides the following cover functions whose behavior is essentially the same as the original functions being covered, but augmented slightly where the connections are also HA-aware:

ha open(), ha open64()

Open a connection and attach it to the HA lib. These functions, in addition to calling the underlying *open* calls also make the connections HA-aware by calling $ha_attach()$ automatically. As a result, using these calls is equivalent to calling open() or open64() and following that with a call to $ha_attach()$.

ha creat(), ha creat64()

Create a connection and attach it to the HA lib. These functions, in addition to calling the underlying *creat* calls also make the connections HA-aware by calling *ha_attach()* automatically. As a result, using these calls is equivalent to calling *creat()* or *creat64()* and following that with a call to *ha_attach()*.

ha ConnectAttach(), ha ConnectAttach r()

Create a connection using *ConnectAttach()* and attach it to the HA lib. These functions, in addition to calling the underlying *ConnectAttach* calls also make the connections HA-aware by calling *ha_attach()* automatically. As a result, using these calls is equivalent to calling *ConnectAttach()* or *ConnectAttach_r()* and following that with a call to *ha_attach()*.

ha ConnectDetach(), ha ConnectDetach r()

Detach an attached fd, then close the connection using ConnectDetach(). These functions, in addition to calling the underlying ConnectDetach calls also make the connections HA-aware by calling $ha_attach()$ automatically. As a result, using these calls is equivalent to calling ConnectDetach() or ConnectDetach() and following that with a call to $ha_attach()$.

ha fopen()

Open a file stream and attach it to the HA lib. This function, in addition to calling the underlying *fopen()* call also makes connections HA-aware by calling *ha_attach()* automatically. As a result, using this call is equivalent to calling *fopen()* and following that with a call to *ha_attach()*.

ha fclose()

Detach an attached HA fd for a file stream, then close it. This function, in addition to calling the underlying fclose() call also makes connections HA-aware by calling ha_attach() automatically. As a result, using this call is equivalent to calling fclose() and following that with a call to ha_attach().

ha close()

Detach an attached HA fd, then close it. This function, in addition to calling the underlying close() call also makes connections HA-aware by calling ha_attach() automatically. As a result, using this call is equivalent to calling close() and following that with a call to ha attach().

ha_dup()

Duplicate an HA connection. This function, in addition to calling the underlying dup() call also makes connections HA-aware by calling $ha_attach()$ automatically. As a result, using this call is equivalent to calling dup() and following that with a call to $ha_attach()$.

Convenience functions

In addition to the covers, the library also provides these two convenience functions that reopen connections for recovery:

ha_reopen() Reopen a connection while performing recovery.

ha ReConnectAttach()

Reopen a connection while performing recovery.



For descriptions of all of the HA library functions, see the Client Recovery Library Reference chapter in this guide.

A simple example

Here's a simple example of a client that has a connection open to a server and tries to read data from it. After reading from the descriptor, the client goes off to do something else (possibly causing a delay), and then returns to read again.

During this window of delay, the server might have died and returned, in which case the initial connection to the server (that has died) is now stale.

But since the connection has been made HA-aware, and a recovery function has been associated with it, the connection is able to reestablish itself.

```
#include <stdio.h>
#include <string.h>
#include <stdlib.h>
#include <unistd.h>
#include <sys/stat.h>
#include <fcntl.h>
#include <errno.h>
#include <ha/cover.h>
#define SERVER "/path/to/server"
typedef struct handle {
   int nr;
} Handle ;
int recover_conn2(int oldfd, void *hdl)
    int newfd;
   Handle *thdl;
   thdl = (Handle *)hdl;
   printf("recovering for fd %d inside function 2\n",oldfd);
    /* re-open the connection */
   newfd = ha_reopen(oldfd, SERVER, O_RDONLY);
  /* perform any other kind of state re-construction */
    (thdl->nr)++;
```

```
return (newfd);
int recover_conn(int oldfd, void *hdl)
{
   int newfd:
   Handle *thdl;
    thdl = (Handle *)hdl;
   printf("recovering for fd %d inside function\n",oldfd);
    /* re-open the connection */
   newfd = ha reopen(oldfd, SERVER, O RDONLY);
   /* perform any other kind of state reconstruction */
    (thdl->nr)++;
   return (newfd);
}
int main(int argc, char *argv[])
   int status;
   int fd;
   int fd2;
   int fd3;
   Handle hdl;
   char buf[80];
   int i;
   hdl.nr = 0;
    /* open a connection and make it HA aware */
    fd = ha_open(SERVER, O_RDONLY, recover_conn, (void *)&hdl, 0);
    if (fd < 0) {
       printf("could not open %s\n", SERVER);
        exit(-1);
   printf("fd = %d\n",fd);
  /* Dup the FD. the copy will also be HA aware */
   fd2 = ha_dup(fd);
   printf("dup-ped fd2 = %d\n",fd2);
   printf("before sleeping first time \n");\\
  Go to sleep...
  Possibly the SERVER might die and return in this little
  time period.
   sleep(15);
  reading from dup-ped fd
  this should work just normally if SERVER has not died.
  But if the SERVER has died and returned, the
  initial read will fail, but the recovery function
  will be called, and it will re-establish the
   connection, and then re-establish the current
  file position and then re-issue the read call
  which should succeed now.
   printf("trying to read from %s using fd %d\n", SERVER, fd2);
    status = read(fd2,buf,30);
   if (status < 0)
       printf("error: %s\n", strerror(errno));
  fd and fd2 are dup-ped fd's
  changing the recovery function for {\tt fd2}
  From this point forwards, the recovery (if at all)
  will performed using "recover_conn2" as the recovery
  function.
    status = ha_attach(fd2, recover_conn2, (void *)&hd1, HAREPLACERECOVERYFN);
   ha_close(fd); /* close fd */
```

```
/* open a new connection */
 fd = open(SERVER, O_RDONLY);
 printf("New fd = %d\n",fd);
/* make it HA aware. */
 status = ha_attach(fd, recover_conn, (void *)&hdl, 0);
 printf("before sleeping again\n");
/* copy it again */
 fd3 = ha dup(fd);
/* go to sleep...possibly another option for the server to fail. */
 sleep(15);
get rid of one of the fd's
we still have a copy in fd3, which must have the
recovery functions associated with it.
 ha close(fd);
 printf("trying to read from %s using fd %d\n", SERVER, fd3);
if it fails, the call will generate a call back to the
recovery function "recover_conn"
 status = read(fd3,buf,30);
 if (status < 0)
     printf("error: %s\n", strerror(errno));
 printf("trying to read from %s once more using fd %d\n", SERVER, fd2);
if this call fails, recovery will be via the
second function "recover conn2", since we replaced
the function for fd2.
 status = read(fd2,buf,30);
     printf("error: %s\n", strerror(errno));
/* close the fd2, and detach it from the HA lib */
 ha close(fd2);
finally print out our local statistics that we have been
retaining along the way.
 printf("total recoveries, %d\n",hdl.nr);
  exit(0);
```

State-reconstruction example

In the following example, in addition to reopening the connection to the server, the client also reconstructs the state of the connection by seeking to the current file (connection) offset.

This example also shows how the client can maintain state information that can be used by the recovery functions to return to a previously check-pointed state before the failure, so that the message transmission can continue properly.

```
#include <stdio.h>
#include <string.h>
#include <stdlib.h>
```

```
#include <unistd.h>
#include <sys/stat.h>
#include <fcntl.h>
#include <errno.h>
#include <ha/cover.h>
#define REMOTEFILE "/path/to/remote/file"
typedef struct handle {
   int nr;
   int curr_offset;
} Handle ;
int recover_conn(int oldfd, void *hdl)
   int newfd;
   int newfd2;
   Handle *thdl;
   thdl = (Handle *)hdl;
   printf("recovering for fd %d inside function\n",oldfd);
   /* re-open the file */
   newfd = ha_reopen(oldfd, REMOTEFILE , O_RDONLY);
   /* re-construct state, by seeking to the correct offset. */
   if (newfd >= 0)
      lseek(newfd, thdl->curr_offset, SEEK_SET);
    (thdl->nr)++;
   return (newfd);
}
int main(int argc, char *argv[])
   int status;
   int fd;
   int fd2;
   int fd3;
    Handle hdl;
    char buf[80];
    int i;
    hdl.nr = 0;
    hdl.curr_offset = 0;
    /* open a connection */
    fd = ha_open(REMOTEFILE, O_RDONLY, recover conn,
               (void *) &hdl, 0);
    if (fd < 0) {
       printf("could not open file\n");
        exit(-1);
    fd2 = open(REMOTEFILE, O_RDONLY);
    printf("trying to read from file using fd %d\n",fd);
   printf("before sleeping first time\n");
    status = read(fd,buf,15);
    if (status < 0)
       printf("error: %s\n", strerror(errno));
   \verb"else" \{
        for (i=0; i < status; i++)</pre>
            printf("%c",buf[i]);
        printf("\n");
   /*
   update state of the connection
    this is a kind of checkpointing method.
    we remember state, so that the recovery functions
    have an easier time.
```

```
*/
    hdl.curr offset += status;
}
fd3 = ha dup(fd);
sleep(18);
sleep for some arbitrary period
this could be some other computation
or some other blocking operation, which gives
a window within which the server might fail
/* reading from dup-ped fd */
printf("trying to read from file using fd %d\n",fd);
printf("after sleeping\n");
if the read initially fails
it will recover, re-open and seek to the right spot!!
status = read(fd,buf,15);
if (status < 0)
    printf("error: %s\n", strerror(errno));
else {
    for (i=0; i < status; i++)
        printf("%c",buf[i]);
    printf("\n");
    hdl.curr_offset += status;
}
printf("trying to read from file using fd %d\n",fd2);
/*
try it again.. this time using the copy.
recovery will again happen upon failure,
automatically re-connecting/seeking etc.
*/
status = read(fd2,buf,15);
if (status < 0)
    printf("error: %s\n", strerror(errno));
 else {
    for (i=0; i < status; i++)
        printf("%c",buf[i]);
    printf("\n");
printf("total recoveries, %d\n",hdl.nr);
ha_close(fd);
close(fd2);
 exit(0);
```

}

Chapter 6

HAM API Reference

The High Availability Framework includes the following functions you can use in your applications to interact with a HAM:

Function	Description
ham_action_control()	Perform control operations on an action object in a HAM.
ham_action_execute()	Add an execute action to a condition.
ham_action_fail_execute()	Add an execute action to an action, that will be executed if the corresponding action fails.
ham_action_fail_log()	Insert a log message into the activity log of a HAM.
ham_action_fail_notify_pulse()	Add a notify pulse action to an action, that will be executed if the corresponding action fails.
ham_action_fail_notify_pulse_node()	Add a notify pulse action to an action, that will be executed if the corresponding action fails, using a nodename.
ham_action_fail_notify_signal()	Add a notify signal action to an action, that will be executed if the corresponding action fails.
ham_action_fail_notify_signal_node()	Add a notify signal action to an action, that will be executed if the corresponding action fails, using a nodename.
ham_action_fail_waitfor()	Add a waitfor action to an action, that will be executed if the corresponding action fails
ham_action_handle()	Get a handle to an action in a condition in an entity.
ham_action_handle_node()	Get a handle to an action in a condition in an entity, using a nodename.
ham_action_handle_free()	Free a previously obtained handle to an action in a condition in an entity.
ham_action_heartbeat_healthy()	Reset a heartbeat's state to healthy.
ham_action_log()	Insert a log message into the activity log of the HAM.
ham_action_notify_pulse()	Add a notify-pulse action to a condition.

continued...

Function	Description
ham_action_notify_pulse_node()	Add a notify-pulse action to a condition, using a nodename.
ham_action_notify_signal()	Add a notify-signal action to a condition.
ham_action_notify_signal_node()	Add a notify-signal action to a condition, using a nodename.
ham_action_remove()	Remove an action from a condition.
ham_action_restart()	Add a restart action to a condition.
ham_action_waitfor()	Add a waitfor action to a condition.
ham_attach()	Attach an entity.
ham_attach_node()	Attach an entity, using a nodename.
ham_attach_self()	Attach an application as a self-attached entity.
ham_condition()	Set up a condition to be triggered when a certain event occurs.
ham_condition_control()	Perform control operations on a condition object in a HAM.
ham_condition_handle()	Get a handle to a condition in an entity.
ham_condition_handle_node()	Get a handle to a condition in an entity, using a nodename.
ham_condition_handle_free()	Free a previously obtained handle to a condition in an entity.
ham_condition_raise()	Attach a condition associated with a condition raise condition that is triggered by an entity raising a condition.
ham_condition_remove()	Remove a condition from an entity.
ham_condition_state()	Attach a condition associated with a state transition condition that is triggered by an entity reporting a state change.
ham_connect()	Connect to a HAM.
ham_connect_nd()	Connect to a remote HAM.
ham_connect_node()	Connect to a remote HAM, using a nodename.
ham_detach()	Detach an entity from a HAM.

 $continued. \dots$

Function	Description
ham_detach_name()	Detach an entity from a HAM, using an entity name.
ham_detach_name_node()	Detach an entity from a HAM, using an entity name and a nodename.
ham_detach_self()	Detach a self-attached entity from a HAM.
ham_disconnect()	Disconnect from a HAM.
<pre>ham_disconnect_nd()</pre>	Disconnect from a remote HAM.
ham_disconnect_node()	Disconnect from a remote HAM, using a nodename.
ham_entity()	Create entity placeholder objects in a HAM.
ham_entity_condition_raise()	Used by an entity to raise a condition.
ham_entity_condition_state()	Used by an entity to notify the HAM of a state transition.
ham_entity_control()	Perform control operations on an entity object in a HAM.
ham_entity_handle()	Get a handle to an entity.
ham_entity_handle_node()	Get a handle to an entity, using a nodename.
ham_entity_handle_free()	Free a previously obtained handle to an entity.
ham_entity_node()	Create entity placeholder objects in a HAM, using a nodename.
ham_heartbeat()	Send a heartbeat to a HAM.
ham_stop()	Stop a HAM.
ham_stop_nd()	Stop a remote HAM.
ham_stop_node()	Stop a remote HAM, using a nodename.
ham_verbose()	Modifies the verbosity of a HAM.

Perform control operations on an action object in a HAM

Synopsis:

Library:

libham

Description:

The *ham_action_control()* function can be used to control the state of an action object in a HAM. This function is designed to be extensible with additional commands. Currently, the following commands are defined:

HENABLE Enable the action.

HDISABLE Disable the action.

HADDFLAGS Add the flags.

HREMOVEFLAGS Remove the flags.

HSETFLAGS Set the flags to the given value.

HGETFLAGS Get the current flags.

When an action item is enabled (the default), it's executed when the condition associated with it is triggered. When an action item is disabled, the action *isn't* executed when the condition associated with it is triggered. Individual conditions and entities can be enabled and disabled using the corresponding control functions for conditions and entities, respectively.

The add flags, remove flags, and set flags commands can be used to modify the set of flags associated with the entity being controlled. Add flags and remove flags are used to either add to or remove from the current set of flags, the specified set of flags (as given in *flags*). The set flags function is called when the current set of flags is to be replaced by *flags*.

Flags

Any flag that is valid for the corresponding action can be used when $ham_action_control()$ is being used to set flags, with the exception of HACTIONDONOW.

For the HENABLE and HDISABLE commands:

HRECURSE Applies the command recursively.

Returns:

For the enable, disable, add flags, remove flags, and set flags functions:

Success.

-1 An error occurred (errno is set).

For the get flags function:

flags Success.

-1 An error occurred (errno is set).

Errors:

EBADF Couldn't connect to the HAM.

EINVAL The *command* or *flags* variable is invalid.

In addition to the above errors, the HAM returns any error it encounters while servicing this request.

Classification:

QNX Neutrino

Safety	
Cancellation point	No
Interrupt handler	No
Signal handler	No
Thread	Yes

See also:

ham_condition_control(), ham_entity_control()

Add an execute action to a condition

Synopsis:

Library:

libham

Description:

The ham_action_execute() function adds an action (aname) to the specified condition. The action will execute an external program or command specified by path. The path parameter must contain the FULL path to the executable along with all parameters to be passed to it. If either the pathname or the arguments contain spaces that need to be passed on literally to the spawn call, they need to be quoted. As long as the subcomponents within the path arguments are quoted, using either of the following methods:

```
\'path with space\'
or
\"path with space\",
the following is allowed:
"\'path with space\' arg1 arg2 \"arg3 with space\"".
This would be parsed as
"path with space" -> path
arg1 = arg1
arg2 = arg2
arg3 = "arg3 with space".
```

The command line is in turn passed onto a *spawn* command by the HAM to create a new process that will execute the command.

The handle (*chdl*) is obtained either:

- from one of the ham_condition*() functions to add conditions or:
- by calling any of the *ham_condition_handle()* functions to request a handle to a specific condition.

The action is executed when the appropriate condition is triggered.

Currently the following flags are defined:

HACTIONDONOW

Tells the HAM to perform the action once immediately, in addition to performing it whenever the condition is triggered.

HREARMAFTERRESTART

Indicates that the action is to be automatically rearmed after the entity that it belongs to is restarted. By default, this flag is *disabled* — actions automatically get pruned across restarts of the entity. Note that if the condition that this action belongs to is pruned after a restart, this action will also be removed, regardless of the value of this flag.

HACTIONBREAKONFAIL

Indicates that if this action were to fail, and it is part of a list of actions, none of the actions following this one in the list of actions will be executed.

HACTIONKEEPONFAIL

Indicates that the action will be retained even if it fails. The default behavior is to remove failed actions. Nevertheless if the condition that this action is associated with is not retained, the action will get automatically removed.

Users can specify what will be done if an action fails. By adding action fail *actions* to a list associated with an action, users can determine what will be done in the case of an action failure. For every action that fails, the corresponding action fail list will be executed. Certain actions (e.g. ham_action_log() and

ham_action_heartbeat_healthy()) never fail. For more details, refer to the appropriate section in the HAM API reference for the ham action fail *() calls.

Returns:

A valid handle to an action to a condition, or NULL if an error occurred (errno is set).

Errors:

EBADF Couldn't connect to the HAM.

EINVAL The name given in *aname* is invalid (e.g. it contains the "/" character) or is NULL.

The connection to the HAM is invalid. This happens when the process that opened the connection (using *ham_connect()*) and the process that's calling *ham_action_execute()* aren't the same.

ENAMETOOLONG

The name given (in *aname*) is too long, i.e. it exceeds _POSIX_PATH_MAX (defined in limits.h>). Note that the

 $combined\ length$ of an entity/condition/action name is also limited by

POSIX_PATH_MAX.

ENOENT There's no entity or condition specified by the given handle (chdl).

ENOMEM Not enough memory to create a new handle.

In addition to the above errors, the HAM returns any error it encounters while servicing this request.

Classification:

QNX Neutrino

Safety	
Cancellation point	No
Interrupt handler	No
Signal handler	No
Thread	Yes

See also:

```
ham_action_notify_pulse(), ham_action_notify_signal(), ham_action_remove(),
ham_action_restart(), ham_action_waitfor(), ham_condition(),
ham_condition_handle()
```

Add an execute action to an action, that will be executed if the corresponding action fails

Synopsis:

Library:

libham

Description:

The <code>ham_action_fail_execute()</code> function adds an action fail item (<code>aname</code>) to the specified action. The action will execute an external program or command specified by <code>path</code>. The <code>path</code> parameter must contain the FULL path to the executable along with all parameters to be passed to it. along with all parameters to be passed to it. If either the pathname or the arguments contain spaces that need to be passed on literally to the spawn call, they need to be quoted. As long as the subcomponents within the <code>path</code> arguments are quoted, using either of the following methods:

```
\'path with space\'
or
\"path with space\",
the following is allowed:
"\'path with space\' arg1 arg2 \"arg3 with space\"".
This would be parsed as
"path with space" -> path
arg1 = arg1
arg2 = arg2
arg3 = "arg3 with space".
```

The command line is in turn passed onto a *spawn()* command by the HAM to create a new process that will execute the command.

The handle (ahdl) is obtained either:

- from one of the ham_action*() functions to add actions or:
- by calling any of the *ham_action_handle()* functions to request a handle to a specific action.

Returns:

- 0 Success.
- -1 An error occurred (*errno* is set).

Errors:

EBADF Couldn't connect to the HAM.

EINVAL The name given in *aname* is invalid (e.g. it contains the "/" character) or is NULL.

The connection to the HAM is invalid. This happens when the process that opened the connection (using <code>ham_connect()</code>) and the process that's calling <code>ham_action_execute()</code> aren't the same.

ENAMETOOLONG

The name given (in *aname*) is too long, i.e. it exceeds _POSIX_PATH_MAX (defined in limits.h>). Note that the *combined length* of an entity/condition/action name is also limited by _POSIX_PATH_MAX.

ENOENT There's no entity or condition specified by the given handle (*ahdl*).

ENOMEM Not enough memory to create a new handle.

In addition to the above errors, the HAM returns any error it encounters while servicing this request.

Classification:

QNX Neutrino

Safety	
Cancellation point	No
Interrupt handler	No
Signal handler	No
Thread	Yes

See also:

ham_action_execute(), ham_action_fail_execute(), ham_action_handle(),
ham_action_handle_free(), ham_action_heartbeat_healthy(), ham_action_log(),
ham_action_notify_pulse(), ham_action_notify_signal(), ham_action_remove(),
ham_action_restart(), ham_action_waitfor(), ham_condition(),
ham_condition_handle()

Insert a log message into the activity log of a HAM

Synopsis:

Library:

libham

Description:

You can use the *ham_action_fail_log()* function to insert log messages into the activity log stream that a HAM maintains. This action is executed when the corresponding action that it is associated with fails.

The handle (ahdl) is obtained either:

- from one of the *ham_action*()* functions to add actions or:
- by calling any of the *ham_action_handle()* functions to request a handle to a specific action.

The log message to be inserted is specified by *msg*, and will be generated if the verbosity of the HAM is greater than or equal to the value specified in *verbosity*. Also, if *attachprefix* is non-zero, a prefix will be added to the log message that contains the current entity/condition/action that this message is related to.

Returns:

- Success.
- -1 An error occurred (*errno* is set).

Errors:

EBADF Couldn't connect to the HAM.

EINVAL The name given in *aname* is invalid (e.g. it contains the "/" character) or is NULL.

The connection to the HAM is invalid. This happens when the process that opened the connection (using *ham_connect()*) and the process that's calling *ham_action_restart()* aren't the same.

ENAMETOOLONG

The name given (in *aname*) is too long, i.e. it exceeds _POSIX_PATH_MAX (defined in limits.h>). Note that the *combined length* of an entity/condition/action name is also limited by _POSIX_PATH_MAX.

ENOENT There's no entity or condition specified by the given handle (*ahdl*).

ENOMEM Not enough memory to create a new handle.

In addition to the above errors, the HAM returns any error it encounters while servicing this request.

Classification:

QNX Neutrino

Safety	
Cancellation point	No
Interrupt handler	No
Signal handler	No
Thread	Yes

See also:

ham_action_execute(), ham_action_fail_execute(), ham_action_handle(), ham_action_handle_free(), ham_action_heartbeat_healthy(), ham_action_log(), ham_action_notify_pulse(), ham_action_notify_signal(), ham_action_remove(), ham_action_restart(), ham_action_waitfor(), ham_condition(), ham_condition handle()

Add a notify pulse action to a an action, that will be executed if the corresponding action fails

Synopsis:

```
#include <ha/ham.h>
int ham action fail notify pulse(
                   ham action t *ahdl,
                   const char *aname,
                   int nd,
                   pid_t topid,
                   int chid,
                   int pulsecode,
                   int value,
                   unsigned flags);
int ham_action_fail_notify_pulse_node(
                   ham action t *ahdl,
                   const char *aname,
                   const char *nodename,
                   pid t topid,
                   int chid,
                   int pulsecode,
                   int value,
                   unsigned flags);
```

Library:

libham

Description:

The ham_action_fail_notify_pulse*() functions add an action fail item (aname) to the specified action. The action will deliver a pulse specified by pulsecode to the specified nd/pid/chid or the nodename/pid/chid with value given by value. The nd specified to ham_action_notify_pulse() is the node identifier of the recipient node. This nd must be valid at the time the call is made.

The handle (*ahdl*) is obtained either:

- from one of the *ham_action*()* functions to add actions or:
- by calling any of the *ham_action_handle()* functions to request a handle to a specific action.

The action is executed when the corresponding action that it is associated with, fails. Currently, there are no flags defined.

Returns:

- 0 Success.
- -1 An error occurred (*errno* is set).

Errors:

EBADF Couldn't connect to the HAM.

EINVAL The name given in *aname* is invalid (e.g. it contains the "/" character)

or is NULL.

The connection to the HAM is invalid. This happens when the process that opened the connection (using *ham_connect()*) and the process

that's calling ham action execute() aren't the same.

ENAMETOOLONG

The name given (in *aname*) is too long, i.e. it exceeds _POSIX_PATH_MAX (defined in limits.h>). Note that the *combined length* of an entity/condition/action name is also limited by POSIX_PATH_MAX.

ENOENT There's no entity or condition specified by the given handle (*ahdl*).

ENOMEM Not enough memory to create a new handle.

In addition to the above errors, the HAM returns any error it encounters while servicing this request.

Classification:

QNX Neutrino

Safety	
Cancellation point	No
Interrupt handler	No
Signal handler	No
Thread	Yes

See also:

ham_action_execute(), ham_action_fail_execute(), ham_action_handle(),
ham_action_handle_free(), ham_action_heartbeat_healthy(), ham_action_log(),
ham_action_notify_pulse(), ham_action_notify_signal(), ham_action_remove(),
ham_action_restart(), ham_action_waitfor(), ham_condition(),
ham_condition_handle()

Add a notify signal action to a an action, that will be executed if the corresponding action fails

Synopsis:

```
#include <ha/ham.h>
int ham action fail notify signal(
                  ham action t *ahdl,
                   const char *aname,
                   int nd,
                   pid_t topid,
                   int signum,
                   int code,
                   int value,
                   unsigned flags);
int ham_action_fail_notify_signal_node(
                  ham action t *ahdl,
                  const char *aname,
                   const char *nodename,
                  pid t topid,
                   int signum,
                   int code,
                   int value,
                  unsigned flags);
```

Library:

libham

Description:

The ham action fail notify signal*() functions add an action fail item (aname) to the specified action. The action will deliver a signal specified by signum to the specified *nd/pid* or *nodename/pid* with code specified in *code* and value given by value. The nd specified to ham action notify signal() is the node identifier of the recipient node. This *nd* must be valid at the time the call is made.

The handle (*ahdl*) is obtained either:

- from one of the *ham action*()* functions to add actions
- by calling any of the ham action handle() functions to request a handle to a specific action.

The action is executed when the corresponding action that it is associated with, fails. Currently, there are no flags defined.

Returns:

- 0 Success.
- -1 An error occurred (errno is set).

Errors:

EBADF Couldn't connect to the HAM.

EINVAL The name given in *aname* is invalid (e.g. it contains the "/" character)

or is NULL.

The connection to the HAM is invalid. This happens when the process that opened the connection (using *ham_connect()*) and the process

that's calling ham action execute() aren't the same.

ENAMETOOLONG

The name given (in *aname*) is too long, i.e. it exceeds _POSIX_PATH_MAX (defined in limits.h>). Note that the *combined length* of an entity/condition/action name is also limited by POSIX_PATH_MAX.

ENOENT There's no entity or condition specified by the given handle (*ahdl*).

ENOMEM Not enough memory to create a new handle.

In addition to the above errors, the HAM returns any error it encounters while servicing this request.

Classification:

QNX Neutrino

Safety	
Cancellation point	No
Interrupt handler	No
Signal handler	No
Thread	Yes

See also:

ham_action_execute(), ham_action_fail_execute(), ham_action_handle(),
ham_action_handle_free(), ham_action_heartbeat_healthy(), ham_action_log(),
ham_action_notify_pulse(), ham_action_notify_signal(), ham_action_remove(),
ham_action_restart(), ham_action_waitfor(), ham_condition(),
ham_condition_handle()

Add a waitfor action to an action, that will be executed if the corresponding action fails

Synopsis:

```
#include <ha/ham.h>
int ham action fail waitfor(
                  ham action t *ahdl,
                  const char *aname,
                  const char *path,
                  int delay,
                  unsigned flags);
```

Library:

libham

Description:

The ham action fail waitfor() function adds an action fail item (aname) to the specified action. The action will either delay for delay milliseconds or wait until path (if specified) appears in the name space (whichever is earlier). The path parameter must contain the FULL path that is being watched for.

The handle (ahdl) is obtained either:

- from one of the ham action*() functions to add actions or:
- by calling any of the ham action handle() functions to request a handle to a specific action.

The action is executed when the corresponding action that it is associated with, fails. Currently, there are no flags defined.

Returns:

- 0 Success.
- -1 An error occurred (errno is set).

Errors:

EBADF Couldn't connect to the HAM.

EINVAL The name given in *aname* is invalid (e.g. it contains the "/" character) or is NULL.

> The connection to the HAM is invalid. This happens when the process that opened the connection (using ham connect()) and the process that's calling ham action execute() aren't the same.

ENAMETOOLONG

The name given (in *aname*) is too long, i.e. it exceeds _POSIX_PATH_MAX (defined in limits.h>). Note that the *combined length* of an entity/condition/action name is also limited by POSIX_PATH_MAX.

ENOENT There's no entity or condition specified by the given handle (*ahdl*).

ENOMEM Not enough memory to create a new handle.

In addition to the above errors, the HAM returns any error it encounters while servicing this request.

Classification:

QNX Neutrino

Safety	
Cancellation point	No
Interrupt handler	No
Signal handler	No
Thread	Yes

See also:

ham_action_execute(), ham_action_fail_execute(), ham_action_handle(), ham_action_handle_free(), ham_action_heartbeat_healthy(), ham_action_log(), ham_action_notify_pulse(), ham_action_notify_signal(), ham_action_remove(), ham_action_restart(), ham_action_waitfor(), ham_condition(), ham_condition_handle()

Get a handle to an action in a condition in an entity

Synopsis:

```
#include <ha/ham.h>
```

```
ham action t *ham action handle(int nd,
                                  const char *ename,
                                  const char *cname,
                                  const char *aname,
                                  unsigned flags);
ham action t *ham action handle node(int nd,
                                  const char *nodename,
                                  const char *ename,
                                  const char *cname,
                                  const char *aname,
                                  unsigned flags);
```

Library:

libham

Description:

The ham action handle() function returns a handle to an action (aname) in a condition (cname) in an entity (ename).

You can pass the handle obtained from this function to other functions that expect a handle (e.g. ham action remove() or ham action handle free()).

The handle returned is opaque — its contents are internal to the library.

If a node (nd) is specified, the handle is to an entity/condition/action combination that refers to a process on that remote node. The ham action handle node() function is used when a nodename is used to specify a remote HAM instead of a node identifier (*nd*).

There are no flags defined at this time.

Returns:

A valid ham action tor NULL if an error occurred (errno is set).

Errors:

EINVAL The name given in *ename*, *cname*, or *aname* is invalid (e.g. it contains the "/" character) or is NULL.

ENAMETOOLONG

The name given is too long, i.e. it exceeds POSIX PATH MAX (defined in limits.h>). Note that the combined length of an entity/condition/action name is also limited by POSIX PATH MAX.

ENOENT There's no action of the name aname in a condition cname defined in an entity ename in the HAM's current context.

ENOMEM Not enough memory to create a new handle.

Classification:

QNX Neutrino

Safety	
Cancellation point	No
Interrupt handler	No
Signal handler	No
Thread	Yes

Caveats:

A call to *ham_action_handle()* and a subsequent use of the handle returned in a call such as *ham_action_remove()* are completely *asynchronous*. Therefore, a valid action/condition/entity may no longer exist when the handle is used at a later time.

In such an event, the *ham_action*()* functions will return an error (ENOENT) that the action in the condition doesn't exist in the given entity.

See also:

ham_action_execute(), ham_action_handle_free(), ham_action_notify_pulse(), ham_action_notify_signal(), ham_action_remove(), ham_action_restart(), ham_action_waitfor(), ham_condition_handle(), ham_condition_handle_free(), ham_entity_handle(), ham_entity_handle_free()

Free a previously obtained handle to an action in a condition in an entity

Synopsis:

#include <ha/ham.h>

int ham action handle free(ham action t *ahdl);

Library:

libham

Description:

The ham action handle free() function frees a handle (ahdl) associated with a given action in a condition in an entity. The function reclaims all storage associated with the handle.

The handle you pass as an argument (ahdl) must be obtained from ham_action_execute(), ham_action_restart(), ham_action_notify_pulse(), ham_action_notify_signal(), or ham_action_waitfor().

Once a handle is freed, it is no longer available to refer to any action. The ham action handle free() call frees storage allocated for the handle, but does not remove the action itself, which is in the HAM.

Returns:

- Success.
- -1 An error occurred (errno is set).

Errors:

The handle isn't valid. EINVAL

Classification:

QNX Neutrino

Safety

Cancellation point	No
Interrupt handler	No
Signal handler	No
Thread	Yes

Caveats:

The *ham_action_handle_free()* function frees storage related only to the handle in the client — it doesn't remove the corresponding action.

See also:

ham_action_execute(), ham_action_handle(), ham_action_restart(),
ham_action_notify_pulse(), ham_action_notify_signal(), ham_action_waitfor(),
ham_condition_handle_free(), ham_entity_handle_free()

Reset a heartbeat's state to healthy

Synopsis:

#include <ha/ham.h>

Description:

You use this function to reset the state of a heartbeat to healthy so that HAM can resume monitoring. Assuming that the client missed one or more heartbeats (i.e. the condition CONDHBEATMISSEDLOW | HIGH is true), and that a recovery has been performed, the <code>ham_action_heartbeat_healthy()</code> call instructs HAM to monitor the client again.

The following flag is currently defined:

HREARMAFTERRESTART

Indicates that the action is to be automatically rearmed after the entity that it belongs to is restarted. By default, this flag is *disabled* — actions automatically get pruned across restarts of the entity. Note that if the condition that this action belongs to is pruned after a restart, this action will also be removed, regardless of the value of this flag.

Returns:

A valid handle to an action to a condition, or NULL if an error occurred (errno is set).

Errors:

EBADF Couldn't connect to the HAM.

EEXIST This action already exists in the specified condition.

EINVAL The name given in *aname* is invalid (e.g. it contains the "/" character)

or is NULL.

ENAMETOOLONG

The name given (in *aname*) is too long, i.e. it exceeds _POSIX_PATH_MAX (defined in limits.h>). Note that the *combined length* of an entity/condition/action name is also limited by _POSIX_PATH_MAX.

ENOMEM Not enough memory to create a new handle.

In addition to the above errors, the HAM returns any error it encounters while servicing this request.

Classification:

QNX Neutrino

Saf	etv

Cancellation point	No
Interrupt handler	No
Signal handler	No
Thread	Yes

See also:

ham_action_notify_pulse(), ham_action_notify_signal(), ham_action_remove(),
ham_action_restart(), ham_action_waitfor(), ham_condition(),
ham_condition_handle()

Insert a log message into the activity log of the HAM

Synopsis:

```
#include <ha/ham.h>
ham action t *ham action log(
                  ham condition t *chdl,
                  const char *aname,
                  const char *msg,
                  unsigned attachprefix,
                  int verbosity,
                  unsigned flags);
```

Library:

libham

Description:

You can use the ham action log() function to insert log messages into the activity log stream that the HAM maintains.

The handle (*chdl*) is obtained either:

- from one of the ham condition*() functions to add conditions or:
- by calling any of the ham condition handle() functions to request a handle to a specific condition.

The log message to be inserted is specified by msg, and will be generated if the verbosity of the HAM is greater than or equal to the value specified in verbosity. Also, if attachprefix is non-zero, a prefix will be added to the log message that contains the current entity/condition/action that this message is related to.

The following flag is currently defined:

HREARMAFTERRESTART

Indicates that the action is to be automatically rearmed after the entity that it belongs to is restarted. By default, this flag is disabled — actions automatically get pruned across restarts of the entity. Note that if the condition that this action belongs to is pruned after a restart, this action will also be removed, regardless of the value of this flag.

Returns:

A valid handle to an action to a condition, or NULL if an error occurred (errno is set).

Errors:

EBADF Couldn't connect to the HAM.

EINVAL The name given in *aname* is invalid (e.g. it contains the "/" character)

or is NULL.

The connection to the HAM is invalid. This happens when the process that opened the connection (using <code>ham_connect()</code>) and the process

that's calling ham action restart() aren't the same.

ENAMETOOLONG

The name given (in *aname*) is too long, i.e. it exceeds _POSIX_PATH_MAX (defined in limits.h>). Note that the *combined length* of an entity/condition/action name is also limited by POSIX_PATH_MAX.

ENOENT There's no entity or condition specified by the given handle (*chdl*).

ENOMEM Not enough memory to create a new handle.

In addition to the above errors, the HAM returns any error it encounters while servicing this request.

Classification:

QNX Neutrino

Safety	
Cancellation point	No
Interrupt handler	No
Signal handler	No
Thread	Yes

Add a notify-pulse action to a condition

Synopsis:

```
#include <ha/ham.h>
ham action t *ham action notify pulse(
                  ham condition t *chdl,
                  const char *aname,
                   int nd,
                  pid_t topid,
                   int chid,
                   int pulsecode,
                   int value,
                  unsigned flags);
ham_action_t *ham_action_notify_pulse_node(
                   ham condition t *chdl,
                  const char *aname,
                  const char *nodename,
                  pid t topid,
                  int chid,
                   int pulsecode,
                   int value,
                   unsigned flags);
```

Library:

libham

Description:

These functions add an action to a given condition. This action will deliver a pulse notification to the process given in *topid*.

The handle (*chdl*) is obtained either:

- from one of the ham_condition*() functions to add conditions or:
- by calling any of the *ham_condition_handle()* functions to request a handle to a specific condition.

The action is executed when the appropriate condition is triggered.

The *nd* specifies the node identifier of the remote node (or local node) to which the pulse is targeted The *nd* specified is the node identifier of the remote node at the time the call is made.

2009, QNX Software Systems GmbH & Co. KG.



Since node identifiers are transient objects, you should obtain the value for *nd* immediately before the call, using *netmgr_strtond()* or another function that converts nodenames into node identifiers.

Use the <code>ham_action_notify_pulse_node()</code> function when a nodename is used to specify a remote HAM instead of a node identifier (<code>nd</code>). The <code>ham_action_notify_pulse_node()</code> function takes as a parameter a fully qualified node name (FQNN)

The pulse in *pulsecode* with the given *value* will be delivered to *topid* on the specified channel ID (*chid*).

Currently the following flag is defined:

HREARMAFTERRESTART

Indicates that the action is to be automatically rearmed after the entity that it belongs to is restarted. By default, this flag is *disabled* — actions automatically get pruned across restarts of the entity. Note that if the condition that this action belongs to is pruned after a restart, this action will also be removed, regardless of the value of this flag.

HACTIONBREAKONFAIL

Indicates that if this action were to fail, and it is part of a list of actions, none of the actions following this one in the list of actions will be executed.

HACTIONKEEPONFAIL

Indicates that the action will be retained even if it fails. The default behavior is to remove failed actions. Nevertheless if the condition that this action is associated with is not retained, the action will get automatically removed.

Users can specify what will be done if an action fails. By adding action fail *actions* to a list associated with an action, users can determine what will be done in the case of an action failure. For every action that fails, the corresponding action fail list will be executed. Certain actions (e.g. *ham_action_log()* and

ham_action_heartbeat_healthy()) never fail. For more details, refer to the appropriate section in the HAM API reference for the ham action fail *() calls.

Returns:

A valid ham_action_t or NULL if an error occurred (errno is set).

Errors:

EBADF Couldn't connect to the HAM.

EEXIST The name provided for the action already exists.

ham_action_notify_pulse(), ham action notify pulse node()

EINVAL

The name given in *aname* is invalid (e.g. it contains the "/" character) or is NULL.

The connection to the HAM is invalid. This happens when the process that opened the connection (using *ham_connect()*) and the process that's calling *ham_action_notify_pulse()* aren't the same.

ENAMETOOLONG

The name given is too long, i.e. it exceeds <code>_POSIX_PATH_MAX</code> (defined in <code><liimits.h></code>). Note that the *combined length* of an entity/condition/action name is also limited by <code>POSIX_PATH_MAX</code>.

ENOENT There's no action of the name aname in a condition cname defined in an

entity ename in the HAM's current context.

ENOMEM Not enough memory to create a new handle.

In addition to the above errors, the HAM returns any error it encounters while servicing this request.

Classification:

QNX Neutrino

Safety	
Cancellation point	No
Interrupt handler	No
Signal handler	No
Thread	Yes

See also:

ham_action_execute(), ham_action_notify_signal(), ham_action_remove(), ham_action_restart(), ham_action_waitfor(), ham_condition()

ham action notify signal(), ham action notify signal node() o

2009, QNX Software Systems GmbH & Co. KG.

Add a notify-signal action to a condition

Synopsis:

```
#include <ha/ham.h>
ham action t *ham action notify signal(
                  ham condition t *chdl,
                  const char *aname,
                  int nd,
                  pid t topid,
                  int signum,
                  int code,
                  int value,
                  unsigned flags);
ham_action_t *ham_action_notify_signal_node(
                  ham condition t *chdl,
                  const char *aname,
                  const char *nodename,
                  pid t topid,
                  int signum,
                  int code,
                  int value,
                  unsigned flags);
```

Library:

libham

Description:

These functions add an action to a given condition. The action will deliver a signal notification to the process given in *topid*.

The handle (*chdl*) is obtained either:

- from one of the ham_condition*() functions to add conditions or:
- by calling any of the *ham_condition_handle()* functions to request a handle to a specific condition.

The action is executed when the appropriate condition is triggered.

You use the node descriptor (nd) to specify where in the network the recipient of the notification resides.

The *nd* specifies the node identifier of the remote (or local) node to which the signal is targeted The *nd* specified is the node identifier of the remote node at the time the call is made.



Since node identifiers are transient objects, you should obtain the value for *nd* immediately before the call, using *netmgr_strtond()* or another function that converts nodenames into node identifiers.

Use the *ham_action_notify_signal_node()* function when a nodename is used to specify a remote HAM instead of a node identifier (*nd*). The *ham_action_notify_signal_node()* function takes as a parameter a fully qualified node name (FQNN)

The signal in *signum* with the given *value* will be delivered to the process *pid* on node *nd*. This can also be used to terminate processes by sending them appropriate signals like SIGTERM, SIGKILL etc.

Currently the following flags are defined:

HREARMAFTERRESTART

Indicates that the action is to be automatically rearmed after the entity that it belongs to is restarted. By default, this flag is *disabled* — actions automatically get pruned across restarts of the entity. Note that if the condition that this action belongs to is pruned after a restart, this action will also be removed, regardless of the value of this flag.

HACTIONBREAKONFAIL

Indicates that if this action were to fail, and it is part of a list of actions, none of the actions following this one in the list of actions will be executed.

HACTIONKEEPONFAIL

Indicates that the action will be retained even if it fails. The default behavior is to remove failed actions. Nevertheless if the condition that this action is associated with is not retained, the action will get automatically removed.

Users can specify what will be done if an action fails. By adding action fail *actions* to a list associated with an action, users can determine what will be done in the case of an action failure. For every action that fails, the corresponding action fail list will be executed. Certain actions (e.g. *ham_action_log()* and

ham_action_heartbeat_healthy()) never fail. For more details, refer to the appropriate section in the HAM API reference for the ham action fail *() calls.

Returns:

A valid handle to an action to a condition, or NULL if an error occurred (errno is set).

Errors:

EBADF Couldn't connect to the HAM.

EEXIST The name provided for the action already exists.

ham_action_notify_signal(), ham_action_notify_signal_node() o

2009, QNX Software Systems GmbH & Co. KG.

EINVAL

The name given in *aname* is invalid (e.g. it contains the "/" character) or is NULL.

The connection to the HAM is invalid. This happens when the process that opened the connection (using *ham_connect()*) and the process that's calling *ham_action_notify_signal()* aren't the same.

ENAMETOOLONG

The name given is too long, i.e. it exceeds _POSIX_PATH_MAX (defined in limits.h>). Note that the *combined length* of an entity/condition/action name is also limited by POSIX_PATH_MAX.

ENOENT

There's no action of the name aname in a condition cname defined in an

entity ename in the HAM's current context.

ENOMEM

Not enough memory to create a new handle.

In addition to the above errors, the HAM returns any error it encounters while servicing this request.

Classification:

QNX Neutrino

Safety	
Cancellation point	No
Interrupt handler	No
Signal handler	No
Thread	Yes

See also:

ham_action_execute(), ham_action_notify_pulse(), ham_action_remove(), ham_action_restart(), ham_action_waitfor(), ham_condition()

Remove an action from a condition

Synopsis:

#include <ha/ham.h>

Library:

libham

Description:

You use the *ham_action_remove()* function to remove an action from a condition in a specific entity.

You can obtain the handle (ahdl) either:

- from one of the ham_action*() functions that add actions or:
- by calling *ham_action_handle()* to request a handle to a specific condition.

The flags argument isn't currently used.

Returns:

0 Success.

-1 An error occurred (*errno* is set).

Errors:

EBADF Couldn't connect to the HAM.

EINVAL The handle passed is invalid.

The connection to the HAM is invalid. This happens when the process that opened the connection (using *ham_connect()*) and the process that's calling *ham_action_remove()* aren't the same.

ENOENT There's no action corresponding to the given handle (*ahdl*).

In addition to the above errors, the HAM returns any error it encounters while servicing this request.

Classification:

QNX Neutrino

C	- C-4	
	arer	٦

Cancellation point	No
Interrupt handler	No
Signal handler	No
Thread	Yes

See also:

ham_action_execute(), ham_action_handle(), ham_action_heartbeat_healthy(),
ham_action_log(), ham_action_notify_pulse(), ham_action_notify_signal(),
ham_action_restart(), ham_action_waitfor()

Add a restart action to a condition

Synopsis:

Library:

libham

Description:

You use the *ham_action_restart()* function to add an action (*aname*) to a given condition. In this case, the action will restart a program that has died.



Restart actions can be associated only with death conditions (CONDDEATH).

Note also that there can be only one restart action over all the death conditions in an entity.

The handle (*chdl*) is obtained either:

- from one of the ham_condition*() functions to add conditions
- by calling any of the *ham_condition_handle()* functions to request a handle to a specific condition.

You use the *path* parameter to specify the external program or command line to be executed — *path* must contain the FULL path to the executable along with all parameters to be passed to it. If either the pathname or the arguments contain spaces that need to be passed on literally to the spawn call, they need to be quoted. As long as the subcomponents within the *path* arguments are quoted, using either of the following methods:

```
\'path with space\'
or
\"path with space\",
the following is allowed:
"\'path with space\' arg1 arg2 \"arg3 with space\"".
This would be parsed as
"path with space" -> path
arg1 = arg1
```

arg2 = arg2

arg3 = "arg3 with space".

The command line is in turn passed onto a *spawn* command by the HAM to create a new process that will execute the command.

The action is executed when the appropriate condition is triggered.

Note that this action also triggers a restart *condition* in the entity.

Currently the following flags are defined:

HREARMAFTERRESTART

Indicates that the action is to be automatically rearmed after the entity that it belongs to is restarted. By default, this flag is *disabled* — actions automatically get pruned across restarts of the entity. Note that if the condition that this action belongs to is pruned after a restart, this action will also be removed, regardless of the value of this flag.

HACTIONBREAKONFAIL

Indicates that if this action were to fail, and it is part of a list of actions, none of the actions following this one in the list of actions will be executed.

HACTIONKEEPONFAIL

Indicates that the action will be retained even if it fails. The default behavior is to remove failed actions. Nevertheless if the condition that this action is associated with is not retained, the action will get automatically removed.

Users can specify what will be done if an action fails. By adding action fail *actions* to a list associated with an action, users can determine what will be done in the case of an action failure. For every action that fails, the corresponding action fail list will be executed. Certain actions (e.g. *ham_action_log()* and

ham_action_heartbeat_healthy()) never fail. For more details, refer to the appropriate section in the HAM API reference for the ham action fail *() calls.

Returns:

A valid handle to an action in a condition, or NULL if an error occurred (errno is set).

Errors:

EBADF Couldn't connect to the HAM.

EINVAL The name given in *aname* is invalid (e.g. it contains the "/" character) or is NULL.

The connection to the HAM is invalid. This happens when the process that opened the connection (using *ham_connect()*) and the process that's calling *ham_action_restart()* aren't the same.

ENAMETOOLONG

The name given (in *aname*) is too long, i.e. it exceeds POSIX PATH MAX (defined in limits.h>). Note that the combined length of an entity/condition/action name is also limited by _POSIX_PATH_MAX.

ENOENT There's no entity or condition specified by the given handle (*chdl*).

Not enough memory to create a new handle. **ENOMEM**

In addition to the above errors, the HAM returns any error it encounters while servicing this request.

Classification:

QNX Neutrino

Safety	
Cancellation point	No
Interrupt handler	No
Signal handler	No
Thread	Yes

See also:

ham_action_execute(), ham_action_notify_pulse(), ham_action_notify_signal(), ham action remove(), ham action waitfor(), ham condition(), ham_condition_handle()

Add a waitfor action to a condition

Synopsis:

Library:

libham

Description:

The *ham_action_waitfor()* function adds an action (*aname*) to a given condition. In this case, the action is one that lets you insert arbitrary delays into a sequence of actions.

The waitfor call fails if the specified path does not appear in the specified interval.

The handle (chdl) is obtained either:

- from one of the ham_condition*() functions to add conditions or:
- by calling any of the *ham_condition_handle()* functions to request a handle to a specific condition.

You use the *delay* parameter to specify the "waitfor" period in milliseconds.

You can also specify a *path* in order to control the delay. If *path* is specified, then the action waits for either the pathname to appear in the namespace or for the period specified in *delay*, whichever is *lower*.

Currently the following flag is defined:

HREARMAFTERRESTART

Indicates that the action is to be automatically rearmed after the entity that it belongs to is restarted. By default, this flag is *disabled* — actions automatically get pruned across restarts of the entity. Note that if the condition that this action belongs to is pruned after a restart, this action will also be removed, regardless of the value of this flag.

Returns:

A valid handle to an action to a condition, or NULL if an error occurred (errno is set).

Errors:

EBADF Couldn't connect to the HAM.

EINVAL The name given in *aname* is invalid (e.g. it contains the "/" character)

or is NULL.

The connection to the HAM is invalid. This happens when the process that opened the connection (using ham_connect()) and the process that's calling *ham action waitfor()* aren't the same.

The delay specified is invalid. Only values greater than zero are permitted.

The condition into which the action is being added has the HCONDNOWAIT set.

EEXIST The name provided for the action already exists.

ENAMETOOLONG

The name given (in *aname*) is too long, i.e. it exceeds POSIX PATH MAX (defined in limits.h>). Note that the combined length of an entity/condition/action name is also limited by _POSIX_PATH_MAX.

ENOENT There's no entity or condition specified by the given handle (*chdl*).

ENOMEM Not enough memory to create a new handle.

In addition to the above errors, the HAM returns any error it encounters while servicing this request.

Classification:

QNX Neutrino

Safety

Cancellation point	No
Interrupt handler	No
Signal handler	No
Thread	Yes

See also:

ham_action_execute(), ham_action_notify_pulse(), ham_action_notify_signal(), ham action remove(), ham_action_restart(), ham_condition(), ham condition handle()

Attach an entity

Synopsis:

Library:

libham

Description:

You use the *ham_attach()* function to attach an *entity* to the HAM. The *ham_attach_node()* function is used when a nodename is used to specify a remote HAM instead of a node identifier (*nd*). An entity can be any process on the system. You can use this function to:

- attach a process that's already running or:
- tell the HAM to start a process and then add it as an entity to its context.

Once an entity has been attached, you can add *conditions* and *actions* to it. For arbitrary processes, the HAM can monitor either:

- processes that are in session 1 (e.g. by calling procmgr_daemon())
 or:
- any process that dies due to the delivery of a core-dump signal, i.e. one of the set of signals that causes a core-dump. For more information on these signals, please refer to the dumper utility in the *Utility Reference*.



Since the *ham_attach*()* functions open a connection to the HAM, for convenience they also perform the initial *ham_connect()* call. So any client that makes a *ham_attach()* call doesn't need to call *ham_connect()* or *ham_disconnect()* before and after the call to *ham_attach()*.

The arguments are as follows:

ename The name of the entity; it must be unique across the whole context of the HAM.

nd

This *ham_attach()* parameter specifies the node identifier of the remote node on which the entity being targeted is running (or will be run). The *nd* is the node identifier of the remote node at the time the call is made.



Since node identifiers are transient objects, you should obtain the value for *nd* immediately before the call, using *netmgr_strtond()* or another function that converts nodenames into node identifiers.

pid Process ID to attach to, if the process is already running. If $pid \le 0$, the

HAM starts the process and begins monitoring it. In this case, line must

also be specified with the FULL path (including all required

arguments) to start the process.

nodename This ham_attach_node() parameter is a fully qualified node name

(FQNN).

line

This contains the FULL command line, including arguments, to start the process. This is used ONLY if $pid \le 0$ and is ignored otherwise. If either the pathname or the arguments contain spaces that need to be passed on literally to the spawn call, they need to be quoted. As long as the subcomponents within the path arguments are quoted, using either of the following methods:

```
\'path with space\'
```

or

\"path with space\",

the following is allowed:

"\'path with space\' arg1 arg2 \"arg3 with space\"".

This would be parsed as

"path with space" -> path

arg1 = arg1

arg2 = arg2

arg3 = "arg3 with space".

flags Currently, the following flag is defined:

HENTITYKEEPONDEATH

Indicates that the entity and all it conditions will be retained when the entity dies and is not restarted. The default is to remove all entities that are not restarted.

Returns:

Errors:

A valid handle to an entity on success; otherwise, NULL (errno is set).

EBADF Couldn't connect to the HAM.

EEXIST The name provided for the entity already exists.

EINVAL The name given in *ename* is invalid (e.g. it contains the "/" character)

or is NULL.

The *pid* provided is ≤ 0 , but no *line* was provided.

ENAMETOOLONG

The name given (in *ename*) is too long, i.e. it exceeds _POSIX_PATH_MAX (defined in limits.h>). Note that the *combined length* of an entity/condition/action name is also limited by _POSIX_PATH_MAX.

ENOMEM Not enough memory to create a new handle.

In addition to the above errors, the HAM returns any error it encounters while servicing the request to add a new entity to its context.

Classification:

QNX Neutrino

Safety	
Cancellation point	No
Interrupt handler	Yes
Signal handler	Yes
Thread	Yes

See also:

ham_attach(), ham_connect(), ham_detach(), ham_detach_self(), ham_disconnect()
procmgr_daemon() in the Neutrino Library Reference

Attach an application as a self-attached entity

Synopsis:

```
#include <ha/ham.h>
ham entity t *ham attach self(
                  const char *ename,
                   Uint64t hp,
                  int hpdl,
                  int hpdh.
                  unsigned flags );
```

Library:

libham

Description:

You use the ham attach self() call to attach an application as a self-attached entity to the HAM. A self-attached entity is a process that chooses to send heartbeats to the HAM, which will then monitor the process for failure. Self-attached entities can, on their own, decide at exactly what point in their lifespan they want to be monitored, what conditions they want acted upon, and when they want to stop the monitoring.

Note that self-attached entities can be any processes, not just those in session 1 (unlike the requirement for the *ham attach()* call).

Once an entity has been attached, you can add *conditions* and *actions* to it.



Since the ham attach*() functions open a connection to the HAM, for convenience they also perform the initial ham connect() call. So any client that makes a ham attach self() call doesn't need to call ham connect() or ham disconnect() before and after the call to ham attach self().

The arguments are as follows:

The name of the entity. This must be unique across the whole context of ename

> the HAM. Self-attached entities can also specify an interval at which they'll send heartbeats to the HAM. The heartbeat can be used to detect

unresponsive processes that aren't dead.

hp The heartbeat interval in nanoseconds. The lowest permissible heartbeat

interval is defined in the constant HAMHBEATMIN (see <ha/ham.h>).

Use 0 if no heartbeat is desired.



Note that here you're specifying the heartbeat interval — the client must still call the ham heartbeat() function to actually transmit the heartbeat.

hpdl The number of permissible missed heartbeats before CONDHBEATMISSEDLOW is triggered. The value of *hpdl* must be $\leq hpdh$. hpdh As for hpdl, but for CONDHBEATMISSEDHIGH. The value of hpdh must be

 $\geq hpdl$.

flags There are no flags defined at this time.

Returns:

A valid handle to an entity on success; otherwise, NULL (errno is set).

Errors:

EBADF Couldn't connect to the HAM.

EEXIST The name provided for the entity already exists.

EINVAL The name given in *ename* is invalid (e.g. it contains the "/" character)

or is NULL.

ENAMETOOLONG

The name given (in *aname*) is too long, i.e. it exceeds _POSIX_PATH_MAX (defined in limits.h>). Note that the *combined length* of an entity/condition/action name is also limited by _POSIX_PATH_MAX.

ENOMEM Not enough memory to create a new handle.

In addition to the above errors, the HAM returns any error it encounters while servicing the request to add a new entity to its context.

Classification:

QNX Neutrino

Safety

Cancellation point No
Interrupt handler No
Signal handler No
Thread Yes

See also:

ham_attach(), ham_condition(), ham_connect(), ham_detach(), ham_detach_self(),
ham_disconnect(), ham_heartbeat()

In the *Library Reference*: procmgr_daemon()

Set up a condition to be triggered when a certain event occurs

Synopsis:

Library:

libham

Description:

You call this function to set up a condition that will be triggered when a significant event occurs.

Each entity can be associated with several different conditions, and associated with each of these conditions is a set of actions that will be performed in FIFO sequence when the condition is true. If an entity has multiple conditions that are true simultaneously, with different sets of actions associated with each condition, then all the actions associated with each condition are performed, in sequence.

This mechanism lets you combine actions together into sets and choose to remove/control them as a single "group" instead of as individual items.

The *ehdl* argument is an entity handle obtained either:

- from a ham_attach*() call or a ham_entity*() call or:
- by calling *ham_entity_handle*()* with an existing entity name. Since conditions are associated with entities, the entity handle (*ehdl*) must be available before you can add conditions.

Since conditions are associated with entities, the entity handle (*ehdl*) must be available before you can add conditions.

You can specify any of the following for type:

CONDDEATH The entity died.

An entity's death is detected for all processes in session 1, for processes that terminate abnormally (typically due to the delivery of a signal), and for processes that are attached as self-attached entities.

CONDDETACH The entity detached from the HAM.

CONDHBEATMISSEDLOW

The entity missed a heartbeat specified as "low" severity.

CONDHBEATMISSEDHIGH

The entity missed a heartbeat specified as "high" severity.

CONDRESTART The entity was restarted.

The *cname* argument is the condition name. It must be unique across all conditions in the given entity.

When a condition is triggered, all actions defined in all conditions of the given type are executed. When an entity dies, a condition of type HCONDDEATH is triggered, and all actions in all conditions that match this type are executed.

Currently the following flags are defined:

HCONDINDEPENDENT

Indicates that the actions associated with this condition are to be performed in a separate thread. When a condition is triggered, actions within it are performed in FIFO order. For multiple conditions that are simultaneously triggered, the conditions are serviced in an arbitrary order. By setting this flag, you're marking the condition as *independent* — all actions associated with it are executed in a separate thread, independent of actions in other conditions.

HCONDNOWAIT

Indicates that the condition can't contain any "waitfor" actions. Waitfor actions are normally slow and may contain significant delays. This will delay the execution of subsequent actions in the list. Specifying HCONDNOWAIT guarantees there will be no delays once the condition is triggered.

HREARMAFTERRESTART

Indicates that the condition is to be automatically re-armed after the entity that it belongs to is restarted. Be default, this flag is disabled — conditions automatically get removed across restarts of the entity. Note that if the entity that the condition belongs to gets removed, this condition will also be removed, regardless of the state of this flag.



You must call the <code>ham_connect()</code> function <code>before</code> the first call to <code>ham_condition()</code> in a process. If a process calls <code>ham_connect()</code> and then calls <code>fork()</code>, the child process must call <code>ham_connect()</code> again before it can successfully call <code>ham_condition()</code> in order to add conditions.

Returns:

Errors:

A valid handle to a condition in the given entity; otherwise, NULL (and errno is set).

EBADF Couldn't connect to the HAM.

EEXIST The name provided for the condition already exists.

EINVAL The handle, type, or name given is invalid (e.g. it contains the "/"

character) or is NULL.

The connection to the HAM is invalid. This happens when the process that opened the connection (using ham_connect()) and the process

that's calling *ham condition()* aren't the same.

ENAMETOOLONG

The name given (in *aname*) is too long, i.e. it exceeds _POSIX_PATH_MAX (defined in limits.h>). Note that the *combined length* of an entity/condition/action name is also limited by _POSIX_PATH_MAX.

ENOMEM Not enough memory to create a new handle.

In addition to the above errors, the HAM returns any error it encounters while servicing this request.

Classification:

QNX Neutrino

Safety	
Cancellation point	No
Interrupt handler	No
Signal handler	No
Thread	Yes

See also:

ham_attach(), ham_attach_self(), ham_condition_remove(), ham_connect(), ham_entity_handle() Perform control operations on an entity object in a HAM

Synopsis:

Library:

libham

Description:

The *ham_entity_control()* function can be used to control the state of an entity object in a HAM. This function is designed to be extensible with additional commands. Currently, the following commands are defined:

```
HENABLE, /* enable item */
HDISABLE, /* disable item */
HADDFLAGS, /* add flag */
HREMOVEFLAGS, /* remove flag */
HSETFLAGS, /* set flag to specific */
HGETFLAGS, /* get flag */
```

When an entity item is enabled (the default), any event that occurs in relation to this event will trigger appropriate conditions and actions related to the entity. If an entity item is disabled, no events relating to that entity will be *reacted to*. If an entity is disabled, all conditions and actions under it are also disabled. Individual conditions and actions can be enabled and disabled using the corresponding control functions for conditions and actions, respectively.

The HADDFLAGS, HREMOVEFLAGS, and HSETFLAGS commands can be used to modify the set of flags associated with the entity being controlled. Add flags and remove flags are used to either add to or remove from the current set of flags, the specified set of flags (as given in *flags*). The set flags function is called when the current set of flags is to be replaced by *flags*.

Flags

Any flag that is valid for the corresponding condition can be used when <code>ham_condition_control()</code> is being used to set flags, with the exception of HCONDNOWAIT if the existing condition already has some waitfor actions associated with it.

For the HENABLE and HDISABLE commands:

HRECURSE Applies the command recursively.

Returns:

For enable, disable, add flags, remove flags, and set flags functions:

0 Success.

-1 An error occurred (*errno* is set).

For get flags function

flags Success.

-1 An error occurred (*errno* is set).

Errors:

EBADF Couldn't connect to the HAM.

EINVAL The *command* or *flags* variable is invalid.

In addition to the above errors, the HAM returns any error it encounters while servicing this request.

Classification:

QNX Neutrino

Safety	
Cancellation point	No
Interrupt handler	No
Signal handler	No
Thread	Yes

See also:

ham_action_control(), ham_condition_control()

Software Systems GmbH & Co. KG.

Get a handle to a condition in an entity

Synopsis:

Library:

libham

Description:

The *ham_condition_handle()* function returns a handle to a condition (*cname*) in an entity (*ename*).

The handle obtained from this function can be passed to other functions, such as ham action restart() or ham condition handle free().

The handle returned is opaque — its contents are internal to the library.

If a node (nd) is specified, the handle is to an entity/condition/action combination that refers to a process on that remote node. The ham_condition_handle_node() function is used when a nodename is used to specify a remote HAM instead of a node identifier (nd).

There are no flags defined at this time.

Returns:

A valid ham condition tor NULL if an error occurred (errno is set).

Errors:

EINVAL The name given in *cname* or *ename* is invalid (e.g. it contains the "/" character) or is NULL.

ENAMETOOLONG

The name given (in *aname*) is too long, i.e. it exceeds _POSIX_PATH_MAX (defined in limits.h>). Note that the *combined length* of an entity/condition/action name is also limited by _POSIX_PATH_MAX.

ENOENT There's no condition by the name *cname* defined in an entity by name

ename in the current context of the HAM.

ENOMEM Not enough memory to create a new handle.

Classification:

QNX Neutrino

Safety	
Cancellation point	No
Interrupt handler	No
Signal handler	No
Thread	Yes

Caveats:

A call to *ham_condition_handle()* and a subsequent use of the handle returned in a call such as *ham_action_restart()* are completely *asynchronous*. Therefore, a valid action/condition/entity may no longer exist when the handle is used to attach actions at a later time.

In such an event, the *ham_action*()* functions will return an error (ENOENT) that the condition doesn't exist in the given entity.

See also:

ham_action_execute(), ham_action_handle(), ham_action_handle_free(), ham_action_notify_pulse(), ham_action_notify_signal(), ham_action_remove(), ham_action_restart(), ham_action_waitfor(), ham_condition_handle_free(), ham_entity_handle(), ham_entity_handle_free() Free a previously obtained handle to a condition in an entity

Synopsis:

#include <ha/ham.h>

int ham_condition_handle_free(ham_condition_t *chdl);

Library:

libham

Description:

The *ham_condition_handle_free()* function frees a handle associated with a condition (*chdl*) and reclaims all storage associated with the given handle.

The handle *chdl* must be obtained from *ham_condition_handle()* or *ham_condition()*. Once a handle is freed, it is no longer available to refer to any condition. The *ham_condition_handle_free()* call frees storage allocated for the handle itself but does not remove the condition itself, which is in the HAM.

Returns:

- 0 Success.
- -1 An error occurred (*errno* is set).

Errors:

EINVAL The handle passed to the function isn't valid.

Classification:

QNX Neutrino

Safety Cancellation point No Interrupt handler No Signal handler No Thread Yes

Caveats:

The *ham_condition_handle_free()* function frees storage related only to the handle in the client — it doesn't remove the corresponding entity.

See also:

ham_action_handle_free(), ham_condition(), ham_condition_handle(), ham_entity_handle_free() Attach a condition associated with a condition raise condition

Synopsis:

Library:

libham

Description:

This condition is triggered whenever an entity raises a condition, which matches the given *rtype*, *rclass*, and *rseverity*. An entity that raises a condition, does so with a given set of values for type, class, and severity. Subscribers to this event can specify the conditions they are interested in either explicitly or by using the following special wild cards for each of these values.

```
CONDRAISETYPEANY /* ANY type : raised condition */
CONDRAISECLASSANY /* ANY class : raised condition */
CONDRAISESEVERITYANY /* ANY severity : raised condition */
```

The *ehdl* argument is an entity handle obtained either:

- from a ham_attach*() call or a ham_entity*() call or:
- by calling ham_entity_handle*() with an existing entity name. Since conditions are
 associated with entities, the entity handle (ehdl) must be available before you can
 add conditions.

Returns:

```
a condition handle Success.
```

NULL Failure (*errno* is set).

Errors:

EBADF Couldn't connect to the HAM.

EEXIST The name provided for the condition already exists.

EINVAL

The handle, type, or name given is invalid (e.g. it contains the "/" character) or is NULL.

The connection to the HAM is invalid. This happens when the process that opened the connection (using *ham_connect()*) and the process that's calling *ham_condition()* aren't the same.

ENAMETOOLONG

The name given (in *aname*) is too long, i.e. it exceeds _POSIX_PATH_MAX (defined in limits.h>). Note that the *combined length* of an entity/condition/action name is also limited by _POSIX_PATH_MAX.

ENOMEM Not enough memory to create a new handle.

In addition to the above errors, the HAM returns any error it encounters while servicing this request.

Classification:

QNX Neutrino

_	Safety	
	Cancellation point	No
	Interrupt handler	No
	Signal handler	No
,	Thread	Yes

See also:

ham_condition(), ham_condition_state(), ham_attach() ham_attach_self()
ham_entity() ham_entity_control() ham_entity_handle() ham_entity_handle_free()
ham_entity_node()

Remove a condition from an entity

Synopsis:

#include <ha/ham.h>

int ham condition remove (ham condition t *chdl, unsigned flags);

Library:

libham

Description:

The ham condition remove() function removes a condition from an entity.

The chdl argument is a handle to a condition that was previously obtained by a call to ham_condition() or to ham_condition_handle().

There are no flags defined at this time.



The ham connect() function must be called before the first call to ham condition remove() in a process. If a process calls ham connect() and then calls fork(), the child process needs to call ham connect() again before it can successfully call ham condition remove() to remove conditions.

Returns:

- 0 Success.
- -1 An error occurred (errno is set).

Errors:

EBADF Couldn't connect to the HAM.

EINVAL The handle passed as an argument is invalid.

> The connection to the HAM is invalid. This happens when the process that opened the connection (using ham connect()) and the process that's

calling *ham_condition_remove()* aren't the same.

ENOENT There's no condition corresponding to the handle supplied.

In addition to the above errors, the HAM returns any error it encounters while servicing the request.

Classification:

QNX Neutrino

Safety	
Cancellation point	No
Interrupt handler	No
Signal handler	No
Thread	Yes

See also:

 $ham_condition(), \, ham_condition_handle(), \, ham_connect()$

Attach a condition associated with a state transition

Synopsis:

Library:

libham

Description:

This condition is triggered when the specified entity changes from a state matching *fromstate* to a state matching *tostate*.

CONDSTATEANY can be used to specify a wild card signifying any STATE. The matching of states is based on either an explicit match or special conditions explained in the Flags section below.

The *ehdl* argument is an entity handle obtained either:

- from a ham_attach*() call or a ham_entity*() call or:
- by calling *ham_entity_handle*()* with an existing entity name. Since conditions are associated with entities, the entity handle (*ehdl*) must be available before you can add conditions.

Flags

Standard flags that are applicable for conditions are also valid here. (See *ham_condition()* for more details). In addition, the following flags are also defined:

```
/* special condition flags */
HCONDSTATEFROMSET /* from state is a set */
HCONDSTATETOSET /* to state is a set */
HCONDSTATEFROMINV /* invert from state set */
HCONDSTATETOINV /* invert to state set */
```

States can be given using:

- individual values
- the wild card CONDSTATEANY
- bitmaps that allow several states to be referred to collectively as sets.

If *fromstate* or *tostate* refers to a set, the corresponding flag HCONDSTATEFROMSET or HCONDSTATETOSET must be set.

If you want *fromstate* or *tostate* to refer to the logical negation of a set of states define HCONDSTATEFROMINV or HCONDSTATETOINV in flags. This would logically invert the set of states specified (equivalent to saying "any state other than this set").

Returns:

a condition handle Success.

NULL Failure (*errno* is set).

Errors:

EBADF Couldn't connect to the HAM.

EEXIST The name provided for the condition already exists.

EINVAL The handle, type, or name given is invalid (e.g. it contains the "/"

character) or is NULL.

The connection to the HAM is invalid. This happens when the process that opened the connection (using <code>ham_connect()</code>) and the process

that's calling *ham_condition()* aren't the same.

ENAMETOOLONG

The name given (in *aname*) is too long, i.e. it exceeds _POSIX_PATH_MAX (defined in limits.h>). Note that the *combined length* of an entity/condition/action name is also limited by POSIX_PATH_MAX.

ENOMEM Not enough memory to create a new handle.

In addition to the above errors, the HAM returns any error it encounters while servicing this request.

Classification:

QNX Neutrino

Safety	
Cancellation point	No
Interrupt handler	No
Signal handler	No
Thread	Vec

See also:

ham_condition(), ham_condition_raise(), ham_attach() ham_attach_self()
ham_entity() ham_entity_control() ham_entity_handle() ham_entity_handle_free()
ham_entity_node()

Connect to the HAM

Synopsis:

```
#include <ha/ham.h>
int ham_connect( unsigned flags);
int ham_connect_nd( int nd, unsigned flags);
int ham connect_node( const char *nodename, unsigned flags);
```

Library:

libham

Description:

The *ham_connect()* function initializes a connection to a HAM. The *ham_connect_nd()* and *ham_connect_node()* functions initialize connections to remote HAMs.



A process may have only a single connection open to a HAM at any time.

The *nd* specified to ham_connect_nd is the node identifier of the remote node at the time the *ham connect nd()* call is made.



Since node identifiers are transient objects, you should obtain the value for *nd* immediately before the call, using *netmgr_strtond()* or another function that converts nodenames into node identifiers.

The *ham_connect_node()* function takes as a parameter a fully qualified node name (FQNN).

You can call these functions any number of times, but because the library maintains a reference count, you need to call *ham_disconnect()* the same number of times to release the connection.

Connections are associated with a specific process ID (*pid*). If a process performs $ham_connect()$ and then calls fork(), the child process needs to reconnect to the HAM by calling $ham_connect()$ again.

But if a process calls any of the following:

- ham attach self()
- ham attach()
- ham attach node()
- ham detach()
- ham_detach_self()
- ham detach name()

- ham_detach_name_node()
- ham stop()
- ham stop nd()
- ham_stop_node()
- ham_entity()
- ham_entity_node()
- ham verbose()

it doesn't need to call *ham_connect*()*, since those functions do so on their own.

For all other *ham*()* functions, clients must call *ham_connect()* first.

There are no flags defined at this time.

Returns:

- 0 Success.
- -1 An error occurred (*errno* is set).

Errors:

Upon failure, the *ham_connect*()* functions return the error as set by the underlying *open()* library call that failed.

Classification:

QNX Neutrino

Safety	
Cancellation point	No
Interrupt handler	No
Signal handler	No
Thread	Yes

See also:

ham_attach_self(), ham_disconnect(), ham_stop()
In the Library Reference: fork(), open(), netmgr_strtond()

Detach an entity from the HAM

Synopsis:

```
#include <ha/ham.h>
```

Library:

libham

Description:

This function detaches an attached entity from the HAM. The entity being detached must NOT be a self-attached entity.

The handle passed into this function (*ehdl*) is either returned by a previous *ham_attach()* call or obtained from *ham_entity_handle()*.

There are no flags defined at this time.

This function automatically calls <code>ham_connect()</code> and <code>ham_disconnect()</code> for the client.

The *ham_detach()* call automatically raises a HCONDDETACH condition in the HAM for that entity.

Returns:

Success.

-1 An error occurred (*errno* is set).

Errors:

EBADF Couldn't connect to the HAM.

EINVAL The handle passed as an argument is invalid.

ENOENT There's no entity corresponding to the handle supplied.

In addition to the above errors, the HAM returns any error it encounters while servicing the request to remove the entity from its context.

Classification:

QNX Neutrino

Safety

Cancellation point No

 $continued. \dots$

Safety	
Interrupt handler	No
Signal handler	No
Thread	Yes

See also:

ham_attach(), ham_attach_self(), ham_connect(), ham_detach_name(), ham_detach_self(), ham_disconnect()

In the Library Reference: procmgr_daemon()

Detach an entity from the HAM, using an entity name

Synopsis:

Library:

libham

#include <ha/ham.h>

Description:

These functions detach an attached entity (*ename*) from a HAM. The entity being detached must NOT be a self-attached entity.

The *nd* specifies the node identifier of the remote node on which the entity being targeted is running, at the time the call is made.



Since node identifiers are transient objects, you should obtain the value for *nd* immediately before the call, using *netmgr_strtond()* or another function that converts nodenames into node identifiers.

The *ham_detach_name_node()* function is used when a nodename is used to specify a remote HAM instead of a node identifier (*nd*).

There are no flags defined at this time.

This function automatically calls ham connect() and ham disconnect() for the client.

Returns:

0 Success.

-1 An error occurred (*errno* is set).

Errors:

EBADF Error connecting to the HAM.

EINVAL The name passed as an argument is invalid.

ENOENT There's no entity corresponding to the name supplied.

In addition to the above errors, the HAM returns any error it encounters while servicing the request to remove the entity from its context.

Classification:

QNX Neutrino

S	afe	ts

Cancellation point	No
Interrupt handler	No
Signal handler	No
Thread	Yes

See also:

 $ham_attach(), ham_attach_self(), ham_connect(), ham_detach(), ham_detach_self(), ham_detach(), ham$ ham disconnect()

Detach a self-attached entity from the HAM

Synopsis:

```
#include <ha/ham.h>
```

Library:

libham

Description:

This function detaches a self-attached entity from the HAM. The entity being detached *must* be a self-attached entity.

The handle passed into this function (*ehdl*) is either returned by a previous *ham_attach_self()* call or obtained from *ham_entity_handle()*.

There are no flags defined at this time.

This function automatically calls *ham_connect()* and *ham_disconnect()* for the client.

Returns:

- 0 Success.
- -1 An error occurred (*errno* is set).

Errors:

EBADF Error connecting to the HAM.

EINVAL The handle passed as an argument is invalid.

ENOENT There is no entity corresponding to the handle supplied.

In addition to the above errors, the HAM returns any error it encounters while servicing the request to remove the entity from its context.

Classification:

QNX Neutrino

Safety

-	
Cancellation point	No
Interrupt handler	No
Signal handler	No

Thread Yes

See also:

ham_attach(), ham_attach_self(), ham_connect(), ham_detach(), ham_detach_name(), ham_disconnect()

Disconnect from the HAM

Synopsis:

```
#include <ha/ham.h>
int ham_disconnect( unsigned flags);
int ham_disconnect_nd( int nd, unsigned flags);
int ham_disconnect_node( const char *nodename, unsigned flags);
```

Library:

libham

Description:

The <code>ham_disconnect()</code> function closes a previously open connection to a HAM. The <code>ham_disconnect_nd()</code> and <code>ham_disconnect_node()</code> functions close previously opened connections to remote HAMs.

The *nd* specified to ham_disconnect_nd is the node identifier of the remote node at the time the *ham disconnect nd()* call is made.



Since node identifiers are transient objects, you should obtain the value for *nd* immediately before the call, using *netmgr_strtond()* or another function that converts nodenames into node identifiers.

The *ham_disconnect_node()* function takes as a parameter a fully qualified node name (FQNN).

Because the library maintains a reference count, the actual connection to the HAM is released only when the number of calls made to *ham_disconnect()* matches the number of calls previously made to *ham_connect()*.

When a process calls *ham_connect()* and then calls *fork()*, the connection is no longer valid in the child process. To reconnect to the HAM, the child process must call either:

• ham_connect() directly, which will automatically close the existing connection and reopen a new one

or:

• *ham disconnect()*, followed by *ham connect()*.

There are no flags defined at this time.

Returns:

- 0 Success.
- -1 An error occurred (*errno* is set).

© 2009, QNX Software Systems GmbH & Co. KG.

Errors:

EINVAL There's no valid connection to the HAM to disconnect.

Classification:

QNX Neutrino

Cancellation point No
Interrupt handler No
Signal handler No
Thread Yes

See also:

ham_attach_self(), ham_connect(), ham_connect_nd(), ham_connect_node(),
ham_stop()

In the *Library Reference*: fork()

Create entity placeholder objects in a HAM

Synopsis:

Library:

libham

Description:

These functions are used to create placeholders for entity objects in a HAM. The *ham_entity_node()* function is used when a nodename is used to specify a remote HAM instead of a node identifier (*nd*).

You can use these functions to create entities, and associate conditions and actions with them, before the process associated with an entity is started (or attached). Subsequent *ham_attach*()* calls by entities can attach to these placeholder and thereby enable conditions and actions when they occur.

The *nd* variable specifies the node identifier of the remote node at the time the call is made.



Since node identifiers are transient objects, we recommend that the value for *nd* is obtained at the time of the call, using *netmgr_strtond()* or another function that converts nodenames into node identifiers.

The *ham_entity_node()* function takes as a parameter a fully qualified node name (FQNN).

Returns:

an entity handle Success.

NULL Failure (*errno* is set).

Errors:

EBADF Couldn't connect to the HAM.

EINVAL The name given in *ename* is invalid (e.g. it contains the "/" character)

or is NULL.

ENAMETOOLONG

The name given (in *aname*) is too long, i.e. it exceeds _POSIX_PATH_MAX (defined in limits.h>). Note that the *combined length* of an entity/condition/action name is also limited by _POSIX_PATH_MAX.

ENOMEM Not enough memory to create a new handle.

In addition to the above errors, the HAM returns any error it encounters while servicing this request.

Classification:

QNX Neutrino

Safety	
Cancellation point	No
Interrupt handler	No
Signal handler	No
Thread	Yes

See also:

ham_attach(), ham_attach_self(), ham_condition(), ham_condition_control(),
ham_condition_handle(), ham_condition_handle_free(), ham_condition_remove(),
ham_detach(), ham_detach_name(), ham_detach_self(),

Used by an entity to raise a condition

Synopsis:

```
#include <ha/ham.h>
```

```
int ham entity condition raise(
                            ham entity t *ehdl,
                            unsigned rtype,
                            unsigned rclass,
                            unsigned rseverity,
                            unsigned flags );
```

Library:

libham

Description:

This function is used by an entity to notify a HAM of an interesting event of its choice. This in turn triggers a CONDITION RAISE in the HAM, which will search for matching subscribers for this event and execute all associated actions.

The values of rtype, rclass, and rseverity can be used to permit finer grain matching and to gather additional information relating to the condition.

To learn more about the matching mechanism, refer to the API documentation for ham condition raise().

Returns:

0 Success.

-1 An error occurred (errno is set).

Errors:

EBADF Couldn't connect to the HAM.

The handle specified in *ehdl* is invalid. **EINVAL**

> The connection to the HAM is invalid. This happens when the process that opened the connection (using ham connect()) and the process that's

calling this function are not the same.

ENOENT There's no entity by the given handle (*ehdl*).

In addition to the above errors, the HAM returns any error it encounters while servicing this request.

Classification:

QNX Neutrino

Safety

Cancellation point	No
Interrupt handler	No
Signal handler	No
Thread	Yes

See also:

ham_condition(), ham_condition_raise(), ham_condition_state(), ham_attach()
ham_attach_self() ham_entity() ham_entity_control() ham_entity_handle()
ham_entity_handle_free() ham_entity_node()

Synopsis:

```
#include <ha/ham.h>
int ham entity condition state(
                           ham entity t *ehdl,
                           unsigned tostate,
                           unsigned flags );
```

Library:

libham

Description:

This function enables an entity to report a transition to the HAM; the value tostate indicates the transitional state. The HAM in turn triggers a condition state event for this entity, and will search for matching subscribers for this event and execute all associated actions. For more details of the matching mechanisms refer to the API documentation for ham condition state().

Returns:

- 0 Success.
- -1 An error occurred (errno is set).

Errors:

EBADF Couldn't connect to the HAM.

EINVAL The handle specified in *ehdl* is invalid.

> The connection to the HAM is invalid. This happens when the process that opened the connection (using ham connect()) and the process that's

calling this function are not the same.

ENOENT There's no entity by the given handle (*ehdl*).

In addition to the above errors, the HAM returns any error it encounters while servicing this request.

Classification:

QNX Neutrino

Safety

Cancellation point No

continued...

Safety	
Interrupt handler	No
Signal handler	No
Thread	Yes

See also:

ham_condition(), ham_condition_raise(), ham_condition_state(), ham_attach()
ham_attach_self() ham_entity() ham_entity_control() ham_entity_handle()
ham_entity_handle_free() ham_entity_node()

Perform control operations on an entity object in a HAM

Synopsis:

Library:

libham

Description:

The *ham_entity_control()* function can be used to control the state of an entity object in a HAM. This function is designed to be extensible with additional commands. Currently, the following commands are defined:

```
HENABLE, /* enable item

HDISABLE, /* disable item

HADDFLAGS, /* add flag

HREMOVEFLAGS, /* remove flag

HSETFLAGS, /* set flag to specific

HGETFLAGS, /* qet flag
```

When an entity item is enabled (the default), any event that occurs in relation to this event will trigger appropriate conditions and actions related to the entity. If an entity item is disabled, no events relating to that entity will be *reacted to*. If an entity is disabled, all conditions and actions under it are also disabled. Individual conditions and actions can be enabled and disabled using the corresponding control functions for conditions and actions, respectively.

The HADDFLAGS, HREMOVEFLAGS, and HSETFLAGS commands can be used to modify the set of flags associated with the entity being controlled. Add flags and remove flags are used to either add to or remove from the current set of flags, the specified set of flags (as given in *flags*). The set flags function is called when the current set of flags is to be replaced by *flags*.

Flags

Any flag that is valid for the corresponding entity can be used when *ham_entity_control()* is being used to set flags.

For the HENABLE and HDISABLE commands:

HRECURSE Applies the command recursively.

Returns:

For enable, disable, add flags, remove flags, and set flags functions:

0 Success.

-1 An error occurred (*errno* is set).

For get flags function

flags Success.

-1 An error occurred (*errno* is set).

Errors:

EBADF Couldn't connect to the HAM.

EINVAL The *command* or *flags* variable is invalid.

In addition to the above errors, the HAM returns any error it encounters while servicing this request.

Classification:

QNX Neutrino

Safety	
Cancellation point	No
Interrupt handler	No
Signal handler	No
Thread	Yes

See also:

ham_action_control(), ham_condition_control()

Get a handle to an entity

Synopsis:

Library:

libham

Description:

The *ham_entity_handle()* function returns a handle to an entity (*ename*). The handle can then be passed to other functions that expect a handle to an entity (such as *ham_condition()* or *ham_entity_handle_free()*).

The handle returned is opaque — its contents are internal to the library.

If a node (nd) is specified, the handle is to an entity/condition/action combination that refers to a process on that remote node. The ham_entity_handle_node() function is used when a nodename is used to specify a remote HAM instead of a node identifier (nd).

There are no flags defined at this time.

Returns:

A valid ham_entity_t or NULL if an error occurred (errno is set).

Errors:

EINVAL The name given in *ename* is invalid (e.g. it contains the "/" character) or is NULL.

ENAMETOOLONG

The name given (in *ename*) is too long, i.e. it exceeds _POSIX_PATH_MAX (defined in limits.h>). Note that the *combined length* of an entity/condition/action name is also limited by POSIX_PATH_MAX.

ENOENT There's no entity by this name defined in the current context of the HAM.

ENOMEM Not enough memory to create a new handle.

Classification:

QNX Neutrino

Cancellation point	No
Interrupt handler	No
Signal handler	No
Thread	Yes

Caveats:

A call to ham entity handle() and a subsequent use of the handle returned in a call such as ham condition() are completely asynchronous. Therefore, a valid action/condition/entity may no longer exist when the handle is used at a later time.

In such an event, the ham condition*() functions will return an error (ENOENT) that the action in the condition doesn't exist in the given entity.

See also:

ham action handle(), ham action handle free(), ham condition(), ham_condition_handle(), ham_condition_handle_free(), ham_condition_remove(), ham entity handle free()

Free a previously obtained handle to an entity

Synopsis:

#include <ha/ham.h>

int ham_entity_handle_free(ham_entity_t *ehdl);

Library:

libham

Description:

The *ham_entity_handle_free()* function frees a handle associated with an entity (*ehdl*) and reclaims all storage associated with the given handle.

The handle (*ehdl*) must be obtained from ham_entity_handle(), ham_attach(), or ham_attach_self(). Once a handle is freed, it is no longer available to refer to any condition. The ham_entity_handle_free() call frees storage allocated for the handle but does not remove the condition itself, which is in the HAM.

Returns:

- 0 Success.
- -1 An error occurred (*errno* is set).

Errors:

EINVAL The name given in *ename* isn't valid.

Classification:

QNX Neutrino

Safety	
Cancellation point	No
Interrupt handler	No
Signal handler	No
Thread	Yes

Caveats:

The *ham_entity_handle_free()* function frees storage related only to the handle in the client — it doesn't remove the corresponding entity.

ham_action_handle_free(), ham_condition(), ham_condition_handle(), ham_entity_handle_free()

Send a heartheat to the HAM

Synopsis:

#include <ha/ham.h>

int ham_heartbeat(void);

Library:

libham

Description:

Self-attached entities that have committed to sending heartbeats at prescribed intervals need to call *ham heartbeat()* when they want to transmit a heartbeat.

The *ham_heartbeat()* function does nothing if the client isn't a self-attached entity or hasn't committed to sending heartbeats.

Returns:

This function always succeeds.

Classification:

QNX Neutrino

α	P 4	
• •	TOTA	

Cancellation point	No
Interrupt handler	No
Signal handler	No
Thread	Yes

Caveats:

Although this function always succeeds, the HAM doesn't always receive the heartbeat right away.

For example, if a client commits to sending a heartbeat every 5 seconds (at 5-, 10-, 15-second intervals, and so on), but instead transmits at the 2-second mark, then the HAM won't receive a heartbeat until the 5-second mark.

Or if the client sends a heartbeat at the 7-second mark and another at the 8-second mark, then the HAM will receive only *one heartbeat* at the 10-second mark.

ham_attach_self(), ham_detach_self()

Stop the HAM

Synopsis:

```
#include <ha/ham.h>
int ham_stop( void );
int ham_stop_nd( int nd);
int ham stop node( const char *nodename);
```

Library:

libham

Description:

The *ham_stop()* function instructs the HAM to terminate. The *ham_stop_nd()*, and *ham_stop_node()* functions are used to terminate remote HAMs. These are the only proper ways to stop the HAM.

The *nd* specified to *ham_stop_nd()* is the node identifier of the remote node at the time the *ham_stop_nd()* call is made.



Since node identifiers are transient objects, you should obtain the value for *nd* immediately before the call, using *netmgr_strtond()* or another function that converts nodenames into node identifiers.

The *ham_stop_node()* function takes as a parameter a fully qualified node name (FQNN). The *ham_stop_node()* function is used when a nodename is used to specify a remote HAM instead of a node identifier (*nd*).

Since the HAM and its "clone" the Guardian monitor each other, and re-spawn should the other fail, the HAM must first terminate the Guardian before it terminates itself.

Returns:

- 0 Success.
- -1 An error occurred (*errno* is set).

Errors:

EBADF Couldn't connect to the HAM.

In addition to the above, the HAM returns any error it encounters while servicing the request to terminate.

Classification:

QNX Neutrino

Safety

Cancellation point No
Interrupt handler No
Signal handler No
Thread Yes

Modify the verbosity of a HAM

Synopsis:

```
#include <ha/ham.h>
```

Arguments:

nodename

The name of the node on which to make the change, or NULL if you want to change the verbosity on the current node.

op

The operation to perform on the verbosity; one of the following:

- VERBOSE_SET_INCR increment the verbosity.
- VERBOSE SET DECR decrement the verbosity.
- VERBOSE SET set the verbosity to a specific value.
- VERBOSE GET get the verbosity.

value

The increment, decrement, or specific value for the verbosity, depending on the value of *op*. The *value* must be a non-negative integer. If *value* is zero, the function uses 1 for the increment or decrement.

Library:

libham

Description:

The *ham_verbose* function can be used to get or modify the verbosity of a HAM. You can also use the hamctrl utility to do this.

Returns:

When setting the verbosity:

- 0 Success.
- -1 An error occurred (*errno* is set).

If *op* is VERBOSE_GET, the function returns the current verbosity, or -1 if an error occurred (*errno* is set).

Errors:

EBADF Couldn't connect to the HAM.

EINVAL The *value* or *op* variable is invalid.

In addition to the above errors, the HAM returns any error it encounters while servicing this request.

Classification:

QNX Neutrino

Safety	
Cancell	

Cancellation point No
Interrupt handler No
Signal handler No
Thread Yes

See also:

ham_stop()

Chapter 7

Client Recovery Library Reference

The Client Recovery Library includes the following convenience functions you can use in your applications to transparently restore client/server connections in the event of failures:

Function	Description
ha_attach()	Attach a recovery function to a connection to make it HA-aware.
ha_close()	Detach an attached HA fd, then close it.
$ha_connection_ctrl()$	Control the operation of a HA-aware connection.
ha_ConnectAttach(), ha_ConnectAttach_r()	Create a connection using <i>ConnectAttach()</i> and attach it to the HA lib.
ha_ConnectDetach(), ha_ConnectDetach_r()	Detach an attached fd, then close the connection using ConnectDetach().
ha_creat(), ha_creat64()	Create a connection and attach it to the HA lib.
ha_detach()	Detach a connection previously attached via ha_attach().
ha_dup()	Duplicate an HA connection.
ha_fclose()	Detach an attached HA fd for a file stream, then close it.
ha_fopen()	Open a file stream and attach it to the HA lib.
ha_open(), ha_open64()	Open a connection and attach it to the HA lib.
ha_ReConnectAttach()	Reopen a connection while performing recovery.
ha_reopen()	Reopen a connection while performing recovery.



For information on using these $ha_*()$ functions, see the chapter Using the Client Recovery Library in this guide.

Attach a recovery function to a connection to make it HA-aware

Synopsis:

Library:

libha

Description:

The *ha_attach()* function attaches a recovery function to a connection in order to make the connection identified by *coid* HA-aware. If any operation on the connection *coid* returns an EBADF error, the recovery function pointed to by *rfn* will be called. The recovery function is defined by the following type declaration in <ha/>ha/types.h>:

```
typedef int (*RFp)(int coid, void *rhdl);
```

The recovery function identified by *rfn* will be called with *rhdl* as a parameter. The *rhdl* parameter is an opaque handle to data that will be interpreted and used by the recovery function itself. The recovery function is expected to perform client-specific recovery on the existing connection.

The recovery function returns a connection ID associated with the recovered connection. This connection ID must be the same as the one that had failed. The client can choose to recover in any way it thinks appropriate. It could reconnect to the same server (if the service is available), and then reconstruct its state with respect to the connection as appropriate from the client's perspective.

The client could also reconnect to a new server. The client recovery function must return the same connection ID in order to indicate successful recovery to the HA library so that the library can re-initiate the previous failed operation on the connection.

If the client doesn't want to — or can't — recover, it can return -1 to the library. The library will then immediately propagate the error relating to the failed operation on the connection back to the caller. For convenience, the HA library provides $ha_reopen()$ and $ha_ReConnectAttach()$ calls that close the old connection and obtain the new connection appropriately.

You normally call *ha_attach()* after a connection is established and a valid *coid* is available.

The other method to make a connection HA-aware is to call the convenience functions ha open(), ha $creat \mid 64()$, ha $ConnectAttach \mid r()$, or ha fopen().

Currently the following flag is defined:

HAREPLACERECOVERYFN

Indicates that the call to *ha_attach()* is replacing the recovery function with a new one. You can replace recovery functions only if the connection already has a recovery function associated with it.

Returns:

- 0 Success
- -1 An error occurred (*errno* is set).

Errors:

EBADF There's no connection identified by *coid*.

Or, HAREPLACERECOVERYFN is set, but there's no HA-aware

connection identified by coid.

EEXIST There's already an HA-aware connection identified by *coid*.

The flag HAREPLACERECOVERYFN isn't set.

ENOMEM Memory couldn't be allocated while creating the structures in the

library.

Classification:

QNX Neutrino

Safety	
Cancellation point	No
Interrupt handler	No
Signal handler	No
Thread	Yes

See also:

ha_close(), ha_detach(), ha_ConnectAttach(), ha_ConnectDetach(), ha_creat(),
ha_fclose(), ha_fopen(), ha_open(), ha_ReConnectAttach(), ha_reopen()

Detach an attached HA file descriptor, then close it

Synopsis:

#include <ha/unistd.h>

int ha_close(int fd);

Library:

libha

Description:

The $ha_close()$ convenience function detaches a connection that was previously attached using $ha_attach()$, and then closes the connection.

The fd is the file descriptor originally obtained from ha open().

Returns:

- 0 Success
- -1 An error occurred (*errno* is set).

Errors:

The $ha_close()$ function returns errors as returned by either the underlying close() call or the $ha_detach()$ call.

Classification:

QNX Neutrino

Safety

Cancellation point No
Interrupt handler No
Signal handler No
Thread Yes

See also:

ha_attach(), ha_ConnectDetach(), ha_detach(), ha_open()

In the *Library Reference*: close()

Control the operation of a HA-aware connection

Synopsis:

#include <ha/cover.h>
int ha connection ctrl(int coid, int command, void *args)

Library:

libha

Description:

The *ha_connection_ctrl()* function can be used to control the operation of the HA-aware conenction. Specifically it can be used to control the recovery method, temporarily suspend recovery and also control the number of times that will be attempted both consecutively for a single failure, or across all failures. Currently the following commands are defined:

HA RECOVERY ACOUNT

This sets the maximum number of times recovery is performed for this connection. The value is specified by passing it via "args" as an integer. A negative value implies that there is no limit on the number of times recovery will be performed, and this is the default state of the connection when it is made HA aware.

HA RECOVERY ICOUNT

This sets the maximum number of iterations, recovery is performed for this connection, each time a connection is found to have failed. This count is reset each time the connection is successfully recovered. The value is specified by passing it via "args" as an integer. A negative value implies that there is no limit on the number of times recovery will be performed, and this is the default state of the connection when it is made HA aware.

HA RECOVERY SUSPEND

Temporarily suspends any recovery on this connection. It will behave like a normal connection.

HA RECOVERY ENABLE

Re-enables any recovery on this connection. All other recovery options are unaffected. This just toggles the "recovery enabled/disabled" bit.

HA RECOVERY RESET ICOUNT

Resets the iteration count used by HA_RECOVERY_ICOUNT above. This sets the internal count per iteration to zero.

HA RECOVERY RESET ACOUNT

Resets the total count used by HA_RECOVERY_ACOUNT above. This sets the internal count of recoveries to zero.

Returns:

0 Success.

-1 An error occurred (errno is set).

Errors:

EBADF No connection is specified by this *coid*, or connection is not HA-aware.

EINVAL Invalid command.

Classification:

QNX Neutrino

Safety	
Cancellation point	No
Interrupt handler	No
Signal handler	No
Thread	Yes

See also:

 $ha_attach(), ha_detach(), ha_open(), ha_reopen(), ha_ConnectAttach(), ha_ConnectDetach()$

Create a connection and attach it to the HA li

Synopsis:

```
#include <ha/neutrino.h>
int ha ConnectAttach( Uint32t *nd,
                       pid t pid,
                       int chid,
                       unsigned index,
                       unsigned flags,
                       RFp rfn,
                       void *rhdl,
                       unsigned haflags);
int ha ConnectAttach r( Uint32t *nd,
                         pid_t pid,
                         int chid,
                         unsigned index,
                         unsigned flags,
                         RFp rfn,
                         void *rhdl,
                          unsigned haflags);
```

Library:

libha

Description:

The ha_ConnectAttach() and ha_ConnectDetach_r() functions are identical except in the way they return errors. (For details, see the "Returns" section.)

In addition to creating the connection using the standard $ConnectAttach/_r()$ call, these convenience functions also call $ha_attach()$ with the connection returned by the ConnectAttach() call.

The parameters rfn(), and rhdl(), and haflags() are passed to the $ha_attach()$ call along with the connection ID returned by the ConnectAttach() call.

The remaining parameters are passed to the corresponding parameters in the *ConnectAttach()* call in their appropriate positions.

Returns:

The only difference between these functions is the way they indicate errors:

ha ConnectAttach()

A connection ID that's used by the message primitives. If an error occurs, -1 is returned and *errno* is set.

 $ha\ ConnectAttach\ r()$

A connection ID that's used by the message primitives. This function does NOT set *errno*. If an error occurs, the negative of a value from the errors returned by either the underlying *ConnectAttach()* call or the *ha attach()* call.

Errors:

The $ha_ConnectAttach \mid r()$ call returns errors as returned by either the underlying ConnectAttach() call or the ha attach() call.

Classification:

QNX Neutrino

Safety	
Cancellation point	No
Interrupt handler	No
Signal handler	No
Thread	Yes

See also:

 $ha_attach(), ha_close(), ha_ConnectAttach(), ha_creat(), ha_detach(), ha_open()$ In the *Library Reference*: ConnectAttach()

Detach an attached file descriptor, then close the connection

Synopsis:

#include <ha/neutrino.h>

int ha_ConnectDetach(int coid);

int ha ConnectDetach r(int coid);

Library:

libha

Description:

The *ha_ConnectDetach()* and *ha_ConnectDetach_r()* functions are identical except in the way they return errors. (For details, see the "Returns" section.)

The $ha_ConnectDetach \mid _r()$ call detaches a connection (coid) that was previously attached using $ha_attach()$, and then closes the connection by calling the appropriate $ConnectDetach \mid r()$ call.

Returns:

The only difference between these functions is the way they indicate errors:

ha_ConnectDetach()

If an error occurs, -1 is returned and *errno* is set. Any other value returned indicates success.

ha_ConnectDetach_r()

EOK is returned on success. This function does NOT set *errno*. If an error occurs, any value from the errors returned by either the underlying *ConnectDetach()* call or the *ha_detach()* call may be returned.

Errors:

The $ha_ConnectDetach \mid _r()$ call returns errors as returned by either the underlying ConnectDetach() call or the $ha_detach()$ call.

Classification:

QNX Neutrino

Safety

Cancellation point No

Interrupt handler No

continued...

KG

Safety	
Signal handler	No
Thread	Yes

See also:

 $ha_attach(), ha_ConnectAttach(), ha_detach()$

In the Library Reference: ConnectDetach()

Synopsis:

```
#include <ha/fcntl.h>
int ha creat(const char *path,
              mode t mode,
              RFp rfn,
              void *rhdl,
              unsigned haflags);
int ha_creat64(const char *path,
                mode t mode,
                RFp rfn,
                void *rhdl,
                unsigned haflags);
```

Library:

libha

Description:

In addition to opening the connection using the standard *create* | 64() call, these convenience functions also call ha attach() with the connection returned by the creat() call.

The parameters rfn(), and rhdl(), and haflags() are passed to the ha attach() call along with the connection ID returned by the *creat()* call.

The remaining parameters are passed to the corresponding parameters in the *creat()* call in their appropriate positions.

Returns:

A new connection ID or -1 if an error occurred (errno is set).

Errors:

The ha creat() call returns errors as returned by either the underlying creat() call or the *ha* attach() call.

Classification:

QNX Neutrino

Safety

Cancellation point	No
Interrupt handler	No
Signal handler	No
continued	

Safety	
Thread	Yes

 $ha_open(),\,ha_attach(),\,ha_close(),\,ha_detach()$

In the *Library Reference*: creat()

Detach a previously attached connection

Synopsis:

#include <ha/cover.h>

int ha_attach(int coid)

Library:

libha

Description:

The *ha_detach()* function detaches a connection from the HA library. This effectively makes the connection non HA-aware. After the detach operation is complete, no more recovery will be performed for any message operations on this connection.

The connection referred to by coid must be a connection previously attached to using $ha_attach()$. Normally, you detach connections just prior to closing them. The functions $ha_close()$, $ha_ConnectDetach | _r()$, and $ha_fclose()$ perform the required $ha_detach()$ operation before closing the connection.

Returns:

- 0 Success
- -1 An error occurred (*errno* is set).

Errors:

EBADF There's no connection *coid* that's currently attached.

Classification:

QNX Neutrino

Safat	-
Sale	v

Cancellation point No
Interrupt handler No
Signal handler No
Thread Yes

See also:

ha_attach(), ha_close(), ha_ConnectDetach(), ha_fclose()



Duplicate an HA connection

Synopsis:

#include <ha/unistd.h>

int ha dup(int oldfd);

Library:

libha

Description:

The $ha_dup()$ function duplicates the HA-aware file descriptor specified by oldfd. The functionality of $ha_dup()$ is similar to that of the standard dup() call, with the addition that the new file descriptor also shares the recovery mechanisms associated with oldfd.

Changing the recovery function for one file descriptor will automatically change the recovery function for the other as well.

Note that HA connections are also reference-counted across $ha_dup()$ calls. This implies that when HA connections that have been dup()'d are closed, the recovery functions will continue to exist until the last reference to them has been closed.

Returns:

The new file descriptor or -1 if an error occurred (errno is set).

Errors:

EBADF The connection identified by *oldfd* isn't an HA-aware connection.

ENOMEM Couldn't allocate memory for structures in the library to successfully

duplicate the connection.

In addition, the *ha* dup() call returns any errors returned by the underlying dup() call.

Classification:

QNX Neutrino

Safety

Cancellation point No
Interrupt handler No
Signal handler No
Thread Yes

 $ha_attach(), ha_close(), ha_detach(), ha_open()$

In the Library Reference: dup(

Detach an attached HA file descriptor for a file stream, then close it

Synopsis:

#include <ha/stdio.h>

int ha_fclose(FILE *stp);

Library:

libha

Description:

The ha_fclose() convenience function detaches a connection associated with the file stream stp that was previously attached using ha_attach(), and then closes the connection.

Returns:

- 0 Success
- -1 An error occurred (*errno* is set).

Errors:

The *ha_fclose()* function returns errors as returned by either the underlying *fclose()* call or the *ha_detach()* call.

Classification:

QNX Neutrino

Safety

Cancellation point No
Interrupt handler No
Signal handler No
Thread Yes

See also:

ha_attach(), ha_ConnectDetach(), ha_detach(), ha_open()

In the *Library Reference*: fclose()



Synopsis:

```
#include <ha/stdio.h>
int ha fopen(const char *path,
              const char *mode,
              RFp rfn,
              void *rhdl,
              unsigned haflags);
```

Library:

libha

Description:

In addition to opening the connection using the standard *fopen()* call, this convenience function also calls ha attach() with the connection returned by the fopen() call.

The parameters rfn(), and rhdl(), and haflags() are passed to the ha attach() call along with the connection ID returned by the underlying *fopen()* call.

The remaining parameters are passed to the corresponding parameters in the *fopen()* call in their appropriate positions.

Returns:

A pointer to a file stream or NULL if an error occurs (errno is set).

Errors:

The ha fopen() call returns errors as returned by either the underlying fopen() call or the *ha_attach()* call.

Classification:

QNX Neutrino

Safety	
Cancellation point	No
Interrupt handler	No
Signal handler	No
Thread	Yes

 $ha_attach(), ha_detach(), ha_fclose()$

In the Library Reference: fclose(), fopen()

Synopsis:

```
#include <ha/fcntl.h>
int ha open(const char *path,
             int oflag,
             RFp rfn,
             void *rhdl,
             unsigned haflags, ...);
int ha_open64(const char *path,
             int oflag,
             RFp rfn,
             void *rhdl,
             unsigned haflags, ...);
```

Library:

libha

Description:

In addition to opening the connection using the standard open | 64() call, these convenience functions also call ha attach() with the connection returned by the open() call.

The parameters rfn(), and rhdl(), and haflags() are passed to the ha attach() call along with the connection ID returned by the open() call.

The remaining parameters are passed to the corresponding parameters in the open() call in their appropriate positions.

Returns:

A new connection ID or -1 if an error occurred (errno is set).

Errors:

The *ha open()* call returns errors as returned by either the underlying *open()* call or the *ha* attach() call.

Classification:

QNX Neutrino

Safety

Cancellation point No Interrupt handler continued...

Safety	
Signal handler	No
Thread	Yes

 $ha_attach(),\, ha_creat(),\, ha_close(),\, ha_detach()$

In the *Library Reference*: open()

Reopen a connection while performing recovery

Synopsis:

```
#include <ha/neutrino.h>
```

Library:

libha

Description:

You can use the *ha_ReConnectAttach()* convenience function to reopen a connection while in the recovery phase. The *oldcoid* argument refers to the connection that has failed. The *ha_ReConnectAttach()* function closes the previous connection and opens a new connection using the parameters specified by calling *ConnectAttach()*.

The *ha_ReConnectAttach()* function also verifies that the new connection ID returned is the same as the *oldcoid* (as required by the HA library mechanism).

Returns:

A new connection ID or -1 if an error occurred (errno is set).

Errors:

The *ha_ReConnectAttach()* call returns errors as returned by the underlying *ConnectAttach()* call.

Classification:

QNX Neutrino

Safety	
Cancellation point	No
Interrupt handler	No
Signal handler	No
Thread	Yes

 $ha_attach(), ha_close(), Connect_Attach(), Connect_Detach(), ha_detach(), ha_open()$

In the *Library Reference*: ConnectAttach()

Reopen a connection while performing recovery

Synopsis:

Library:

libha

Description:

You can use the *ha_reopen()* convenience function to reopen a connection while in the recovery phase. The *oldfd* argument refers to the connection that has failed. The *ha_reopen()* function closes the previous connection and opens a new connection using the parameters specified by calling *open()*.

The *ha_reopen()* function also verifies that the new connection ID returned is the same as the *oldfd* (as required by the HA library mechanism). If the new connection ID obtained is not the same as *oldfd*, it will attempt to obtain the same *fd*, by calling the *dup2()* function.

Returns:

A new connection ID or -1 if an error occurred (errno is set).

Errors:

The *ha_reopen()* call returns errors as returned by the underlying *open()* call.

Classification:

QNX Neutrino

Cancellation point No Interrupt handler No Signal handler No Thread Yes

See also:

```
ha_attach(), ha_close(), ha_detach(), ha_open(), ReConnect_Attach()
In the Library Reference: open()
```

Appendix A

Examples

In this appendix...

Simple restart 173 Compound restart 174 Death/condition notification 175 Heartbeating clients (liveness detection) 178 Process starvation 183

Simple restart

The most basic form of recovery is the simple death-restart mechanism. Since the QNX Neutrino realtime operating system provides virtually all non-kernel functionality via user-installable programs, and since it offers complete memory protection, not only for user applications, but also for OS components (device drivers, filesystems, etc.), a resource manager or other server program can be easily *decoupled from the OS*.

This decoupling lets you safely stop, start, and upgrade resource managers or other key programs *dynamically*, without compromising the availability of the rest of the system.

Consider the following code, where we restart the inetd daemon:

```
/* addinet.c */
#include <stdio.h>
#include <string.h>
#include <stdlib.h>
#include <unistd.h>
#include <svs/stat.h>
#include <sys/netmgr.h>
#include <fcntl.h>
#include "ha/ham.h"
int main(int argc, char *argv[])
     int status;
     char *inetdpath;
   ham_entity_t *ehdl;
   ham condition t *chdl;
   ham action t *ahdl;
   int inetdpid:
   if (argc > 1)
        inetdpath = strdup(argv[1]);
        inetdpath = strdup("/usr/sbin/inetd -D");
    if (argc > 2)
       inetdpid = atoi(argv[2]);
    else
       inetdpid = -1;
   ham connect(0);
    ehd1 = ham_attach("inetd", ND_LOCAL_NODE, inetdpid, inetdpath, 0);
     chdl = ham condition(ehdl,CONDDEATH, "death", HREARMAFTERRESTART);
    if (chdl != NULL) {
        ahdl = ham_action_restart(chdl, "restart", inetdpath,
                             HREARMAFTERRESTART);
         if (ahdl == NULL)
             printf("add action failed\n");
        else
           printf("add condition failed\n");
       printf("add entity failed\n");
   ham disconnect(0);
    exit(0);
}
```

The above example attaches the inetd process to a HAM, and then establishes a condition *death* and an action *restart* under it.



You need to specify the -D option to inetd, to force inetd to daemonize by calling $procmgr_daemon()$ instead of by calling daemon(). The HAM can see death messages only from tasks that are running in session 1, and the call to daemon() doesn't put the caller into that session.

When inetd terminates, the HAM will automatically restart it by running the program specified by inetdpath. If inetd were already running on the system, we can pass the *pid* of the existing inetd into inetdpid and it will be attached to directly. Otherwise, the HAM will start and begin to monitor inetd.

You could use the same code to monitor, say, <code>slogger</code> (by specifying <code>/usr/sbin/slogger</code>), <code>mqueue</code> (by specifying <code>/sbin/mqueue</code>), etc. Just remember to specify the *full path* of the executable with all its required command-line parameters.

Compound restart

Recovery often involves more than restarting a single component. The death of one component might actually require restarting and resetting many other components. We might also have to do some initial cleanup before the dead component is restarted.

A HAM lets you specify a list of actions that will be performed when a given condition is triggered. For example, suppose the entity being monitored is fs-nfs2, and there's a set of directories that have been mounted and are currently in use. If fs-nfs2 were to die, the simple restart of that component won't remount the directories and make them available again! We'd have to restart fs-nfs2, and then follow that up with the explicit mounting of the appropriate directories.

Similarly, if io-pkt* were to die, it would take down the network drivers and TCP/IP stack (npm-tcpip.so) with it. So restarting io-pkt* involves also reinitializing the network driver. Also, any other components that use the network connection will also need to be reset (like inetd) so that they can reestablish their connections again.

Consider the following example of performing a compound restart mechanism.

```
/* addnfs.c */
#include <stdio.h>
#include <string.h>
#include <stdlib.h>
#include <unistd.h>
#include <svs/stat.h>
#include <sys/netmgr.h>
#include <fcntl.h>
#include <ha/ham.h>
int main(int argc, char *argv[])
     int status;
   ham_entity_t *ehdl;
   ham condition t *chdl;
   ham action t *ahdl;
   char *fsnfspath;
    int fsnfs2pid;
   if (argc > 1)
        fsnfspath = strdup(argv[1]);
```

```
else
    fsnfspath = strdup("/usr/sbin/fs-nfs2");
if (argc > 2)
   fsnfs2pid = atoi(argv[2]);
else
   fsnfs2pid = -1;
ham connect(0);
ehdl = ham_attach("Fs-nfs2", ND_LOCAL_NODE, fsnfs2pid, fsnfspath, 0);
if (ehdl != NULL)
{
 chdl = ham condition(ehdl,CONDDEATH, "Death", HREARMAFTERRESTART);
if (chdl != NULL) {
    ahdl = ham action restart(chdl, "Restart", fsnfspath,
                         HREARMAFTERRESTART);
     if (ahdl == NULL)
         printf("add action failed\n");
        /* else {
      ahdl = ham_action_waitfor(chdl, "Delay1", NULL, 2000, HREARMAFTERRESTART);
       if (ahdl == NULL)
           printf("add action failed\n");
      ahdl = ham_action_execute(chdl, "MountPPCBE",
              "/bin/mount -t nfs 10.12.1.115:/ppcbe /ppcbe",
               HREARMAFTERRESTART ((fsnfs2pid == -1) ? HACTIONDONOW:0));
       if (ahdl == NULL)
           printf("add action failed\n");
      ahd1 = ham action waitfor(chd1, "Delay2", NULL, 2000, HREARMAFTERRESTART);
       if (ahdl == NULL)
           printf("add action failed\n");
      ahd1 = ham_action_execute(chd1, "MountWeb",
      "/bin/mount -t nfs 10.12.1.115:/web /web",
       HREARMAFTERRESTART | ((fsnfs2pid == -1) ? HACTIONDONOW:0));
       if (ahdl == NULL)
           printf("add action failed\n");
       printf("add condition failed\n");
}
else
   printf("add entity failed\n");
ham_disconnect(0);
exit(0);
```

This example attaches fs-nfs2 as an entity, and then attaches a series of *execute* and *waitfor* actions to the condition *death*. When fs-nfs2 dies, HAM will restart it and also remount the remote directories that need to be remounted in sequence. Note that you can specify *delays* as actions and also wait for specific names to appear in the namespace.

Death/condition notification

Fault notification is a crucial part of the availability of a system. Apart from performing recovery per se, we also need to keep track of failures in order to be able to analyze the system at a later point.

For fault notification, you can use standard notification mechanisms such as pulses or signals. Clients specify what pulse/signal with specific values they want for each notification, and a HAM delivers the notifications at the appropriate times.

```
/* regevent.c */
#include <stdio.h>
#include <string.h>
#include <stdlib.h>
#include <unistd.h>
#include <sys/stat.h>
```

```
#include <fcntl.h>
#include <errno.h>
#include <sys/neutrino.h>
#include <sys/iomsg.h>
#include <sys/netmgr.h>
#include <signal.h>
#include <ha/ham.h>
#define PCODEINETDDEATH _PULSE_CODE_MINAVAIL+1
#define PCODEINETDDETACH _PULSE_CODE_MINAVAIL+2
#define PCODENERDETAYED
#define PCODENFSDELAYED
                              PULSE CODE MINAVAIL+3
#define PCODEINETDRESTART1 _PULSE_CODE_MINAVAIL+4
#define PCODEINETDRESTART2 _PULSE_CODE_MINAVAIL+5
#define MYSIG SIGRTMIN+1
int fsnfs value;
/* Signal handler to handle the death notify of fs-nfs2 */
void MySigHandler(int signo, siginfo_t *info, void *extra)
  printf("Received signal %d, with code = %d, value %d\n",
        signo, info->si_code, info->si_value.sival_int);
  if (info->si value.sival int == fsnfs value)
   printf("FS-nfs2 died, this is the notify signal\n");
  return;
int main(int argc, char *argv[])
  int chid, coid, revid;
  struct _pulse pulse;
  pid t pid;
  int status;
  int value;
  ham_entity_t *ehdl;
  ham_condition_t *chdl;
  ham action t *ahdl;
  struct sigaction sa;
  int scode;
  int svalue;
  /* we need a channel to receive the pulse notification on */
  chid = ChannelCreate( 0 );
  /* and we need a connection to that channel for the pulse to be
    delivered on */
  coid = ConnectAttach( 0, 0, chid, _NTO_SIDE_CHANNEL, 0 );
  /* fill in the event structure for a pulse */
  pid = getpid();
  value = 13:
  ham connect(0);
  /* Assumes there is already an entity by the name "inetd" */
  chdl = ham_condition_handle(ND_LOCAL_NODE, "inetd", "death", 0);
  ahdl = ham_action_notify_pulse(chdl, "notifypulsedeath", ND_LOCAL_NODE, pid, chid,
                              PCODEINETDDEATH, value, HREARMAFTERRESTART);
  ham action handle free(ahdl);
  ham condition handle free(chdl);
  ehdl = ham_entity_handle(ND_LOCAL_NODE, "inetd", 0);
  chdl = ham_condition(ehdl, CONDDETACH, "detach", HREARMAFTERRESTART);
  ahdl = ham_action_notify_pulse(chdl, "notifypulsedetach", ND_LOCAL_NODE, pid, chid,
                              PCODEINETDDETACH, value, HREARMAFTERRESTART);
  ham action handle free(ahdl);
  ham condition handle free(chdl);
  ham_entity_handle_free(ehdl);
  fsnfs_value = 18; /* value we expect when fs-nfs dies */
  scode = 0;
  svalue = fsnfs_value;
  sa.sa_sigaction = MySigHandler;
  sigemptyset(&sa.sa mask);
  sa.sa_flags = SA_SIGINFO;
  sigaction (MYSIG, &sa, NULL);
   Assumes there is an entity by the name "Fs-nfs2".
```

```
We use "Fs-nfs2" to symbolically represent the entity
fs-nfs2. Any name can be used to represent the
entity, but it's best to use a readable and meaningful name.
ehdl = ham entity handle(ND LOCAL NODE, "Fs-nfs2", 0);
Add a new condition, which will be an "independent" condition
this means that notifications/actions inside this condition
are not affected by "waitfor" delays in other action
sequence threads
chdl = ham_condition(ehdl,CONDDEATH, "DeathSep",
                 HCONDINDEPENDENT | HREARMAFTERRESTART);
ahdl = ham_action_notify_signal(chdl, "notifysignaldeath", ND_LOCAL_NODE, pid, MYSIG,
                 scode, svalue, HREARMAFTERRESTART);
ham_action_handle_free(ahdl);
ham_condition_handle_free(chdl);
ham_entity_handle_free(ehdl);
chdl = ham_condition_handle(ND_LOCAL_NODE, "Fs-nfs2", "Death", 0);
this actions is added to a condition that does not
have a hoondnowait. Since we are unaware what the condition
already contains, we might end up getting a delayed notification
since the action sequence might have "arbitrary" delays, and
"waits" in it.
ahdl = ham_action_notify_pulse(chdl, "delayednfsdeathpulse", ND_LOCAL_NODE,
          pid, chid, PCODENFSDELAYED, value, HREARMAFTERRESTART);
ham action handle free(ahdl);
ham condition handle free(chdl);
ehdl = ham entity handle(ND LOCAL NODE, "inetd", 0);
chdl = ham_condition(ehdl, CONDRESTART, "restart",
                          HREARMAFTERRESTART | HCONDINDEPENDENT);
ahdl = ham_action_notify_pulse(chdl, "notifyrestart_imm", ND_LOCAL_NODE,
                pid, chid, PCODEINETDRESTART1, value, HREARMAFTERRESTART);
ham_action_handle_free(ahdl);
ahdl = ham action waitfor(chdl, "delay", NULL, 6532, HREARMAFTERRESTART);
ham action handle free(ahdl);
ahdl = ham_action_notify_pulse(chdl, "notifyrestart_delayed", ND_LOCAL_NODE,
                pid, chid, PCODEINETDRESTART2, value, HREARMAFTERRESTART);
ham_action_handle_free(ahdl);
ham_condition_handle_free(chdl);
ham entity handle free(ehdl);
while (1) {
 rcvid = MsgReceivePulse( chid, &pulse, sizeof( pulse ), NULL );
 if (rcvid < 0) {
   if (errno != EINTR) {
     exit(-1);
   }
 }
  else {
          switch (pulse.code) {
             case PCODEINETDDEATH:
                   printf("Inetd Death Pulse\n");
                 break;
             case PCODENFSDELAYED:
                   printf("Fs-nfs2 died: this is the possibly delayed pulse\n");
                   break:
             case PCODEINETDDETACH:
                   printf("Inetd detached, so quitting\n");
                   goto the_end;
             case PCODEINETDRESTART1:
                   printf("Inetd Restart Pulse: Immediate\n");
                 break;
             case PCODEINETDRESTART2:
                   printf("Inetd Restart Pulse: Delayed\n");
                  break:
           }
 }
}
At this point we are no longer waiting for the
information about inetd, since we know that it
has exited.
```

```
We will still continue to obtain information about the death of fs-nfs2, since we did not remove those actions if we exit now, the next time those actions are executed they will fail (notifications fail if the receiver does exist anymore), and they will automatically get removed and cleaned up.

*/
the_end:
ham_disconnect(0);
exit(0);
}
```

In the above example a client registers for various different types of notifications relating to significant events concerning inetd and fs-nfs2. Notifications can be sent immediately or after a certain delay.

The notifications can also be received for each condition *independently* — for the entity's death (CONDDEATH), restart (CONDRESTART), and detaching (CONDDETACH).

The CONDRESTART is asserted by a HAM when an entity is successfully restarted.

Heartbeating clients (liveness detection)

Sometimes components become unavailable not because of the occurrence of a specific "bad" event, but because the components become unresponsive by getting stuck somewhere to the extent that the service they provide becomes effectively unavailable.

One example of this is when a process or a collection of processes/threads enters a state of deadlock or starvation, where none or only some of the involved processes can make any useful progress. Such situations are often difficult to pinpoint since they occur quite randomly.

You can have your clients assert "liveness" properties by actively sending heartbeats to a HAM. When a process deadlocks (or starves) and makes no progress, it will no longer heartbeat, and the HAM will automatically detect this condition and take corrective action.

The corrective action can range from simply terminating the offending application to restarting it and also delivering notifications about its state to other components that depend on the safe and correct functioning of this component. If necessary, a HAM can restart those other components as well.

We can demonstrate this condition by showing a simple process that has two threads that use mutual-exclusion locks incorrectly (by a design flaw), which causes them on occasion to enter a state of deadlock — each of the threads holds a resource that the other wants.

Essentially, each thread runs through a segment of code that involves the use of two mutexes.

```
Thread 1 Thread 2
...
while true while true
```

```
do
obtain lock a
(compute section1)
obtain lock b
(compute section2)
release lock b
release lock a
release lock a
do
obtain lock b
obtain lock a
(compute section2)
release lock b
release lock a
release lock b
done
```

The code segments for each thread are shown below. The only difference between the two is the order in which the locks are obtained. The two threads deadlock upon execution, quite randomly; the exact moment of deadlock is related to the lengths of the "compute sections" of the two threads.

```
/* mutexdeadlock.c */
#include <errno.h>
#include <stdio.h>
#include <stdlib.h>
#include <string.h>
#include <unistd.h>
#include <sys/types.h>
#include <sys/wait.h>
#include <signal.h>
#include <pthread.h>
#include cess.h>
#include <sys/neutrino.h>
#include <sys/procfs.h>
#include <sys/procmgr.h>
#include <ha/ham.h>
pthread mutex t mutex a = PTHREAD MUTEX INITIALIZER;
pthread_mutex_t mutex_b = PTHREAD_MUTEX_INITIALIZER;
FILE *logfile;
pthread_t threadID;
int doheartbeat=0;
#define COMPUTE DELAY 100
void *func1(void *arg)
    int id;
    /* obtain the two locks in the order
      a -> b
      perform some computation and then
       release the locks ...
       do this continuously
    id = pthread_self();
    while (1) {
        delay(85); /* delay to let the other one go */
        if (doheartbeat)
            ham_heartbeat();
        pthread_mutex_lock(&mutex_a);
        fprintf(logfile, "Thread 1: Obtained lock a\n");
        fprintf(logfile, "Thread 1: Waiting for lock b\n");
        pthread mutex lock(&mutex b);
        \label{eq:continuous} \texttt{fprintf(logfile, "Thread 1: Obtained lock b\n");}
        fprintf(logfile, "Thread 1: Performing computation\n");
        delay(rand()%COMPUTE_DELAY+5); /* delay for computation */
        fprintf(logfile, "Thread 1: Unlocking lock b\n");\\
        pthread_mutex_unlock(&mutex_b);
        fprintf(logfile, "Thread 1: Unlocking lock a\n");
        pthread_mutex_unlock(&mutex_a);
    return(NULL);
```

```
void *func2(void *arg)
   int id;
   /* obtain the two locks in the order
      b -> a
      perform some computation and then
      release the locks ...
      do this continuously
   id = pthread_self();
   while (1) {
       delay(25);
       if (doheartbeat)
           ham_heartbeat();
       pthread_mutex_lock(&mutex_b);
       fprintf(logfile, "\tThread 2: Obtained lock b\n");
       fprintf(logfile, "\tThread 2: Waiting for lock a\n");
       pthread_mutex_lock(&mutex_a);
       fprintf(logfile, "\tThread 2: Performing computation\n");
       delay(rand()%COMPUTE_DELAY+5); /* delay for computation */
       fprintf(logfile, "\tThread 2: Unlocking lock a\n");
       pthread mutex unlock(&mutex a);
       fprintf(logfile, "\tThread 2: Unlocking lock b\n");
       pthread_mutex_unlock(&mutex_b);
   return(NULL);
int main(int argc, char *argv[])
{
   pthread_attr_t attrib;
   struct sched_param param;
   ham_entity_t *ehdl;
   ham_condition_t *chdl;
   ham action t *ahdl;
   int i=0;
   char c;
   logfile = stderr;
   while ((c = getopt(argc, argv, "f:l" )) != -1 ) {
       switch(c) {
           case 'f': /* log file */
               logfile = fopen(optarg, "w");
               break;
           case 'l': /* do liveness heartbeating */
              if (access("/proc/ham",F_OK) == 0)
                   doheartbeat=1;
               break;
        }
   }
    setbuf(logfile, NULL);
    srand(time(NULL));
   fprintf(logfile, "Creating separate competing compute thread\n");
   pthread attr init (&attrib);
   pthread_attr_setinheritsched (&attrib, PTHREAD_EXPLICIT SCHED);
   pthread_attr_setschedpolicy (&attrib, SCHED_RR);
   param.sched_priority = getprio (0);
   pthread attr setschedparam (&attrib, &param);
   if (doheartbeat) {
       /* attach to ham */
       ehd1 = ham_attach_self("mutex-deadlock",100000000UL,5 ,5, 0);
       chdl = ham_condition(ehdl, CONDHBEATMISSEDHIGH, "heartbeat-missed-high", 0);
       ahdl = ham_action_execute(chdl, "terminate",
                              "/proc/boot/mutex-deadlock-heartbeat.sh", 0);
    /* create competitor thread */
   pthread_create (&threadID, &attrib, func1, NULL);
   pthread_detach(threadID);
```

```
func2(NULL):
exit(0):
```

Upon execution, what we see is:

Starting two-threaded process.

The threads will execute as described earlier, but will eventually deadlock. We'll wait for a reasonable amount of time (a few seconds) until they do end in deadlock. The threads write out a simple execution log into /dev/shmem/mutex-deadlock.log.

Blocked

2 Waiting for them to deadlock.

pid tid name

Here's the current state of the threads in process 73746:

```
prio STATE
        1 oot/mutex-deadlock 10r MUTEX
  73746
                                         73746-02 #-21474
  73746
         2 oot/mutex-deadlock 10r MUTEX
                                          73746-01 #-21474
And here's the tail from the threads' log file:
Thread 2: Obtained lock b
Thread 2: Waiting for lock a
Thread 2: Obtained lock a
Thread 2: Performing computation
Thread 2: Unlocking lock a
Thread 2: Unlocking lock b
Thread 2: Obtained lock b
Thread 2: Waiting for lock a
Thread 1: Obtained lock a
```

3 Extracting core current process information:

Thread 1: Waiting for lock b

```
/tmp/mutex-deadlock.core:
processor=PPC num_cpus=2
 cpu 1 cpu=602370 name=604e speed=299
 flags=0xc0000001 FPU MMU EAR
 cpu 2 cpu=602370 name=604e speed=299
  flags=0xc0000001 FPU MMU EAR
cyc/sec=16666666 tod_adj=999522656000000000 nsec=5190771360840 inc=999960
boot=999522656 epoch=1970 intr=-2147483648
rate=600000024 scale=-16 load=16666
  MACHINE="mtx604-smp" HOSTNAME="localhost"
hwflags=0x000004
pretend cpu=0 init msr=36866
pid=73746 parent=49169 child=0 pgrp=73746 sid=1
flags=0x000300 umask=0 base_addr=0x48040000 init_stack=0x4803fa20
ruid=0 euid=0 suid=0 rgid=0 egid=0 sgid=0
ign=0000000006801000 queue=ff0000000000000 pending=00000000000000
fds=4 threads=2 timers=0 chans=1
thread 1 REOUESTED
 ip=0xfe32f838 sp=0x4803f920 stkbase=0x47fbf000 stksize=528384
 state=MUTEX flags=0 last_cpu=1 timeout=00000000
 pri=10 realpri=10 policy=RR
thread 2
 ip=0xfe32f838 sp=0x47fbef80 stkbase=0x47f9e000 stksize=135168
 state=MUTEX flags=4020000 last_cpu=2 timeout=00000000
 pri=10 realpri=10 policy=RR
```

The processes are deadlocked, with each process holding one lock and waiting for the other.

The process is made to heartbeat

Now consider the case where the client can be made to heartbeat so that a HAM will automatically detect when it's unresponsive and will terminate it.

```
Thread 1
                                    Thread 2
while true
                                   while true
 obtain lock a
                                     obtain lock b
   (compute section1)
                                       (compute section1)
   obtain lock b
                                       obtain lock a
     send heartbeat
                                         send heartbeat
     (compute section2)
                                         (compute section2)
   release lock b
                                       release lock a
 release lock a
                                     release lock b
done
                                    done
```

Here the process is expected to send heartbeats to a HAM. By placing the heartbeat call within the inside loop, the deadlock condition is trapped. The HAM notices that the heartbeats have stopped and can then perform recovery.

Let's look at what happens now:

1 Starting two-threaded process.

The threads will execute as described earlier, but will eventually deadlock. We'll wait for a reasonable amount of time (a few seconds) until they do end in deadlock. The threads write out a simple execution log into

/dev/shmem/mutex-deadlock-heartbeat.log. The HAM detects that the threads have stopped heartbeating and terminates the process, after saving its state for postmortem analysis.

2 Waiting for them to deadlock.

Here's the current state of the threads in process 462866 and the state of mutex-deadlock when it missed heartbeats:

```
prio STATE
    pid tid name
          2 oot/mutex-deadlock 63r RECEIVE 1
3 oot/mutex-deadlock 63r RECEIVE 1
  462866 1 oot/mutex-deadlock 10r MUTEX
  462866 3 oot/mutex-deadlock 10r MUTEX
                                                462866-01 #-2147
    Entity state from HAM
Path : mutex-deadlock
Entity Pid : 462866
Num conditions : 1
Condition type : ATTACHEDSELF
HeartBeat Period: 1000000000
HB Low Mark
              : 5
HB High Mark
Last Heartbeat : 2001/09/03 14:40:41:406575120
HeartBeat State : MISSEDHIGH
Created : 2001/09/03 14:40:40:391615720
Num Restarts : 0
And here's the tail from the threads' log file:
Thread 2: Obtained lock b
Thread 2: Waiting for lock a
```

```
Thread 2: Obtained lock a
Thread 2: Performing computation
Thread 2: Unlocking lock a
Thread 2: Unlocking lock b
Thread 2: Obtained lock b
Thread 2: Waiting for lock a
Thread 1: Obtained lock a
Thread 1: Waiting for lock b
```

3 Extracting core current process information:

```
/tmp/mutex-deadlock.core:
processor=PPC num_cpus=2
 cpu 1 cpu=602370 name=604e speed=299
  flags=0xc0000001 FPU MMU EAR
 cpu 2 cpu=602370 name=604e speed=299
  flags=0xc0000001 FPU MMU EAR
 cyc/sec=16666666 tod adj=999522656000000000 nsec=5390696363520 inc=999960
boot=999522656 epoch=1970 intr=-2147483648
 rate=600000024 scale=-16 load=16666
  MACHINE="mtx604-smp" HOSTNAME="localhost"
hwflags=0x000004
pretend cpu=0 init msr=36866
pid=462866 parent=434193 child=0 pgrp=462866 sid=1
flags=0x000300 umask=0 base_addr=0x48040000 init_stack=0x4803f9f0
ruid=0 euid=0 suid=0 rgid=0 egid=0 sgid=0
 ign=0000000006801000 queue=ff0000000000000 pending=00000000000000
 fds=5 threads=3 timers=1 chans=4
thread 1 REOUESTED
 ip=0xfe32f838 sp=0x4803f8f0 stkbase=0x47fbf000 stksize=528384
 state=MUTEX flags=0 last cpu=2 timeout=00000000
 pri=10 realpri=10 policy=RR
 thread 2
 ip=0xfe32f1a8 sp=0x47fbef50 stkbase=0x47f9e000 stksize=135168
 state=RECEIVE flags=4000000 last_cpu=2 timeout=00000000
 pri=63 realpri=63 policy=RR
 blocked chid=1
thread 3
 ip=0xfe32f838 sp=0x47f9df80 stkbase=0x47f7d000 stksize=135168
 state=MUTEX flags=4020000 last_cpu=1 timeout=00000000
 pri=10 realpri=10 policy=RR
```

Process starvation

We can demonstrate this condition by showing a simple process containing two threads that use mutual exclusion locks to manage a critical section. Thread 1 runs at a high priority, while Thread 2 runs at a lower priority. Essentially, each thread runs through a segment of code that looks like this:

```
Thread1

...

(Run at high priority)

while true

do

obtain lock a

(compute section1)

release lock a

done

Thread 2

...

(Run at low priority)

while true

do

obtain lock a

(compute section1)

release lock a

done
```

The code segments for each thread is shown below; the only difference being the priorities of the two threads. Upon execution, Thread 2 eventually starves.

```
/* mutexstarvation.c */
```

```
#include <errno.h>
#include <stdio.h>
#include <stdlib.h>
#include <string.h>
#include <unistd.h>
#include <sys/types.h>
#include <sys/wait.h>
#include <signal.h>
#include <pthread.h>
#include <process.h>
#include <sys/neutrino.h>
#include <sys/procfs.h>
#include <sys/procmgr.h>
#include <ha/ham.h>
pthread_mutex_t mutex_a = PTHREAD_MUTEX_INITIALIZER;
FILE *logfile;
int doheartbeat=0;
#define COMPUTE DELAY 900
void *func1(void *arg)
{
    int id:
    id = pthread_self();
    while (1) \{
       pthread mutex lock(&mutex a);
        fprintf(logfile, "Thread 1: Locking lock a\n");
        delay(rand()%COMPUTE_DELAY+50); /* delay for computation */
        fprintf(logfile, "Thread 1: Unlocking lock a\n");
        pthread_mutex_unlock(&mutex_a);
    return(NULL);
void *func2(void *arg)
    int id;
    id = pthread self();
    while (1) {
        pthread_mutex_lock(&mutex_a);
        fprintf(logfile, \ "\tThread 2: Locking lock a\n");
        if (doheartbeat)
            ham_heartbeat();
        delay(rand()%COMPUTE DELAY+50); /* delay for computation */
        fprintf(logfile, "\tThread 2: Unlocking lock a\n");
        pthread_mutex_unlock(&mutex_a);
    return(NULL);
}
int main(int argc, char *argv[])
{
    pthread attr t attrib;
    struct sched_param param;
    ham_entity_t *ehdl;
    ham_condition_t *chdl;
    ham action t *ahdl;
    int i=0;
    char c;
    pthread_attr_t attrib2;
    struct sched_param param2;
    pthread_t threadID;
    pthread_t threadID2;
    logfile = stderr;
    while ((c = getopt(argc, argv, "f:l" )) != -1 ) {
        switch(c) {
            case 'f': /* log file */
                logfile = fopen(optarg, "w");
```

```
break;
        case 'l': /* do liveness heartbeating */
          if (access("/proc/ham",F_OK) == 0)
               doheartbeat=1;
           break;
    }
}
setbuf(logfile, NULL);
srand(time(NULL));
fprintf(logfile, "Creating separate competing compute thread\n");
if (doheartheat) {
    /* attach to ham */
    ehdl = ham_attach_self("mutex-starvation",100000000UL, 5, 5, 0);
    chdl = ham_condition(ehdl, CONDHBEATMISSEDHIGH, "heartbeat-missed-high", 0);
    ahdl = ham_action_execute(chdl, "terminate",
                           "/proc/boot/mutex-starvation-heartbeat.sh", 0);
/* create competitor thread */
pthread_attr_init (&attrib2);
pthread_attr_setinheritsched (&attrib2, PTHREAD_EXPLICIT_SCHED);
pthread_attr_setschedpolicy (&attrib2, SCHED_RR);
param2.sched priority = sched get priority min(SCHED RR);
pthread_attr_setschedparam (&attrib2, &param2);
pthread create (&threadID2, &attrib2, func2, NULL);
delay(3000); /* let the other thread go on for a while... */
pthread attr init (&attrib);
pthread_attr_setinheritsched (&attrib, PTHREAD_EXPLICIT_SCHED);
pthread_attr_setschedpolicy (&attrib, SCHED_RR);
param.sched_priority = sched_get_priority_max(SCHED_RR);
pthread_attr_setschedparam (&attrib, &param);
pthread_create (&threadID, &attrib, func1, NULL);
pthread join(threadID, NULL);
pthread_join(threadID2, NULL);
exit(0);
```

Upon execution, here's what we see:

1 Starting two-threaded process.

The threads will execute as described earlier, but eventually Thread 2 will starve. We'll wait for a reasonable amount of time (some seconds) until Thread 2 ends up starving. The threads write out a simple execution log into /dev/shmem/mutex-starvation.log.

2 Waiting for them to run for a while.

Here's the current state of the threads in process 622610:

```
pid tid name prio STATE Blocked
622610 1 t/mutex-starvation 10r JOIN 3
622610 2 t/mutex-starvation 1r MUTEX 622610-03 #-2147
622610 3 t/mutex-starvation 63r NANOSLEEP
And here's the tail from the threads' log file:

Thread 1: Unlocking lock a
Thread 1: Locking lock a
Thread 1: Locking lock a
Thread 1: Unlocking lock a
Thread 1: Locking lock a
Thread 1: Unlocking lock a
Thread 1: Unlocking lock a
Thread 1: Locking lock a
```

```
Thread 1: Unlocking lock a Thread 1: Locking lock a
```

3 Extracting core current process information:

```
/tmp/mutex-starvation.core:
processor=PPC num_cpus=2
 cpu 1 cpu=602370 name=604e speed=299
  flags=0xc0000001 FPU MMU EAR
 cpu 2 cpu=602370 name=604e speed=299
  flags=0xc0000001 FPU MMU EAR
cvc/sec=16666666 tod adi=999522656000000000 nsec=5561011550640 inc=999960
boot=999522656 epoch=1970 intr=-2147483648
rate=600000024 scale=-16 load=16666
  MACHINE="mtx604-smp" HOSTNAME="localhost"
hwflags=0x000004
pretend cpu=0 init msr=36866
pid=622610 parent=598033 child=0 pgrp=622610 sid=1
flags=0x000300 umask=0 base_addr=0x48040000 init_stack=0x4803fa10
ruid=0 euid=0 suid=0 rgid=0 egid=0 sgid=0
ign=0000000006801000 queue=ff0000000000000 pending=00000000000000
fds=4 threads=3 timers=0 chans=1
thread 1 REOUESTED
 ip=0xfe32f8c8 sp=0x4803f8a0 stkbase=0x47fbf000 stksize=528384
 state=JOIN flags=0 last cpu=1 timeout=00000000
 pri=10 realpri=10 policy=RR
thread 2
 ip=0xfe32f838 sp=0x47fbef80 stkbase=0x47f9e000 stksize=135168
 state=MUTEX flags=4000000 last_cpu=2 timeout=00000000
 pri=1 realpri=1 policy=RR
thread 3
 ip=0xfe32f9a0 sp=0x47f9df20 stkbase=0x47f7d000 stksize=135168
 state=NANOSLEEP flags=4000000 last_cpu=2 timeout=0x1001000
 pri=63 realpri=63 policy=RR
```

Thread 2 is made to heartbeat

Now consider the case where Thread 2 is made to heartbeat. A HAM will automatically detect when the thread is unresponsive and can terminate it and/or perform recovery.

```
Thread 1
                                      Thread 2
(Run at high priority)
                                      (Run at low priority)
while true
                                      while true
do
                                      do
                                          obtain lock a
    obtain lock a
                                              send heartbeat
        (compute section1)
                                              (compute section1)
    release lock a
                                          release lock a
done
                                      done
```

Here Thread 2 is expected to send heartbeats to a HAM. By placing the heartbeat call within the inside loop, the HAM detects when Thread 2 begins to starve.

The threads will execute as described earlier, but eventually Thread 2 will starve. We'll wait for a reasonable amount of time (some seconds) until it does. The threads write out a simple execution log into

/dev/shmem/mutex-starvation-heartbeat.log. The HAM detects that the thread has stopped heartbeating and terminates the process, after saving its state for postmortem analysis.

Let's look at what happens:

1 Waiting for some time.

Here's the current state of the threads in process 753682 and the state of mutex-starvation when it missed heartbeats:

```
prio STATE
                                             Blocked
  753682 1 t/mutex-starvation 10r JOIN
  753682
         2 t/mutex-starvation 63r RECEIVE
                                             1
  753682 3 t/mutex-starvation 1r MUTEX
                                             753682-04 #-2147
  753682 4 t/mutex-starvation 63r NANOSLEEP
   Entity state from HAM
Path
              : mutex-starvation
Entity Pid
             : 753682
Num conditions : 1
Condition type : ATTACHEDSELF
HeartBeat Period: 1000000000
HB Low Mark
              : 5
HB High Mark : 5
Last Heartbeat : 2001/09/03 14:44:37:796119160
HeartBeat State : MISSEDHIGH
Created : 2001/09/03 14:44:34:780239800
Num Restarts : 0
And here's the tail from the threads' log file:
Thread 1: Unlocking lock a
Thread 1: Locking lock a
Thread 1: Unlocking lock a
Thread 1: Locking lock a
Thread 1: Unlocking lock a
Thread 1: Locking lock a
Thread 1: Unlocking lock a
Thread 1: Locking lock a
Thread 1: Unlocking lock a
```

2 Extracting core current process information:

Thread 1: Locking lock a

```
/tmp/mutex-starvation.core:
 processor=PPC num cpus=2
  cpu 1 cpu=602370 name=604e speed=299
   flags=0xc0000001 FPU MMU EAR
  cpu 2 cpu=602370 name=604e speed=299
  flags=0xc0000001 FPU MMU EAR
 cyc/sec=16666666 tod_adj=999522656000000000 nsec=5627098907040 inc=999960
 boot=999522656 epoch=1970 intr=-2147483648
 rate=600000024 scale=-16 load=16666
  MACHINE="mtx604-smp" HOSTNAME="localhost"
 hwflags=0x000004
pretend cpu=0 init msr=36866
pid=753682 parent=729105 child=0 pgrp=753682 sid=1
 flags=0x000300 umask=0 base addr=0x48040000 init stack=0x4803f9f0
 ruid=0 euid=0 suid=0 rgid=0 egid=0 sgid=0
 ign=0000000006801000 queue=ff0000000000000 pending=00000000000000
 fds=5 threads=4 timers=1 chans=4
 thread 1 REQUESTED
  ip=0xfe32f8c8 sp=0x4803f880 stkbase=0x47fbf000 stksize=528384
  state=JOIN flags=0 last_cpu=2 timeout=00000000
 pri=10 realpri=10 policy=RR
 thread 2
  ip = 0xfe32f1a8 \ sp = 0x47fbef50 \ stkbase = 0x47f9e000 \ stksize = 135168
  state=RECEIVE flags=4000000 last_cpu=2 timeout=00000000
  pri=63 realpri=63 policy=RR
  blocked_chid=1
 thread 3
 ip=0xfe32f838 sp=0x47f9df80 stkbase=0x47f7d000 stksize=135168
  state=MUTEX flags=4000000 last_cpu=2 timeout=00000000
  pri=1 realpri=1 policy=RR
 thread 4
```

ip=0xfe32f9a0 sp=0x47f7cf20 stkbase=0x47f5c000 stksize=135168 state=NANOSLEEP flags=4000000 last_cpu=1 timeout=0x1001000 pri=63 realpri=63 policy=RR

Glossary

April 20, 2009 Glossary **189**

action

A specific task the HAM will perform under certain associated **conditions**. Examples of actions include executing an external process, restarting a process that has died, sending a signal or pulse notification, etc.

availability

The ability of a system to provide its intended service without interruption for extended periods of time.

clustering

A method of distributing processing among several computers in order to reduce the number of **SPOFs**. QNX native networking offers transparent network-wide processing, which facilitates building clustered HA applications.

condition

An event that will trigger certain **actions** for the HAM to perform. Examples of conditions include the death of entity, a missed heartbeat, etc.

entity

A process that the HAM will monitor. Entities can explicitly ask to be monitored (i.e. as *self-attached* entities), or they may be monitored without ever realizing it.

five nines

The celebrated **availability** metric that refers to a system's ability to remain up and running 99.999% of the time per year.

Guardian

The HAM's "clone", a stand-in process that the HAM creates to ensure uninterrupted HA management within the QNX environment.

HAM

High Availability Manager.

heartbeat

A "wellness" or "liveness" notification sent at specific intervals by a client to the HAM.

hot swap

The ability to remove or insert a component in a live system.

MMU

Memory Management Unit. A device on many CPUs that alerts the OS if a process tries to access memory that's been allocated to another process.

April 20, 2009 Glossary 191

MTTF

Mean Time To Failure. This is the average length of time that the system will remain in service before failing. You want this to be as long as possible.

MTTR

Mean Time To Repair. This is the amount of time it takes for the system to resume operation after any component fails or is upgraded. You want this to be as small as possible.

Neutrino

Name of the QNX microkernel.

SPOF

Single point of failure. Any particular "weak link" in a system would be considered a SPOF, because its demise would put the entire system at risk.

watchdog

A trusted piece of hardware whose main purpose is to trigger code that will check the sanity of the system. There are software watchdogs as well; the HAM may be considered a "smart watchdog."

192 Glossary April 20, 2009

five nines" metric 3 A action adding a notify pulse action to an action on failure 69 adding a notify signal action to an action on failure 71 adding a restart 91 control 60 defined 20 executing a waitfor action on action fail 73 executing an external command 62 executing an external command on action fail 65 inserting delays into a sequence of actions 94 log activity 81 logging messages on action fail 67 removing from a condition 89 restart can be associated only with death conditions 91 restarting a program 92 action_fail defined 22	close() 150 code example compound restart 174 death/condition notification 175 heartbeating clients (liveness detection) 178 process starvation 183 simple restart 173 CONDABNORMALDEATH 31 CONDANY 31 CONDATTACH 31 CONDEATH 31, 101 CONDETACH 31, 101 CONDHEATMISSEDHIGH 31, 102 CONDHBEATMISSEDLOW 31, 101 condition associated with a condition raise condition 110 defined 19 flags 32 freeing 108 removing 112 restart 92 setting up 101 triggered on state change 114 types of 31, 101 CONDRESTART 31, 102 ConnectAttach() 153, 167 ConnectDetach() 155 connection attaching a recovery function 148
C checkpoint 52	attaching a recovery function 148 attaching to the HA lib 153, 157, 165 closing 125, 150, 155 creating 153, 157 detaching 150, 155, 159, 162

April 20, 2009 Index 193

duplicating 160 opening 165	G
reopening during recovery 167, 169 setting up 117 conventions typographical ix	global entity 19 Guardian (HAM "stand-in") 17, 24, 25
creat() 157	Н
* * * *	HA microkernel architecture inherently suited for 7 ha_attach() 148, 150, 162, 165 ha_close() 150 ha_ConnectAttach_r() 148 ha_ConnectDetach() 155 ha_creat() 148, 157 ha_creat64() 148 ha_detach() 159, 162 ha_dup() 160 ha_fclose() 162 ha_fopen() 148, 163 ha_open() 148, 165 ha_ReConnectAttach() 148, 167 ha_reopen() 148, 169 HADDFLAGS 60 HAM as self-monitoring manager 7 hierarchy 17 multistage recovery 4 starting 40 stopping 41 ham (utility) 40 ham_action_control() 60 ham_action_execute() 62, 92 ham_action_fail_execute() 65 ham_action_fail_log() 67 ham_action_fail_notify pulse_node() 69
designing for in order to recover 4 fclose() 162 file stream attaching to the HA lib 163 detaching a connection associated with a	ham_action_fail_notify_pulse() 69 ham_action_fail_notify_signal_node() 71 ham_action_fail_notify_signal() 71 ham_action_fail_waitfor() 73 ham_action_handle_free() 77 ham_action_handle() 75 ham_action_heartbeat_healthy() 79 ham_action_log() 81

194 Index April 20, 2009

ham_action_notify_pulse_node() 83	subsequent use of after a call
ham action notify pulse() 83	toham action handle() 76
ham action notify signal node() 86	subsequent use of after a call
ham action notify signal() 86	toham condition handle() 107
ham action remove() 89	subsequent use of after a call
ham action restart() 91	toham entity handle() 136
ham action waitfor() 94	HAREPLACERECOVERYFN 149
ham attach node() 96	HCONDINDEPENDENT 102
ham attach self() 99	HCONDNOWAIT 102
ham attach() 96	HDISABLE 60
ham condition handle free() 108	heartbeat
ham condition handle() 106	as a way to detect deadlock 182
ham condition raise() 110	as a way to detect starvation 186
ham condition remove() 112	clients assert "liveness" by sending 178
ham condition state() 114	possible delay in receiving 139
ham condition() 101	resetting the state of 79
ham_connect_nd() 117	setting interval for 99
ham connect node() 117	transmitting 139
ham connect() 117	HENABLE 60
ham connect*()	HGETFLAGS 60
reference counts and 117	HREARMAFTERRESTART 79, 84, 92, 94, 102
ham detach name node() 121	caveat regarding 87
ham detach name() 121	HREMOVEFLAGS 60
ham detach self() 123	HSETFLAGS 60
ham detach() 119	
ham disconnect nd() 125	
ham disconnect node() 125	
ham disconnect() 125	1
reference counts and 125	
ham_entity_condition_raise() 129	inetd
ham_entity_condition_state() 131	- D option 174
ham entity control() 104, 133	restarting 173
ham entity handle free() 137	
ham entity handle() 135	
ham entity() 127	M
ham heartbeat() 139	IVI
ham stop() 41	message passing 13
ham_verbose() 42, 143	MMU 4
hamctrl (utility) 41, 42	MTTR 12
handle	WITTE 12
entity 135	
freeing 77, 137	
functions that expect 75	N
getting 75	
getting a condition 106	Neutrino microkernel 12

April 20, 2009 Index 195

0	isolating 4
open() 118, 165, 169	main cause of system failure 3 traditional ways to handle 11 SPOF 4 starting a HAM 40
pathname delimiter in QNX documentation x placeholders for entity objects 127 POSIX process model 12 postmortem analysis 4, 182, 186 procmgr_daemon() 25 pulse setting up notification of 83	starting a HAW 40 starvation condition resulting from mutex problem 185 detected by HAM 186 stopping a HAM 41 T typographical conventions ix
Q	V
QNX key factors for intrinsic HA 12 microkernel architecture inherently reduces SPOFs 4	VERBOSE_GET 143 VERBOSE_SET 143 VERBOSE_SET_DECR 143 VERBOSE_SET_INCR 143 verbosity, modifying 42, 143
R	W
recovery functions attaching to a connection 148 defined in <ha types.h=""> 148 restart action 91 condition 92</ha>	watchdog 11, 17
S	
self-attached entity 18, 99, 119, 123 session 1 96, 99 signal setting up notification of 86 software faults detecting 11	

196 Index April 20, 2009