CS250 Computer Architecture

Ø 20FG

Part Í: More MIPS Instructions and Function Calls

Outline

- We'll go into more detail about the ISA.
 - Pseudo-instructions
 - Using branches for conditionals

Pseudo-instructions

- MIPS assemblers support pseudo-instructions that give the illusion of a more expressive instruction set, but are actually translated into one or more simpler, "real" instructions.
- Examples: the li and move pseudo-instructions:

They are probably clearer than their corresponding MIPS instructions:

```
addi $a0, $0, 2000  # Initialize $a0 to 2000
add $a1, $t0, $0  # Copy $t0 into $a1
```

- We'll see lots more pseudo-instructions this semester.
 - Unless otherwise stated, you can always use pseudo-instructions in your assignments and on exams.

Control flow in high-level languages

- The instructions in a program usually execute one after another, but it's often necessary to alter the normal control flow.
- Conditional statements execute only if some test expression is true.

```
// Find the absolute value of *a0 v0 = *a0; if (v0 < 0) v0 = -v0; // This might not be executed v1 = v0 + v0;
```

Loops cause some statements to be executed many times.

```
// Sum the elements of a five-element array a0 v0 = 0; t0 = 0; while (t0 < 5) { v0 = v0 + a0[t0]; // These statements will t0++; // be executed five times }
```

Control-flow graphs

It can be useful to draw control-flow graphs when writing loops and conditionals in assembly:

```
// Find the absolute value of *a0 v0 = *a0; if (v0 < 0) v0 = -v0; v1 = v0 + v0;
```

```
// Sum the elements of a0
v0 = 0;
t0 = 0;
while (t0 < 5) {
    v0 = v0 + a0[t0];
    t0++;
}</pre>
```

MIPS control instructions

In section, we introduced some of MIPS's control-flow instructions

```
j // for unconditional jumps
bne and beq // for conditional branches
slt and slti // set if less than (w/ and w/o an immediate)
```

- And how to implement loops
- Today, we'll talk about
 - MIPS's pseudo branches
 - if/else

What does this code do?

label: sub \$a0, \$a0, 1

bne \$a0, \$zero, label



Pseudo-branches

 The MIPS processor only supports two branch instructions, beq and bne, but to simplify your life the assembler provides the following other branches:

```
blt $t0, $t1, L1 // Branch if $t0 < $t1
ble $t0, $t1, L2 // Branch if $t0 <= $t1
bgt $t0, $t1, L3 // Branch if $t0 > $t1
bge $t0, $t1, L4 // Branch if $t0 >= $t1
```

- There are also immediate versions of these branches, where the second source is a constant instead of a register.
- Later this semester we'll see how supporting just beq and bne simplifies the processor design.

Implementing pseudo-branches

Most pseudo-branches are implemented using slt. For example, a branch-if-less-than instruction blt \$a0, \$a1, Label is translated into the following.

```
slt $at, $a0, $a1  // $at = 1 if $a0 < $a1
bne $at, $0, Label  // Branch if $at != 0
```

■ This supports immediate branches, which are also pseudo-instructions. For example, blti \$a0, 5, Label is translated into two instructions.

```
slti $at, $a0, 5  // $at = 1if $a0 < 5
bne $at, $0, Label  // Branch if $a0 < 5
```

- All of the pseudo-branches need a register to save the result of slt, even though it's not needed afterwards.
 - MIPS assemblers use register \$1, or \$at, for temporary storage.
 - You should be careful in using \$at in your own programs, as it may be overwritten by assembler-generated code.

Translating an if-then statement

 We can use branch instructions to translate if-then statements into MIPS assembly code.


```
v0 = *a0;

if (v0 < 0)

v0 = -v0;

v1 = v0 + v0;
```

- Sometimes it's easier to invert the original condition.
 - In this case, we changed "continue if v0 < 0" to "skip if v0 >= 0".
 - This saves a few instructions in the resulting assembly code.



Control-flow Example

Let's write a program to count how many bits are set in a 32-bit word.

Translating an if-then-else statements

- If there is an else clause, it is the target of the conditional branch
 - And the then clause needs a jump over the else clause

```
// increase the magnitude of v0 by one

if (v0 < 0)
    v0 --;

el se
    v0 ++;

v1 = v0;

magnitude of v0 by one

bge $v0, $0, E

sub $v0, $v0, 1

j L

E: add $v0, $v0, 1

L: move $v1, $v0
```

- Dealing with else-if code is similar, but the target of the first branch will be another if statement.
 - Drawing the control-flow graph can help you out.

Functions in MIPS

- We'll talk about the 3 steps in handling function calls:
 - 1. The program's flow of control must be changed.
 - 2. Arguments and return values are passed back and forth.
 - 3. Local variables can be allocated and destroyed.
- And how they are handled in MIPS:
 - New instructions for calling functions.
 - Conventions for sharing registers between functions.
 - Use of a stack.



Control flow in C

- Invoking a function changes the control flow of a program twice.
 - 1. Calling the function
 - 2. Returning from the function
- In this example the main function calls fact twice, and fact returns twice—but to different locations in main.
- Each time fact is called, the CPU has to remember the appropriate return address.
- Notice that main itself is also a function! It is, in effect, called by the operating system when you run the program.

```
int main()
{
  t1 = fact(8);
  t2 = fact(3);
  t3 = t1 + t2;
}
int fact(int n)
  int i, f = 1;
  for (i = n; i > 1; i--)
     f = f * i;
  return f;
}
```

Control flow in MIPS

- MIPS uses the jump-and-link instruction jal to call functions.
 - The jal saves the return address (the address of the next instruction)
 in the dedicated register \$ra, before jumping to the function.
 - jal is the only MIPS instruction that can access the value of the program counter, so it can store the return address PC+4 in \$ra.

 To transfer control back to the caller, the function just has to jump to the address that was stored in \$ra.

 Let's now add the jal and jr instructions that are necessary for our factorial example.

Data flow in C

- Functions accept arguments and produce return values.
- The blue parts of the program show the actual and formal arguments of the fact function.
- The purple parts of the code deal with returning and using a result.

```
int main()
  t1 = fact(8);
  t2 = fact(3);
  t3 = t1 + t2;
int fact(int n)
  int i, f = 1;
  for (i = n; i > 1; i--)
     f = f * i;
  return f;
```

Data flow in MIPS

- MIPS uses the following conventions for function arguments and results.
 - Up to four function arguments can be "passed" by placing them in argument registers \$a0-\$a3 before calling the function with jal.
 - A function can "return" up to two values by placing them in registers \$v0-\$v1, before returning via jr.
- These conventions are not enforced by the hardware or assembler, but programmers agree to them so functions written by different people can interface with each other.
- Later we'll talk about handling additional arguments or return values.

A note about types

- Assembly language is untyped—there is no distinction between integers, characters, pointers or other kinds of values.
- It is up to you to "type check" your programs. In particular, make sure your function arguments and return values are used consistently.
- For example, what happens if somebody passes the address of an integer (instead of the integer itself) to the fact function?

The big problem so far

- There is a big problem here!
 - The main code uses \$t1 to store the result of fact(8).
 - But \$t1 is also used within the fact function!
- The subsequent call to fact(3) will overwrite the value of fact(8) that was stored in \$11.

Nested functions

- A similar situation happens when you call a function that then calls another function.
- Let's say A calls B, which calls C.
 - The arguments for the call to C would be placed in \$a0-\$a3, thus overwriting the original arguments for B.
 - Similarly, jal C overwrites the return address that was saved in \$ra by the earlier jal B.

```
A: ...

# Put B's args in $a0-$a3

jal B # $ra = A2

A2: ...
```

```
C: ...
jr $ra
```

Spilling registers

- The CPU has a limited number of registers for use by all functions, and it's possible that several functions will need the same registers.
- We can keep important registers from being overwritten by a function call, by saving them before the function executes, and restoring them after the function completes.
- But there are two important questions.
 - Who is responsible for saving registers—the caller or the callee?
 - Where exactly are the register contents saved?



Who saves the registers?

- Who is responsible for saving important registers across function calls?
 - The caller knows which registers are important to it and should be saved.
 - The callee knows exactly which registers it will use and potentially overwrite.
- However, in the typical "black box" programming approach, the caller and callee do not know anything about each other's implementation.
 - Different functions may be written by different people or companies.
 - A function should be able to interface with any client, and different implementations of the same function should be substitutable.
- So how can two functions cooperate and share registers when they don't know anything about each other?

The caller could save the registers...

- One possibility is for the caller to save any important registers that it needs before making a function call, and to restore them after.
- But the caller does not know what registers are actually written by the function, so it may save more registers than necessary.
- In the example on the right, frodo wants to preserve \$a0, \$a1, \$s0 and \$s1 from gollum, but gollum may not even use those registers.

```
frodo: 1i $a0, 3
           $a1, 1
      li
          $s0, 4
      lί
           $s1, 1
      # Save registers
      # $a0, $a1, $s0, $s1
      jal gollum
      # Restore registers
      # $a0, $a1, $s0, $s1
      add $v0, $a0, $a1
      add $v1, $s0, $s1
      jr
           $ra
```

...or the callee could save the registers...

- Another possibility is if the callee saves and restores any registers it might overwrite.
- For instance, a gollum function that uses registers \$a0, \$a2, \$s0 and \$s2 could save the original values first, and restore them before returning.
- But the callee does not know what registers are important to the caller, so again it may save more registers than necessary.

```
gollum:
        # Save registers
         # $a0 $a2 $s0 $s2
              $a0, 2
         li 🗆
              $a2, 7
         li 💮
              $s0, 1
              $s2, 8
        # Restore registers
         # $a0 $a2 $s0 $s2
         jr
              $ra
```

...or they could work together

- MIPS uses conventions again to split the register spilling chores.
- The caller is responsible for saving and restoring any of the following caller-saved registers that it cares about.

In other words, the callee may freely modify these registers, under the assumption that the caller already saved them if necessary.

The callee is responsible for saving and restoring any of the following callee-saved registers that it uses. (Remember that \$ra is "used" by jal.)

Thus the caller may assume these registers are not changed by the callee.

- \$ra is tricky; it is saved by a callee who is also a caller.
- Be especially careful when writing nested functions, which act as both a caller and a callee!

Register spilling example

This convention ensures that the caller and callee together save all of the important registers—frodo only needs to save registers \$a0 and \$a1, while gollum only has to save registers \$s0 and \$s2.


```
frodo: 1i $a0, 3
                                qollum:
       li $a1, 1
                                         # Save registers
       li $s0, 4
                                         # $s0 and $s2
       li $s1, 1
                                              $a0, 2
                                         li $a2, 7
       # Save registers
                                         li $s0, 1
       # $a0, $a1, $ra
                                         li $s2, 8
       ial gollum
       # Restore registers
                                         # Restore registers
                                         # $s0 and $s2
       # $a0, $a1, $ra
       add $v0, $a0, $a1
                                         jr $ra
       add $v1, $s0, $s1
       ir $ra
```

How to fix factorial

- In the factorial example, main (the caller) should save two registers.
 - \$t1 must be saved before the second call to fact.
 - \$ra will be implicitly overwritten by the jal instructions.
- But fact (the callee) does not need to save anything. It only writes to registers \$t0, \$t1 and \$v0, which should have been saved by the caller.


Where are the registers saved?

- Now we know who is responsible for saving which registers, but we still need to discuss where those registers are saved.
- It would be nice if each function call had its own private memory area.
 - This would prevent other function calls from overwriting our saved registers—otherwise using memory is no better than using registers.
 - We could use this private memory for other purposes too, like storing local variables.



Function calls and stacks

- Notice function calls and returns occur in a stack-like order: the most recently called function is the first one to return.
 - 1. Someone calls A
 - 2. A calls B
 - 3. B calls C
 - 4. C returns to B
 - 5. B returns to A
 - 6. A returns
- Here, for example, C must return to B before B can return to A.




Stacks and function calls

- It's natural to use a stack for function call storage. A block of stack space, called a stack frame, can be allocated for each function call.
 - When a function is called, it creates a new frame onto the stack, which will be used for local storage.
 - Before the function returns, it must pop its stack frame, to restore the stack to its original state.
- The stack frame can be used for several purposes.
 - Caller- and callee-save registers can be put in the stack.
 - The stack frame can also hold local variables, or extra arguments and return values.



The MIPS stack

- In MIPS machines, part of main memory is reserved for a stack.
 - The stack grows downward in terms of memory addresses.
 - The address of the top element of the stack is stored (by convention) in the "stack pointer" register, \$sp.
- MIPS does not provide "push" and "pop" instructions. Instead, they must be done explicitly by the programmer.



Pushing elements


- To push elements onto the stack:
 - Move the stack pointer \$sp down to make room for the new data.
 - Store the elements into the stack.
- For example, to push registers \$t1 and \$t2 onto the stack:


```
sub $sp, $sp, 8
sw $t1, 4($sp)
sw $t2, 0($sp)
```

An equivalent sequence is:

```
sw $t1, -4($sp)
sw $t2, -8($sp)
sub $sp, $sp, 8
```

 Before and after diagrams of the stack are shown on the right.







Accessing and popping elements

- You can access any element in the stack (not just the top one) if you know where it is relative to \$sp.
- For example, to retrieve the value of \$t1:

- You can pop, or "erase," elements simply by adjusting the stack pointer upwards.
- To pop the value of \$t2, yielding the stack shown at the bottom:

 Note that the popped data is still present in memory, but data past the stack pointer is considered invalid.






20

Stack

The stack can be used for

- storing return addresses
- storing register values
- parameter passing
- **-** ...



$$$sp = $sp - 12$$

Factorial

- Compute n!
- Recall that
 - 0! = 1
 - -1! = 1
 - n! = n(n-1)!
- Store on the stack
 - \$s0 = n, the parameter
 - \$ra, the return address

```
factorial:
     bgt $a0,$0,gen # if $a0>0 goto generic case
     li $v0, 1
                      \# base case, 0! = 1
     jr $ra
                      # return
    subi $sp,$sp,8  # create a stack frame
gen:
     sw $s0,0($sp) # store register $s0's value
     sw $ra,4($sp) # store return address
     move $s0,$a0 # save argument
     subi $a0,$a0,1 # factorial (n-1)
     jal factorial # v0 = (n-1)!
     mul $v0,$s0,$v0 # n*(n-1)!
     lw $s0,0($sp) # restore $s0=n
     lw $ra,4($sp) # restore $ra
     addi $sp,$sp,8  # destruct the stack frame
     jr $ra
                      # return
```

Fibonacci

```
fib(0) = 0
fib(1) = 1
fib(n) = fib(n-1) + fib(n-2)
0, 1, 1, 2, 3, 5, 8, 13, 21,...
```

Fibonacci

```
li $a0, 10  # call fib(10)
jal fib  #
move $s0, $v0  # $s0 = fib(10)
```

fib is another recursive procedure with one argument \$a0 need to store argument \$a0, temporary register \$s0 for intermediate results, and return address \$ra

```
fib:
        subi $sp,$sp,12
                                # save registers on stack
        sw $a0, 0($sp)
                                \# save $a0 = n
        sw $s0, 4($sp)
                               # save $s0
        sw $ra, 8($sp)
                               # save return address $ra
        bgt $a0,1, gen
                                # if n>1 then goto generic case
        move $v0,$a0
                                # output = input if n=0 or n=1
        i rest
                                # goto restore registers
       subi $a0,$a0,1
                                \# param = n-1
gen:
        jal fib
                                # compute fib(n-1)
        move $s0,$v0
                                # save fib(n-1)
        sub $a0,$a0,1
                                # set param to n-2
        jal fib
                                # and make recursive call
        add $v0, $v0, $s0
                                # $v0 = fib(n-2) + fib(n-1)
        lw $a0, 0($sp)
rest:
                                # restore registers from stack
                                #
        lw $s0, 4($sp)
        lw $ra, 8($sp)
        addi $sp, $sp, 12
                                # decrease the stack size
        ir $ra
```

Summary

- Today we focused on implementing function calls in MIPS.
 - We call functions using jal, passing arguments in registers \$a0-\$a3.
 - Functions place results in \$v0-\$v1 and return using jr \$ra.
- Managing resources is an important part of function calls.
 - To keep important data from being overwritten, registers are saved according to conventions for caller-save and callee-save registers.
 - Each function call uses stack memory for saving registers, storing local variables and passing extra arguments and return values.
- Assembly programmers must follow many conventions. Nothing prevents a rogue program from overwriting registers or stack memory used by some other function.