
### Introduction to I/O

- Where does the data for our CPU and memory come from or go to?
- Computers communicate with the outside world via I/O devices.
  - Input devices supply computers with data to operate on.
  - Results of computations can be sent to output devices.
- Today we'll talk a bit about I/O system issues.
  - I/O performance affects the overall system speed.
  - We'll look at some common devices and estimate their performance.
  - We'll look at how I/O devices are connected (by buses).



## I/O is important!



- Many tasks involve reading and processing enormous quantities of data.
  - CCSO (counterpart of ITaP at UIUC) has two machines and 144GB of storage for a local web cache.
  - Institutions like banks and airlines have huge databases that must be constantly accessed and updated.
  - Celera Genomics is a company that sequences genomes, with the help of computers and 100 trillion bytes of storage!
- I/O is important for us small people too!
  - People use home computers to edit movies and music.
  - Large software packages may come on multiple compact discs.
  - Everybody and their grandparents surf the web!

### I/O is slow!


- How fast can a typical I/O device supply data to a computer?
  - A fast typist can enter 9-10 characters a second on a keyboard.
  - Common local-area network (LAN) speeds reach 1Gbit/s, which is about 125MB/s.
  - Today's hard disks provide a lot of storage and transfer speeds around 40-60MB per second.
- Unfortunately, this is excruciatingly slow compared to modern processors and memory systems:
  - Modern CPUs can execute more than a billion instructions per second.
  - Modern memory systems can provide 2-4 GB/s bandwidth.
- I/O performance has not increased as quickly as CPU performance, partially due to neglect and partially to physical limitations.
  - This is changing, with faster networks, better I/O buses (e.g., optical bus by IBM, 2010), RAID drive arrays, and other new technologies.

## I/O speeds often limit system performance


- Many computing tasks are I/O-bound, and the speed of the input and output devices limits the overall system performance.
- This is another instance of Amdahl's Law. Improved CPU performance alone has a limited effect on overall system speed.

### Common I/O devices

- Hard drives are almost a necessity these days, so their speed has a big impact on system performance.
  - They store all the programs, movies and assignments you crave.
  - Virtual memory systems let a hard disk act as a large (but slow) part of main memory.
- Networks are also ubiquitous nowadays.
  - They give you access to data from around the world.
  - Hard disks can act as a cache for network data. For example, web browsers often store local copies of recently viewed web pages.




# The Hardware (the motherboard)



### What is all that stuff?

- Different motherboards support different CPUs, types of memories, and expansion options.
- The picture is an Asus A7V.
  - The CPU socket supports AMD Duron and Athlon processors.
  - There are three DIMM slots for standard PC100 memory. Using 512MB DIMMs, you can get up to 1.5GB of main memory.
  - The AGP slot is for video cards, which generate and send images from the PC to a monitor.
  - IDE ports connect internal storage devices like hard drives, CD-ROMs, and Zip drives.
  - PCI slots hold other internal devices such as network and sound cards and modems.
  - Serial, parallel and USB ports are used to attach external devices such as scanners and printers.

### How is it all connected?




### **Frequencies**

- CPUs actually operate at two frequencies.
  - The internal frequency is the clock rate inside the CPU, which is what we've been talking about so far.
  - The external frequency is the speed of the processor bus, which limits how fast the CPU can transfer data.
- The internal frequency is usually a multiple of the external bus speed.
  - A 2.167 GHz Athlon XP sits on a 166 MHz bus (166 x 13).
  - A 2.66 GHz Pentium 4 might use a 133 MHz bus (133 x 20).
    - You may have seen the Pentium 4's bus speed quoted at 533MHz. This is because the Pentium 4's bus is "quad-pumped", so that it transfers 4 data items every clock cycle.

### The North Bridge

- To achieve the necessary bandwidths, a "frontside bus" is often dedicated to the CPU and main memory.
  - "bus" is actually a bit of a misnomer as, in most systems, the interconnect consists of point-to-point links.
  - The video card, which also need significant bandwidth, is also given a direct link to memory via the Accelerated Graphics Port (AGP).
- All this CPU-memory traffic goes through the "north bridge" controller, which can get very hot (hence the little green heatsink).




### **PCI**

- Peripheral Component Interconnect is a synchronous 32-bit bus running at 33MHz, although it can be extended to 64 bits and 66MHz.
- The maximum bandwidth is about 132 MB/s.

#### 33 million transfers/second x 4 bytes/transfer = 132MB/s

- Cards in the motherboard PCI slots plug directly into the PCI bus.
- Devices made for the older and slower ISA bus standard are connected via a "south bridge" controller chip, in a hierarchical manner.



### **External buses**

- External buses are provided to support the frequent plugging and unplugging of devices
  - As a result their designs significantly differ from internal buses
- Two modern external buses, Universal Serial Bus (USB) and FireWire, have the following (desirable) characteristics:
  - Plug-and-play standards allow devices to be configured with software, instead of flipping switches or setting jumpers.
  - Hot plugging means that you don't have to turn off a machine to add or remove a peripheral.
  - The cable transmits power! No more power cables or extension cords.
  - Serial links are used, so the cable and connectors are small.





### The Serial/Parallel conundrum

- Why are modern external buses serial rather than parallel?
- Generally, one would think that having more wires would increase bandwidth and reduce latency, right?
  - Yes, but only if they can be clocked at comparable frequencies.
- Two physical issues allow serial links to be clocked significantly faster:
  - On parallel interconnects, interference between the signal wires becomes a serious issue.
  - Skew is also a problem; all of the bits in a parallel transfer could arrive at slightly different times.
- Serial links are being increasingly considered for internal buses:
  - Serial ATA is a new standard for hard drive interconnects
  - PCI-Express (aka 3GI/O) is a PCI bus replacement that uses serial links


### I/O Mechanisms

- Most I/O requests are made by applications or the operating system, and involve moving data between an I/O device and main memory.
- There are several ways of performing data transfers between devices and main memory.
  - Programmed I/O
  - Interrupt-driven I/O
  - Direct memory access (DMA)

## Transferring data with programmed I/O


- Under programmed I/O, it's all up to a user program or the operating system.
  - The CPU makes a request and then waits for the device to become ready (e.g., to move the disk head).
  - Buses are only 32-64 bits wide, so the last few steps are repeated for large transfers.
- A lot of CPU time is needed for this!
  - If the device is slow the CPU might have to wait a long time—as we will see, most devices are slow compared to modern CPUs.
  - The CPU is also involved as a middleman for the actual data transfer.

(This CPU flowchart is based on one from *Computer Organization and Architecture* by William Stallings.)



## Can you hear me now? Can you hear me now?

- Continually checking to see if a device is ready is called polling.
- It's not a particularly efficient use of the CPU.
  - The CPU repeatedly asks the device if it's ready or not.
  - The processor has to ask often enough to ensure that it doesn't miss anything, which means it can't do much else while waiting.
- An analogy is waiting for your car to be fixed.
  - You could call the mechanic every minute,
     but that takes up all your time.
  - A better idea is to wait for the mechanic to call you.



### Interrupt-driven I/O

- Interrupt-driven I/O attacks the problem of the processor having to wait for a slow device.
- Instead of waiting, the CPU continues with other calculations. The device interrupts the processor when the data is ready.
- The data transfer steps are still the same as with programmed I/O, and still occupy the CPU.

CPU sends read request to device CPU does other stuff CPU receives interrupt CPU reads word from device CPU writes word to main memory No Done? Yes

17

(Flowchart based on Stallings again.)

I/O Programming, Interrupts and Exceptions

### Interrupts

- Interrupts are external events that require the processor's attention.
  - I/O devices may need attention.
  - Timer interrupts to mark the passage of time.
- These situations are not errors.
  - They happen normally.
  - All interrupts are recoverable:
    - The interrupted program will need to be resumed after the interrupt is handled.
- It is the operating system's responsibility to do the right thing, such as:
  - Save the current state and shut down the hardware devices.
  - Find and load the correct data from the hard disk
  - Transfer data to/from the I/O device, or install drivers.

### **Direct memory access**

- One final method of data transfer is to introduce a direct memory access, or DMA, controller.
- The DMA controller is a simple processor which does most of the functions that the CPU would otherwise have to handle.
  - The CPU asks the DMA controller to transfer data between a device and main memory. After that, the CPU can continue with other tasks.
  - The DMA controller issues requests to the right
     I/O device, waits, and manages the transfers
     between the device and main memory.
  - Once finished, the DMA controller interrupts the CPU.
- This is yet another form of parallel processing.

CPU sends read request to DMA unit


CPU does other stuff
....

CPU receives DMA interrupt

(Flowchart again.)


### Hard drives

- The figure below shows the ugly guts of a hard disk.
  - Data is stored on double-sided magnetic disks called platters.
  - Each platter is arranged like a record, with many concentric tracks.
  - Tracks are further divided into individual sectors, which are the basic unit of data transfer.
  - Each surface has a read/write head like the arm on a record player,
     but all the heads are connected and move together.
- A 75GB IBM Deskstar has roughly:
  - 5 platters (10 surfaces),
  - 27,000 tracks per surface,
  - 512 sectors per track, and
  - 512 bytes per sector.



## Accessing data on a hard disk

- Accessing a sector on a track on a hard disk takes a lot of time!
  - Seek time measures the delay for the disk head to reach the track.
  - A rotational delay accounts for the time to get to the right sector.
  - The transfer time is how long the actual data read or write takes.
  - There may be additional overhead for the operating system or the controller hardware on the hard disk drive.
- Rotational speed, measured in revolutions per minute or RPM, partially determines the rotational delay and transfer time.



## Estimating disk latencies (seek time)

- Manufacturers often report average seek times of 8-10ms.
  - These times average the time to seek from any track to any other track.
- In practice, seek times are often much better.
  - For example, if the head is already on or near the desired track, then seek time is much smaller. In other words, locality is important!
  - Actual average seek times are often just 2-3ms.

## Estimating Disk Latencies (rotational latency)

- Once the head is in place, we need to wait until the right sector is underneath the head.
  - This may require as little as no time (reading consecutive sectors) or as much as a full rotation (dang, just missed it).
  - On average, for random reads/writes, we can assume that the disk spins halfway on average.

Rotational delay depends partly on how fast the disk platters spin.

Average rotational delay = 0.5 rotations / rotational speed

For example, a 5400 RPM disk has an average rotational delay of:

0.5 rotations / (5400 rotations/minute) = 5.55ms

## Estimating disk times

- The overall response time is the sum of the seek time, rotational delay, transfer time, and overhead.
- Assume a disk has the following specifications.
  - An average seek time of 9ms
  - A 5400 RPM rotational speed
  - A 10MB/s average transfer rate
  - 2ms of overheads



- The average rotational delay is 5.55ms.
- The transfer time will be about (1024 bytes / 10 MB/s) = 0.1 ms.
- The response time is then 9ms + 5.55ms + 0.1ms + 2ms = 16.7ms.
  That's 16,700,000 cycles for a 1GHz processor!
- One possible measure of throughput would be the number of random sectors that can be read in one second.

 $(1 \text{ sector } / 16.7 \text{ms}) \times (1000 \text{ms} / 1 \text{s}) = 60 \text{ sectors/second.}$ 



## Estimating disk times

- The overall response time is the sum of the seek time, rotational delay, transfer time, and overhead.
- Assume a disk has the following specifications.
  - An average seek time of 3ms
  - A 6000 RPM rotational speed
  - A 10MB/s average transfer rate
  - 2ms of overheads
- How long does it take to read a random 1,024 byte sector?
  - The average rotational delay is:
  - The transfer time will be about:
  - The response time is then:
- How long would it take to read a whole track (512 sectors) selected at random, if the sectors could be read in any order?

### Parallel I/O

- Many hardware systems use parallelism for increased speed.
  - Pipelined processors include extra hardware so they can execute multiple instructions simultaneously.
  - Dividing memory into banks lets us access several words at once.
- A redundant array of inexpensive disks or RAID system allows access to several hard drives at once, for increased bandwidth.
  - The picture below shows a single data file with fifteen sectors denoted A-O, which are "striped" across four disks.

