Title:

Dowel Pin Handbook

Word Count:

1327

#### Summary:

Dowel Pins are industrial fasteners that are used in aerospace, military, construction and other industrial industries. Their primary function is for fastening two components but they are frequently used as an alignment or locating pin for components that are disassembled and reassembled. Frequently they are used as a hinge pin between pivoting components or as an axel for a rotating element.

#### Keywords:

dowel pins, .22 dowel pin, parallel dowel pins, precision dowel pins, stepped dowel pins, definition of dowel pins, pull dowel pins

#### Article Body:

Dowel Pins are industrial fasteners that are used in aerospace, military, construction and other industrial industries. Their primary function is for fastening two components but they are frequently used as an alignment or locating pin for components that are disassembled and reassembled. Frequently they are used as a hinge pin between pivoting components or as an axel for a rotating element.

<a href="http://www.rinomechanical.com/dowel-pin.htm">Dowel Pins</a> can be made
out of any rigid material including wood, steel and plastic. The most common
materials for industrial applications are hardened alloy steel and stainless
steel. Wood and plastic is most frequently used for fastening wooden objects
such as furniture. Dowel Pins are available in a wide range of diameters and
lengths in both imperial (inch) and metric (mm) sizes. Dowel Pins are made to
commercial diameter tolerances of approximately plus or minus 0.005 inch
(0.13mm) or to precision diameter tolerances which are normally plus or minus
0.0001 inch (0.0025mm).

Dowel pins are an important component when it comes to fastening. They are widely used and serve the purpose well.

<br/>b>Definition of dowel pins</b>

A dowel pin is used to secure two objects together. A hole is bored in one or

both of the objects and the dowel is inserted into the hole(s). They are non - threaded fasteners. These fasteners can be quickly assembled and removed from components and do not need extra fastening hardware. <a href="http://www.rinomechanical.com/dowel-pin.htm">Dowel pins</a> can be straight, tapered, rolled or grooved and provide perfect alignment, holding parts in absolute relation to one another. They also prevent slippage due to high motion.

<br/><b>Types of dowel pins:</b>

<b>Parallel dowel pins</b> - The most common of dowel pins and sometimes
referred to as straight pins, they have a uniform diameter over the full length
of the pin. These pins are especially useful application where the torque and
high accuracy is important. They keep motion smooth and guard against any
displacement of assembled parts.

<b>Stepped dowel pins</b> - These are <a
href="http://www.rinomechanical.com/dowel-pin.htm">parallel dowel pins</a> with
two different diameters along their length.

<b>Pull dowel pins</b> - These are also parallel dowel pins which are
supplied with a threaded hole in one end so that a screw can be inserted to help
remove the pin from a blind hole.

<b>Commercial dowel pins</b> - These are parallel dowel pins that are made
to commercial diameter tolerances of approximately plus or minus 0.005 inch (0.13mm).

<b>Precision dowel pins</b> - These are parallel dowel pins that are made to
precision diameter tolerances which are normally plus or minus 0.0001 inch (0.0025mm). A precision dowel pin is needed for an interference fit.

<br/>tapered Dowel pins</b> - Tapered dowel pins are most commonly called
Taper Pins and are produced with a diameter that reduces in size from one end to
the other end. The large end is referred to as the Head. A taper pin is
forcefully inserted into a tapered hole to make an extremely strong fastening
between two components. The tapered hole can be made by first drilling a small
diameter hole and then using a taper pin reamer to exactly shape the tapered
hole. Alternatively, a small diameter hole can be drilled deep into the part
followed by a larger drill to two thirds of the depth and finally the largest
drill diameter to one third of the depth. The most common taper is ¼" per foot.
If there is access to the pin at the small end, the taper pin can easily be
removed with slight force to the pin.

<b>Roll Pins (Spring Pins)</b> - These are parallel pins which are produced
by forming strips of flat metal into a partial coil. From an end view they look
like the letter C. These coiled pins can be made in a wide range of diameters
and lengths. The biggest advantage to a coiled pin is in the fact that when they
are forced into a hole that is intentionally undersize, the pins compress and
then hold position with a great deal of force. Roll Pins can be used as a hinge
pin.

<b>Spiral Pins</b> - These are similar to roll pins except that they are
formed into a complete coil where the outside of the coil overlaps the inside by
approximately 1-1/2 to 2 turns. Spiral Pins perform much like the Roll Pins
however since they have a protruding edge along their diameter it is not
recommended that they be used for hinge pins.

<b>Grooved Pins</b> - Sometimes called a groove pin, is a parallel dowel pin
which has a portion of the diameter deformed with grooves that run parallel to
the diameter. This functionality allows a portion of the pin to be tightly press
fit into one component while another component can freely rotate or be easily
removed from the end of the pin that has a smooth diameter.

<b>Spring Post</b> - a spring post is a parallel dowel pin with a radial
groove around the diameter located at one end of the length. One end of the
spring post is press fit into a component leaving the radial groove end exposed.
The groove is used to attach an expansion spring.

One application which requires <a href="http://www.rinomechanical.com/dowel-pin.htm">dowel pins</a> uses a grid pattern of holes to locate and mount other accessories. The main advantage in using a dowel pin system is the multiple dowel points provided by the multiple dowel pin locations. Components are typically faster and easier to mount with these systems since the dowel pins provide almost automatic location.

There are various <a href="http://www.rinomechanical.com/dowel-pin.htm">types of dowel pins</a> available, each with its own set of pros and cons. Applications are limitless. They can be used to attach components of furniture, electronic equipment, appliances, automobiles and building structures. The selection of a dowel pin depends upon the type, size, shape and weight of the material being connected. Length of the pin should be appropriate. Environmental conditions such as temperature and humidity should be considered. Chemicals or other corrosive substances to which the dowel may be exposed should also be kept in mind.

If after all research, you are still confused about the type and measurement of

the dowel pin you need, you can always refer to the dowel pin technical data. There are many websites and catalogs which give a complete inventory on types and sizes of pins. This data combines all types and specifications along with other helpful charts and diagrams. The <a

href="http://www.rinomechanical.com/dowel-pin.htm">dowel pin technical data</a> also judges dowel pins according to the main sizing standards provided by ASTM (American Society for Testing and Materials), SAE (Society of Automotive Engineers) and ISO (International Organization for Standards).

#### <b>About the author</b>

<a href="http://www.rinomechanical.com/">Rino Mechanical Components Inc.</a> is
a manufacturing resource which specializes in production of all types of
mechanical components, including <a href="http://www.rinomechanical.com/dynatork/products/air\_motors/air\_motors\_home.htm">air motors</a>. <a
href="http://www.rinomechanical.com/">Mechanical parts</a> are custom made as
per the client's specifications. A guarantee of two years is provided with all
products. All equipment is of top quality made exactly to the consumer's liking.

© Copyright 2005-07, Rino Mechanical Components Inc. All rights reserved.

This Article is Copyright protected. Republishing & syndication of this article is granted only with the due credit, as mentioned, retained in the republished article. Permission to reprint or republish does not waive any copyright. The text, hyperlinks embedded on the article and headers should remain unaltered. This article must not be used in unsolicited mail.