



Service Information System

Shutdown SIS

[Previous Screen](#)

◀ Product: BACKHOE LOADER

Model: 416F2 BACKHOE LOADER LYA

Configuration: 416F2 Center Pivot Backhoe Loader LYA00001-UP (MACHINE) POWERED BY C4.4 Engine

Operation and Maintenance Manual

416F2, 420F2 and 430F2 Backhoe Loaders

Media Number -SEBU9212-05

Publication Date -01/02/2015

Date Updated -26/02/2016

i05897772

Capacities (Refill)

SMCS - 1000; 7000; 7560

Table 1

Approximate Refill Capacities			
Component or System	Liters	US gal	Recommended Type
Engine Crankcase	8.8	2.3	Refer to Operation and Maintenance Manual, "Lubricant Viscosities".
Hydraulic Tank	40.0	10.6	
Transmission	15.0	4.0	
Power Shift Transmission	19.0	5	
Cooling System with Heater	18.5	4.9	
Cooling System without Heater	16.5	4.4	
Fuel Tank	160	42.3	
Rear Axle ⁽¹⁾	16.5	4.4	
Final Drive for the Rear Axle (each side)	1.7	0.45	
Front Powered Axle	11	2.9	
Final Drive for the Front Powered Axle (Each Side)	0.7	0.2	
Rear Axle ⁽¹⁾⁽²⁾	16	4.2	

Final Drive for the Rear Axle (each side) ⁽²⁾	1	0.26	
Front Powered Axle ⁽²⁾	13	3.4	
Final Drive for the Front Powered Axle (Each Side) ⁽²⁾	1	0.26	
	kg	lbs	
Refrigerant ⁽³⁾	1.4	3.1	R-134a
	mL	oz	
Refrigerant Oil (Compressor) ⁽¹⁾	300	10.1	Polyalkylene Glycol (PAG) Oil

⁽¹⁾ Add 0.5 L (0.5 qt) of **197-0017** Axle and Brake Oil Additive to the rear axle. Do not add to the final drives.

⁽²⁾ For machines (S/N: LBF) and (S/N: LBS) only.

⁽³⁾ Refer to Service Manual, "Air Conditioning and Heating R-134a for All Caterpillar Machines" for additional information

Note: When you work on extreme slopes, consult your Cat dealer for the correct fluid levels.

[Copyright 1993 - 2018 Caterpillar Inc.](#)

[All Rights Reserved.](#)

[Private Network For SIS Licensees.](#)

Thu Jul 26 12:06:57 UTC+0800 2018