WARREN FERNANDES SE COMPS B (8940) Batch B

EXPERIMENT 5

OBJECTIVE: To use data transfer, Logical instructions and Rotate instructions, accepting input from keyboard and to understand basic concepts of ALP.

Aim: To perform code conversion

- Hex to BCD □ BCD to Hex
- ASCII to BCD
- BCD to ASCII

Theory:

Logical Instructions:

Logical Instructions are bit manipulation instructions. These instructions are used to perform logical operations like NOT, AND, OR, XOR They are also used to perform rotate or shift operations.


The **AND** operations is also called as a mask operation i.e. it can be used to mask a part of data without affecting the remaining part of data. For example, When a data 35H is ANDed with 0FH, the result is 05H. Hence upper nibble gets masked without affecting the lower nibble. Similarly any part of data can be masked using AND operation.

Rotate instructions:

RCL - Rotate Through Carry Left

Usage: RCL destination, count

Modifies Flags: CF OF




Rotates the bits in the destination to the left "count" times with all data pushed out the left side re-entering on the right. The Carry Flag holds the last bit rotated out.

RCR - Rotate Through Carry Right

Usage: RCR destination, count

Modifies Flags: CF OF




Rotates the bits in the destination to the right "count" times with all data pushed out the right side re-entering on the left. The Carry Flag holds the last bit rotated out.

ROL - Rotate Left

Usage: ROL destination, count

Modifies Flags: CF OF




Rotates the bits in the destination to the left "count" times with all data pushed out the left side re-entering on the right. The Carry Flag will contain the value of the last bit rotated out.

ROR - Rotate Right

Usage: ROR destination, count

Modifies Flags: CF OF



Rotates the bits in the destination to the right "count" times with all data pushed out the right side re-entering on the left. The Carry Flag will contain the value of the last bit rotated out.

Algorithm:

a. BCD to HEX

- 1. Initialize the data segment.
- 2. Move 8 bit data into any of the general purpose register
- 3. Perform Logical AND operation on it with F0h.
- 4. Rotate the resultant data four times to the right to get the upper nibble.
- 5. Multiply Upper nibble by 0A and store product in register dl.
- 6. Separate lower nibble by ANDing 0Fh and add it with the contents of dl register which holds the partial product.
- 7. Finally dl register will have the resultant HEX value.

b. Hex to BCD

- 1. Initialize the data segment.
- 2. Move 8 bit data into any of the general purpose register
- 3. Divide the 8 bit number by 0Ah
- 4. Rotate the quotient stored in AL register by 4 times to the right to make it upper nibble.
- 5. Add the rotated data with remainder stored in AH to get the resultant BCD equivalent.

c. BCD to ASCII

- 1. Initialize the data segment.
- 2. Move 8 bit data into any of the general purpose register
- 3. Perform Logical AND operation on it with 0Fh and store in AL
- 4. Perform Logical AND with original data with F0h and store the result in AH.
- 5. Add 3030h to get AX to get equivalent ASCII data.

d. ASCII to BCD

- 1. Initialize the data segment.
- 2. Move 8 bit data into any of the general purpose register
- 3. Subtract 30h from data to get equivalent BCD

Post lab Questions:

- 1. Write any 10 Bit manipulation instructions with example
- 2. Explain 8086 in minimum and Maximum mode

```
.8086
.model small
.data num db
37h num1 db
35h num2 db
22h num3 db
35h
res db?
res1 db ?
res2 db
result db?
msg2 db 'option 1: Ascii to BCD [ascii value is 37]$'
msg3 db 'option 2: BCD to Ascii [ascii value is 35] $'
msg4 db 'option 3: Hex to BCD [ascii value is 22] $'
msg5 db 'option 4: BCD to Hex [ascii value is 35]$'
msg1 db 'Enter option $'
.code Start:
mov ax,@data
mov ds, ax
lea dx,msg2
mov ah,09h
int 21h
lea dx,msg3
mov ah,09h
int 21h
lea dx,msg4
mov ah,09h
int 21h
```

lea dx,msg5 mov ah,09h int 21h

lea dx,msg1 mov ah,09h int 21h

mov ah,08h int 21h

cmp al,31h jnz next ;AsciiToBCD mov al, num sub al, 30h mov res ,al jmp exit next :cmp al,32h jnz next1

;BCDtoAscii mov al,num1 and al,0F0h ror al, 4 add al,30h mov bl,num1 and bl,0Fh add bl,30h mov res1, al mov res2, bl jmp exit next1:cmp al,33h jnz next2

;HextoDEC mov al,num2 mov ah,00h mov bl,0Ah div bl ror al,04h add al,ah jmp exit

next2:cmp al,34h ;BCDtoHEX mov al,num3 mov dl,00h mov bl,al and bl, 0F0h mov cl,04h ror bl,cl back: add dl, 0Ah dec bl jnz back and al,0Fh add dl, al mov result ,dl jmp exit exit:int 3h end start



Postlabs:

Q1. Ans. Bit Manipulation Instructions

Name	Mnemonic	Explanation	Example
Clear	CLR	It will set the accumulator	CLR
		to 0	
		AC<-0	
Complement	COM	It will complement the	COM A
		accumulator	
		AC<-(AC)'	
AND	AND	It will AND the contents of	AND B
		register B with the	
		contents of accumulator	
		and store it in the	
		accumulator	
		AC<-AC AND B	
OR	OR	It will OR the contents of	OR B
		register B with the	
		contents of accumulator	
		and store it in the	
		accumulator	
		AC<-AC OR B	
Exclusive-OR	XOR	It will XOR the contents of	XOR B
		register B with the	
		contents of the	
		accumulator and store it	
		in the accumulator	
		AC<-AC XOR B	
Clear carry	CLRC	It will set the carry flag to 0	CLRC
		Carry flag<-0	
Set carry	SETC	It will set the carry flag to 1	SETC
		Carry flag<-1	
Complement carry	СОМС	It will complement the	COMC
		carry flag	
		Carry flag<- (Carry flag)'	
Enable interrupt	EI	It will enable the interrupt	El
Disable interrupt	DI	It will disable the interrupt	DI

Ans.

Minimum Mode 8086 System

The microprocessor 8086 is operated in minimum mode by strapping its MN/MX pin to logic 1.

- In this mode, all the control signals are given out by the microprocessor chip itself. There is a single microprocessor in the minimum mode system.
- The remaining components in the system are latches, transreceivers, clock generator, memory and I/O devices.
- Latches are generally buffered output D-type flip-flops like 74LS373 or 8282. They are used for separating the valid address from the multiplexed address/data signals and are controlled by the ALE signal generated by 8086 Transreceivers are the bidirectional buffers and some times they are called as data amplifiers. They are required to separate the valid data from the time multiplexed address/data signals. They are controlled by two signals namely, DEN and DT/R.
- The DEN signal indicates the direction of data, i.e. from or to the processor.
- The system contains memory for the monitor and users program storage. Usually, EPROM are used for monitor storage, while RAM for users program storage. A system may contain I/O devices.
- The opcode fetch and read cycles are similar. Hence the timing diagram can be categorized in two parts, the first is the timing diagram for read cycle and the second is the timing diagram for write cycle.
- The read cycle begins in T1 with the assertion of address latch enable (ALE) signal and also M / IO signal. During the negative going edge of this signal, the valid address is latched on the local bus.
- The BHE and A0 signals address low, high or both bytes. From T1 to T4, the M/IO signal indicates a memory or I/O operation.
- At T2, the address is removed from the local bus and is sent to the output. The bus is then tristated. The read (RD) control signal is also activated in T2.

Maximum Mode 8086 System

In the maximum mode, the 8086 is operated by strapping the MN/MX pin to ground.

- In this mode, the processor derives the status signal S2, S1, S0. Another chip called bus controller derives the control signal using this status information .
- In the maximum mode, there may be more than one microprocessor in the system configuration. The components in the system are same as in the minimum mode system.
- The basic function of the bus controller chip IC8288, is to derive control signals like RD and WR (for memory and I/O devices), DEN, DT/R, ALE etc. using the information by the processor on the status lines.
- The bus controller chip has input lines S2, S1, S0 and CLK. These inputs to 8288 are driven by CPU.
- It derives the outputs ALE, DEN, DT/R, MRDC, MWTC, AMWC, IORC, IOWC and AIOWC. The AEN, IOB and CEN pins are specially useful for multiprocessor systems.
- AEN and IOB are generally grounded. CEN pin is usually tied to +5V. The significance of the MCE/PDEN output depends upon the status of the IOB pin.
- INTA pin used to issue two interrupt acknowledge pulses to the interrupt controller or to an interrupting device.
- IORC, IOWC are I/O read command and I/O write command signals respectively. These signals enable an IO interface to read or write the data from or to the address port.
- The MRDC, MWTC are memory read command and memory write command signals respectively and may be used as memory read or write signals.
- All these command signals instructs the memory to accept or send data from or to the bus.