


SNES bootup sequence (the llvm-mos-65816 platform)


How a `snes` / `snes-far` ROM goes from power-on to `main()`. This is a **reference** for the existing behavior; the *why* of the native-mode design lives in the plans linked at the end. Source of truth: [platforms/snes/crt0.c](#), [platforms/snes/link.ld](#), [platforms/snes/header.s](#), and the common chain merged via [platforms/snes/CMakeLists.txt](#).

TL;DR

The 65816 powers on in **6502-emulation mode**, reads the **emulation RESET vector** at `$FFFC` → `_start` (= the start of `.text` = `.init.50`). The crt0 preamble switches to **65816 native mode** and pins a known machine contract (E/M/X/SP/DBR/DP), then the **common init chain** (`.init.100` → `.200` → `.300`) sets up the soft stack, copies `.data`, clears `.bss`, and runs constructors, then `.call_main` calls `main()`. On the SNES there is no OS to return to, so a return from `main()` lands in an infinite **exit loop**.

The whole sequence at a glance





`.init.*` fragments are emitted into `.text` and ordered by their numeric suffix, so the **section number is the boot order**. Unused fragments are garbage-collected (e.g. `hello.c` pulls in only `.init.50`, `.100`, `.200` -zero-zp-bss, `.call_main` — no `.data` to copy, no constructors).

Stage 0 — power-on and the reset vector

The 5A22 (the SNES's 65816) comes out of reset in **emulation mode (E=1)**, so it fetches the **emulation** RESET vector at `$FFFC`. The linker points it at `_start`, which is the very first byte of `.text`:

<code>\$8000</code>	<code>_start = .</code>		← <code>.text</code> base = reset entry
<code>\$8000</code>	<code>crt0.o:(.init.50)</code>	<code>0x18</code>	← native-mode preamble (this is <code>_start</code>)
<code>\$FFFC</code>	<code>SHORT(_start)</code>		← emulation RESET vector

(LoROM maps ROM `$8000-$FFFF` to file offset `$0000-$7FFF`, so `$FFFC` is file offset `$7FFC`.)

Stage 1 — `.init.50` : native-mode preamble (`crt0.c`)

The 24-byte fragment that establishes the machine contract:

```
.section .init.50, "axR", @progbits
```

```

sei          ; mask IRQ
cld          ; binary mode (decimal flag is undefined at reset)
clc          ; clear carry, then exchange it with E (next op):
xce          ; E = 0 -> 65816 native mode (M=1, X=1 kept)
rep #10      ; 16-bit index regs, so the next txs takes a 16-bit value
ldx #$01ff   ; 16-bit immediate (an 8-bit txs would leave SP=$00FF)
txs          ; hardware stack pointer -> $01FF (page 1)
sep #30      ; M=1, X=1: 8-bit A + index (the codegen default)
phk          ; push program bank (= 0; reset code is in bank $00) ...
plb          ; ... pull it into DBR -> DBR := 0 (abs globals + MMIO read DBR:addr)
lda #$00     ; A = $00 for the NMITIMEN store below
sta $4200    ; NMITIMEN: no NMI / IRQ / auto-joypad
lda #$8f     ; bit 7 = force-blank, brightness 0
sta $2100    ; INIDISP: force blank, brightness 0

```

crt0 is built with `-mcpu=mosw65816 -fno-lto` (set in `platforms/snes/CMakeLists.txt`), so the 65816-only ops are plain mnemonics. `-fno-lto` is required because module-level inline `asm()` under LTO does not receive the `w65816` subtarget feature; with it, `ldx #$01ff` assembles to the correct 16-bit immediate (`a2 ff 01`), byte-identical to the old hand-encoded `.byte` form.

What actually executes (the linked bytes)

```

78 d8 18 fb c2 10 a2 ff 01 9a e2 30 4b ab a9 00 8d 00 42 a9 8f 8d 00 21
SEI CLD CLC XCE REP#10 LDX#$01ff TXS SEP#30 PHK PLB LDA#0 STA $4200 LDA#8F STA $2100
      ^ X→16 ^ 16-bit | ^ M=1 | | ^ NMITIMEN ^ INIDISP
          SP value | X=1 | ^ DBR := 0 off force-blank
                  SP=$01FF PB pushed (=0)

```

`dev/run.sh crt0native` asserts this byte sequence (and the runtime DBR=0) as a standing gate.

The native-mode contract this leaves

Register	Value after <code>.init.50</code>	How / why
E	0 (native)	<code>XCE</code> — required for 16-bit accumulator/index codegen (<code>+mos-a16</code> / <code>+mos-xy16</code>)
SP	\$01FF	page-1 hardware stack via a transient 16-bit <code>ldx #\$01ff; txs</code> (an 8-bit <code>txs</code> would set <code>\$00FF</code> and collide with the direct page)

Register	Value after .init.50	How / why
M	1 (8-bit A)	SEP #\$30 — the codegen default; 16-bit regions are bracketed by rep/sep #\$20
X	1 (8-bit index)	SEP #\$30 ; 16-bit-index regions bracketed by rep/sep #\$10 (+mos-xy16)
DBR	0	PHK; PLB — explicit, so the 8-bit abs / R_MOS_ADDR16 global path and the MMIO writes (which read DBR:addr) land in bank 0. Reset already leaves DBR=0; making it explicit means a later bank switch / MVN / MVP / interrupt can't silently break the invariant. The native-16 long / R_MOS_ADDR24 path is DBR-independent.
DP	0	reset default; the direct page never moves on this platform (imaginary registers + zero page live at \$0000)
PPU	force-blank, NMI/IRQ off	INIDISP=\$8F , NMITIMEN=\$00 — a known display state with interrupts masked through bring-up

Stage 2 — the common init chain

Pulled in by [CMakeLists.txt](#) (merge_libraries(snes-crt0 common-copy-data common-init-stack common-zero-bss common-exit-loop)), each piece contributing a numbered .init fragment that runs after .init.50 :

Order	Fragment	Source	Does
.init.100	__do_init_stack	common/crt0/init-stack.S	point the soft stack at __stack = \$2000 (it grows down through low WRAM)
.init.200	copy .data , clear .bss	copy-data.c , copy-zp-data.c , zero-bss.c , zero-zp-bss.c	copy initialized .data from its ROM image (LMA) into RAM (VMA); zero .bss and the zero-page .bss
.init.300	__init_array	init-array.c	run C++ static constructors / __attribute__((constructor)) (omitted if none)

Order	Fragment	Source	Does
—	.call_main	crt0.o	jsr main

The **soft stack** (the C call/local stack) is deliberately separate from the 65816 **hardware stack** (\$0100-\$01FF). Locals/spills use the soft stack via the `__rc0/__rc1` pointer; `JSR / RTS` return addresses use the hardware stack. This is why a page-1 hardware stack (`SP=$01FF`) is sufficient even in native mode.

Stage 3 — `main()` and exit

`.call_main` calls `main()` . On a console there is no OS to return to, so `common-exit-loop` makes a return from `main()` fall into an **infinite loop** (the program "ends" by spinning). Bring-up test ROMs typically compute a `corpus_result / sentinel` global and then `for (;;) {}` so an emulator can settle and read the value out of WRAM.

Memory map at boot ([link.ld](#))

\$0000-\$001F	imaginary (zero-page) registers <code>__rc0..__rc31</code>	(the GPR/Imag8/Imag16 file)
\$0020-\$00FF	zero page / direct page	
\$0100-\$01FF	hardware stack (JSR/RTS, interrupts)	SP set to \$01FF
\$0200-\$1FFF	low WRAM: soft stack grows DOWN from \$2000;	.data / .bss / heap grow UP from \$0200
\$2000-\$7FFF	(bank \$00) PPU/CPU MMIO, etc.	\$2100 INIDISP, \$4200 NMITIMEN
\$8000-\$FFFF	cartridge ROM (LoROM): <code>.text/.init, .rodata, .data</code> LOAD image	header @ \$FFB0, vectors @ \$FFE0-\$FFFF

`snes-far` adds a second ROM bank (`$018000-$01FFFF`) for cross-bank far **data**, read via DBR-independent `long / [dp]` addressing; code stays in bank `$00` , so the boot sequence is identical (the `crt0` is inherited via `PARENT snes`).

Interrupt & reset vectors ([link.ld](#))

The 65816 has **two** vector tables — one used in native mode, one in emulation mode. The machine boots in emulation mode (→ `$FFFC` RESET); after `XCE` any interrupt would use the native table, but interrupts stay masked through bring-up (`SEI + NMITIMEN=0`), and both tables point NMI/IRQ at the same stubs.

```
Native ($FFE0-$FFE0F): $FFE6 BRK→irq $FFEA NMI→nmi $FFEE IRQ→irq (COP/ABORT→0)
Emulation ($FFF0-$FFFF): $FFFA NMI→nmi $FFFC RESET→_start $FFFE IRQ→irq
```

The default handlers are **weak** bare- `rti` stubs (`crt0.c`), overridable by defining `nmi` / `irq` in user code. A bare `rti` is width-safe (it restores `P` , hence M/X, on return).

For a future real handler (out of scope today): a native-mode ISR can be entered with **M=0 and/or X=0** (it may interrupt a `rep #$30` region), so it must save `P` and force known widths before touching A/X/Y, and restore via `rti` . The current stubs sidestep this by doing nothing while interrupts are masked.

Cartridge header (`header.s`)

Not executed, but part of the boot image: the LoROM internal header at `$FFB0-$FFDF` (title "LLVM-MOS SNES" , map mode `$20` = LoROM/slow, ROM size `$05` = 32 KiB, NTSC). The checksum/complement at `$FFDC/$FFDE` are placeholders patched post-link by `tools/snes-checksum.py` .

References

- Native-mode entry rationale + the 8-bit-safe argument: [2026-06-14-321-native-mode-crt0.md](#) .
- Explicit DBR=0 contract (the `phk; plb`) + the addressing/relocation analysis: [2026-06-18-321-native-mode-crt0-xy16.md](#) .
- Standing contract gate: `dev/run.sh crt0native` ([dev/crt0native.sh](#)).
- Build/test mechanics & the addressing/DBR note: [agent-handoff.md](#) .