

**ERASMUS+  
GEMS  
DIAMOND**




Diamond by GEMS Erasmus+, Some rights reserved

# DC drive close-loop control

How to design and tune a DC drive close-loop controller?

Dr. Hassan HosseinNia






# Lecture Outline

- 1 DC drive system dynamics
- 2 PI control for current control
- 3 Cascaded speed/position control
- 4 Discrete controller implementation

How to describe the  
dynamics of a DC drive  
system?

# DC drive system dynamic models: electrical dynamics



$V_a$ : armature voltage

$R_a$ : armature resistance

$L_a$ : armature inductance

$i_a$ : armature current

$e_b$ : back electromotive force (emf)

$$\begin{aligned}v_a &= R_a i_a + L_a \frac{di_a}{dt} + e_b \\&= R_a i_a + L_a \frac{di_a}{dt} + K\Omega \\e_b &= K\Omega\end{aligned}$$

$K$ : motor constant

$\Omega$ : angular velocity

Taking Laplace transformation

$$V_a(s) = (R_a + sL_a)I_a(s) + K\Omega(s)$$


Now solve for  $I_a(s)$ :

$$I_a(s) = G_e(s)V_a(s) - G_e(s)K\Omega(s)$$

where

$$G_e(s) = \frac{1}{R_a + sL_a}$$

# DC drive system dynamic models: mechanical dynamics



$V_a$ : armature voltage

$R_a$ : armature resistance

$L_a$ : armature inductance

$i_a$ : armature current

$e_b$ : back electromotive force (emf)

$$T = J \frac{d\Omega}{dt} + b\Omega$$

$T$ : torque

$J$ : moment of inertia

$b$ : damping coefficient


Taking Laplace transformation

$$T(s) = sJ\Omega(s) + b\Omega(s)$$

Convert to transfer function

$$\frac{\Omega(s)}{T(s)} = \frac{1}{sJ + b} = G_m(s)$$

# DC drive system dynamic models: electromechanical model



$V_a$ : armature voltage

$R_a$ : armature resistance

$L_a$ : armature inductance

$i_a$ : armature current

$e_b$ : back electromotive force (emf)


Substitute  $i_a(s)$  from torque equation to electrical model

$$V_a(s) = (R_a + sL_a) \frac{T(s)}{K} + K\Omega(s)$$

Substitute the mechanical model

$$V_a(s) = \frac{(R_a + sL_a)(sJ + b)}{K} \Omega(s) + K\Omega(s)$$

Resulted block diagram




Final transfer functions

$$\frac{\Omega(s)}{V_a(s)} = \frac{K}{(R_a + sL_a)(sJ + b) + K^2}$$

$$\frac{\theta(s)}{V_a(s)} = \frac{1}{s} \frac{\Omega(s)}{V_a(s)}$$

# DC drive system dynamic models: frequency response

Block diagram and transfer functions




$$G_e(s) = \frac{1}{R_a + sL_a}$$

$$\frac{\Omega(s)}{T(s)} = \frac{1}{sJ + b} = G_m(s)$$

$$\frac{\Omega(s)}{V_a(s)} = \frac{K}{(R_a + sL_a)(sJ + b) + K^2}$$

$$\frac{\theta(s)}{V_a(s)} = \frac{1}{s} \frac{\Omega(s)}{V_a(s)}$$

Frequency response example



## Problems

- Slow response and non-controlled current
- Steady state error
- To be solved by close-loop control


# How to regulate the torque and speed of a DC drive system?

# Torque control and current loop

## Transfer functions

Electrical system  $G_e(s) = \frac{1}{R_a + sL}$

PI controller  $C(s) = K_p \left(1 + \frac{K_i}{s}\right)$



## Open-loop transfer function

$$C(s)G_e(s) = \frac{K_p s + K_i}{s} \frac{1}{R_a + sL_a}$$

Set equal to design target


$$C(s)G_e(s) = \frac{\omega_c}{s} \rightarrow K_p s + K_i = \omega_c(R_a + sL_a)$$
$$K_i = \omega_c R_a, \quad K_p = \omega_c L_a$$

## Design goals

$$\frac{T}{T_r} = \frac{KI_a}{KI_r} \approx 1 \rightarrow \text{Current } I \text{ closely follows reference } I_r$$

Target open loop transfer function  $\rightarrow C(s)G_e(s) = \frac{\omega_c}{s}$   
 $\omega_c$  is a design parameter called bandwidth.


## Close-loop response



- ~0 dB at low frequency (reference following)
- Attenuation at high frequency (noise rejection)

# Simplified drive dynamics

## Close-loop response



- $\sim 0$  dB at low frequency (reference following)
- Attenuation at high frequency (noise rejection)

## Simplified drive model with closed current loop

- Below bandwidth frequency  $\omega_c$ , any reference torque is follow, i.e. for sufficiently large bandwidth,

$$\frac{T}{T_r} = \frac{KI_a}{KI_r} \approx 1$$


- Back emf acts as a disturbance to the loop and is rejected in the closed loop below bandwidth frequency.



$$\frac{\Omega(s)}{T_r(s)} = G_m(s) = \frac{1}{sJ + b}$$

# Cascaded speed control: loop shaping and tuning

## Speed close-loop control



Mechanical system  $G_m(s) = \frac{1}{sJ + b}$

Speed PI controller  $C_m(s) = K_{pm} \left(1 + \frac{\omega_{im}}{s}\right)$

## Close-loop transfer function

$$L(s) = C_m(s)G_m(s) = \frac{K_{pm}(\omega_{im} + s)}{s(Js + b)}$$



$$\frac{\Omega(s)}{\Omega_r(s)} = \frac{L(s)}{1 + L(s)}$$

Design target: design  $C_m$  so that

$$\frac{\Omega(s)}{\Omega_r(s)} \approx \frac{\omega_m}{s + \omega_m}$$

$\omega_m$  is the desired speed loop bandwidth

## Controller tuning

To achieve the desired bandwidth  $\omega_m$

- Choose  $\omega_{im} = \omega_m < \omega_c / 10$  so that simplification applies
- Then compute the speed loop gain

$$K_{Pm} = \frac{1}{|G_m(j\omega_m)|} = |Js + b| \Big|_{s=j\omega_m} = \sqrt{(J\omega_m)^2 + b^2}$$

# Cascaded speed control: theory vs. reality

Design target: design  $C_m$  so that

$$\frac{\Omega(s)}{\Omega_r(s)} \approx \frac{\omega_m}{s + \omega_m}$$

$\omega_m$  is the desired speed loop bandwidth

Reality check

- If current loop bandwidth is **not significantly larger, inner loop dynamics no longer negligible**, system becomes **second-order**
- Stability and performance affected

Practical recommendation

- Maintain stability
- Always choose sufficiently low speed loop bandwidth, even if inner loop bandwidth is not high

Assumption in theory

The drive is simplified under the condition


$$\omega_c \gg \omega_m \quad (\text{e.g., } \omega_c > 10\omega_m)$$

Then the inner torque control loop behaves as a **unity gain**


# How to realize position tracking in a DC drive system?

# Cascaded position control

Plant model simplified



Position close-loop



Close-loop transfer function

$$\begin{aligned}\frac{\theta(s)}{\theta_r(s)} &= \frac{L_\theta(s)}{1 + L_\theta(s)} \\ &= \frac{\frac{K_{dp}s + K_{pp}}{s(Js+b)}}{1 + \frac{K_{dp}s + K_{pp}}{s(Js+b)}} = \frac{K_{dp}s + K_{pp}}{s(Js + b) + K_{dp}s + K_{pp}}\end{aligned}$$

Integrator (1/s) in the plant model


- PI controller not needed (improper phase margin)
- A PD controller necessary to ensure stability

Open-loop  
transfer function

$$\begin{aligned}L_\theta(s) &= C_\theta(s)G_\theta(s) = (K_{dp}s + K_{pp})\frac{1}{s(sJ + b)} \\ &= \frac{K_{dp}s + K_{pp}}{s(Js + b)}\end{aligned}$$

# Cascaded position control: tuning

Position close-loop



$$\begin{aligned}\frac{\theta(s)}{\theta_r(s)} &= \frac{L_\theta(s)}{1 + L_\theta(s)} \\ &= \frac{\frac{K_{dp}s + K_{pp}}{s(Js+b)}}{1 + \frac{K_{dp}s + K_{pp}}{s(Js+b)}} = \frac{K_{dp}s + K_{pp}}{s(Js+b) + K_{dp}s + K_{pp}}\end{aligned}$$

Shape the closed-loop system to match a standard second-order response

$$\frac{\theta(s)}{\theta_r(s)} = \frac{\omega_n^2}{s^2 + 2\zeta\omega_n s + \omega_n^2}$$

Controller parameters for loop shaping

$$K_{pp} = \omega_n^2 \cdot J$$


$$K_{dp} = 2\zeta\omega_n \cdot J - b$$

$\omega_n$  is the desired position tracking bandwidth  
 $\zeta$  is the damping coefficient of the closed loop

If  $b \ll 2\zeta\omega_n J$ , then  $K_{dp} \approx 2\zeta\omega_n \cdot J$

# Cascaded position control: problem with PD controller

PD controller at high frequencies



$$C_\theta(s) = K_{dp}s + K_{pp}$$

$$\frac{\theta(s)}{\theta_r(s)} = \frac{K_{dp}/Js + \omega_n^2}{s^2 + 2\zeta\omega_n s + \omega_n^2}$$

Results in  
infinite gain at  
high frequency

Noise  
amplification

Solution: Tamed PD or lead compensator

Apply a low pass filter to a PD controller

$$C_\theta^{\text{new}}(s) = \frac{K_{dp}s + K_{pp}}{\frac{s}{\omega_l} + 1} \quad \text{A lead compensator}$$

$\omega_l$  is usually chosen to be 3-10 times the bandwidth  $\omega_n$

# How to implement the controller in a digital system?

# Digital implementation: Tustin (Bilinear Transform)

Discretization: micro-controllers (MCUs) operate in accurate steps

- Convert a continuous controller to a discretized controller
- From Laplace domain  $C(s)$  to z domain  $C(z)$

Solution: Tustin approximation

Substitute Laplace variable  $s$  with

$$s \approx \frac{2}{T} \cdot \frac{1 - z^{-1}}{1 + z^{-1}}$$

$T$ : sampling period

$z$ : z-transform variable

Advantages of Tustin approximation


Compared to other methods (e.g. Euler)

- Preserves stability
- Approximates response accurately near Nyquist
- Common and reliable for implementing analog controllers digitally

You can use Scilab function [cls2dls\(\)](#) or Matlab function [c2d\(\)](#) for bilinear transform based discretization.

# Conclusions

- Dynamics of DC drive system can be modelled in transfer functions
- Torque control loop can be realized with a PI controller
- In cascaded speed control, the external speed loop should have sufficiently lower bandwidth
- A tamed PD controller is suitable for position tracking
- Controller designed based on transfer functions can be digitalized by Tustin transformations.



# Thank you for watching!

This video was created by Delft University of Technology for the GEMS Erasmus+ project (a collaboration between University of Ljubljana, University of Alcala, Teaching Factory Competence Center, and Delft University of Technology). It is released under a [Creative Commons Attribution Non Commercial Share Alike 4.0 International License](#)



**Co-funded by  
the European Union**

Views and opinions expressed are however those of the author(s) only and do not necessarily reflect those of the European Union or CMEPIUS. Neither the European Union nor the granting authority can be held responsible for them.