

**ERASMUS+
GEMS
DIAMOND**



Tutorial 3

Losses in a Motor Drive

Dr. ir. Sachin Yadav

DCE&S, ESE, TU Delft



① Motor Drive - Operation and Losses

② Example - DRV8411

③ Thermals

① Motor Drive - Operation and Losses

② Example - DRV8411

③ Thermals

Operating modes

$$\omega \propto V_{12} \propto D$$

D is changed through half bridges (S_1 & S_2 and S_3 & S_4)

Two modes:

- High-side recirculation
- Low-side recirculation





Figure: DC motor drive.

Power losses in motor drive



High side recirculation - voltage at point 2:



$$P_{loss} = P_{cond,S1} + P_{cond,S4}$$

Power losses in motor drive



High side recirculation - voltage at point 2:



$$P_{loss} = P_{cond,S1} + P_{sw,S4} + P_{cond,D3}$$

Power losses in motor drive



High side recirculation - voltage at point 2:



$$P_{loss} = P_{cond,S1} + P_{sw,D3} + P_{cond,S3}$$

Power losses in motor drive


High side recirculation - voltage at point 2:



$$P_{loss} = P_{cond,S1} + P_{sw,D3} + P_{cond,D3}$$

Power losses in motor drive

High side recirculation - voltage at point 2:



$$P_{loss} = P_{cond,S1} + P_{sw,S4} + P_{cond,S4}$$

① Motor Drive - Operation and Losses

② Example - DRV8411

③ Thermals

DRV8411

The DC motor driver is used in the GEMS Diamond board.

- Two H-bridges




Figure: Functional block diagram of DRV8411 [1].

DRV8411

The DC motor driver is used in the GEMS Diamond board.

- Two H-bridges
- Outputs are connected in parallel




Figure: Connection in Diamond board [1].

DRV8411

The DC motor driver is used in the GEMS Diamond board.

- Two H-bridges
- Outputs are connected in parallel
- Same PWM signals for corresponding switches in two H-bridges




Figure: Connection in Diamond board [1].

Loss parameters

Table: DRV8411 switch parameters.

Symbol	Value
$R_{HS-DS, on}$	200 mΩ @ $I_L = 0.2$ A
$R_{LS-DS, on}$	200 mΩ @ $I_L = -0.2$ A
V_{SD}	1 V @ $I_L = -0.5$ A
t_{rise}	100 ns @ $V_{dc} = 5$ V
t_{fall}	50 ns @ $V_{dc} = 5$ V
t_{dead}	400 ns

Table: Operating parameters.

Symbol	Value
V_{dc}	4.2 V
D	0.5
I_L	0.2 A
f_{PWM}	5 kHz

Loss calculation

- Conduction losses:

$$P_{\text{cond},S1} = 0.5I_L^2 R_{\text{HS-DS, on}} = 4 \text{ mW}$$

$$P_{\text{cond},S2} = 0 \text{ W}$$

$$P_{\text{cond},S3} = 0.5DI_L^2 R_{\text{HS-DS, on}} = 2 \text{ mW}$$

$$P_{\text{cond},S4} = 0.5(1 - D)I_L^2 R_{\text{LS-DS, on}} = 2 \text{ mW}$$




Figure: DRV8411 motor drive switch configuration.

Loss calculation

- Switching losses:

$$P_{sw,S1} = 0$$

$$P_{sw,S2} = 0$$

$$P_{sw,S3} = 0$$

$$P_{sw,S4} = 0.5V_{dc}I_L t_{rise} f_{PWM}$$

$$+ 0.5V_{dc}I_L t_{fall} f_{PWM} = 0.315 \text{ mW}$$




Figure: DRV8411 motor drive switch configuration.

Loss calculation

- Diode conduction losses:
 $P_{\text{cond},D1} = 0$
 $P_{\text{cond},D2} = 0$
 $P_{\text{cond},D3} = 2V_{\text{DC}}I_L t_{\text{dead}} f_{\text{PWM}}$
 $= 3.36 \text{ mW}$
 $P_{\text{cond},D4} = 0$




Figure: DRV8411 motor drive switch configuration.

Loss calculation

- Other negligible losses:
 - Gate driver losses
 - Device consumption losses
 - In some chips: LDO regulator losses




Figure: DRV8411 motor drive switch configuration.

① Motor Drive - Operation and Losses

② Example - DRV8411

③ Thermals

Heat dissipation mechanisms




Figure: Heat dissipation mechanisms. Source: [2].

Semiconductor thermal parameters




Figure: Heat dissipation parameters. Source: [2].

DRV8411

Table: Thermal data for DRV8411

Symbol	Description	Value
$R_{\theta JA}$	Junction-to-ambient thermal resistance	$45.1 \text{ } ^\circ\text{C W}^{-1}$
$R_{\theta JC(\text{top})}$	Junction-to-case (top) thermal resistance	$43.7 \text{ } ^\circ\text{C W}^{-1}$
$R_{\theta JB}$	Junction-to-board thermal resistance	$19.9 \text{ } ^\circ\text{C W}^{-1}$
$R_{\psi JT}$	Junction-to-top characterization parameter	$2.6 \text{ } ^\circ\text{C W}^{-1}$
$R_{\psi JB}$	Junction-to-board characterization parameter	$19.9 \text{ } ^\circ\text{C W}^{-1}$
$R_{\theta JC(\text{bot})}$	Junction-to-case (bottom) thermal resistance	$4.9 \text{ } ^\circ\text{C W}^{-1}$

DRV8411

Total IC losses calculated previously: 11.675 mW.

- How to calculate the temperature rise?

DRV8411

Total IC losses calculated previously: 11.675 mW.

- How to calculate the temperature rise?

$$T_{rise} = R_{\theta xy} P_{loss}$$

DRV8411

Total IC losses calculated previously: 11.675 mW.

- How to calculate the temperature rise?

$$T_{rise} = R_{\theta xy} P_{loss}$$

- Which thermal parameters ($R_{\theta xy}$) to use?

DRV8411

Total IC losses calculated previously: 11.675 mW.

- How to calculate the temperature rise?

$$T_{rise} = R_{\theta xy} P_{loss}$$

- Which thermal parameters ($R_{\theta xy}$) to use?

- Depends upon the main power sinks!
- Some parameters are not applicable. For e.g. $R_{\theta JA}$.





Figure: IC package. Source: [2].

Conclusion

- Converter operating modes, and power losses.
- DRV8411 application and loss calculation.
- Thermal dissipation.



Images by [GEMS Erasmus Plus](#)

Thank you for watching!

This video was created by Delft University of Technology for the GEMS Erasmus+ project (a collaboration between University of Ljubljana, University of Alcala, Teaching Factory Competence Center, and Delft University of Technology). It is released under a [Creative Commons Attribution Non Commercial Share Alike 4.0 International License](#)



**Co-funded by
the European Union**

Views and opinions expressed are however those of the author(s) only and do not necessarily reflect those of the European Union or CMEPIUS. Neither the European Union nor the granting authority can be held responsible for them.

References |

- [1] T. Instruments. *DRV8411A Dual H-Bridge Motor Driver with Current Regulation datasheet (Rev. B)*. July 2024.
URL: <https://www.ti.com/lit/ds/symlink/drv8411a.pdf>.
- [2] R. Semiconductor. *Basics of Thermal Resistance and Heat Dissipation*. Aug. 2021. URL:
https://fscdn.rohm.com/en/products/databook/applinote/common/basics_of_thermal_resistance_and_heat_dissipation_an-e.pdf.