

USONIAN 4-STRING BASS NUT SPACING GUIDE

Electric bass


Print at 100% / Actual Size - do not fit to page

INSTRUCTIONS

- 1. First attach the two outside strings to the instrument and lightly tension them. Mark the locations of the two outside-string centers on the nut.
- 2. Hold the nut with its top edge facing down and slide it down the page.
- 3. Align the marked outside-string centers with the two outside guide lines.
- 4. Mark the remaining strings where the guide lines cross the nut.

BASS / LOW

TREBLE / HIGH



Top and bottom values are center-to-center string spacing in millimeters.

Outside string centers are 3.18 mm (1/8 in.) from each nut edge.

