4107056006 資工三 游庭瑋

4107056019 資工三 廖柏丞

HW3: WeMoS IoT 系統整合

一、建立資料庫

1. 下載 xampp·將其內容完整安裝

開啟 Apache 和 MySQL



2. 進入 localhost/phpmyadmin/ 使用者帳號 新增使用者帳號

鍵入帳號密碼,全域權限全選並執行


使用者名稱:	使用文字方塊	~	test123	▲ 已有與此帳號相同
主機名稱:	任何主機	~	%	0
密碼:	使用文字方塊	~	•••••	強度: 極差
重新輸入:			******	
認證外掛程式			原生 MySQL 認證 🗸	
產生密碼:	產生			
使用者帳號的資料庫				
□ 建立與使用者同名的資料庫,並授予所有權限。				
□ 給以 帳號_ 開頭的資料庫 (username_%) 授予所有權限。				
全域權限 <mark>✓</mark> 全選				
注意:MySQL 權限名稱會以英文表示。				

3. 同上部, 輸入一樣的帳號密碼, 主機名稱選本機



4. 使用 hedisql 登入管理


輸入剛剛的帳號密碼後登入



5. 建立新的資料庫,參數如下



6. 在 aiot 上右鍵選建立新的資料表,輸入名稱並加入以下欄位,調整其資料類型



7. 最後在 id 上右鍵建立新的索引->primary key 並儲存




8. 在查詢的地方輸入 SQL 語句:

INSERT INTO lights (humi, temp, light) VALUES (RAND()*100, RAND()*40, RAND());

並複製貼上數次,以讓資料達到40筆,並按下執行


二、建立 php 後端

1. 在安裝目錄/htdocs 下新建 aiot 資料夾,將老師所附的 iot 資料夾解壓縮到此




2. 編輯三個檔案,調整成設定的資料庫參數

3. 開啟 localhost/aiot/home.html,確定可以顯示



三. 連接 WeMoS

1. 接上 WeMoS 並連接 DHT11 感測器



2. 開啟 IDE 編寫下列程式

```
#include "pin.h"
#include "ESP8266WiFi.h"
#include "ESP8266WiFiMulti.h"

#include "ESP8266HTTPClient.h"
#include "DHT.h"
#include "WiFiClient.h"

ESP8266WiFiMulti WiFiMulti;
DHT dht(D5, DHT11);

char *SSID = "SSID";
char *PASSWORD = "PASSWD";

void setup() {

Serial.begin(115200);
```

```
Serial.setDebugOutput(true);
 Serial.println();
 Serial.println();
 Serial.println();
 for (uint8_t t = 4; t > 0; t--) {
  Serial.printf("[SETUP] WAIT %d...\n", t);
  Serial.flush();
  delay(1000);
WiFi.mode(WIFI_STA);
 WiFiMulti.addAP(SSID, PASSWORD);
 while (WiFiMulti.run() != WL_CONNECTED){
  Serial.println("wait..");
  delay(500);
void loop() {
//DHT setup
float h = dht.readHumidity();
float t = dht.readTemperature();
 int I = random(100) \% 2;
 if(isnan(h) || isnan(t)){
  Serial.println("Unable to read value from DHT sensor!");
  return;
}
 Serial.printf("humidity: %f, temp: %f\n", h, t);
// wait for WiFi connection
 if ((WiFiMulti.run() == WL_CONNECTED)) {
  WiFiClient client;
  HTTPClient http;
  const char *host = "192.168.43.236";
  const int port = 80;
```

}

```
if(!client.connect(host, port)){
   Serial.println("connect failed");
   Serial.println("wait 3 sec...");
   delay(3000);
   return;
  }
  Serial.print("[HTTP] begin...\n");
  String url ="/aiot/adddata.php?t="+String(t)+"&h="+String(h)+"&l="+String(l);
  client.print(String("GET")+url+" HTTP/1.1\r\n"+
  "Host: "+host+"\r\n"+
  "Connection: close\r\n\r\n");
  Serial.println("connect closed");
  client.stop();
 }
 delay(1000);
}
```

其中 SSID 和 PASSWD 更換成等會要連接的 wifi 參數

3. 燒錄到 WeMoS 板上

```
Unable to read value from DHT sensor!
Unable to read value from DHT sensor!
humidity: 86.000000, temp: 25.100000
[HTTP] begin...
connect closed
humidity: 86.000000, temp: 25.100000
[HTTP] begin...
connect closed
```

4. 打開 localhost/aiot/home.html,確認資料都有成功輸入並顯示

Sensor data from MySQL to Highcharts

