1.1 (5%) Consider two processors, A and B, which have the following characteristics:

Processor A: Clock rate: 2.5 GHz CPI: 1.8 Processor B: Clock rate: 3 GHz

Assuming both processors execute the same program with a total of 10 billion instructions, how long does it take for the two processors to run the program? which processor is faster in terms of execution time?

## Solution:

CPI: 2.2

```
Execution time = (Number of instructions) x CPI x Cycle time = (Number of instructions) x CPI / Frequency

Execution time for A = 1e10 x 1.8 / 2.5e9 = 7.2 seconds

Execution time for B = 1e10 x 2.2 / 3.0e9 = 7.33 seconds
```

Therefore, processor A is faster in terms of execution time

1.2 (5%) A computer system has a task that can be divided into two parts: Part A and Part B. Part A takes up 60% of the total time to complete the task, while Part B takes up the remaining 40%.

(1) If we can speed up Part A by a factor of 4 and Part B by a factor of 2, what is the overall speedup we can achieve using Amdahl's law?

## Solution:

According to Amdahl's Law, the overall speedup of a program with an improvement is given by:



Total time = time for Part A + time for Part B Total time = 0.6T + 0.4T = T

New total time = time for new Part A + time for new Part B New time for Part A = 0.6T / 4 = 0.15T New time for Part B = 0.4T / 2 = 0.2T New total time = 0.15T + 0.2T = 0.35T

The speedup achieved by the optimizations is:

Speedup = Total time / New total time
Speedup = T / 0.35T
Speedup = 2.86

1.3 (5%) We have eight great ideas in computer design, match them to the following  $\underline{\mathbf{seven}}$  examples in real world (hint: one example gets two idea).

Design for Moore's Law, Use Abstraction to Simplify Design, Make the Common Case Fast, Performance via Parallelism, Performance via Pipelining, Performance via Prediction, Hierarchy of Memories, Dependability via Redundancy

- Cooking recipes that only specify the type of sugars, oils and flours without naming the detailed brand.
   Abstraction
- Apply for multiple waitlist when you book your train tickets on 12306.

Redundancy

Organize your clothes and pack them in storage boxes while only leave your favorite ones in your closet.

Hierarchy, common case

 Dividing a team of workers into different groups, each team work independently on their own tasks.

Parallel

- Dividing a team of workers into different groups, each team is in charge of a specific task and work in series Pipeline
- A supermarket manager decided to open five checkout lanes at 6pm, and 2 lanes at 9pm.

Prediction

 Ultralight fiber materials which can make large size backpacks with reasonable weight.
 Design for Moore's Law

<pre>2. Arithmetic for Computer (35%) 2.1 (4%) What is the octal value of 0x20230508. A:</pre>
2.2 (4%) What is the binary value of -503 using 2-s complement).
<pre>2.3 (4%) What is the binary bit pattern representation of -11.53125 (using single precision). A:</pre>
2.4 (4%) Double precision representation of -11.53125 A:
2.5 (4%) Assume that registers in RV32I (Risc-V 32-bit) hold the following values: x1: 0x7FFFFFFF x2: 0x00000001 x3: 0x12345678 What is the value of x3 immediate after the execution of the following assembly code?
add x3,x1,x2
Α.

```
Solution:
2.1
= 0 4 0 1 0 6 0 2 4 1 0<sub>8</sub>
2.2
503 = 01 1111 0111
-503 = 10\ 0000\ 1000\ +\ 1 = 10\ 0000\ 1001
2.3 - 2.4
11 = 1011
0.53125 = 10001
-11.53125 = -1011.10001 = -1.0111 0001 \times 2^3
Single Precision
Exponent = 3 + 127 = 130 = 1000 0010
Double Precision
Exponent = 3 + 1023 = 1026 = 100 0000 0010
2.5
X1 + x2 results in overflow
X3 = 0x12345678
```

(1)Calculate 5.9140625 + 2.34375  $\times$  10<sup>-2</sup> by hand, assume 1 guard, 1 round bit and 1 sticky bit, and round to the nearest even. Show all the steps, write your answers in single precision floating point format, show all the necessary steps.

```
Solution:
5.9140625 = 0101.1110101 = 1.01 111 0101 \times 2^{2}
2.34375 \times 10^{-2} = 0.0000011 = 1.1 \times 2^{-6}
Step1: shift smaller one
       1.5625 \times 10^{-2} = 0.000000011 \times 2^{2}
Step2: addition
       1.011110101
       0.000000011
= 1.011111000
Step3: Normalize sum and checking for overflow or underflow
No change
Step4: Round the sum
No change
Result = 1.0111111000 \times 2^2
Exponent = 2 + 127 = 129 = 1000 0001
0, 1000\ 0001, 0111\ 1100\ 0000\ 0000\ 0000\ 000 = 5.9375
```

```
3. Instruction (30%)
3.1 (6%) Translate the following two RISC-V assembly code into the binary and the hex:
(1) sw x9, 120(x10)

A:
0000011 01001 01010 010 11000 0100011, 0x06952C23

(2) beq x7,x8,100

A:
00000011 01000 00111 000 00100 1100111 (or 1100011), 0x6838267 (or 0x6838263)

3.2 (4%) What is the assembly instruction of the following machine code 0x10D62C23.

A:
0001000 01101(x13) 01100(x12) 010(sw) 11000 0100011(s), imm = 280 sw x13,280(x12)
```


```
Sort.
   addi sp, sp, -8
                      # allocate stack space
   sw ra, 4(sp)
                      # save return address
   sw s0, 0(sp)
                      # save s0
                     \# s0 = &A[0]
   addi s0, sp, 8
   li tl, 1
                      # i = 1
   bge tl, al, Exit
                     # if i >= n goto Exit
Loop:
   slli t2, t1, 2
                    # t2 = i * sizeof(int)
   add t2, s0, t2
                     # t2 = &A[i]
   lw t3, 0(t2)
                     \# x = A[i]
   addi t4, t1, -1 # j = i - 1
InnerLoop:
   slli t5, t4, 2 # t5 = j * sizeof(int)
   add t5, s0, t5 # t5 = &A[j]
   lw t6, 0(t5)
                     # A[j]
                     # if A[j] < x goto Done
   blt t6, t3, Done
   sw t6, 4(t5) # A[j+1] = A[j]
   addi t4, t4, -1 # j--
   bge t4, x0, InnerLoop # if j >= 0 goto InnerLoop
Done:
   sw t3, 4(t5)
                     \# A[j+1] = x
   addi tl, tl, 1
                     # 1++
   blt tl, al, Loop # if i < n goto Loop
Exit:
   lw ra, 4(sp)
                     # restore return address
   lw s0, 0(sp)
                     # restore s0
                      # deallocate stack space
   addi sp, sp, 8
```

## Here are the the registers used:

- sp: stack pointer register that points to the top of the stack.
- re: return address register that stores the address to return to after a function call.
- s0: base pointer register that points to the base of the stack frame.
- t1: temporary register used as a loop counter for variable i.
- t2: temporary register used to calculate the address of variable x.
- t3: temporary register used to store variable x.
- t4: temporary register used as a loop counter for variable j.
- tä: temporary register used to calculate the address of variable A[i].
- t6: temporary register used to store variable A[j].

## 4. Single cycle processor (20%)

4.1 (10%) Suppose you are designing a single cycle processor that only support R-type and S-type instructions, draw the most compact processor design below, including both datapath and control logic



4.2 (5%) How many control signals are decoded from the instruction? what their values for instruction add, x1,x2,x3?

RegWrite, ALUsrc, ALUop, MemWrite 1 0 'add' 0