

MODE		MII_BASIC_CONFIG[MII_MODE]	MII_BASIC_CONFIG[ROLE]	XMM_CLK_CONFIG[MII_CLK_REF]	TXC dir.	RXC dir.	REFCLK src.	TX FIFO	RX FIFO
MII	100	0	0		out		XI pin	No	No
revMII	100	1	0		in	in	XI pin	Yes	Yes
RMII	101	0	0		in	-	XI pin	Yes	Yes
RMII clock mode	101	0	1		in	-	TXC	Yes	Yes
revRMII	101	1	0		out	-	XI pin	Yes	Yes
RGMII	111	0	0		in	out	XI pin	Yes	No

