

拉力計

Grip Pull Force Gauges



油壓機械式結構，高穩定性

Oil Pressure Mechanical Structure, High Stability.

- 確認拉力計上的拉桿螺栓規格是否與主軸夾爪的規格相對應。
- 量測環境溫度須控制在室溫 $25 \pm 1^\circ\text{C}$ 內。
- 將拉力計及主軸前端錐度部分擦拭乾淨後，夾持拉力計即可。
- Check the specification of pull studs on the pull force gauges should correspond the specification of pull stud clamping unit.
- Measuring environment's temperature should be controlled within $25 \pm 1^\circ\text{C}$.
- Clean the pull force gauges and front-end taper parts and then clamp the pull force gauge.
- 為確保量測數值的正確性，拉力計須在有預拉的情況下使用 (如左下方錶圖)。
- ISO 拉力計使用前：請將拉桿螺栓鎖緊，完成預壓 (鎖緊即可)。
- HSK 拉力計使用前：請將六角扳手置入錐度內底部六角孔，順時針鎖緊至指針外圈一格 (如左下方錶圖) 即可。
- 實測拉力：以指針所指外圈之數值 $\times 10$ ，即為實測拉力 (kg-f)。
- To ensure the accuracy of the pull force measurement, gauge has to be used in the pre-pull condition (as shown in the left below picture).
- Before using the ISO force gauge, please lock the pull stud to be at pre-pull condition (not lock too tight).
- Before using the HSK force gauge, please put the hexagon wrench into the hexagonal hole at the bottom of the taper, then lock clockwise till the indicator moved one scale in the outer ring (as shown in the left below picture).
- The finger indicated the value of the outer ring $\times 10$; the value is pull force measured.

規格 Part No.	量測範圍 Measuring Range
ISO20	0~40 kg/cm ²
ISO25	0~40 kg/cm ²
ISO30	0~60 kg/cm ²
ISO40	0~160 kg/cm ²
ISO50	0~350 kg/cm ²
HSK32	0~160 kg/cm ²
HSK40	0~160 kg/cm ²
HSK50	0~350 kg/cm ²
HSK63	0~350 kg/cm ²
HSK100	0~600 kg/cm ²