动手实践-编写一个简单的块设备驱动


笨叔叔

什么是块设备?

- 块设备的特点:
 - ✓ 字符设备是以字节流为传输单位的
 - ✓ 块设备是以块 (block) 为传输单位的
 - ✓ 字符设备按照字节流顺序来访问的
 - ✓ 块设备可以随机访问




- ✓ 磁头(head): 磁头固定在可移动的机械臂上,用于读写数据
- ✓ 磁道(track): 每个盘面都有 n 个同心圆组成, 每个同心圆称之为一个磁道
- ✓ 柱面(cylinder): n 个盘面的相同磁道 (位置相同) 共同组成一个柱面
- ✓ 扇区(sector): 从磁盘中心向外画直线,可以将磁道划分为若干个弧段。每个磁 个弧段被称之为一个扇区
- ➤ 其他常见块设备:光盘,SSD等



块设备驱动架构

- > 块设备驱动架构
 - ✓ 文件系统层:包含了常用的文件系统如ext4
 - ✓ 通用块层:
 - ✓ IO 调度器:
 - ✓ 具体块设备驱动:



block_device数据结构

- ➤ block_device数据结构用来抽象和描述一个块设备。
- ▶ block_device把虚拟文件系统VFS和块设备子系统关联起来

gendisk数据结构

- ▶ 磁盘类设备的一个抽象
- ▶ 可以表示一个已经分区的磁盘,也可以表示一个未分区的磁盘

```
struct gendisk {
    int major;
    int first_minor;
    int minors;
    char disk_name[DISK_NAME_LEN];
    struct disk_part_tbl __rcu *part_tbl;
    const struct block_device_operations *fops;
    struct request_queue *queue;
};
```


block_device_operations操作方法集

> 块设备的操作方法集,类似字符设备的file_opereations操作方法集

```
struct block device operations {
      int (*open) (struct block device *, fmode t);
      void (*release) (struct gendisk *, fmode t);
      int (*rw page)(struct block device *, sector t, struct page *, int rw);
      int (*ioctl) (struct block_device *, fmode_t, unsigned, unsigned long);
      int (*compat ioctl) (struct block device *, fmode t, unsigned, unsigned long);
      long (*direct access)(struct block device *, sector t,
                                  void **, unsigned long *pfn, long size);
      unsigned int (*check events) (struct gendisk *disk,
                              unsigned int clearing);
      int (*media_changed) (struct gendisk *);
      void (*unlock native capacity) (struct gendisk *);
      int (*revalidate disk) (struct gendisk *);
      int (*getgeo)(struct block_device *, struct hd_geometry *);
      /* this callback is with swap lock and sometimes page table lock held */
      void (*swap slot free notify) (struct block device *, unsigned long);
      struct module *owner;
};
```


请求队列request_queue

- ➤ request_queue数据 结构来抽象和描述请 求队列
- 》当文件系统这样的高层代码有新的请求就会加入到请求队列中。只要请求队列不为空,那么队列中对应中的块设备驱动程序就会从请求队列中获取request,然后送到对应的块设备驱动中。




bio数据结构

> 块设备数据传输的数据结构



块设备子系统常用数据结构的关系图



- > 注册函数
 - √ int register_blkdev(unsigned int major, const char *name)

- > 注销函数
 - void unregister_blkdev(unsigned int major, const char *name)

- ➤ 初始化请求队列:
 - ✓ struct request_queue *blk_init_queue(request_fn_proc *rfn, spinlock_t *lock)

- > 注销请求队列
 - √ void blk_cleanup_queue(struct request_queue *q)

- ➤ 分配gendisk对象:
 - ✓ struct gendisk *alloc_disk(int minors)
- ➤ 注册gendisk对象
 - √ void add disk(struct gendisk *disk)
- ➤ 注销gendisk对象
 - √ void del gendisk(struct gendisk *disk)

- ➤ 初始化一个BIO:
 - √ void bio_init(struct bio *bio)

- ➤ 提交BIO:
 - √ void submit_bio(int rw, struct bio *bio)

实验

实验: 写一个简单的ramdisk设备驱动

- ▶ 使用系统的物理内存来实现一个块设备, ramdisk
- > 实验要求
 - 1. 写一个简单的ramdisk设备驱动。可以使用ext4或者ext2的格式化工具来格式化 这个ramdisk。
 - 2. 在这个设备驱动中,实现HDIO_GETGEO的ioctl命令,可以读出ramdisk的hd_geometry参数,比如有多少磁头,多少个柱面,多少个扇区等信息。写一个简单的用户空间的测试程序来读取hd_geometry参数。


进阶思考


进阶思考题

➤ 假设系统使用eMMC作为存储介质,文件系统采用ext4。使用C语言的open函数打开一个文件,然后使用write函数来对写入内容,比如字符串"hello world"

请阅读Linux内核代码,跟踪从用户空间write函数到eMMC存储设备了解写入内容经历了内核中哪些内核模块,期间使用了哪些主要的数据结构,并请画出其代码workflow。

BACKUP





Card Identification (卡检测过程)



When eMMCinit

```
mmc_detect_change()
mmc rescan()
mmc_rescan_try_freq(): try to scan card by
100kHz/200K/300K/400K
    mmc attach mmc()
           Send CMD1 get OCR
           Set lowest voltage depend on OCR
           mmc_init_card()
                > Set ORC bit30, sector mode
                Send CMD2 fetch CID
                > Set card RCA and open drain mode
                > Send CMD9 fetch CSD, decode it.
                > Send CMD8 fetch EXT CSD, decode it
                Active high speed.
                      ✓ Use CMD 6 to Set HS TIMING= 1, enable high speed mode
                      ✓ mmc set timing() => mmc set ios() => host->ops->set ios()
                Set max clock: ext_csd.hs_max_dtr => mmc_set_clock()
                > Activate wide bus and DDR mode
                      ✓ select PowerClass for the current bus width. Select pwrclass val by vdd
                        (OCR), set pwrclass_val to EXT_CSD[187]

✓ Set bus width to EXT_CSD[183], and mmc_set_bus_width()

                      ✓ Enable DDR mode: DDR PowerClass, DDR bus width, mmc_set_timing(),
                        mmc set bus width()
           > mmc_add_card()
                ✓ device_add()
```