

## QUICK START GUIDE

- Type and run autotracker in the MATLAB command window
- Select mode and confirm camera
- 3. Run ROI detection
- 4. Adjust and accept ROIs
- 5. Initialize background referencing
- 6. Adjust tracking threshold and accept reference image
- 7. Confirm tracking and sample tracking noise
- 8. Select protocol and adjust experiment parameters (if applicable)
- 9. Enter labels
- 10. Select directory to save output
- 11. Save parameter configuration for future use
- 12. Begin tracking