```
1
2 % Clear the console
3 clc:
4 % Close all the windows
5 close all;
6 % Clear Workspace Variables
7 clear;
9 global S1_MIN S1_MAX S1_POINTS;
10 global S2_MIN S2_MAX S2_POINTS;
11 global INVALID FLOWRATE;
12 global Fethyl_S1S2_plotOpt;
13 global MT_PER_KT G_PER_KT GJ_PER_KJ;
14 global VALUE ETHANE VALUE ETHYLENE VALUE HYDROGEN CHEM;
15 global COST RATES STEAM;
16 global VALUE_HYDROGEN_FUEL VALUE_METHANE_FUEL VALUE_PROPANE_FUEL VALUE_BUTANE_FUEL;
17 global VALUE_NATGAS_FUEL VALUE_NUM2OIL_FUEL;
18 global ENTHALPY PROPANE ENTHALPY BUTANE;
19 global MOLMASS_PROPANE MOLMASS_BUTANE;
20 global PROFIT_S1S2_OPT;
21 global HEAT_CAPACITY_ETHANE;
22 global HEAT FORMATION ETHANE;
23 global STEAM_30PSIA STEAM_50PSIA STEAM_100PSIA STEAM_200PSIA STEAM_500PSIA STEAM_750PSIA;
24 global HYDROGEN METHANE ETHYLENE PROPANE BUTANE;
25 global ENTHALPY METHANE ENTHALPY PROPANE ENTHALPY BUTANE HEAT CAPACITY ETHANE;
26 global KT_PER_G KG_PER_KT KJ_PER_GJ MT_PER_G ENTHALPY_NAT_GAS MOLMASS_ETHANE...
27 MOLMASS_ETHYLENE MOLMASS_NATGAS;
28 global MT_CO2_PER_KT_METHANE MT_CO2_PER_KT_PROPANE MT_CO2_PER_KT_BUTANE ...
29 MT_CO2_PER_KT_NATURALGAS;
30 global TAX CO2 PER MT;
31 global STEAM_PRESSURE_COL STEAM_TEMP_COL;
32 global MOLMASS_METHANE MOLMASS_WATER BAR_PER_PSIA;
33 global C TO K HEAT CAPACITY WATER;
34 global R k1_f k1_r k2 k3 R 2 C TO K YR PER_SEC SEC_PER_YR MOLMASS_HYDROGEN
35 global PSA_TOGGLE ENTHALPY_HYDROGEN T_SEPARATION P_SEPARATION M3_PER_L DENSITY_LIQ_WATER
36 global MAX_CAPEX MAX_OPEX MAX_TFCI PRESS_RXTR
37
38 % USER NOTES
40 % Note: The primary (high level) units of this script are ...
41 % Mass
             kta
42 % Energy
            GI
43 % Pressure Bar
44 % Temperature Celcius
45 % Moles Moles
46 % Value Dollars
48 % [ ] THIS MEANS DIMENSIONLESS UNITS
50 % USER INPUTS | DESIGN PARAMETERS
51
52 % Product
53 P_ETHYLENE_DES = 200;
                            % [kta]
```

```
54 % Note! This design parameter's units are changed prior to the matrix def
55
56 YEARS IN OPERATION = 10;
57
58 % USER INPUTS | GLOBAL CONSTANTS_
60 % USER INPUTS | 3D PLOT, CONTOUR, LVL 2 & 3 CALCS
61
62 % Reactor Conditions | 3D PLOT & CONTOUR PLOT (S1 S2) && THE LVL3 CALCS
63 STEAM_TO_FEED_RATIO_MOLS = 0.6; % [ _ ] 0.6 to 1.0
64 TEMP_RXTR = 825;
                       %[C]
65 PRESS_RXTR = 2; % [ Bar ] 2 to 5 bar
66 TEMP_ETHANE_FEED = 25; % [ C ]
67 CONVERSION = 0.17053; \% [ _ ] % Level 2 & 3 Calculations
68 USERINPUT S1 = 0.96971; % [ ] % Level 2 & 3 Calculations
69 USERINPUT_S2 = 0.00011843; % [ _ ] % Level 2 & 3 Calculations
70 STEAM_CHOICE = 1;
71 % STEAM 30PSIA = 1;
72 % STEAM_50PSIA = 2;
73 % STEAM_100PSIA = 3;
74 % STEAM_200PSIA = 4;
75 % STEAM 500PSIA = 5;
76 % STEAM_750PSIA = 6;
77
      % % Steam
78
      % % [ psia Temp[C] $/MT kJ/kg ]
79
      % COST_RATES_STEAM = [
80
     % 30 121 2.38 2213;
     % 50 138 3.17 2159;
81
   % 100 165 4.25 2067;
82
      % 200 194 5.32 1960;
83
84
     % 500 242 6.74 1755;
      % 750 266 7.37 1634
85
86
87
88 % Plotting | 3D PLOT & CONTOUR PLOT (S1 S2)
89 NUM POINTS = 10^4;
90
91 % USER INPUTS | RXTR TABLE PARAMETERS_
93 % Reactor Script Parameters | RXTR TABLE OUTPUT
94 V MIN = 0.1; % [ L ]
                 %[L]
95 V_MAX = 10^4;
96 NUM_V_POINTS = 20; % [__]
98 P_MIN = 2; % [ Bar ]
99 P_MAX = 5; % [ Bar ]
100 NUM_P_POINTS = 2; % [ __ ]
101
102 T_MIN = 775;
                   % [ Celcius ]
                % [ Celcius ]
103 T_MAX = 825;
106 STEAM_MIN = 0.6;
                    %[_]
```

```
107 STEAM_MAX = 1.0;
108 NUM_STEAM_POINTS = 2;
                               %[_]
109
110 % Table Overrides | RXTR TABLE OUTPUT
111 T_P_OVERRIDE = true;
112 T_OVERRIDE = 825;
                           %[C]
    P OVERRIDE = 2;
                          %[Bar]
    STEAM_MR_OVERRIDE = 0.6;% [_]
115
116 % Output fuel costs
117 CONSOLE OUTPUT EFFECTIVE VALUE FUELS = true;
118
119 % Output the level 2 and 3 calculations
120 OUTPUT LVL3 FLOWRATES TO CONSOLE = true;
    SANITY_CHECK_CALCULATIONS = true;
121
122
123 % Plot the 3D and Contour plot's
124 CALCULATE ALL SELECTIVITIES = true;
    PLOT_ECON_3D = true;
    PLOT_ECON_COUNTOUR = true;
126
127
128 % Output the Reactor Design tables
129 CALCULATE_REACTOR_FLOWS = true;
130
131 % PSA Toggle switch
132 PSA_TOGGLE = true;
133
134 % Do you want to add the work of the compressor to the heat flux of heating
135 % the steam from the temp it's avilable at, to the temp of the reactor?
136 ADD_COMPRESSOR_WORK_TO_STEAM_HEATFLUX = true;
137
138 % Separation System Thermodynamics
139 T SEPARATION = 173.15;
140 P_SEPARATION = PRESS_RXTR; % [ bar ]
141 MAX_OPEX = false; % [ _ ]
142 MAX TFCI = false;
143 MAX_CAPEX = false;
144
145 % Zeolite and waste stream
146 % zeo 1.2 - 2.2 wt% absobtion = max of zeolite (g/g)
147
148 % NOTE SEARCH FOR "??" TO SEE MY ASSUMPTIONS AND OTHER NOTES IN THE CODE
150 % WORK OF THE COMPRESSOR HAS NOT BEEN IMPLEMENTED
151 % THE STEAM TO FEED RATIO LIKELY HAS UNIT ISSUES OF (g/g) vs (mol/mol)
152 %
      I think I implemented both
153
155 % DON'T TOUCH ANYTHING BELOW THIS LINE
156 %
157
159 % CONSTANTS | PLOTTING
```

```
160
161 CONSOLE_SECTION_DIVIDER = ...
162
163 S1 MIN = 0.01;
164 S1_MAX = 1.00;
165 S1_POINTS = NUM_POINTS ^ (1/2);
166 S2 MIN = 0.01;
167 S2_MAX = 1.00;
168 S2_POINTS = NUM_POINTS ^ (1/2);
169 INVALID_FLOWRATE = 0;
170 Fethyl_S1S2_plotOpt = { ...
171 'S_1 Selectivity', ...
172 'S_2 Selectivity', ...
173 'Ethylene Flowrate [kta]',...
174 'P_ethylene_VS_S1_S2.jpg'};
175 PROFIT_S1S2_OPT = { ...
176 'S_1 Selectivity', ...
177 'S 2 Selectivity', ...
     'Annual Profit [$ MM USD]',...
     'P_ethylene_VS_S1_S2.jpg'};
179
180
181 % CONSTANTS | UNITS
182
183 % Mass
184 MT PER KT = 10<sup>3</sup>; % [ MT / kt ]
185
186 G_PER_KT = 10^9; % [ g / kt ]
187 KT_PER_G = 10^-9; % [ kt / g ]
189 KG_PER_KT = 10^6; % [ kg / MT ]
190
191 MT_PER_G = 10^-6; % [ MT / g ]
193 % Energy
194 GJ_PER_KJ = 10^-6; % [ GJ / kJ ]
195 KJ_PER_GJ = 10^6; % [ kJ / GJ ]
196
197 % Temperature
198 C_TO_K = 273.15; % [ C -> K ]
200 MMDOLLA_PER_DOLLA = 10^-6; % [ $ MM / $]
201 DOLLA_PER_MMDOLLA = 10^6; % [ $ / $ MM ]
202
203 % Pressure
204 BAR_PER_PSIA = 0.0689476; % [ Bar / Psia ]
205
207 YR_PER_SEC = 1 / (3.154 * 10^7); % [ yr / s ]
208 SEC_PER_YR = 3.154 * 10^7; % [ s / yr ]
209
210 % Volumes
211 M3_PER_L = 0.001;
212
```

```
213 % CONSTANTS | PHYSICAL
214
215 DENSITY_LIQ_WATER = 10^3;
                                % [ kg / m^3 ]
217 % CONSTANTS | CHEMICAL
218
219 % Chemical | Molar Mass
220 MOLMASS HYDROGEN = 2.01588;
                                      % [g/mol]
221 % Source: https://webbook.nist.gov/cgi/cbook.cgi?ID=1333-74-0
222 MOLMASS_METHANE = 16.0425;
                                     % [g/mol]
    % Source: https://webbook.nist.gov/cgi/cbook.cgi?ID=74-82-8
224 MOLMASS WATER = 18.015;
                                    % [g/mol]
225 % source : https://pubchem.ncbi.nlm.nih.gov/compound/Water
226 MOLMASS CO2 = 44.01;
                                % [g/mol]
    % Source: https://pubchem.ncbi.nlm.nih.gov/compound/Carbon-dioxide-water
228 MOLMASS_PROPANE = 44.0956;
                                     % [g/mol]
     230 MOLMASS BUTANE = 58.1222;
                                    % [g/mol]
231 % Source: https://webbook.nist.gov/cgi/cbook.cgi?ID=C106978&Mask=1
232 MOLMASS_ETHANE = 30.0690;
                                    % [ g / mol ]
     % Source: https://webbook.nist.gov/cgi/cbook.cgi?ID=C74840
234 MOLMASS ETHYLENE = 28.0532;
                                     % [g/mol]
    % Source = https://webbook.nist.gov/cgi/cbook.cgi?ID=74-85-1&Type=IR-SPEC&Index=QUANT-IR,20
236 MOLMASS_NATGAS = 16.04;
                                   % [g/mol]
237
     % ASSUMING NATURAL GAS IS ALL METHANE
238
239 % Chemical | Combustion Stochiometery
240 CO2 TO METHANE COMBUSTION STOICH = 1;
241 CO2_TO_PROPANE_COMBUSTION_STOICH = 3;
242 CO2 TO BUTANE COMBUSTION STOICH = 4;
243 CO2_TO_NATGAS_COMBUSTION_STOICH = CO2_TO_METHANE_COMBUSTION STOICH;
     % Natural gas is assumed to be entirely methane
244
246
247 % CONSTANTS | THERMODYNAMICS
248
249 % Gas Constant
                         % [ J / mol K ]
250 R = 8.314:
251 R 2 = 0.0831446261815324;
                           % [ L bar / K mol ]
253 % Heat capacities
254 HEAT_CAPACITY_WATER = 33.79 * 10^-3; % [ kJ / mol K ] Ref Temp = 298K
255 % Source: https://webbook.nist.gov/cgi/cbook.cgi?ID=C14940637&Mask=1&Type=JANAFG&Table=on
256 HEAT CAPACITY ETHANE = 52.71 * 10^-3; % [kJ / mol K] Reference Temp = 300K
     % Source: https://webbook.nist.gov/cgi/cbook.cgi?ID=C74840&Units=SI&Mask=1EFF
258
259 % Heats of Formation (at 25C)
260 HEAT FORMATION ETHANE = -83.8;
                                      % [k] / mol ] reference Temp = std
261 % Source : https://webbook.nist.gov/cgi/cbook.cgi?ID=C74840&Units=SI&Mask=1EFF
262 HEAT FORMATION METHANE = -74.87;
                                        % [kJ/mol] reference Temp = std
263 % Source : https://webbook.nist.gov/cgi/cbook.cgi?ID=C74828&Mask=1
264 HEAT FORMATION ETHYLENE = 52.47; % [kJ / mol] reference Temp = std
     % Source: https://webbook.nist.gov/cgi/cbook.cgi?ID=C74851&Mask=1
```

```
266 HEAT FORMATION HYDROGEN = 0;
                                         % [kJ/mol] reference Temp = std
267 HEAT_FORMATION_PROPANE = -104.7; % [kJ/mol] reference Temp = std
268 % Source: https://webbook.nist.gov/cgi/cbook.cgi?ID=C74986&Mask=1
269 HEAT FORMATION BUTANE = -125.6;
                                        % [kJ/mol] reference Temp = std
     % Source: https://webbook.nist.gov/cgi/cbook.cgi?ID=C106978&Mask=1
270
271
272 % Enthalpy of combustion (std conditions)
273 ENTHALPY HYDROGEN = 286;
274 % Source: https://chem.libretexts.org/Courses/University_of_Kentucky/UK%3A_General_Chemistry/05%3A_Thermochemistry/5.3%3A_Enthalpy
275 ENTHALPY_METHANE = 890;
                                    % [ kJ / mol ]
     % Source: https://webbook.nist.gov/cgi/cbook.cgi?ID=C74828&Mask=1
277 ENTHALPY PROPANE = 2219.2;
                                    % [ kJ / mol ]
     % Source : https://webbook.nist.gov/cgi/cbook.cgi?ID=C74986&Mask=1
279 ENTHALPY BUTANE = 2877.5;
                                    % [ kJ / mol ]
     % Source: https://webbook.nist.gov/cgi/cbook.cgi?ID=C106978&Mask=1
281 ENTHALPY_NAT_GAS = ENTHALPY_METHANE;
     \% Source: https://afdc.energy.gov/fuels/natural_gas\_basics.html \#: \sim : text=Natural\%20 gas\%20 is \%20 an \%20 od or less, used \%20 in \%20 the \%20 United \%20 States.
     % Natural gas is mostly methane, so assumed to be 100% methane in the calcs
283
284
285 % Enthalpy of Reactions [kJ/extent rxn]
286 ENTHALPY_RXN_1 = HEAT_FORMATION_HYDROGEN + HEAT_FORMATION_ETHYLENE ...
                       - HEAT FORMATION ETHANE;
287
288 ENTHALPY RXN 2 = HEAT FORMATION METHANE + HEAT FORMATION PROPANE ...
                       - 2 * HEAT_FORMATION_ETHANE;
289
290 ENTHALPY RXN 3 = HEAT FORMATION ETHANE - HEAT FORMATION ETHANE ...
291
                      - HEAT_FORMATION_ETHYLENE;
292 % CONSTANTS | ECONOMICS
293
294 % Chemicals
295 VALUE ETHANE = 200;
                              %[$/MT]
296 VALUE_ETHYLENE = 900; % [ $ / MT ]
297 VALUE_HYDROGEN_CHEM = 1400; % [ $ / MT ]
299 % Steam
300 % [ psia Temp[C] $/MT kJ/kg ]
301 COST RATES STEAM = [
302 30 121 2.38 2213;
303 50 138 3.17 2159;
304 100 165 4.25 2067;
305 200 194 5.32 1960;
306 500 242 6.74 1755;
307 750 266 7.37 1634
308];
309
310 % Accessing the Steam P,T Data
    STEAM PRESSURE COL = 2;
311
     STEAM_TEMP_COL = 1;
312
313
   STEAM_COST_COL = 3;
314 STEAM 30PSIA = 1;
315 STEAM 50PSIA = 2;
316 STEAM_100PSIA = 3;
317
   STEAM 200PSIA = 4;
   STEAM_500PSIA = 5;
```

```
319 STEAM_750PSIA = 6;
320
321 % Economic | Fuel
322 VALUE HYDROGEN FUEL = 3;
                                  %[$/GJ]
323 VALUE_METHANE_FUEL = 3;
                                 %[$/GJ]
324 VALUE_PROPANE_FUEL = 3;
                                % [$/GJ]
325 VALUE BUTANE FUEL = 3;
                              %[$/G]]
326 VALUE_NATGAS_FUEL = 3;
                               % [$/GJ]
327 VALUE_NUM2OIL_FUEL = 4.5;
                               % [ $ / US Gallon ]
328
329 % Economics | Enviormental
330 TAX CO2 PER MT = 125;
                               %[$/MT]
331
332 % [$ / GJ] = 1GJ(basis) * (KJ / GJ) * (mol gas / KJ) *
                                                  (mol CO2 / mol gas)
                                                                        * (g / mol C02)*(MT / g) * ($ / MT)
333 TAX CO2 PER GJ METHANE = KJ PER GJ * (1/ENTHALPY METHANE) * CO2 TO METHANE COMBUSTION STOICH * MOLMASS CO2 * MT PER G * TAX CO2 PER MT;
334 TAX CO2 PER GJ PROPANE = KJ PER GJ * (1 / ENTHALPY PROPANE) * CO2 TO PROPANE COMBUSTION STOICH * MOLMASS CO2 * MT PER G * TAX CO2 PER MT;
335 TAX_CO2_PER_GJ_BUTANE = KJ_PER_GJ * (1 / ENTHALPY_BUTANE) * CO2_TO_BUTANE_COMBUSTION_STOICH * MOLMASS_CO2 * MT_PER_G * TAX_CO2_PER_MT;
336 TAX CO2 PER GJ NATGAS = TAX CO2 PER GJ METHANE; %
337
338 % Chemistry | MT of CO2 per KT of Fuel used
339 % (MT CO2) = 1KT(basis) * (g / KT) * (mol gas/ g gas) *
340 MT CO2 PER KT METHANE = G PER KT * (1/MOLMASS METHANE) *...
341 ... % (mol CO2 / mol gas) * (g CO2 / mol CO2) * (MT / g)
342 CO2_TO_METHANE_COMBUSTION_STOICH * MOLMASS_CO2 * MT_PER_G;
343 MT CO2 PER KT PROPANE = G PER KT * (1/MOLMASS PROPANE) *...
344 CO2 TO PROPANE COMBUSTION STOICH * MOLMASS CO2 * MT PER G;
345 MT_CO2_PER_KT_BUTANE = G_PER_KT * (1/MOLMASS_BUTANE) *..
346 CO2 TO BUTANE COMBUSTION STOICH * MOLMASS CO2 * MT PER G;
347 MT CO2 PER KT NATURALGAS = MT CO2 PER KT METHANE;
348
349 % FUNCTIONS | FLOWRATE
350
351 P ETHYLENE = P ETHYLENE DES;
352 P_ETHYLENE_DES = P_ETHYLENE_DES * (1 / MOLMASS_ETHYLENE);
353 P_PROPANE = @(s1, s2) (s2 / s1 *P_ETHYLENE_DES) * ...
354
                      MOLMASS PROPANE;
355 P_BUTANE = @(s1, s2) (P_ETHYLENE_DES*(1/(2*s1) - s2/s1 - 1/2)) * ...
                      MOLMASS_BUTANE;
356
357 F_ETHANE = @(s1, s2) (P_ETHYLENE_DES / s1) * ...
                      MOLMASS_ETHANE;
358
359 P_METHANE = @(s1, s2) (s2 / s1 * P_ETHYLENE_DES) * ...
                      MOLMASS_METHANE;
360
361 P_HYDROGEN = @(s1, s2) (P_ETHYLENE_DES * ((1/(2*s1) - s2/s1 + 1/2))) * ...
                      MOLMASS HYDROGEN;
362
363
364 % FUNCTIONS | EXTENT OF REACTION
365
366 % Returns molar flowrates [ mol / yr ]
367 get_xi = @(flowrates) [ flowrates(HYDROGEN) * G_PER_KT / MOLMASS_HYDROGEN, ...
             flowrates(PROPANE) * G PER KT / MOLMASS PROPANE, ...
368
             flowrates(BUTANE) * G_PER_KT / MOLMASS_BUTANE ];
369
370
371 % FUNCTIONS | VALIDATION
```

```
372
373 flowrates_valid = @( flowrates ) all(flowrates >= 0);
374
375 % FUNCTIONS | ECONOMICS
376
377 % ($ / yr) =
                      (kta) * (MT / KT) * ($ / MT)
378 value ethane = @(P ethane) P ethane * MT PER KT * VALUE ETHANE;
379 value_ethylene = @(P_ethylene) P_ethylene * MT_PER_KT * VALUE_ETHYLENE;
380 value_h2_chem = @(P_h2_chem) P_h2_chem * MT_PER_KT * VALUE_HYDROGEN_CHEM;
381 value_methane = @(P_methane) P_methane * MT_PER_KT * VALUE_METHANE_FUEL;
382 value propane = (a)(P propane) P propane * MT PER KT * VALUE PROPANE FUEL;
383 value_butane = @(P_butane) P_butane * MT_PER_KT * VALUE_BUTANE_FUEL;
384
385 % ($ / yr) =
                           (kta) * (MT / kt) * ($ / MT)
386 cost steam = @(F steam, steam rate) F steam * MT PER KT * steam rate;
388 % FUNCTIONS | THEROMODYNAMICS
389 % (GJ / yr) =
                           (kta) * (g / KT) * (mol gas/ g gas) * (kJ / mol K)
                                                                             * (GJ / KJ) * (K)
390 heat_ethane = @(F_ethane, To, Tf) F_ethane * G_PER_KT * (1 / MOLMASS_ETHANE) * HEAT_CAPACITY_ETHANE * GJ_PER_KJ * (Tf - To);
391
392\% (GJ/yr) = (mol/yr)*(kJ/mol)*(GJ/kJ)
393 heat rxn1 = @(xi 1) xi 1 * ENTHALPY RXN 1 * GJ PER KJ;
394 heat rxn2 = @(xi 2) xi 2 * ENTHALPY RXN 2 * GJ PER KJ;
395 heat_rxn3 = @(xi_3) xi_3 * ENTHALPY_RXN_3 * GJ_PER_KJ;
396 heat_rxn = @(xi) heat_rxn1(xi(1)) + heat_rxn2(xi(2)) + heat_rxn3(xi(3));
397
398 % FUNCTIONS | RATE CONTANTS
399
400 % T is [ Kelvin ] R is [ J / mol K ]
401 k1 f = (a(T) (4.652 * 10^13) * exp((-273000 / (R * (T))));
402 k1_r = (3(T) (9.91 * 10^8) * exp((-137800 / (R * (T))));
403 \text{ k2} = (a(T) (4.652 * 10^1)) * exp((-273000 / (R * (T))));
404 \text{ k3} = (a(T) (7.083 * 10^13) * exp((-252600 / (R * (T))));
405
406
407 % DESIGN PARAMS
408 STEAM_TO_FEED_RATIO_MASS = (MOLMASS_WATER / MOLMASS_ETHANE) * STEAM_TO_FEED_RATIO_MOLS;
409
410
411 % SCRIPT
412
413 % Economics | Post-Tax Value of different fuel sources
414 if (CONSOLE OUTPUT EFFECTIVE VALUE FUELS)
     disp("[$/GJ]")
     EFFECTIVE_VALUE_HYDROGEN_FUEL = VALUE_HYDROGEN_FUEL
416
     EFFECTIVE VALUE METHANE FUEL = VALUE METHANE FUEL + TAX CO2 PER GJ METHANE
417
     EFFECTIVE_VALUE_PROPANE_FUEL = VALUE_PROPANE_FUEL + TAX_CO2_PER_GJ_PROPANE
418
     EFFECTIVE VALUE BUTANE FUEL = VALUE BUTANE FUEL + TAX CO2 PER GJ BUTANE
419
     EFFECTIVE_VALUE_NAT_GAS_FUEL = VALUE_NATGAS_FUEL + TAX_CO2_PER_GJ_NATGAS
421% EFFECTIVE_VALUE_NUM2_FUEL = VALUE_NATGAS_FUEL + TAX_CO2_PER_GJ_NUM2;
422
423 end
424
```

```
425 if (OUTPUT_LVL3_FLOWRATES_TO_CONSOLE)
426
     % Calculate the flow rates of each species (kta)
427
428
     P hydrogen = P HYDROGEN(USERINPUT S1, USERINPUT S2);
     P_methane = P_METHANE(USERINPUT_S1, USERINPUT_S2);
429
     P_ethylene = P_ETHYLENE;
430
     P propane = P PROPANE(USERINPUT S1, USERINPUT S2);
431
     P_butane = P_BUTANE(USERINPUT_S1, USERINPUT_S2);
     F_ethane = F_ETHANE(USERINPUT_S1, USERINPUT_S2);
433
     P_flowrates = [ P_hydrogen, P_methane, P_ethylene, P_propane, P_butane ];
434
435
436
     disp(CONSOLE_SECTION_DIVIDER)
     if (flowrates_valid(P_flowrates))
437
438
       fprintf("Flowrates for the reactor given that s1 = %f, s2 = %f conv = %f\n\n", ...
439
          USERINPUT_S1, USERINPUT_S2, CONVERSION)
440
441
442
       disp(CONSOLE SECTION DIVIDER)
443
        disp("Level 2 Flowrates in / out of the entire plant [ kt / yr ]")
       P_hydrogen
444
       P_methane
445
       P ethylene
446
447
       P_propane
       P_butane
448
449
450
        disp("Fresh Feed Flowrate")
451
       F_ethane
452
       disp(CONSOLE_SECTION_DIVIDER)
453
454
        disp("Level 3 Flowrates [ kt / yr ] ")
455
       disp("Recycle Stream Flowrate")
456
457
       R_ethane = F_ethane * ((1-CONVERSION) / (CONVERSION))
458
       % R_ethane = (P_ethylene/USERINPUT_S1) * ((1-CONVERSION)/CONVERSION)
459
460
461
       disp("Reactor Flowrates")
462
       F_ethane_into_reactor = R_ethane + F_ethane
463
464
        if SANITY_CHECK_CALCULATIONS
465
         disp(CONSOLE_SECTION_DIVIDER)
466
467
         disp("Sanity Checking the Calculations")
          Conservation of mass = F ethane - sum(P flowrates)
468
469
         if Conservation_of_mass
470
           fprintf("WARNING: YOU ARE NOT CONSERVING MASS\n\n")
         end
471
472
       end
473
       disp("ERROR: Selectivities S1 S2 chosen are not physically possible")
474
476 end
477
```

```
478 % SCRIPT | PLOTTING
479
480 if (CALCULATE ALL SELECTIVITIES)
481
     disp(CONSOLE SECTION DIVIDER)
      disp("Calculating all selectivities...")
482
      % Iterates through each value of selectivities S1 and S2 to find the economic
483
      % potential for different reaction conditions
484
      s1_domain = linspace(S1_MIN, S1_MAX, S1_POINTS);
485
      s2_domain = linspace(S2_MIN, S2_MAX, S2_POINTS);
486
     [s1_mesh, s2_mesh] = meshgrid(s1_domain, s2_domain);
487
      % All flowrates are initialized as matricies of zeros
488
489
      ethylene_flowrates = (s1_mesh + s2_mesh) .* 0;
     hydrogen_flowrates = (s1_mesh + s2_mesh) .* 0;
490
     methane flowrates = (s1 mesh + s2 mesh) .* 0;
491
      ethylene flowrates = (s1 mesh + s2 mesh) .* 0;
492
      propane_flowrates = (s1_mesh + s2_mesh) .* 0;
493
      butane_flowrates = (s1_mesh + s2_mesh) .* 0;
494
495
      ethane_flowrates = (s1_mesh + s2_mesh) .* 0;
      profit = (s1_mesh + s2_mesh) .* 0;
497
498
      % Flow rate Indicies | For the flowrates(i) array
499
500
      HYDROGEN = 1;
     METHANE = 2;
501
     ETHYLENE = 3;
502
503
      PROPANE = 4;
504
      BUTANE = 5;
505
506
     i = 1;
507
      for s1 = s1_domain
       for s2 = s2_domain
508
509
510
         P hydrogen = P HYDROGEN(s1, s2);
511
         P_methane = P_METHANE(s1, s2);
         P_ethylene = P_ETHYLENE;
512
         P propane = P PROPANE(s1, s2);
513
514
         P_butane = P_BUTANE(s1, s2);
         F_ethane = F_ETHANE(s1, s2);
515
516
         P_flowrates = [ P_hydrogen, P_methane, P_ethylene, P_propane, P_butane ];
517
518
         if (flowrates_valid(P_flowrates))
519
520
           % Store for plotting (kta)
521
           hydrogen_flowrates(i) = P_HYDROGEN(s1, s2);
522
523
            methane_flowrates(i) = P_METHANE(s1, s2);
            ethylene_flowrates(i) = P_ETHYLENE;
524
525
            propane_flowrates(i) = P_PROPANE(s1, s2);
            butane_flowrates(i) = P_BUTANE(s1, s2);
526
527
            ethane_flowrates(i) = F_ETHANE(s1, s2);
528
            % F ethane = F ETHANE(select 1(i), select 2(i));
529
            % F_fresh_ethane = F_ethane;
530
```

```
531
           % F_ethane_rxtr = F_ethane(i) * ( conversion(i) / (1 - conversion(i)) );
532
           xi = [];
533
534
            % Calculate the heat flux needed to keep reactor isothermal
           heat_flux = 0;
535
            xi = get_xi(P_flowrates);
536
           F steam = STEAM TO FEED RATIO MASS * F ethane;
537
            heat_flux = heat_flux + heat_ethane(F_ethane, TEMP_ETHANE_FEED, TEMP_RXTR);
538
            % heat_flux = heat_flux + heat_ethane(F_ethane_into_reactor, TEMP_SEPARATION, TEMP_RXTR);
539
            heat_flux = heat_flux + heat_steam(F_steam, STEAM_CHOICE, PRESS_RXTR, TEMP_RXTR);
540
           heat flux = heat flux + heat rxn(xi);
541
542
             % Use the heat flux to calculate the fuel cost
543
            [combusted fuel flow rates, heat flux remaining] = fuel combustion(heat flux, P flowrates);
544
545
            % Calculate how much natural gas you needed to combust
546
            F_natural_gas = natgas_combustion(heat_flux_remaining);
547
548
549
            % Determine how much of the product streams were combusted to keep the reactor isothermal
550
551
           combusted_hydrogen = combusted_fuel_flow_rates(HYDROGEN);
            combusted methane = combusted fuel flow rates(METHANE);
552
553
            combusted propane = combusted fuel flow rates(PROPANE);
554
            combusted_butane = combusted_fuel_flow_rates(BUTANE);
555
556
             % VALUE CREATED | Primary Products
557
            profit(i) = profit(i) + value_ethylene(P_ethylene);
            profit(i) = profit(i) + value_h2_chem(P_hydrogen - combusted_hydrogen);
558
559
560
            % VALUE CREATED | Non-combusted fuels
           % profit(i) = profit(i) + value_methane(P_methane - combusted_methane);
561
              % ?? I don't think you can sell methane. IH - need to
562
563
              % determine energy requirements for compressors +
564
              % separation + cooling (will likely need to purchase
565
566
            profit(i) = profit(i) + value propane(P propane - combusted propane);
            profit(i) = profit(i) + value_butane(P_butane - combusted_butane);
567
568
            % COSTS INCURRED
569
            profit(i) = profit(i) - tax_CO2(combusted_fuel_flow_rates, F_natural_gas);
570
           profit(i) = profit(i) - cost steam(F steam, COST RATES STEAM(STEAM CHOICE, STEAM COST COL));
571
            profit(i) = profit(i) - value_ethane(F_ethane);
572
573
           profit(i) = profit(i) - cost_natural_gas_fuel(F_natural_gas);
            profit(i) = profit(i) - cost waste stream(F steam);
574
575
576
         else
            profit(i) = INVALID_FLOWRATE;
577
578
           ethylene_flowrates(i) = INVALID_FLOWRATE;
         end
579
         i = i + 1;
580
581
582
583
```

```
584
     profit = profit ./ 10^6; % Convert to Millions of dollars
585
     profit(profit < 0) = 0; % remove irrelvant data
586
587
     if (PLOT ECON COUNTOUR)
       disp("Plotting EP Contour Map")
588
       plot_contour(s1_mesh, s2_mesh, profit, PROFIT_S1S2_OPT);
589
     end
590
     if (PLOT_ECON_3D)
591
       disp("Plotting 3D EP Surface Function")
592
       plot_3D(s1_mesh, s2_mesh, profit, PROFIT_S1S2_OPT);
593
594
595
     % Prepare the array of flow rate matrices
596
      % flowRatesArray = {hydrogen flowrates, methane flowrates, ethylene flowrates, propane flowrates, butane flowrates, ethane flowrates};
597
598
      % Call the function with the desired row
599
      % plotFlowRatesForRow(4, flowRatesArray); % To plot the first row across all matrices
600
601 end
602
603
604 % SCRIPT | REACTOR
606 T_RANGE = linspace(T_MIN, T_MAX, NUM_T_POINTS);
607 P_RANGE = linspace(P_MIN, P_MAX, NUM_P_POINTS);
608 STEAM_RANGE = linspace(STEAM_MIN, STEAM_MAX, NUM_STEAM_POINTS);
609 V_RANGE = [V_MIN, V_MAX]; % WARNING THESE ARE IN LITERS
610 % H2 Methane Ethane Propane Butane Ethylene
611 F_INTIAL_COND = [ 0; 0; 0; 0; 0; 10]; % These are in kta
612
613
     % Product flow rate indicies
     HYDROGEN = 1;
614
     METHANE = 2;
615
616
     ETHYLENE = 3;
617
     PROPANE = 4;
     BUTANE = 5;
618
619
620
     % Feed flow rate index
     ETHANE = 6;
621
622
623 if (CALCULATE_REACTOR_FLOWS)
     disp("Reactor Script")
624
     for T_i = T_RANGE
625
626
       for P i = P RANGE
         for MR S i = STEAM RANGE
627
628
629
           % override the T_i and P_i with user input
            if T_P_OVERRIDE
630
             disp("WARNING: OVERRIDE HAS BEEN ACTIVATED")
631
             T i = T OVERRIDE;
632
             P i = P OVERRIDE;
633
             MR_S_i = STEAM_MR_OVERRIDE;
634
635
            end
636
```

```
637
            fprintf("\nT = \%f[C], P = \%f[bar] MR = \%f[_]\n", T_i, P_i, MR_S_i)
638
            % Setup the PFR Design Equations
639
640
641
           % BASIS CALCULATIONS_
642
            % CONVERT TO MOLES
643
            % Convert all of the initial conditions to mol / s
            % (mol/s) =
                             (kt / yr) *
                                             (g / kt) * ( mol / g )
                                                                    * ( yr / s)
645
            F_INTIAL_COND(METHANE) = F_INTIAL_COND(METHANE) * G_PER_KT * (1/MOLMASS_METHANE) * YR_PER_SEC;
646
            F INTIAL COND(HYDROGEN) = F INTIAL COND(HYDROGEN) * G PER KT * (1/MOLMASS HYDROGEN) * YR PER SEC;
647
648
            F_INTIAL_COND(ETHANE) = F_INTIAL_COND(ETHANE) * G_PER_KT * (1/MOLMASS_ETHANE) * YR_PER_SEC;
            F_INTIAL_COND(ETHYLENE) = F_INTIAL_COND(ETHYLENE) * G_PER_KT * (1/MOLMASS_ETHYLENE) * YR_PER_SEC;
649
            F INTIAL COND(PROPANE) = F INTIAL COND(PROPANE) * G PER KT * (1/MOLMASS PROPANE) * YR PER SEC;
650
651
652
            % Calculate the molar flow rate of the steam
            % mol/s = __ * mol / s
653
            F steam = MR S i * F INTIAL COND(ETHANE);
654
655
656
            % Solve the system ODE's
            % (L, mol / s)
                              (L, mol/s, Celcius, Bar, mol/s)
657
            odes = @(V, F) reactionODEs(V, F, T i, P i, F steam);
658
            [V_soln_ODE, F_soln_ODE] = ode45(odes, V_RANGE, F_INTIAL_COND);
659
660
           % Calculate the conversion
661
            conversion = (F_INTIAL_COND(ETHANE) - F_soln_ODE(:, ETHANE)) / F_INTIAL_COND(ETHANE);
662
663
            % put handles length of the solution and the initial ethane flow
664
            len = length(F soln ODE(:, 1));
665
666
            F ethane initial = ones(len, 1) * F INTIAL COND(ETHANE);
667
            % Calculate the Selectivities, for each row (aka V_rxtr)
668
669
            select 1 = (F soln ODE(:, ETHYLENE) ) ./ (F ethane initial - F soln ODE(:, ETHANE));
670
            select_2 = (F_soln_ODE(:, PROPANE)) ./ (F_ethane_initial - F_soln_ODE(:, ETHANE));
671
672
            % Calculate the inlet volumetric flow rate
            % (L / s) ?????????????
673
            P_sum = F_soln_ODE(:, HYDROGEN:BUTANE);
674
            % Turn these constants into vectors to operation is valid
675
676
            F_steam = ones(length(P_sum(:,1)), 1) .* F_steam;
677
            % put handles on terms, to make the code readable
            sum\_flowrates\_into\_reactor = F\_INTIAL\_COND(ETHANE) + F\_steam;
678
679
            % Calculate the flow rate into the reactor
            q0 = (R 2 * (T i + C TO K) / P i) .* sum flowrates into reactor;
680
681
             % This is F.30 in the 'Design PFR Algorithm Appendix'
682
            % PLANT CALCULATIONS
683
684
            % Calculate the the flowrates of the plant sized reactor given S1, S2 from ODE's
685
            F ethane = [];
686
            P_ethylene = [];
687
688
            for row = 1:length(select 1)
                            = (kt/yr) *(g/kt) *(mol/g)
689
              % mol/s
                                                               * (yr / s)
```

```
690
              P_ethylene(row, 1) = P_ETHYLENE .* G_PER_KT .* (1/MOLMASS_ETHYLENE) * YR_PER_SEC;
691
           end
692
693
            % Calculate the scaling factor of the plant, from the basis
            % mol / mol = ...
694
            scaling_factor = P_ethylene(:, 1) ./ F_soln_ODE(:, ETHYLENE);
695
696
           % Calculate the volume of the plant sized reactor
697
           % L/s = (L/s)
                              *( (mol/s))/( (mol/s)
698
                  BASIS
                              * PLANT_FLOW / BASIS_FLOW
699
            V plant = V soln ODE(:, 1) .* scaling factor;
700
701
           % cost of the reactor
702
           cost rxt vec = zeros(size(V plant));
703
            for row = 1:length(V plant)
704
705
              %($)
              cost_rxt_vec(row) = cost_reactor(V_plant(row,1) * M3_PER_L);
706
707
              cost rxt vec(row) = cost rxt vec(row) / YEARS IN OPERATION;
708
            end
709
710
           % inlet flow of the plant scaled reactor
           q0 plant = q0(:, 1) .* scaling factor;
711
712
             % Eqn F.35 in 'Design PFR Algorithm Appendix'
713
           % Scaling all of the molar flowrates to the size of the plant
714
715
           F_soln_ODE(:, METHANE) = F_soln_ODE(:, METHANE) .* scaling_factor;
716
           F_soln_ODE(:, HYDROGEN) = F_soln_ODE(:, HYDROGEN) .* scaling_factor;
           F_soln_ODE(:, ETHANE) = F_soln_ODE(:, ETHANE) .* scaling_factor;
717
           F_soln_ODE(:, ETHYLENE) = F_soln_ODE(:, ETHYLENE) .* scaling_factor;
718
719
           F soln ODE(:, BUTANE) = F soln ODE(:, BUTANE) .* scaling factor;
           F_soln_ODE(:, PROPANE) = F_soln_ODE(:, PROPANE) .* scaling_factor;
720
721
722
           % CONVERT BACK TO MASS
723
           % convert back to kta
724
725
           % kt/yr = mol/s *g/mol
                                           *kt/g *s/yr
726
           F_soln_ODE(:, METHANE) = F_soln_ODE(: ,METHANE) * MOLMASS_METHANE * KT_PER_G * SEC_PER_YR;
           F_soln_ODE(:, ETHANE) = F_soln_ODE(:, ETHANE) * MOLMASS_ETHANE * KT_PER_G * SEC_PER_YR;
727
           F_soln_ODE(:, HYDROGEN) = F_soln_ODE(:, HYDROGEN) * MOLMASS_HYDROGEN * KT_PER_G * SEC_PER_YR;
728
           F_soln_ODE(:, ETHYLENE) = F_soln_ODE(:, ETHYLENE) * MOLMASS_ETHYLENE * KT_PER_G * SEC_PER_YR;
729
           F soln ODE(:, BUTANE) = F soln ODE(:, BUTANE) * MOLMASS BUTANE * KT PER G * SEC PER YR;
730
           F_soln_ODE(:, PROPANE) = F_soln_ODE(:, PROPANE) * MOLMASS_PROPANE * KT_PER_G * SEC_PER_YR;
731
732
                    % Check if you're conserving mass
733
734
           conserv_mass = zeros(length(F_soln_ODE(:,1)), 1);
735
           % ECONOMIC CALCULATIONS
736
737
           profit = zeros(length(F_soln_ODE(:,1)), 1);
           for i = 1:length(F_soln_ODE(:, 1))
738
739
              % DEBUGGING
740
741
             if i > 500
742
               disp("")
```

```
743
              end
744
              % P_flowrates = [ P_hydrogen, P_methane, P_ethylene, P_propane, P_butane ];
              P flowrates = F soln ODE(i, HYDROGEN:BUTANE);
745
746
747
              P_hydrogen = P_flowrates(HYDROGEN);
              P_methane = P_flowrates(METHANE);
748
              P ethylene = P flowrates(ETHYLENE);
749
              P_propane = P_flowrates(PROPANE);
750
              P_butane = P_flowrates(BUTANE);
751
752
              F fresh ethane = F ETHANE(select 1(i), select 2(i));
753
754
              R_ethane = F_fresh_ethane * ( ( 1 - conversion(i)) / conversion(i) );
              R_ethane = F_soln_ODE(i, ETHANE);
755
                % ?? These two values R should be the same
756
757
758
              if (~flowrates_valid(P_flowrates))
                disp("WARNING SOME FLOWATES MAY BE INVALID")
759
760
761
              % Calculate the heat flux needed to keep reactor isothermal
762
              heat_flux = 0;
763
              xi = get xi(P flowrates);
764
              F steam = STEAM TO FEED RATIO MASS * (F fresh ethane + R ethane);
765
              heat\_flux = heat\_flux + heat\_ethane (F\_fresh\_ethane, TEMP\_ETHANE\_FEED, TEMP\_RXTR);
766
              heat_flux = heat_flux + heat_ethane(R_ethane, T_SEPARATION - C_TO_K, TEMP_RXTR);
767
              heat_flux = heat_flux + heat_steam(F_steam, STEAM_CHOICE, PRESS_RXTR, TEMP_RXTR);
768
769
              heat_flux = heat_flux + heat_rxn(xi);
770
               % Use the heat flux to calculate the fuel cost
771
772
              [combusted_fuel_flow_rates, heat_flux_remaining] = fuel_combustion(heat_flux, P_flowrates);
773
              % Calculate how much natural gas you needed to combust
774
775
              F natural gas = natgas combustion(heat flux remaining);
776
777
              % Determine how much of the product streams were combusted to keep the reactor isothermal
778
              combusted hydrogen = combusted fuel flow rates(HYDROGEN);
              combusted_methane = combusted_fuel_flow_rates(METHANE);
779
              combusted_propane = combusted_fuel_flow_rates(PROPANE);
780
              combusted_butane = combusted_fuel_flow_rates(BUTANE);
781
782
783
               % VALUE CREATED | Primary Products
              profit(i, 1) = profit(i, 1) + value_ethylene(P_ethylene);
784
785
              profit(i, 1) = profit(i, 1) + value_h2_chem(P_hydrogen - combusted_hydrogen);
786
787
              % VALUE CREATED | Non-combusted fuels
              % The commented line can be removed or modified as per the context.
788
              % profit(i, 1) = profit(i, 1) + value_methane(P_methane - combusted_methane);
789
790
              profit(i, 1) = profit(i, 1) + value_propane(P_propane - combusted_propane);
              profit(i, 1) = profit(i, 1) + value\_butane(P\_butane - combusted\_butane);
791
792
              % COSTS INCURRED
793
794
              profit(i, 1) = profit(i, 1) - tax_CO2(combusted_fuel_flow_rates, F_natural_gas);
              profit(i, 1) = profit(i, 1) - cost\_steam(F\_steam, COST\_RATES\_STEAM(STEAM\_CHOICE, STEAM\_COST\_COL));
795
```

```
796
               profit(i, 1) = profit(i, 1) - value_ethane(F_fresh_ethane);
797
               profit(i, 1) = profit(i, 1) - cost_natural_gas_fuel(F_natural_gas);
               profit(i, 1) = profit(i, 1) - cost_waste_stream(F_steam);
798
799
               profit(i, 1) = profit(i, 1) - cost separation system(P flowrates, F steam, R ethane);
               cost_sep = cost_separation_system(P_flowrates, F_steam, R_ethane);
800
               if cost_sep > 0
801
802
                 fprintf("cost sep = %3.3e \n",cost_sep)
803
804
               end
               % fprintf("cost %s\n", cost_separation_system(P_flowrates, F_steam, R_ethane)')
805
806
807
               % Checking if I still have any sanity left after this, who knows...
               conserv_mass(i, 1) = F_fresh_ethane - sum(P_flowrates);
808
             end
809
810
            % PLOTTING
811
            col_names = {'V_rxtr [L] ', 'Hydrogen [kta]', 'Methane', ...
812
813
               'Ethylene', 'Propane', 'Butane', 'Ethane', 'conversion', ...
814
               'S1', 'S2', 'q0 [L/s]', 'Vol_plant [L]', 'q0 plant', 'cost reactor', 'profit', 'net profit', 'conserv mass'};
            soln_table = table( V_soln_ODE, F_soln_ODE(:, HYDROGEN), ...
815
816
                   F_soln_ODE(:, METHANE), F_soln_ODE(:, ETHYLENE), ...
                   F soln ODE(:, PROPANE), F soln ODE(:, BUTANE), ...
817
818
                   F_soln_ODE(:, ETHANE), conversion, select_1, ...
                   select\_2, q0, V\_plant, q0\_plant, cost\_rxt\_vec, profit - cost\_rxt\_vec, conserv\_mass, "Variable Names", col\_names)
819
              soln table.Properties.VariableNames = col names;
820
821
822
             % Computer Selectivity vs conversion relationships
823
             % Use Selectivity vs Conversion Relationships with Ivl 2 & 3 balances
824
825
             % to calculate the true feed flow rates into the reactor
             npv.ethyleneValue = value_ethylene(P_ethylene);
826
             npv.hydrogenValue = value_h2_chem(P_hydrogen - combusted_hydrogen);
827
828
             npv.ethane = value ethane(F fresh ethane);
             npv.utilitiesCost = cost_steam(F_steam, COST_RATES_STEAM(STEAM_CHOICE, STEAM_COST_COL));
829
             npv.CO2sustainabilityCharge = tax_CO2(combusted_fuel_flow_rates, F_natural_gas);
830
831
            npv.conversion = conversion(i);
832
             npv.isbl = cost_rxt_vec + cost_separation_system(P_flowrates, F_steam, R_ethane);
             % NPV CALCS
833
             npv_graphs(npv)
834
835
836
           end
837
        end
838
      end
839 end
840
841
842
843
844 disp("The Script is done running )
845 % HELPER FUNCTIONS | PLOTTING
846
847 function z = plot_contour(x, y, z, options)
      global PSA_TOGGLE
```

```
% Unpack options
849
850
      x_label = options{1};
      y_label = options{2};
851
852
      plt title = options{3};
      plt_saveName = options{4};
853
854
      if PSA TOGGLE
855
856
        stringValue = 'true';
857
      else
        stringValue = 'false';
858
859
860
      plt_title = plt_title + sprintf(" PSA %s ", stringValue);
861
      hold on
862
863
      [C, h] = contourf(x, y, z); % Create filled contours
864
      clabel(C, h, 'FontSize', 10, 'Color', 'k', 'LabelSpacing', 200); % Customize label properties
865
866
      xlabel(x label);
867
      ylabel(y_label);
      title(plt_title);
868
      saveas(gcf, plt_saveName);
869
870
      hold off
871 end
872
873 function plot_3D(x, y, z, options)
      global PSA_TOGGLE
875
      % Unpack options
876
      x_label = options{1};
877
878
      y_label = options{2};
      plt_title = options{3};
879
      plt_saveName = options{4};
880
881
882
      if PSA_TOGGLE
        stringValue = 'true';
883
884
      else
885
        stringValue = 'false';
886
      plt_title = plt_title + sprintf(" PSA %s ", stringValue);
887
888
889
       % Create a new figure
      hold on; % Hold on to add multiple plot elements
890
891
892
      surf(x, y, z); % Create a 3D surface plot
893
      % Customizing the plot
894
      xlabel(x_label);
895
896
      ylabel(y_label);
      zlabel('Z Value'); % Add a label for the z-axis
897
      title(plt title);
898
      colorbar; % Adds a color bar to indicate the scale of z values
        shading interp; % Option for smoother color transition on the surface
900 %
901
```

```
902 hold off; % Release the figure
903
      saveas(gcf, plt_saveName); % Save the figure to file
904 end
905
906
907 function plotFlowRatesForRow(row, flowRatesArray)
      % flowRatesArray is expected to be an array of matrices, where each matrix corresponds to a species' flow rates
908
      % Names of the gases for labeling purposes
910
     gasNames = {'Hydrogen', 'Methane', 'Ethylene', 'Propane', 'Butane', 'Ethane'};
911
912
913
     % Create a figure
     figure;
914
     hold on; % Hold on to plot all data on the same figure
915
916
     % Loop through each flow rate matrix in the array
917
     for i = 1:length(flowRatesArray)
918
919
       % Extract the specified row from the current matrix
920
        currentRow = flowRatesArray{i}(row, :);
921
922
        % Plot the current row with a marker
        plot(currentRow, '-o', 'DisplayName', gasNames{i});
923
924
925
      % Adding plot features
926
      title(sprintf('Flow Rates for Row %d', row));
927
928
      xlabel('Selectivity 1 (S2 fixed)');
      ylabel('Flow Rate');
929
     legend('show');
930
931
     hold off; % Release the figure for other plots
932 end
933
934 % HELPER FUNCTIONS | HEAT
935
936 function [combusted_fuel_flowrates, heatflux_left] = fuel_combustion(heat_flux, flowrates)
      global HYDROGEN METHANE ETHYLENE PROPANE BUTANE;
937
      global ENTHALPY METHANE ENTHALPY PROPANE ENTHALPY BUTANE HEAT CAPACITY ETHANE;
938
      global MT_PER_KT G_PER_KT GJ_PER_KJ KJ_PER_GJ MOLMASS_METHANE KT_PER_G MOLMASS_BUTANE ...
939
          MOLMASS_PROPANE PSA_TOGGLE ENTHALPY_HYDROGEN MOLMASS_HYDROGEN
940
941
942
      % Note!: Longest Chain Hydrocarbons are cheapest to combust
943
      % initialize all values in the array to be zero
944
      combusted fuel flowrates = flowrates * 0;
945
946
      % LOGIC: Goes through each heat source in order, returns if the heat flux supplied is sufficient.
947
      heatflux_left = heat_flux;
948
949
                     = (kt / yr)
                                  *(g/kt)*(kJ/g)
                                                      * (GJ / kJ)
950
     Q_combust_all_hydrogen = flowrates(HYDROGEN) * G_PER_KT * ENTHALPY_HYDROGEN * GJ_PER_KJ;
951
952
953
      if (~PSA_TOGGLE)
       % Hydrogen
954
```

```
955
        if (heatflux_left > Q_combust_all_hydrogen)
956
          combusted_fuel_flowrates(HYDROGEN) = flowrates(HYDROGEN);
          heatflux_left = heatflux_left - Q_combust_all_hydrogen;
957
958
        else
959
          % (kt / yr)
                               = ((GJ)
                                              ) * (KJ / GJ) *
          combusted_fuel_flowrates(HYDROGEN) = (heatflux_left) * KJ_PER_GJ * ...
960
            ... % (mol / KJ)
                             * (g / mol) * (kt / g)
961
            (1/ENTHALPY_HYDROGEN)* MOLMASS_HYDROGEN* KT_PER_G;
962
          heatflux_left = 0;
963
          return
964
965
966
967
      % (GJ / yr)
                     = (kt / yr)
                                   * (g / kt) * (kJ / g)
                                                       * (GJ / kJ)
968
      Q combust all methane = flowrates(METHANE) * G PER KT * ENTHALPY METHANE * GJ PER KJ;
969
970
     % Methane
971
972
      if (heatflux left > Q combust all methane)
973
        combusted_fuel_flowrates(METHANE) = flowrates(METHANE);
        heatflux_left = heatflux_left - Q_combust_all_methane;
974
975
      else
        % (kt / yr)
                                            ) * (KJ / GJ) *
976
                             = ((GJ)
977
        combusted_fuel_flowrates(METHANE) = (heatflux_left) * KJ_PER_GJ * ...
                           * (g / mol) * (kt / g)
          ... % (mol / KJ)
978
          (1/ENTHALPY_METHANE) * MOLMASS_METHANE * KT_PER_G;
979
980
        heatflux_left = 0;
981
        return
982
      end
983
984
                     = (kt / yr)
                                   * (g / kt) * (kJ / g)
                                                      * (GJ / kJ)
      Q_combust_all_propane = flowrates(PROPANE) * G_PER_KT * ENTHALPY_PROPANE * GJ_PER_KJ;
985
986
987
      % Propane
988
      if (heatflux_left > Q_combust_all_propane)
        combusted fuel flowrates(PROPANE) = flowrates(PROPANE);
989
        heatflux_left = heatflux_left - Q_combust_all_propane;
990
991
     else
        % (kt / yr)
                              = ((GJ)
                                            ) * (KJ / GJ) *
992
        combusted_fuel_flowrates(PROPANE) = (heatflux_left) * KJ_PER_GJ * ...
993
                           * (g / mol) * (kt / g)
994
          ... % (mol / KJ)
          (1/ENTHALPY_PROPANE)* MOLMASS_PROPANE* KT_PER_G;
995
        heatflux_left = 0;
996
997
        return
998
999
      % (GJ / yr)
                      = (kt / yr)
                                    * (g / kt) * (kJ / g)
                                                        * (GJ / kJ)
1000
      Q_combust_all_butane = flowrates(BUTANE) * G_PER_KT * ENTHALPY_BUTANE * GJ_PER_KJ;
1001
1002
1003
      % Butane
      if (heatflux_left > Q_combust_all_butane)
1004
         combusted_fuel_flowrates(BUTANE) = flowrates(BUTANE);
1005
         heatflux_left = heatflux_left - Q_combust_all_butane;
1006
1007
      else
```

```
1008
        % (kt / yr)
                              = ((GJ)
                                            ) * (KJ / GJ) *
1009
         combusted_fuel_flowrates(BUTANE) = (heatflux_left) * KJ_PER_GJ * ...
          ... % (mol / KJ)
                          * (g / mol) * (kt / g)
1010
1011
         (1/ENTHALPY BUTANE) * MOLMASS BUTANE * KT PER G;
        heatflux_left = 0;
1012
        return
1013
      end
1014
1015 end
1016
                    (kta , __
                                 , bar , C)
1017 %
1018 function heat = heat steam(F steam, STEAM CHOICE, P reactor, T reactor)
      global COST_RATES_STEAM;
      global STEAM_PRESSURE_COL STEAM_TEMP_COL COST_RATES_STEAM G_PER_KT ...
1020
          MOLMASS WATER BAR PER PSIA C TO K HEAT CAPACITY WATER GJ PER KJ;
1021
1022
      P_steam = COST_RATES_STEAM(STEAM_CHOICE, STEAM_PRESSURE_COL); % [psia]
1023
      T_steam = COST_RATES_STEAM(STEAM_CHOICE, STEAM_TEMP_COL); % [C]
1024
      P steam = P steam * BAR PER PSIA;
1025
1026
      T_steam = T_steam + C_TO_K;
      T_reactor = T_reactor + C_TO_K;
1027
1028
      if (P steam > P reactor) % Adiabatic Expansion
1029
1030
        T_adibatic = (T_steam) * (P_reactor / P_steam);
        T_steam = T_adibatic;
1031
      elseif (P_steam < P_reactor) % Compression
1032
1033
        W = compressor_work(T_reactor, P_steam, P_reactor);
1034
         if ADD_COMPRESSOR_WORK_TO_STEAM_HEATFLUX
          heat = heat + W;
1035
1036
1037
        % I should add this to the heat flux probably ??
1038
1039
1040
      % KJ = kta * (G / KT) * (mol / g)
                                        * (KJ / MOL K)
      heat = F_steam * G_PER_KT * (1/MOLMASS_WATER) * HEAT_CAPACITY_WATER * (T_reactor - T_steam);
1041
      % GJ = KJ * (KJ / GJ)
1042
      heat = heat * GJ PER KJ;
1043
1044
1045
      % Heat flux after temperture
1046
1047
1048
1049
1050 end
1052 function T_f = adiabatic_temp(T_0, P_0, P_f)
1053
1054 T_f = T_0 * (P_0 / P_f);
1055 end
1056
1057 function W = compressor_work(T, P_0, P_f)
      R = 8.314; % [ J / mol K]
1058
1059
     W = -n * R * T * log(P_f / P_0);
1060
```

```
1061
1062
      % ?? THIS ALWAYS RETURNS 0 OR NULL, NOT IMPLEMENTED YET
1063
1064 end
1065
1066 % HELPER FUNCTIONS | TAXES
1067
1068 function cost = tax_CO2(combusted_flowrates, F_natural_gas)
      global HYDROGEN METHANE ETHYLENE PROPANE BUTANE TAX_CO2_PER_MT;
1069
      global MT_CO2_PER_KT_METHANE MT_CO2_PER_KT_PROPANE MT_CO2_PER_KT_BUTANE ...
1070
      MT CO2 PER KT NATURALGAS;
1071
1072
      % Calculate the cost per kt (in tax) of each combusted fuel
1073
      methane = combusted flowrates(METHANE);
1074
      propane = combusted flowrates(PROPANE);
1075
      butane = combusted_flowrates(BUTANE);
1076
1077
1078
     mt c02 = 0;
1079
      % kta = (MT) + ((kt fuel / yr) * (MT CO2 / KT FUEL))
      mt_c02 = mt_c02 + methane * MT_CO2_PER_KT_METHANE;
1080
1081
      mt_c02 = mt_c02 + propane * MT_CO2_PER_KT_PROPANE;
      mt c02 = mt c02 + butane * MT CO2 PER KT BUTANE;
1082
      mt_c02 = mt_c02 + F_natural_gas * MT_CO2_PER_KT_NATURALGAS;
1083
1084
      cost = mt c02 * TAX CO2 PER MT;
1085
1086 end
1087
1088 % HELPER FUNCTIONS | FUEL COSTS
1089
1090 function cost = cost_natural_gas_fuel(heat_flux_remaining)
      global VALUE_NATGAS_FUEL
1091
1092 % $ / yr = (GJ)
                       * ($ / GJ)
1093
      cost = heat flux remaining * VALUE NATGAS FUEL;
1094 end
1095
1096 % HELPER FUNCTIONS | FUEL FLOWRATES
1097
1098 function F_natural_gas = natgas_combustion(heat_flux_remaining)
      global KJ_PER_GJ ENTHALPY_NAT_GAS KT_PER_G MOLMASS_NATGAS;
1099
      % output should be in kta, input is in GJ
1100
1101
                 GI
                          * (kJ / GJ) * (mol / kJ) *
                                                  (g / mol) *
                                                                  (kt/g)
1102
      F_natural_gas = heat_flux_remaining * KJ_PER_GJ * (1/ENTHALPY_NAT_GAS) * (MOLMASS_NATGAS) * KT_PER_G;
1103
1104
1105 end
1106
1107 % FUNCTIONS | REACTOR ODE SYSTEM
1108
1109 function dFdV = reactionODEs(V, F, T, P, F_steam)
     global R 2 k1 f k1 r k2 k3 C TO K MOLMASS METHANE MOLMASS ETHANE MOLMASS ETHYLENE ...
1110
       MOLMASS_PROPANE MOLMASS_HYDROGEN MOLMASS_BUTANE YR_PER_SEC G_PER_KT SEC_PER_YR KT_PER_G
1111
     % INPUT UNITS
1112
1113 % V [ L ]
```

```
1114 % F [ kta ]
1115
    % T [ Celcius ]
      % P [ bar ]
1116
1117
      \% Change the input units so that evrything is consistent
1118
      % P = P * ATM_PER_BAR;
1119
      T = T + C TO K;
1120
      % Product flow rate indicies
1122
      HYDROGEN = 1;
1123
      METHANE = 2;
1124
1125
      ETHYLENE = 3;
      PROPANE = 4;
1126
      BUTANE = 5;
1127
1128
      % Feed flow rate index
1129
      ETHANE = 6;
1130
1131
1132
      F_tot = sum(F) + F_steam;
1133
1134
       % Hydrogen = A
1135
      dFAdV = (k1_f(T) * ( (F(ETHANE) * P) / (F_tot * R_2 * T) ) ) - ...
1136
           (k1\_r(T) * ( F(ETHYLENE) * F(HYDROGEN) * P^2) ) / (F\_tot * R\_2 * T)^2;
1137
1138
1139
      % Methane = B
1140
       dFBdV = (k2(T) * (F(ETHANE) * P)^2) / (F_tot * R_2 * T)^2;
1141
      % Ethylene = C
1142
       dFCdV = (k1_f(T) * (F(ETHANE) * P / (F_tot * R_2 * T))) - ...
            (k1\_r(T) * (F(ETHYLENE) * F(HYDROGEN) * P^2) / (F\_tot * R\_2 * T)^2) - ... \\
1144
           (k_3(T) * (F(ETHANE) * F(ETHYLENE) * P^2) / (F_tot * R_2 * T)^2);
1145
1146
1147
      % Propane = E
      dFEdV = k2(T) * (F(ETHANE) * P)^2 / (F_tot * R_2 * T)^2;
1148
1149
1150
      dFFdV = (k3(T) * (F(ETHANE) * F(ETHYLENE) * P^2)) / (F_tot * R_2 * T)^2;
1151
1152
1153
       dFDdV = (-k1_f(T) * (F(ETHANE) * P / (F_tot * R_2 * T))) + ...
           (k1_r(T) * (F(ETHYLENE) * F(HYDROGEN) * P^2)/(F_tot * R_2 * T)^2) - ...
1155
1156
           (k2(T) * F(ETHANE)^2 * P^2 / (F_tot * R_2 * T)^2) - ...
           (k3(T) * F(ETHANE) * F(ETHYLENE) * P^2 / (F tot * R 2 * T)^2);
1157
1158
      T = T - C_TO_K;
1159
1160
1161
      dFdV = [dFAdV; dFBdV; dFCdV; dFEdV; dFFdV; dFDdV];
1162
1163 end
1164
1165 function cost = cost_reactor(V_plant_input)
      global FT_PER_METER STEAM_TO_FEED_RATIO
```

```
1167
      FT_PER_METER = 3.28084;
1168
      % ??? WHAT ARE THE UNITS OF TIME
1169
1170
      pi = 3.14159;
1171
      D = 0.05;
                               % [m]
      V_plant_max = pi * (0.025)^2 * 20;
                                         %[m^3]
1172
1173
      % Reactors have a max length, so calculate the number of full size reactors
1174
      % and add it to the cost of the one non-max length reactor
1175
1176
1177
      cost = 0;
1178
      % Find the Cost of the max-sized reactors
1179
      num of additional reactors = int64(V plant input / V plant max);
1180
      num of additional reactors = double(num of additional reactors);
1181
1182
      V_plant = V_plant_max;
1183
1184
      factor 1 = 4.18;
1185
      factor_2 = (V_plant / (pi * (D/2)^2) * FT_PER_METER)^0.82;
      factor_3 = (101.9 * D * FT_PER_METER)^1.066;
1186
1187
      factor_4 = (1800 / 280);
      cost max reactor = factor 1 * factor 2 * factor 3 * factor 4;
1188
1189
      cost = cost + num_of_additional_reactors * cost_max_reactor;
1190
1191
1192
      % Find the cost of the non-max size reactor
1193
      V_plant = V_plant_input - V_plant_max * num_of_additional_reactors;
      if V plant < 0
1194
        V_plant = 0;
1195
1196
      factor_1 = 4.18;
1197
      factor_2 = (V_plant / (pi * (D/2)^2) * FT_PER_METER)^0.82;
1198
1199
      factor 3 = (101.9 * D * FT PER METER)^1.066;
1200
      factor_4 = (1800 / 280);
      cost = cost + factor_1 * factor_2 * factor_3 * factor_4;
1201
1202
1203
1204 end
1205
                         (kta)
1206 %
          [$] =
1207 function cost = cost_waste_stream(F_steam)
       global MOLMASS_WATER G_PER_KT YR_PER_SEC R_2 M3_PER_L T_SEPARATION ...
1208
1209
           P_SEPARATION SEC_PER_YR C_TO_K DENSITY_LIQ_WATER KG_PER_KT
1210
1211
      % m^3 / s = (kt / yr) * (kg / kt) * (m^3 / kg) * (yr / s)
      q = F_steam * KG_PER_KT * (1 / DENSITY_LIQ_WATER) * YR_PER_SEC;
1212
        % ?? Assume that all of the water out of the sep system is liquid
1213
1214
      a = 0.001 + 2e-4*q^{(-0.6)};
1215
        %Source: Uldrich and Vasudevan
1216
1217
1218
        %Source: Uldrich and Vasudevan
     CEPCI = 820:
1219
```

```
1220
        %Source: Lecture slides
1221
     C_f = 3.0;
                        %[$/GJ]
1222
1223
      %$/m^3 waste water
      cost_waste_water = a*CEPCI + b*C_f;
1224
1225
      \% \text{ m}^3 / \text{s} = (\text{m}^3 / \text{s}) * (\text{s} / \text{yr})
1226
      q = q * SEC_PER_YR;
1227
1228
      cost = cost_waste_water * q;
1229
1230
1231
1232 function cost = cost_separation_system(P_flowrates, F_steam, R_ethane)
      global MOLMASS METHANE MOLMASS HYDROGEN MOLMASS ETHANE MOLMASS ETHYLENE ...
1233
        MOLMASS PROPANE MOLMASS BUTANE YR PER SEC
1234
      global T_SEPARATION R PRESS_RXTR R ..
1235
      MAX_OPEX MAX_TFCI MAX_CAPEX G_PER_KT MOLMASS_WATER
1236
1237
1238
      % Product flow rate indicies
      HYDROGEN = 1:
1239
     METHANE = 2;
1240
      ETHYLENE = 3;
1241
      PROPANE = 4;
1242
      BUTANE = 5;
1243
1244
      % Feed flow rate index
1245
1246
      ETHANE = 6;
1247
      % SEPARATION_EFFICIENCY_FACTOR = 30;
1248
1249
      T = T SEPARATION; % [K]
1250
      %Using compositions from ASPEN
1251
1252
      %Component mole flow rate out of rxtr over total mole flow rate out of reactor
1253
      % Mol fractions out of the reactoor
1254
      % (mol/s) = (kt/yr)*(g/kt)*(mol/g)*(yr/s)
1255
      P_flowrates(METHANE) = P_flowrates(METHANE) * G_PER_KT * (1/MOLMASS_METHANE) * YR_PER_SEC;
1256
       P\_flowrates(HYDROGEN) * G\_PER\_KT * (1/MOLMASS\_HYDROGEN) * YR\_PER\_SEC; \\
1257
      R_ethane = R_ethane * G_PER_KT * (1/MOLMASS_ETHANE) * YR_PER_SEC;
1258
      P_flowrates(ETHYLENE) = P_flowrates(ETHYLENE) * G_PER_KT * (1/MOLMASS_ETHYLENE) * YR_PER_SEC;
1259
      P flowrates(PROPANE) = P flowrates(PROPANE) * G PER KT * (1/MOLMASS PROPANE) * YR PER SEC;
      P_flowrates(BUTANE) = P_flowrates(BUTANE) * G_PER_KT * (1/MOLMASS_BUTANE) * YR_PER_SEC; % Add this line for butane
1261
      F_steam = F_steam * G_PER_KT * (1/MOLMASS_WATER) * YR_PER_SEC;
1262
1263
1264
      %CONVERT TO MOLES
1265
      P_tot = sum(P_flowrates(HYDROGEN:BUTANE)) + F_steam + R_ethane;
1266
1267
      z_methane = P_flowrates(METHANE) / P_tot;
1268
      z_hydrogen = P_flowrates(HYDROGEN) / P_tot;
1269
      z_ethane = R_ethane / P_tot;
1270
     z ethylene = P flowrates(ETHYLENE) / P tot;
     z_propane = P_flowrates(PROPANE) / P_tot;
```

```
1273
      z_butane = P_flowrates(BUTANE) / P_tot;
1274
      z_water = F_steam / P_tot;
1275
1276
      %Mol fractions leaving each separation system (refer to Isa's drawing in GN)
1277
      % leaving sep 1
      x_water = 1;
1278
1279
      % leaving sep 4
1280
      x_ethane = 1;
1281
      x_ethylene = 1;
1282
1283
1284
      % leaving sep 2
      x_butane = 0.0003;
1285
      x propane = 1 - x butane;
1286
1287
1288
      % leaving sep 5 (PSA)
      x_methane = 4.03293090303065e-004;
1289
      x hydrogen = 1 - x methane;
1290
1291
        % ?? How should I implement the PSA toggle switch on this
1292
      %Pressures of PSA system [bar]
1293
      P in = PRESS RXTR;
1294
1295
      P H2 = 10;
      P_ME = 1;
                       % [ bar ]
1296
        \% These outlet pressures are constant for PSA system. DONT change
1297
1298
1299
      %Using flow rates from ASPEN [NOTE: FOR MATLAB USE THE VALUES FROM THE
       %SOLN_TABLE. WE USED THESE AS EXPECTED COSTS)
1300
1301
1302
      % Flowrates of each exiting stream from the sep system
1303
      F_water = F_steam;
                                           % mol/s
1304
1305
      F LPG = P flowrates(BUTANE) + P flowrates(PROPANE); % (mol / s)
      F_ethylene = P_flowrates(ETHYLENE);
1306
                                                    % (mol / s)
      F ethane = R ethane;
                                        % (mol / s)
1307
      F H2 = P flowrates(HYDROGEN);
1308
                                                   % (mol / s)
1309
      F_ME = P_flowrates(METHANE);
                                                  % (mol / s);
1310
      %(J/s) = (mol/s) * (J/mol K) * (T)
1311
      W_min_Sep_System = F_water*R*T*log(x_water/z_water) + ...
1312
1313
              F_LPG*R*T*log(x_propane/z_propane + ...
                      x_butane/z_butane) + ...
1314
1315
               F_{ethylene} R^T \log(x_{ethylene} - L_{ethylene}) + ...
               F ethane*R*T*log(x ethane/z ethane) + ...
1316
1317
                 F_H2*log(P_H2/P_in)+ ...
1318
                 F_H2*log(x_hydrogen/z_hydrogen) +...
1319
1320
                 F_ME*log(x_methane/z_methane) +...
                 F_ME*log(P_ME/P_in)...
1321
1322
                 ):
1323
1324
1325
      lamdba_min = 20;
```

```
1326
      lambda_max = 50;
1327
      cost_energy = 3;
                         %($/GJ)
1328
1329
      if MAX OPEX
                     = (J/s) * (GJ/J) * (Work Efficiency) *($/GJ)* (s/yr)
1330
      %($/yr)
        opex = W_min_Sep_System*1e-9 * lambda_max * cost_energy * 30.24e6;
1331
1332
        opex = W_min_Sep_System*1e-9 * lamdba_min * cost_energy * 30.24e6;
1333
1334
      end
1335
1336
      if MAX CAPEX
1337
                   = ($/W) (Efficiency) * (J/s)
        capex = 1 * lambda_max * W_min_Sep_System;
1338
1339
      else
         capex = 0.5 * lamdba min * W min Sep System;
1340
1341
      end
1342
      cost = 2.5 * capex;
1343
1344
1345 end
1346
1347
1348 function void = npv_graphs(npv)
1349
      % npv.ethyleneValue = value ethylene(P ethylene);
1350
      % npv.hydrogenValue = value_h2_chem(P_hydrogen - combusted_hydrogen);
1352
      % npv.ethane = value_ethane(F_fresh_ethane);
      % npv.utilitiesCost = cost_steam(F_steam, COST_RATES_STEAM(STEAM_CHOICE, STEAM_COST_COL));
1353
      % npv.CO2sustainabilityCharge = tax_CO2(combusted_fuel_flow_rates, F_natural_gas);
1354
      % npv.conversion = conversion(i);
      \% \ npv.isbl = cost\_rxt\_vec + cost\_separation\_system(P\_flowrates, F\_steam, R\_ethane);
1356
1357
1358
      % NPV CALCS
1359
      filename = 'npv code.xlsx';
1360
      data = readtable(filename);
1361
1362
      sheetName = 'cf'; % Specify the sheet name or number
1363
      data = readtable(filename, 'Sheet', sheetName);
1364
1365
1366
      n = 5; % Number of times to duplicate the sheet
1367
         % Assuming 'data' is the table you want to duplicate
1368
         writetable(data, filename, 'Sheet', ['DuplicatedSheet' num2str(i)]);
1369
1370
1371
      cellRow = 10; % Row of the cell to modify
1372
1373
      cellCol = 'C'; % Column of the cell to modify, use column index if numerical indexing preferred
      newValue = 69; % New value to assign
1374
1375
1376
1377
        modifiedData = data; % Make a copy of the original data
        modifiedData{cellRow, cellCol} = newValue; % Modify the specific cell
1378
```

```
1379
        % Export the modified data to a new sheet
1380
        writetable(modifiedData, filename, 'Sheet', ['ModifiedSheet' num2str(i)]);
1381
1382
1383
1384
1385
1386 end
1387
1388
1389
1390 function installedCost = calculate_installed_cost(Q, F_d, F_m, F_p)
1391
1392 Q = Q * 106BTU_PER_GJ * yr/hr;
1393
      % Constants
      M_and_S = 1800; % Marshall and Swift index
1394
      base_cost = 5.52 * 10^3;
1395
1396
1397
      % Purchased cost calculation
     % F_c = F_d + F_m + F_p;
1398
1399
      F_c = 1.1;
1400
1401
      % Installed cost calculation
      installedCost = (M_and_S / 280) * (base_cost * Q^0.85 * (1.27 + F_c));
1402
1403 end
1404
1405
1406
1407
1408
1409
1410
1411
1412
1413
1414
1415
1416
1417
1418
1419
1420
1421
1422
1423
1424
1425
1426
1427
1428
1429
1430
1431
```

3/11/24	5:12 AM	/Users/wesle	yjohansor	n/Docum	ents/Co	llege Cla	asses U	Santa B	arbara/0	hE 184A	Design	of/Le	vel3.m	28 of 28
1432														
1433														
1434														
1435														
1436														
1437														
1438														
1439														
1440														