



2025

# VLANs: From Theory to Packet-Level Analysis with GNS3 and Wireshark

From Theory to Packet-Level Reality Perfect  
for Real-World Engineers



Subash Subedi

## Abstract

This hands-on guide provides a complete understanding of IEEE 802.1Q VLANs using a practical GNS3 topology with one Cisco Layer 2 switch and seven PCs. The document explains VLAN theory, switch configuration, tagging and untagging behavior, and packet-level verification using Wireshark.

A Local SPAN (Switched Port Analyzer) session is used to mirror VLAN traffic to a dedicated monitoring port. This allows accurate observation of 802.1Q header behavior on access ports, trunk ports, and native VLAN traffic.

By completing this lab, learners gain both theoretical and practical understanding required for CCNA and real-world network troubleshooting.

## Table of Contents

1.	Introduction.....	4
1.1.	What is a VLAN?.....	4
1.2.	Why VLANs Are Important .....	4
1.3.	Benefits of VLANs in Modern Networks .....	5
2.	VLAN Core Concepts.....	5
2.1.	Broadcast Domains & Network Segmentation .....	5
2.2.	Tagged vs Untagged Traffic .....	6
2.3.	IEEE 802.1Q Standard Overview .....	6
2.4.	The Native VLAN Concept .....	6
2.5.	VLAN IDs and Ranges .....	7
3.	VLAN Types.....	7
3.1.	Static VLANs (Port-Based) .....	7
3.2.	Dynamic VLANs .....	7
3.3.	Voice VLAN (Auto & Manual).....	7
3.4.	Management VLAN & SVI .....	8
3.5.	Default VLAN (VLAN 1).....	8
3.6.	Private VLANs.....	8
4.	Switch Port Modes.....	9
4.1.	Access Port.....	9
4.2.	Trunk Port (ISLCisco & IEEE 802.1Q).....	9
4.3.	Dynamic Auto / Dynamic Desirable (DTP Modes Table).....	9
4.4.	How Switches Decide: Tagging vs Untagging Rules (Decision Matrix) .....	10
5.	Hands-On Lab: VLAN Implementation in GNS3 .....	11
5.1.	Lab Objectives .....	11
5.2.	Lab Topology Overview .....	11
5.3.	Devices and Software Used .....	11

5.4.	VLAN & IP Allocation Table.....	11
5.5.	Step-by-Step Switch Configuration .....	12
5.5.1.	Creating VLANs .....	12
5.5.2.	Configuring Access Ports .....	13
6.	SPAN (Switched Port Analyzer) Configuration .....	17
6.1.	Why Use SPAN in VLAN Labs .....	17
6.2.	Updated Topology with Monitoring Port .....	17
6.3.	Complete SPAN Configuration .....	17
6.4.	Verifying SPAN Session.....	18
6.5.	What You Should See in Wireshark .....	18
6.6.	Tag Behavior Summary Table .....	18
7.	Traffic Capture & VLAN Tag Analysis .....	19
7.1.	Access-Port Traffic --> Untagged.....	19
7.2.	Trunk Traffic --> Tagged (VLAN 10).....	19
7.3.	802.1Q Header Breakdown in Wireshark.....	19
7.4.	Native VLAN Traffic --> Untagged on Trunk .....	19
7.5.	Sample Packet Capture .....	20
8.	Key Observations & Learning Outcomes .....	20
9.	Best Practices & Security Recommendations.....	20
10.	Troubleshooting VLAN Issues .....	20
10.1.	Top 5 VLAN Problems on the Exam.....	20
10.2.	Native VLAN Mismatch Symptoms.....	21
10.3.	Must-Know Commands + Expected Output.....	21
11.	Conclusion .....	21

## 1. Introduction

### 1.1. What is a VLAN?

A Virtual LAN (VLAN) is a logical grouping of devices within a switched network that allows them to communicate as if they were on the same physical segment, even if they are connected to different switches or located on different floors.

VLANs rely on logical connections rather than physical ones. Devices in the same VLAN share a broadcast domain, meaning that unicast, broadcast, and multicast traffic are restricted to that VLAN. Devices in different VLANs cannot communicate directly at Layer 2; communication between VLANs requires a Layer 3 device, such as a router.

Example: In a three-floor office, IT, HR, and Sales departments may each have their own VLAN (VLAN 2, 3, and 4). These VLANs span all floors, allowing devices to communicate logically while remaining physically connected to different switches.

### 1.2. Why VLANs Are Important

VLANs are essential because they:

- Segment networks** logically by function, department, or application, regardless of physical location.

- Reduce broadcast domains**, preventing unnecessary traffic from reaching all devices and improving performance.

- Contain broadcast traffic within each VLAN, improving **efficiency and scalability**.

- Enhance security** and access control by isolating sensitive users or departments (e.g., HR, IT) from general users (e.g., Guests, Students).

- Enable flexible network design, allowing devices to be moved or added without rewiring or creating new physical networks.

### 1.3. Benefits of VLANs in Modern Networks

The main advantages of VLAN implementation include:

#### Improved Performance

Smaller broadcast domains reduce unnecessary traffic and increase network efficiency.

#### Enhanced Security

Logical isolation prevents unauthorized access between VLANs, protecting sensitive departments.

#### Better Organization and Flexibility

Devices can be grouped by role or function rather than physical location, simplifying moves and expansions.

#### Simplified Network Management

Supports hierarchical IP addressing, making administration and troubleshooting easier.

#### Cost Efficiency

Reduces the need for multiple physical networks and equipment while maintaining logical separation.

#### Policy Enforcement

Access control and traffic rules can be applied per VLAN, such as restricting Guest VLANs to internet-only access.

## 2. VLAN Core Concepts

### 2.1. Broadcast Domains & Network Segmentation

A broadcast domain is a set of devices that receive a Layer 2 broadcast frame.

Without VLANs: the entire switched network is one broadcast domain - any broadcast is sent to all devices, causing unnecessary traffic.

With VLANs: each VLAN forms a separate broadcast domain. Broadcasts are limited to devices in the same VLAN, even across different switches.

Result: smaller broadcast domains → improved network performance, scalability, and security.

## 2.2. Tagged vs Untagged Traffic

**Untagged traffic:** Standard Ethernet frames without VLAN information (from PCs or standard devices).

**Tagged traffic:** Frames with a 4-byte 802.1Q tag inserted between Source MAC and Type/Length fields, carrying the VLAN ID (VID).

**Access ports:** Send/receive untagged frames (single VLAN).

**Trunk ports:** Carry tagged frames for multiple VLANs.

**Exception:** Traffic in the native VLAN is sent untagged, even on trunks.

## 2.3. IEEE 802.1Q Standard Overview

IEEE 802.1Q is the industry-standard protocol for VLAN tagging on Ethernet networks.

It inserts a 4-byte tag into the original Ethernet frame header containing:

TPID (Tag Protocol Identifier): 2 bytes, value 0x8100

Priority (PRI): 3 bits for Class of Service (QoS)

CFI: 1 bit (legacy Token Ring support)

VID (VLAN ID): 12 bits, supporting up to 4096 VLANs (0–4095)

After tagging, the switch recalculates and updates the Frame Check Sequence (FCS). 802.1Q enables trunk links to transport traffic from multiple VLANs between switches and other devices.s.

## 2.4. The Native VLAN Concept

Each 802.1Q trunk has a native VLAN (default = VLAN 1).

Untagged frames received on a trunk are assigned to the native VLAN.

Frames for the native VLAN are sent untagged across the trunk.

Important points:

Cisco switches drop incoming tagged frames that match the native VLAN ID.

Control protocols (CDP, STP, VTP, DTP) typically use the native VLAN and are sent untagged.

Security best practice: Change the native VLAN to an unused VLAN (e.g., 999) and do not carry user traffic on it.

Native VLAN must match on both ends of the trunk; mismatch causes errors and warnings.

## 2.5. VLAN IDs and Ranges

Normal VLANs: 1–1005 (stored in vlan.dat, supported on all Cisco switches)

Extended VLANs: 1006–4094 (supported on modern switches in VTP transparent mode)

Reserved IDs: 0 and 4095 cannot be used

Total VLANs possible with 802.1Q: 4096 (12-bit VID field)

# 3. VLAN Types

## 3.1. Static VLANs (Port-Based)

The most common and recommended method.

Ports are manually assigned to a specific VLAN using switchport access vlan X command.

Reliable, secure, and easy to understand - this is the primary method tested in CCNA.

## 3.2. Dynamic VLANs

VLAN assignment is based on the device's MAC address using a VLAN Membership Policy Server (VMPS).

Rarely used today and officially deprecated by Cisco - no longer part of CCNA but may appear in CCNP ENCOR.

## 3.3. Voice VLAN (Auto & Manual)

Allows a single switch port to support both a PC (data) and an IP phone (voice).

The port is configured with one data VLAN and one voice VLAN.

Cisco IP phones use CDP or LLDP to learn the voice VLAN and tag voice traffic accordingly.

Configuration example:

```
switchport mode access
switchport access vlan 20
switchport voice vlan 150
```

### 3.4. Management VLAN & SVI

A dedicated VLAN used for switch management (SSH, Telnet, SNMP, etc.).

Should not be VLAN 1 for security reasons.

A Switch Virtual Interface (SVI) is created using:

```
interface vlan 99
ip address 192.168.99.10 255.255.255.0
```

This provides Layer 3 access to the switch.

### 3.5. Default VLAN (VLAN 1)

All switch ports belong to VLAN 1 by default.

VLAN 1 cannot be deleted or renamed.

Carries all control plane traffic (CDP, STP, VTP, DTP, etc.).

Best security practice:

- Do not use VLAN 1 for user or management traffic
- Change the native VLAN on trunks
- Create separate management and user VLANs

### 3.6. Private VLANs

Advanced feature for further Layer 2 isolation within a single VLAN.

Used in service provider or multi-tenant environments.

Types of ports:

- Isolated: Can only communicate with promiscuous ports
- Community: Can communicate with other members of the same community and promiscuous ports
- Promiscuous: Typically connected to router/firewall

## 4. Switch Port Modes

### 4.1. Access Port

Belongs to exactly one VLAN.

Sends and receives only untagged frames.

Used for end devices (PCs, printers, IP phones).

Configuration:

```
switchport mode access
```

```
switchport access vlan X
```

Strongly recommended to explicitly configure mode access (security).

### 4.2. Trunk Port (ISLCisco & IEEE 802.1Q)

Carries traffic for multiple VLANs.

Uses tagging to identify VLAN membership.

ISL (Cisco proprietary) - deprecated.

802.1Q (IEEE standard) - current standard used everywhere.

Configuration:

```
switchport mode trunk
```

```
switchport trunk native vlan 999
```

```
switchport trunk allowed vlan 10,20,30
```

### 4.3. Dynamic Auto / Dynamic Desirable (DTP Modes Table)

Dynamic Trunking Protocol (DTP) negotiates trunking:

dynamic desirable: Actively tries to form a trunk - trunks with trunk, desirable, or auto

dynamic auto: Passively waits - trunks only if partner is trunk or desirable

trunk: Permanently trunking

access: Permanently access (no trunking)

Best practice: Disable DTP with switchport nonegotiate

#### 4.4. How Switches Decide: Tagging vs Untagging Rules (Decision Matrix)

When a frame enters a port:

Access port ---> untagged frame assigned to configured access VLAN

Trunk port ---> tagged frame forwarded based on VID

Trunk port ---> untagged frame assigned to native VLAN

When a frame exits a port:

Access port ---> always sent untagged

Trunk port ---> tagged (except native VLAN traffic → sent untagged)

Port Type	Incoming Frame	Switch Action	Outgoing Frame
Access	Any	Assign to access VLAN	Untagged
Trunk	Tagged	Forward by VLAN ID	Tagged
Trunk	Untagged	Assigned to native VLAN	Untagged
Trunk	Native VLAN	Forward	Untagged
Trunk	Other VLAN	Forward	Tagged

## 5. Hands-On Lab: VLAN Implementation in GNS3

### 5.1. Lab Objectives

- Create VLAN 10 (IT), VLAN 20 (Finance), VLAN 30 (Sales)
- Assign ports to correct VLANs
- Configure Management VLAN
- Use SPAN to capture frames and verify tagging behavior

### 5.2. Lab Topology Overview

- One Cisco L2 switch
- Six PCs across three VLANs
- One monitoring PC for SPAN

### 5.3. Devices and Software Used

- GNS3
- Cisco vIOS-L2
- Seven VPCS nodes
- Wireshark

### 5.4. VLAN & IP Allocation Table

DEPARTMENT	VLAN	Name	IP Address
IT Department	VLAN 10	PC1-VLAN--10	192.168.1.2
		PC2-VLAN--10	192.168.1.3
Finance Department	VLAN 20	PC3-VLAN--20	192.168.1.4
		PC4-VLAN--20	192.168.1.5
Sales Department	VLAN 30	PC5-VLAN--30	192.168.1.6
		PC6-VLAN--30	192.168.1.7
SPAN (Switched Port Analyzer) Management	VLAN 99	Switch SVI	192.168.1.1

## 5.5. Step-by-Step Switch Configuration

### 5.5.1. Creating VLANs

```
enable
configure terminal

vlan 10
name IT Department
exit

vlan 20
name Finance Department
exit

vlan 30
name Sales Department
exit

vlan 99
name Management
exit

do show vlan
do wr
```

```

Switch>
Switch>enable
Switch#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Switch(config)#
Switch(config)#vlan 10
Switch(config-vlan)#name IT Department
Switch(config-vlan)#exit
Switch(config)#
Switch(config)#vlan 20
Switch(config-vlan)#name Finance Department
Switch(config-vlan)#exit
Switch(config)#
Switch(config)#vlan 30
Switch(config-vlan)#name Sales Department
Switch(config-vlan)#exit
Switch(config)#
Switch(config)#vlan 99
Switch(config-vlan)#name Management
Switch(config-vlan)#exit
Switch(config)#
Switch(config)#do show vlan

VLAN Name                               Status    Ports
---- -
1   default                             active    Gi0/0, Gi0/1, Gi0/2, Gi0/3
                                         Gi1/0, Gi1/1, Gi1/2, Gi1/3
                                         Gi2/0, Gi2/1, Gi2/2, Gi2/3
                                         Gi3/0, Gi3/1, Gi3/2, Gi3/3
10  IT Department                       active
20  Finance Department                  active
30  Sales Department                   active
99  Management                         active
1002 fddi-default                     act/unsup
1003 token-ring-default               act/unsup
1004 fddinet-default                 act/unsup
1005 trnet-default                   act/unsup

VLAN Type   SAID      MTU   Parent RingNo BridgeNo Stp  BrdgMode Trans1 Trans2
---- -
1   enet    100001   1500   -     -     -     -     -     0     0
10  enet    100010   1500   -     -     -     -     -     0     0
20  enet    100020   1500   -     -     -     -     -     0     0
30  enet    100030   1500   -     -     -     -     -     0     0
99  enet    100099   1500   -     -     -     -     -     0     0

VLAN Type   SAID      MTU   Parent RingNo BridgeNo Stp  BrdgMode Trans1 Trans2
---- -
1002 fddi  101002   1500   -     -     -     -     -     0     0
1003 tr    101003   1500   -     -     -     -     -     0     0
1004 fdnet 101004   1500   -     -     -     ieee -     0     0
1005 trnet 101005   1500   -     -     -     ibm  -     0     0

Remote SPAN VLANs
---- -
Primary Secondary Type          Ports
---- -
Switch(config)#
Switch(config)#do wr
Building configuration...

```

### 5.5.2. Configuring Access Ports

#### VLAN 10

enable
--------

```

configure terminal

interface range GigabitEthernet0/0 - 3
switchport mode access
switchport access vlan 10
description THIS INTERFACE BELONG TO IT DEPARTMENT
no shutdown
exit

do show vlan | include IT

```

```

Switch>
Switch>enable
Switch#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Switch(config)#
Switch(config)#interface range GigabitEthernet0/1 - 2
Switch(config-if-range)#switchport mode access
Switch(config-if-range)#switchport access vlan 10
Switch(config-if-range)#description THIS INTERFACE BELONG TO IT DEPARTMENT
Switch(config-if-range)#no shutdown
Switch(config-if-range)#exit
Switch(config)#
Switch(config)#do show vlan | include IT
10  IT Department          active   Gi0/1, Gi0/2
Switch(config)#
Switch(config)#do wr
Building configuration...

```

## VLAN 20

```

enable
configure terminal

interface range GigabitEthernet1/0 - 3
switchport mode access
switchport access vlan 20
description THIS INTERFACE BELONG TO FIANANCE
DEPARTMENT
no shutdown
exit

```

```
do show vlan | include Fi
```

```
Switch>
Switch>enable
Switch#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Switch(config)#
Switch(config)#interface range GigabitEthernet1/1 - 2
Switch(config-if-range)#switchport mode access
Switch(config-if-range)#switchport access vlan 20
Switch(config-if-range)## THIS INTERFACE BELONG TO FIANANCE DEPARTMENT
Switch(config-if-range)#no shutdown
Switch(config-if-range)#exit
Switch(config)#
Switch(config)#do show vlan | include F
20  Finance Department           active   Gi1/1, Gi1/2
Switch(config)#
Switch(config)#do wr
Building configuration...
```

## VLAN 30

```
enable
configure terminal

interface range GigabitEthernet2/0 - 3
switchport mode access
switchport access vlan 30
description THIS INTERFACE BELONG TO SALES DEPARTMENT
no shutdown
exit

do show vlan | include Sales
```

```

Switch>
Switch>enable
Switch#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Switch(config)#
Switch(config)#interface range GigabitEthernet2/1 - 2
Switch(config-if-range)#switchport mode access
Switch(config-if-range)#switchport access vlan 30
Switch(config-if-range)#description THIS INTERFACE BELONG TO SALES DEPARTMENT
Switch(config-if-range)#no shutdown
Switch(config-if-range)#exit
Switch(config)#
Switch(config)#do show vlan | include S
VLAN Name                      Status    Ports
30  Sales Department            active    Gi2/1, Gi2/2
VVLAN Type  SAID      MTU   Parent RingNo BridgeNo Stp  BrdgMode Trans1 Trans2
VLAN Type  SAID      MTU   Parent RingNo BridgeNo Stp  BrdgMode Trans1 Trans2
Remote SPAN VLANs
Primary Secondary Type          Ports
Switch(config)#
Switch(config)#do wr
Building configuration...

```

## VLAN 99

enable
configure terminal
interface range GigabitEthernet3/0 - 3
switchport mode access
switchport access vlan 99
description THIS INTERFACE BELONG TO MANAGEMENT SVI
no shutdown
exit
do show vlan   include Management

```

Switch>
Switch>enable
Switch#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Switch(config)#
Switch(config)#interface range GigabitEthernet3/1 - 2
Switch(config-if-range)#switchport mode access
Switch(config-if-range)#switchport access vlan 99
Switch(config-if-range)#description THIS INTERFACE BELONG TO MANAGEMENT SVI
Switch(config-if-range)#no shutdown
Switch(config-if-range)#exit
Switch(config)#
Switch(config)#do show vlan | include Management
99 Management active Gi3/1, Gi3/2
Switch(config)#
Switch(config)#do wr
Building configuration...

```

## 6. SPAN (Switched Port Analyzer) Configuration

### 6.1. Why Use SPAN in VLAN Labs

To see the truth - prove that access ports really send untagged frames.

### 6.2. Updated Topology with Monitoring Port

PC7 connected to Gi3/1 is used as the SPAN destination port --> receives mirrored traffic.

### 6.3. Complete SPAN Configuration

```

enable
configure terminal

monitor session 1 source interface Gi0/0 - 3 both

monitor session 1 source interface Gi1/0 - 3 both

monitor session 1 source interface Gi2/0 - 3 both

monitor session 1 destination interface Gi3/1

```

```

Switch>
Switch>enable
Switch#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Switch(config)#
Switch(config)#monitor session 1 source interface Gi0/1 - 2 both
Switch(config)#
Switch(config)#monitor session 1 source interface Gi1/1 - 2 both
Switch(config)#
Switch(config)#monitor session 1 source interface Gi2/1 - 2 both
Switch(config)#
Switch(config)#monitor session 1 destination interface Gi3/1
Switch(config)#
Switch(config)#
Switch(config)#do show monitor session 1
Session 1
-----
Type : Local Session
Source Ports :
    Both : Gi0/1-2,Gi1/1-2,Gi2/1-2
Destination Ports : Gi3/1
    Encapsulation : Native

Switch(config)#
Switch(config)#do wr
Building configuration...
-----
```

## 6.4. Verifying SPAN Session

show monitor session 1

```

Switch(config)#do show monitor session 1
Session 1
-----
Type : Local Session
Source Ports :
    Both : Gi0/1-2,Gi1/1-2,Gi2/1-2
Destination Ports : Gi3/1
    Encapsulation : Native

Switch(config)#
-----
```

## 6.5. What You Should See in Wireshark

Access port traffic appears untagged

VLAN tag (TPID 0x8100) appears only on trunk links

Native VLAN traffic remains untagged even on a trunk

## 6.6. Tag Behavior Summary Table

Port Type	VLAN Tagging Behavior
-----------	-----------------------

Access Port	Always untagged
Trunk Port (Native VLAN)	Untagged
Trunk Port (Non-Native VLANs)	Tagged

## 7. Traffic Capture & VLAN Tag Analysis

### 7.1. Access-Port Traffic --> Untagged

We will see normal Ethernet II frames - no “802.1Q Virtual LAN” line in Wireshark.

### 7.2. Trunk Traffic --> Tagged (VLAN 10)

For Trunk Traffics there we should add a second switch --> make link trunk --> we will instantly see TPID 0x8100.

### 7.3. 802.1Q Header Breakdown in Wireshark

Priority Code Point (PCP)


Drop Eligible Indicator (DEI)

VLAN Identifier (VID) → e.g., 10, 20, 30

### 7.4. Native VLAN Traffic --> Untagged on Trunk

Even on a trunk, native VLAN frames appear without tags.

## 7.5. Sample Packet Capture



## 8. Key Observations & Learning Outcomes

Access ports always strip tags

Trunks preserve tags except for native VLAN

SPAN + Wireshark is the ultimate proof tool

Native VLAN mismatch = real production outages

## 9. Best Practices & Security Recommendations

Never use VLAN 1 for user traffic

Change native VLAN on all trunks (**switchport trunk native vlan 999**)

Disable DTP: **switchport nonegotiate**

Explicitly set **switchport mode access** or **trunk**

Use dedicated management VLAN (not 1)

## 10. Troubleshooting VLAN Issues

### 10.1. Top 5 VLAN Problems on the Exam

Native VLAN mismatch

Trunk not allowing required VLANs

Access port in wrong VLAN

- DTP negotiation failure
- Using VLAN 1 for user traffic

## 10.2. Native VLAN Mismatch Symptoms

%CDP-4-NATIVE\_VLAN\_MISMATCH logs

STP loops possible

## 10.3. Must-Know Commands + Expected Output

```
show vlan brief  
show interfaces trunk  
show interfaces switchport  
show monitor session all
```

## 11. Conclusion

This document provides a complete understanding of VLAN configuration, 802.1Q tag behavior, native VLAN operation, and SPAN-based packet analysis. The combination of theory and hands-on practice in GNS3 allows accurate visualization of VLAN operations and prepares learners for both CCNA-level exams and real-world troubleshooting.