Maintenance & Troubleshooting

Maintenance Tips

- Regularly clean the lens and sensor area with a soft cloth.
- Ensure firmware is updated via the app for optimal performance.
- Check battery and solar connections periodically.

Troubleshooting

- Camera Not Turning On: Ensure the battery is charged or try an alternative power source.
- App Not Connecting: Restart both the camera and mobile device, then retry pairing.
- Blurred Images: Clean the lens and ensure the camera is mounted securely, ensure that the camera view is clear, not obstructed.