

GPIO42 - GPS ENABLE	GPS - Quectel LC76G	Connection - UART (115200 baud)
GPIO43 TX (UART)		
GPIO44 RX (UART)		

GPIO21 INT_MAX	Heart Rate Sensor - MAX30102	I2C - 0xAE for writing data
GPIO9 SCL (I2C)		I2C - 0xAF for reading data
GPIO8 SDA (I2C)		

GPIO13 - MOSI (SPI)	Display - 1.28" Touch LCD	Connection - 0x15 I2C & SPI
GPIO13 - MISO (SPI)		
GPIO12 SCLK (SPI)		
GPIO10 CS (SPI)		
GPIO39 LCD_DC		
GPIO40 LCD_RST		
GPIO7 LCD_BK (PWM)		
GPIO9 SCL (I2C)		
GPIO8 SDA (I2C)		
GPIO41 TP_INT		

GPIO9 SCL (I2C)	Temperature MCP9808	0x18 I2C
GPIO8 SDA (I2C)		

GPIO9 SCL (I2C)	Altimeter - BMP280	0x76 I2C
GPIO8 SDA (I2C)		

GPIO2 INT_BNO	IMU - BNO055	0x28 I2C Address
GPIO9 SCL (I2C)		
GPIO8 SDA (I2C)		

BAT_REF - GPIO1 (ADC1_CH0)	
Vibe - GPIO6	
Power/Latch - GPIO17	
Charging State 2 - GPIO5	Detect Charge State (Full/Charging)
Charging State 1 - GPIO4	Detect USB Connection
GPIO18 BT_1	Buttons
GPIO14 BT_2	