

Rig Build Sheet

Sony FX3 • RS 5 • Focus Pro • SDR Transmission



0 of 53 done

0%

☑ Steps

🔧 Fixes

1 Before the shoot

0/6 ^

One-time. Do it the night before — not five minutes before rolling.

☐ Install the apps

Phone: DJI Ronin app.

Computer: DJI Assistant 2 (Ronin Series) — for the tx/rx firmware.

Your video kit is the DJI SDR Transmission — not “DJI Transmission.”
Different, incompatible unit.

☐ Charge everything

Camera batteries, RS 5, hand unit NP-F, video tx, video rx, monitor.

Don't start any firmware update on a low battery.

Activate / update the RS 5

Hold the power button to turn it on.

Phone: turn on Bluetooth, open the DJI Ronin app, log in.

Tap RS 5 > enter 12345678 > Activate

If it offers a firmware update, run it. Don't power off or close the app while it updates.

Activate / update the Focus Pro

Put the NP-F on the hand unit, hold REC to power on.

DJI Ronin app > Hand Unit > enter 12345678 > Activate

Update firmware if offered. The motor updates through the hand unit once it's linked.

Update the video tx + rx

On the computer, in DJI Assistant 2.

Use a USB-A to USB-C cable — not USB-C to USB-C.

Update the tx and the rx one at a time.

Check they end up on the same firmware version.

Camera firmware — only if needed

In Sony Creators' App, if it says "Update your camera": battery 51%+, a formatted card in slot 1, follow the prompts.

Check the version: MENU > Setup > Setup Option > Version

3 Mount + balance the gimbal

0/5 ▾

4 Power + link the focus

0/7 ▾

5 Link the video

0/4 ▾

6 Confirm the chain

0/3 ▾

7 Tracking

OPTIONAL

0/2 ▾

8 Rehearsal

0/3 ▾

🚩 Ready to roll

0/19 ▾

This is real. I am real.