

Wreath Hardware Instructions


REV 01 – 18 Dec 17





Backside View Shown – Insert the LED's starting with #0 up to #47

- Cut off the female connector
- Strip and solder the 3 wires that went to the female connector to the Arduino Nano as follows:
 - o Red 5V
 - o Blue GND
 - o White D6
- Use the AC adaptor barrel adaptor and connect the wires as follows:
 - o Red wire to + screw
 - Blue wire to screw
- Cap off the two flying wires on the far end (end with male connector still on it) of the LED strand with heat shrink as they are not used.
- Glue the male connector at the far end to the backside of the wreath as it is not used.



Suggestions:

- Put a label next to the barrel connector that says "5VDC Center + Only"
- Put a label on the AC adaptor that says it's for the wreath