## **Programming HomeLink**

- 1. For first time training, press and hold the two outer HomeLink® buttons, releasing only when theHomeLink® <u>indicator light</u> begins to flash after 20 seconds. (Do not perform this step when training the additional HomeLink® buttons.)
- 2. Press the appropriate HomeLink® button I, II or III which you want to train and keep holding it until the indicator light starts flashing slowly. Once the indicator light starts flashing slowly, you may release the button. HomeLink® is now in "training mode."

	You will now have 5 minutes to train your <u>hand held transmitter</u> to the HomeLink®
	transmitter in the bumper.
3.	Stand in front of your vehicle with the
	original hand held transmitter for the gate or garage door opener (or other device) that you
	wish to train

The transmitter unit to be trained is located beneath the right headlight.

- 4. Hold the original hand held transmitter between 3-5 inches from the location described above, pointing at your car. NOTE: The distance between the hand held transmitter and the HomeLink® transmitter unit in the bumper depends on the system being trained. It may require several attempts at different distances in order to pick up the signal.
- 5. Now press and hold the button on your original hand held transmitterwhile keeping your hazard <u>warninglights</u> in view. The hazard warninglights will blink **three times** to indicate that the training has been successful.

**Note:** If the training time exceeds the five minutes, the <u>hazardwarning</u> lights blink once. If this happens, you should repeat steps 2 to 5.

- 6. Press and hold the trainedHomeLink® button and observe the indicator light.
  - If the indicator light is solid/continuous, training is complete and your device should activate when theHomeLink® button is pressed and released.
  - If the indicator light blinks rapidly for 2 seconds and then turns a solid/continuous light, proceed with the following training instructions for a <u>rolling code</u> device. A second person may make the following steps quicker & easier.
- 7. At the <u>garage door opener</u> receiver (motorhead unit) in the garage, locate the "learn" or "smart" button (usually near where the hanging antenna <u>wire</u> is attached to the unit). If there is difficulty locating the training button, reference the garage door opener's manual, or<u>contact</u> us.
- 8. Press and release the "learn" or "smart" button (the name and color of the button may vary by manufacturer). NOTE: Once the button is pressed, there are 30 seconds in which to initiate the next step.
- 9. Return to the vehicle and firmly press and hold the trainedHomeLink® button for two seconds and release. Repeat the "press/hold/release" sequence up to 3 times to complete the training process.