# 6.6 WiFi module writing firmware tutorial

# 1. Preparation before burning firmware

There are two ways to write firmware.


- 1-Unplug the jumper cap of the WiFi module. Then, use CH340 serial assistant module to write firmware.
- 2-Plug in the jumper cap of the WiFi module, write the firmware to the WiFi module through the CH340 serial port that comes with the K210 development board. we use the second method as a demonstration.

Note: Before writing firmware, K210 must wrote the firmware of wifi\_AT.bin and insert the jumper cap into the serial port of the WiFi module (the factory default is already inserted).

Connect the K210 development board to the computer through Type-C cable, and identify the serial port number.

# 2. Open the ESP burning tool


2.1 Extract and open the tool ESP\_TOOLS for writing firmware, double-click to open the ESPFlashDownloadTool\_v3.4.1 tool



### 2.2Choose "ESP8285 DownloadTool".




You can see following interface.



#### 3. Clear the Flash chip


Note: The function of this step is to clear the content saved in Flash.

3.1 Select the path of the blank1024.bin firmware in the position in the figure below.




3.2 Click "START". The IDLE button will become SYNC.


At this time, we need to press and hold the ESP-BOOT button of the WIFI module, and press the ESP-RST button, it will automatically enter the download.



3.3 Wait for the scroll bar to finish scrolling.




3.4 After the flash is cleared, you can start to download the firmware.




# 4. Writing wifi module firmware

4.1 Select the path of the **espressif\_AT\_(v1.5.4).bin** firmware in the position in the figure below.




4.2 Click "START". The IDLE button will become SYNC.

At this time, we need to press and hold the ESP-BOOT button of the WIFI module, and press the ESP-RST button, it will automatically enter the download.



4.3 Wait for the scroll bar to finish scrolling.



4.4 After the flash is cleared, you can start to download the firmware.

