

Menu Map NuRAD v1w7s4

MENU ITEM	SUB-MENU 1	SUB-MENU 2	VALUES	DEFAULT	COMMENT
TRANSCOPE			C> to >C< to <C	>C<	-12 to +12 semitones
OCTAVE			-3 to +3	0	
MIDI CH			1 to 16	1	
POLY PLAY					
	POLY MODE		OFF	OFF	All poly functions disabled.
			MGR		Major Gospel Root – a gospel type triad voicing
			MGD		Major Gospel Dominant – same as MGR, but with a dominant on V instead of an inversion of the root
			MA9		Major add9 – pop style add9 harmonisation
			MND		minor Dorian – jazz type minor
			MNA		minor Aeolian – classical minor
			MNH		minor 4-voice Hip – a more hip dorian minor
			FWC		Four Way Close – old school block chord harmony
			RTA		Rotator A
			RTB		Rotator B
			RTC		Rotator C
	HMZ KEY		C to B	C	Selects the key you are playing in for the key based harmonisations.
	OTF KEY		ON/OFF	OFF	On the fly switching of played key by releasing rollers while not blowing.
	HMZ LIMIT		2 to 5	5	Limit number of notes in harmonisation. Applies to the key based harmonisations only.
	FWC TYPE		6, m6, 7, m7	6	Type of block chord for the Four Way Close harmonisation
	FWC LOCKH		ON/OFF	OFF	"Lock Hands" (double melody) adds another melody note one octave down for the FWC.
	FWC DROP2		ON/OFF	OFF	"Drop 2" moves the second note (the one below melody note) one octave down for the FWC.
	PRIORITY		HI/LO	HI	Sets which note will get priority when playing mono patches
	ROTATOR A	RTA PARAL	-24 to +24	+7	Fixed interval second note of rotator A
		RTA ROT 1	-24 to +24	-5	First rotated third note of rotator A
		RTA ROT 2	-24 to +24	-10	Second rotated third note of rotator A
		RTA ROT 3	-24 to +24	-7	Third rotated third note of rotator A
		RTA ROT 4	-24 to +24	-14	Fourth rotated third note of rotator A
	ROTATOR B	RTA PARAL	-24 to +24	+7	Fixed interval second note of rotator B
		RTA ROT 1	-24 to +24	-5	First rotated third note of rotator B
		RTA ROT 2	-24 to +24	-10	Second rotated third note of rotator B
		RTA ROT 3	-24 to +24	-7	Third rotated third note of rotator B
		RTA ROT 4	-24 to +24	-14	Fourth rotated third note of rotator B
	ROTATOR C	RTC PARAL	-24 to +24	+7	Fixed interval second note of rotator C
		RTC ROT 1	-24 to +24	-5	First rotated third note of rotator C
		RTC ROT 2	-24 to +24	-10	Second rotated third note of rotator C
		RTC ROT 3	-24 to +24	-7	Third rotated third note of rotator C
		RTA ROT 4	-24 to +24	-14	Fourth rotated third note of rotator C
SETUP BR					
	BRTH CC A		OFF	BR	No breath CC data is sent
			MW		Breath data is sent as CC#1 (Mod Wheel)
			BR		Breath data is sent as CC#2 (Breath, factory default)
			VL		Breath data is sent as CC#7 (Volume)
			EX		Breath data is sent as CC#11 (Expression)
			MW+		High resolution breath data is sent on CC#1 and CC#33 (Hi-res Mod Wheel)
			BR+		High resolution breath data is sent on CC#2 and CC#34 (Hi-res Breath)
			VL+		High resolution breath data is sent on CC#7 and CC#39 (Hi-res Volume)
			EX+		High resolution breath data is sent on CC#11 and CC#43 (Hi-res Expression)
			CF		Breath data is sent as CC#74 (Filter Cutoff)
			UNO		Breath data is sent as CC#20 (for use with IK Multimedia UNO Synth)
	BRTH CC B		OFF, 1 to 127	OFF	Secondary MIDI CC for breath data. Can be set to any CC between 1 and 127 and be used together with CC A or on its own with CC A set to OFF.
	CC B RISE		1x to 10x	1x	Multiplier to faster reach top value for CC B compared to CC A
	BREATH AT		ON/OFF	OFF	Controls whether or not breath data should be sent as Aftertouch (Channel Pressure)
	VELOCITY		DYN, 1 to 127	DYN	Note On velocity can be set to follow initial breath value dynamically (DYN) or to a fixed value (1 to 127)
CURVE		-4 to LIN to +4, S1, S2, Z1, Z2	LIN	Breath curve	
VEL DELAY		OFF, 1ms to 30ms	20ms	Wait time before sampling breath level for note on velocity	
VEL BOOST		OFF, 1 to 9	OFF	Boost factor to compensate lower vel delay settings than 20ms	
BR INTERV		3 to 15	6	Boost factor to compensate lower vel delay settings than 20ms	
SETUP CTL					
	BITE CTL (Bite pressure exerted on pressure tube)		OFF	GLD	No destination active for this controller
			VIB		Vibrato
			GLD		Glide/portamento (defined by GLIDE MOD and GLIDE MIN/MAX settings)
			CC		Custom CC output (defined in BITE CC settings)
			GLO		Glissando mode (like Portamento but step-wise)
	BITE CC		0 to 127	1	CC number for bite (sent if CC is selected in BITE CTL)
	PAD CTL (Pad control: under RH thumb bridge)		OFF	VIB	No destination active for this controller
			VIB		Vibrato
			GLD		Glide/portamento (defined by GLIDE MOD and GLIDE MIN/MAX settings)
			CC		Custom CC output (defined in PAD CC settings)
	PAD CC		0 to 127	11	CC number for bite (sent if CC is selected in PAD CTL)
	GLIDE MOD (Third lip sensor, touch-sensitive)		OFF	ON	Glide/portamento disabled (for the bite sensor)
			ON		Send glide amount CC
			SW		Send CC for glide amount and on/off
			SEL		Roland SE/02 linear (on/off)
			SEE		Roland SE/02 exponential (on/off)
			SWO		Glide switching on/off only
	GLIDE MAX		0 to 127	127	Max level for glide amount CC
	GLIDE MIN		0 to 127	0	Min level for glide amount CC
	VIBRATO	DEPTH	OFF, 1 to 9	4	Main vibrato level control. OFF disables manual vibrato completely.
		RETURN	0 to 4	2	Vibrato auto return level (do not use 0 value with PneuBite system)
		DIRECTION	NRM/REV	NRM	Vibrato controller direction, normal or reversed
		SENSE PAD	1 to 12	6	Pad sensitivity setting for vibrato
		SQUELCH PAD	1 to 30	12	Pad squelch setting (noise threshold)

MENU ITEM	SUB-MENU 1	SUB-MENU 2	VALUES	DEFAULT	COMMENT
		SENSE BTE	1 to 12	8	Bite sensitivity setting for vibrato
		SQUELCH B	1 to 30	15	Bite squelch setting (noise threshold)
		VIB2BRDIR	POS, NEG	POS	
		VIB2BRAMT	0-10	10	
	EXCT CC A (Extra Controller: lip sensor and/or touch pad)		OFF	MW	EXCT CC A disabled
			MW		Mod Wheel, CC#1
			FP		Foot Pedal, CC#4
			CF		Filter Cutoff, CC#74
			SP		Sustain Pedal, CC#64
			GLD		Glide/portamento (defined by GLIDE MOD and GLIDE MIN/MAX settings)
	EXCT CC B		OFF, 1 to 127	OFF	CC number to be sent
	EXCT HARM		OFF, 1 to 6	OFF	Use Extra Controller (Lip Sensor) for going up or down in harmonic series, set range
	HARM SEL (Harmonic Series Selector)		HM1	HM1	Harmonics 1
			HM2		Harmonics 2 (7th harmonic not excluded)
			5TH		5ths and octaves, up
			OCT		Octaves, up
			H1R		Harmonics 1, down/reverse
			H2R		Harmonics 2 (7th harmonic not excluded), down/reverse
			5TR		5ths and octaves, down/reverse
			OCR		Octaves, down/reverse
	STRIP CRL (Strip Control: right of octave rollers)		OFF	GLD	Strip Destination
			CC		Custom CC output
			GLD		Glide/portamento (defined by GLIDE MOD and GLIDE MIN/MAX settings)
	STRIP CC		0 to 127	1	CC number to be sent
	DEGLITCH		OFF, 1-70ms	20	Fingering deglitch time
	MOD KEY (LH top key AKA "palm D key")		-12 to -1	PBD	Semitones down
			PBD		Pitch bend divider (MIDI EVI legacy function)
			+1 to +12		Semitones up
			ECB		Extra controller B CC sent as momentary switch 0/127 value
			ECS		Extra controller momentary switching from A to B CC output
			LVL		Level setting by pinky key+first or second trill key
			LVP		Same as LVL, but stored level value is sent at power on
			GLD		Glide control using pinky key. Set level using glide limit setting.
			ECH		Momentary extra controller harmonics activation
			QTN		Quarter tone down (using MIDI pitch bend)
	LEVEL CC		AT, 1 to 127	11	CC number for level control of LVL and LVP parameters for Mod Key
	EXTRA KEY (LH Pinky key 3)		OFF, -12 to -1, MOD, 1 to 12	OFF	Setting for LH pinky key 3
	FINGERING		EWI	EWI	Standard EWI fingering
			EWX		Extended EWI fingering
			SAX		Sax fingering (allow low fingers to stay on keys)
			EVI		EVI fingering
			EVR		EVI fingering with reversed roller action
			XVI		WX5 fingering (RH keys-only play 1 octave higher)
			XVR		
			WX5		WX5 fingering (RH keys-only play 1 octave higher)
	ROLLRMODE		1 to 4	2	1 = Highest Touched Roller, No Release Memory; 2 = Highest Touched Roller + Release Memory; 3 = Touched Roller Pair + Release Memory; 4 = Touched Roller Pair + Release Memory + Bonus octave on top
	PITCHBEND		OFF, 1/1 to 1/12	1/1	Pitchbend output control, disable or divide output to limit range
	GLISS (TIME)		OFF, 8-127ms	OFF	Time interval between GLO mode notes
ADJUST					
UP+DOWN buttons together for automatic calibration when THR or MAX bar is flashing	BREATH		THR/MAX	1125 / 2625	
	PAD		THR/MAX	1734 / 1794	
	TOUCH		THR	200	(Note: the sensor indicator movement is reversed i.e. right to left)
	GLS/EC		THR/MAX	2666 / 3152	
	BEND		THR/MAX	3092 / 3892	
	BITE		THR/MAX	1916 / 3116	
EXTRAS					
	LEGACY PB		ON/OFF	OFF	Enable MIDI EVI legacy controls using pitchbenders up+down for activation
	LEGACY BR		ON/OFF	OFF	Enable MIDI EVI legacy controls using negative breath (sucking) for activation
	GATE HOLD		ON/OFF	OFF	Enable gate hold function (touch all rollers and switch on/off with pitch bend up/down)
	3RD TRILL		+4/+3	4	Semitones for EVI third trill key
	DAC OUT		BRTH/PTCH	PTCH	Set DAC output mode. For using built in or external CV board, use PTCH (pitch) setting.
	BAT TYPE		ALK, NMH, LP1, LP2	LP2	Set battery type for correct indication of battery level
	FAST BOOT		ON/OFF	OFF	Enable faster startup
	FASTPATCH		ON/OFF	OFF	Enable FastPatch function
	CV TUNE		-99 to +99	0	Set tuning for note CV output
	CV SCALE		-99 to +99	0	Set scaling for note CV output
	CV EC LFO		OFF, 1 to 8	3	Set rate of LFO vibrato controlled by lip sensor (4.5Hz to 8Hz)
	WL POWER		0, -6, -12, -18	0	Send command to Panda system, 0 is full power
	WL CHAN		4 to 80	4	Send command to Panda system, start channel search at this channel#
	ABOUT				Display version number and battery charge level