











JWF1204 -3101	圆墙板 ROUND FRAME	2	JWF1204 -3102	曲 轨 RAIL	2	JWF1204 -3103A	导 带 LEADER TAPE	2			
											
JWF1204 -3105B	前左弓板 FRONT BENDING PLATE (L)	1	JWF1204 -3106B	前右弓板 FRONT BENDING PLATE (R)	1	JWF1204 -3107B	后左弓板 REAR BENDING PLATE (L)	1	JWF1204 -3108B	后右弓板 REAR BENDING PLATE (R)	1
											
JWF1204 -3109	垫 圈 WAHSE	12	JWF1204 -3110A	左弓板补块 L. BOW PLATE PATCH	1	JWF1204 -3111A	右弓板补块 R. BOW PLATE PATCH	1			
											
JWF1202 -3102	调节螺柱 ADJUSTING LEAD-SCREW	20	JWF1202 -3116	端 盖 END COVER	2						
