









ZFA051A-120-0400										共 1 页 第 1 页	
ZFA051A-120-0400-1	风机蜗壳结合件	1	ZFA051A-120-0400-3	进风管结合件	1	ZFA051A-120-0400-4	风扇结合件	1			
	FAN VOLUTE SUB-ASS			AIR INLET SUB-ASS			FAN SUB-ASS				
											
ZFA051A-0400-6	罩壳结合件	2						LVSAB-0401	法兰	2	
	HOOD CASINTG SUB-ASS							FLANGE			
											
			ZFA051A-0409	密封毡	2	ZFA051A-0420	轴承盖	2	ZFA051A-0421	挡圈	2
				SEALING BLANKET			BEARING COVER			COLLAR	
											
ZFA051A-0422	轴承座	2			TZH1087-10X3X5000	密封条	1	TZH1045-85X6	挡圈	1	
	BEARING SEAT								COLLAR		
