



NOTES:

1. THIS CIRCUIT WAS REVISED FEB 2003 TO SIMPLIFY. THE OLD VERSION NEEDED A TRANSISTOR, SEVERAL RESISTORS AND A ZENER MOUNTED ON A BOOX THIS VERSION CAN MOUNT THE SINGLE COMPONENT (10 OHM, 10 RESISTOR) RIGHT ON THE RELAY BY CRIMPING THE LEADS INTO FAST—ON TERMINALS THAT ATTACH TO THE RELAY.

TITLE PAGE
A/P DISCONNECT

COPYRIGHT ©2003, AEROELECTRIC CONNECTION

AEC