

## PARALLELING D-SUB PINS:

WIRE IN EACH PIN. IF CABLE/CABLE CONNECTOR, PUT 6" IN EACH SIDE. IF CABLE/ECB CONNECTOR USE 12" IN CABLE SIDE CONNECTOR. DROP PIGTAILS INTO BUTT SPLICE. EXTEND SPLICED PIGTAILS WITH SINGLE STRAND RATED FOR DIVIDE AVERAGE CURRENT TO BE CARRIED AVERAGE CURRENT. INSTALL 12" 22AWG BY 3. THIS DE-RATES EACH PIN TO 3A THE TASK AT HAND