

Alphanumeric Codes By Concise Codes

CONCISE CODE	FIO-DEC CODE	CHARACTER LOWER UPPER	CONCISE CODE	FIO-DEC CODE	CHARACTER LOWER UPPER
00	00	Tape Feed	41	241	j J
—	100	Delete	42	242	k K
00	200	Space	43	43	l L
01	01	”	44	244	m M
02	02	,	45	45	n N
03	203	~	46	46	o O
04	04	□	47	247	p P
05	205	∨	50	250	q Q
06	206	∧	51	51	r R
07	07	<	54	54	— +
10	10	>	55	255) J
11	211	↑	56	256	—
—	13	Stop Code			
20	20	0 →	57	57)]
21	221	/ ?	61	61	a A
22	222	s S	62	62	b B
23	23	t T	63	263	c C
24	224	u U	64	64	d D
25	25	v V	65	265	e E
26	26	w W	66	266	f F
27	227	x X	67	67	g G
30	230	y Y	70	70	h H
31	31	z Z	71	271	i I
33	233	,	72	272	Lower Case
34	—	black*	73	73	X
35	—	red*	74	274	Upper Case
36	236	tab	75	75	Backspace
40	40	• —	77	277	Carriage Return

*Used on Type-Out only, not on keyboard