Table: Computation for Design of Storm Sewer

Line Number	Location of Drain			Tributary area (hectares) increment					Weighted Average
	Street	Manhole From	Manhole To	Pervious	20 % Imperviousness	70 % Imperviousness	Impervious	Area	Imperviousness
1	2	3	4	5	6	7	8	9	10
1	South St.			0	0.366	0.286	0.274	0.926	
2				0	0.488	0.167	0.214	0.869	
3	North South St.2			0	0.312	0.415	0.352	1.079	
4				0	0.36	0.358	0.324	1.042	
5	South St.			0	0.466	0.256	0.274	0.996	
6	North South St.3			0	0.492	0.230	0.260	0.982	
7				0	0.310	0.410	0.348	1.068	
8	South St.			0	0.466	0.256	0.274	0.996	
9	North South St.4			0	0.282	0.660	0.517	1.459	
10				0	0.362	0.580	0.479	1.421	
11	South St.			0	0.330	0.670	0.494	1.494	

Table continued to next page

... ... Table continued from previous page

Line Number			Time o	of Concentration	on			Incremental	Total Flow (Q) = Incoming Flow + Incremental Flow/Runoff Ips
	Total Area	Weighted Average Imperviousness	Time of (t _i) inlet to upper end	Time of Flow in Drain t _f	t _c = t _i + t _f	Coefficient of Runoff (C)	Intensity of Rainfall (i)	Flow/Runoff (10 CiA) m³/h	
1	9	10	11	12	13	14	15	16	17
1	0.926		12.0						
2	0.869		13.3						
3	1.079		11.0						
4	1.042		11.5						
5	0.996		12.5						
6	0.982		12.8						
7	1.068		11.0						
8	0.996		12.5						
9	1.459		10.2						
10	1.421		10.8						
11	1.494		10.4						

Table continued to next page

... ... Table continued from previous page

Line Number	Total Flow (Q)			Des	Profile					
	lps	Dia mm	Slope m/1000	Capacity lps	Velocity mps	Length m	Fall m	Drop in Manhole	Invo Eleva Upper end	
1	18	19	20	21	22	23	24	25	26	27
1										
2										
3										
4										
5										
6										
7										
8										
9										
10										
11										