

## COORDENADAS DOS PONTOS DE ESTACIONAMENTO

ONTO SPOT	COORDENADAS COORDINATES	PONTO SPOT	COORDENADAS COORDINATES
	PÁTIO 2 / APRON 2		
В	S05 45 52.16/W035 22 15.23		
A	S05 45 52 59/W035 22 16.29		
B	S05 45 51.84/W035 22 15.59 S05 45 51.64/W035 22 18.42		
7	S05 45 51.32/W035 22 18.78		
7A 8	S05 45 52.06/W035 22 19.49 S05 45 51.63/W035 22 21.27		
9	S05 45 51.37/W035 22 22.88		
10 11	S05 45 51.11/W035 22 24.48 S05 45 50.85/W035 22 26.08		
12B	S05 45 50.46/W035 22 27.48		
12 2A	S05 45 49.81/W035 22 28.06 S05 45 50.24/W035 22 28.82		
	PÁTIO 3 / APRON 3		
13	S05 45 50.24/W035 22 30.49		
14	S05 45 50.20/W035 22 31.45		
15	S05 45 50.04/W035 22 32.41		
R16 R17	S05 45 49.89/W035 22 33.37 S05 45 49.73/W032 22 34.33		
R18	S05 45 49.58/W035 22 35.29		
R19	S05 45 51.63/W035 22 37.62		
R20	S05 45 52.90/W035 22 37.82		