## ILS Z outor LOC Z RWY 11

AD ELEV: 289							
	ATIS <b>127.75</b>	APP SANTA MARIA 119.35 121.35 121.50		TWR SANTA MARIA 118.30 118.85 121.50	AFIS SANTA MARIA 119.35 121.35 118.30		GNDC NIL
	LOC ISM <b>110.30 MHz</b>	FINAL CRS <b>109°</b>	FAF: <b>1930'</b>	CAT I DA / (OCH): <b>REFER TO</b>	мим	LOC only MDA / (OCH): <b>730' / (450')</b>	

APCH Perdida: Subir para 3000. Manter rumo 109 até 800. Então, curvar à DIREITA para interceptar RDL 135 do VOR SMA até NEDEV para espera. IAS MAX 210 KT até NEDEV.

Missed APCH: Climb to 3000. Maintain course 109 up to 800. Then, turn RIGHT to intercept 135 RDL SMA VOR up to NEDEV for holding. IAS MAX 210KT up to NEDEV.

RMK; (\*) VIS RVR ALS 550m para APCH utilizando Diretor de Voo, Piloto automático ou Head-Up Display(HUD)

