## How to run demo-printf on simulator?


How to run demo-printf on simulator?

Step1: Import project

Step2: Select your target. For example, choose target AG101P-N968A

la	arget Chip	
A	DP-AG101P-4GB-N968A-	S
Co	onnection Type	
0	Simulator	
Cl	ean and Rebuild Project	
	Clean project	
1	Build project	

Step3: Modify config.h (Specify BUILD\_MODE to BUILD\_SIMU)



Step4: Build & Run

Step5: Open Device Uart3.

