
VoiceOver Switch Box

What each control does in **VoiceOver mode** (the normal mode, for using the iPad).



Red button lit = box has power. Dark? Flip the USB-C plug at the box.

Hold two buttons for 3 seconds

Hold together	Does
Back + Close app (the two clear buttons)	Switches between VoiceOver mode and TD Snap mode. The box gives no sound or light when it switches.
Back + Green	Turns VoiceOver's Quick Nav on or off. Rarely needed.

Which mode is it in?

- With VoiceOver on, turn the wheel.
- VoiceOver moves from item to item = **VoiceOver mode**.
- Nothing happens = **TD Snap mode**.
- The box remembers its mode when unplugged.

TD Snap mode (scanning)

Control	Does
Wheel, either way	Moves the highlight on
Big button	Chooses the highlighted item
Red	Moves the highlight on
Green	Chooses
Blue	Back
Yellow	iPad Home Screen
Close app (clear)	Next field (Tab)
Back (clear)	Back

If the wheel does nothing with VoiceOver on, the box is probably in TD Snap mode: hold the two clear buttons for 3 seconds. Firmware v10 · github.com/wmetcalf/voiceover-switch-box