Chapter 1

Demo problem: Buckling of a clamped cylindrical shell under pressure loading

In this document, we discuss the solution of the buckling of a cylindrical shell using oomph-lib's Kirchhoff \leftarrow LoveShell elements.

[No documentation yet: Here's the driver code.]

```
//LIC// This file forms part of oomph-lib, the object-oriented,
//LIC// multi-physics finite-element library, available
//LIC// at http://www.oomph-lib.org.
//T.TC//
//LTC// Copyright (C) 2006-2024 Matthias Heil and Andrew Hazel
//LIC/
//LIC// This library is free software; you can redistribute it and/or
//LIC// modify it under the terms of the GNU Lesser General Public
//LIC// License as published by the Free Software Foundation; either
//LIC// version 2.1 of the License, or (at your option) any later version.
//LIC//
//LIC// This library is distributed in the hope that it will be useful,
//LIC// but WITHOUT ANY WARRANTY; without even the implied warranty of
//LIC// MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU
//LIC// Lesser General Public License for more details.
//T.TC//
//LIC// You should have received a copy of the GNU Lesser General Public
//LIC// License along with this library; if not, write to the Free Software //LIC// Foundation, Inc., 51 Franklin Street, Fifth Floor, Boston, MA //LIC// 02110-1301 USA.
//LIC//
//LIC// The authors may be contacted at oomph-lib@maths.man.ac.uk.
//LIC//===
//Driver function for a simple test shell problem:
//Calculate the deformation of an elastic tube approximated
//using Kirchoff--Love shell theory
//Standard system includes
#include <iostream>
#include <fstream>
#include <cmath>
#include <typeinfo>
#include <algorithm>
#include <cstdio>
//Include files from the finite-element library
#include "generic.h'
#include "shell.h"
#include "meshes/rectangular_quadmesh.h"
using namespace std:
using namespace oomph;
/// Global variables that represent physical properties
namespace Global Physical Variables
```

```
/// Prescribed position of control point
   double Prescribed_y = 1.0;
    /// Pointer to pressure load (stored in Data so it can
    /// become an unknown in the problem when displacement control is used
   Data* Pext_data_pt;
    /// Perturbation pressure
   double Pcos=1.0;
    /// Return a reference to the external pressure
    /// load on the elastic tube.
   double external_pressure()
       {return (*Pext_data_pt->value_pt(0))*pow(0.05,3)/12.0;}
    /// Load function, normal pressure loading
   void press_load(const Vector<double> &xi,
                                                    const Vector<double> &x,
                                                     const Vector<double> &N,
                                                    Vector<double>& load)
      //std::cout « N[0] « " " « N[1] « " " « N[2] « std::endl; //std::cout « xi[0] « " " « xi[1] « std::endl;
       for(unsigned i=0;i<3;i++)</pre>
            load[i] = (external_pressure() -
                                              Pcos*pow(0.05,3)/12.0*cos(2.0*xi[1]))*N[i];
         }
 /// A 2D Mesh class. The tube wall is represented by two Lagrangian
 /// coordinates that correspond to z and theta in cylindrical polars.
 /// The required mesh is therefore a 2D mesh and is therefore inherited
 /// from the generic RectangularQuadMesh
 template <class ELEMENT>
class ShellMesh : public virtual RectangularQuadMesh<ELEMENT>,
                                                       public virtual SolidMesh
public:
    /// Constructor for the mesh
   ShellMesh(const unsigned &nx, const unsigned &ny,
                                  const double &lx, const double &ly);
   /// In all elastic problems, the nodes must be assigned an undeformed,
    /// or reference, position, corresponding to the stress-free state
    /// of the elastic body. This function assigns the undeformed position % \left( 1\right) =\left( 1\right) \left( 
    /// for the nodes on the elastic tube
   void assign_undeformed_positions(GeomObject* const &undeformed_midplane_pt);
 };
 //-----
 /// Mesh constructor
 /// Argument list:
 /// nx : number of elements in the axial direction
 /// ny : number of elements in the azimuthal direction
 /// lx : length in the axial direction
/// ly : length in theta direction
 template <class ELEMENT>
 ShellMesh<ELEMENT>::ShellMesh(const unsigned &nx,
                                                                                            const unsigned &ny,
                                                                                            const double &lx.
                                                                                             const double &lv) :
   RectangularQuadMesh<ELEMENT>(nx,ny,lx,ly)
 {
    //Find out how many nodes there are
   unsigned n_node = nnode();
   //Now in this case it is the Lagrangian coordinates that we want to set, //so we have to loop over all nodes and set them to the Eulerian \,
    //coordinates that are set by the generic mesh generator
    for(unsigned i=0;i<n_node;i++)</pre>
        node_pt(i)->xi(0) = node_pt(i)->x(0);
node_pt(i)->xi(1) = node_pt(i)->x(1);
```

```
//Assign gradients, etc for the Lagrangian coordinates of
 //hermite-type elements
 //Read out number of position dofs
unsigned n_position_type = finite_element_pt(0)->nnodal_position_type();
 //{
m If} this is greater than 1 set the slopes, which are the distances between
 //nodes. If the spacing were non-uniform, this part would be more difficult
 if(n_position_type > 1)
   double xstep = (this->Xmax - this->Xmin)/((this->Np-1)*this->Nx);
   double ystep = (this->Ymax - this->Ymin)/((this->Np-1)*this->Ny);
   for (unsigned n=0;n<n_node;n++)</pre>
    {
     //The factor 0.5 is because our reference element has length 2.0 \,
     node_pt(n)->xi_gen(1,0) = 0.5*xstep;
node_pt(n)->xi_gen(2,1) = 0.5*ystep;
}
/// Set the undeformed coordinates of the nodes
template <class ELEMENT>
void ShellMesh<ELEMENT>::assign_undeformed_positions(
GeomObject* const &undeformed_midplane_pt)
{
 //Find out how many nodes there are
unsigned n_node = nnode();
 //Loop over all the nodes
 for(unsigned n=0;n<n_node;n++)</pre>
   //Get the Lagrangian coordinates
   Vector<double> xi(2);
   xi[0] = node_pt(n) -> xi(0);
   xi[1] = node_pt(n) -> xi(1);
   //Assign memory for values of derivatives, etc
   Vector<double> R(3);
   DenseMatrix<double> a(2,3);
   RankThreeTensor<double> dadxi(2,2,3);
   //Get the geometrical information from the geometric object
   undeformed_midplane_pt->d2position(xi,R,a,dadxi);
   //Loop over coordinate directions
   for (unsigned i=0;i<3;i++)</pre>
    {
     //{\rm Set} the position
     node_pt(n) \rightarrow x_gen(0,i) = R[i];
     //Set the derivative wrt Lagrangian coordinates
     //Note that we need to scale by the length of each element here!!
     node_pt(n) \rightarrow x_gen(1,i) = 0.5*a(0,i)*((this \rightarrow Xmax - this \rightarrow Xmin)/this \rightarrow Nx);
     node_pt(n) \rightarrow x\_gen(2,i) = 0.5*a(1,i)*((this \rightarrow Ymax - this \rightarrow Ymin)/this \rightarrow Ny);
     //Set the mixed derivative
     //(symmetric so doesn't matter which one we use)
     node_pt(n) \rightarrow x_gen(3,i) = 0.25*dadxi(0,1,i);
//Problem class to solve the deformation of an elastic tube
template<class ELEMENT>
class ShellProblem : public Problem
public:
 /// Constructor
ShellProblem(const unsigned &nx, const unsigned &nv,
              const double &lx, const double &ly);
 /// Overload Access function for the mesh
 ShellMesh<ELEMENT>* mesh_pt()
  {return dynamic_cast<ShellMesh<ELEMENT>*>(Problem::mesh_pt());}
 /// Actions after solve empty
 void actions_after_newton_solve() {}
```

```
/// Actions before solve empty
void actions_before_newton_solve() {}
//A self_test function
void solve();
 /// Pointer to GeomObject that specifies the undeformed midplane
GeomObject* Undeformed_midplane_pt;
 /// First trace node
Node* Trace node pt;
 /// Second trace node
Node* Trace_node2_pt;
};
//-----
/// Constructor
template<class ELEMENT>
ShellProblem<ELEMENT>::ShellProblem(const unsigned &nx, const unsigned &ny,
                                    const double &lx, const double &ly)
 //Create the undeformed midplane object
Undeformed_midplane_pt = new EllipticalTube(1.0,1.0);
 //Now create the mesh
Problem::mesh_pt() = new ShellMesh<ELEMENT>(nx,ny,lx,ly);
 //Set the undeformed positions in the mesh
mesh_pt()->assign_undeformed_positions(Undeformed_midplane_pt);
 //Reorder the elements, since I know what's best for them....
mesh_pt()->element_reorder();
 //Apply boundary conditions to the ends of the tube
unsigned n_ends = mesh_pt()->nboundary_node(1);
 //Loop over the node
 for(unsigned i=0;i<n_ends;i++)</pre>
   //Pin in the axial direction (prevents rigid body motions)
  mesh_pt()->boundary_node_pt(1,i)->pin_position(2);
  mesh_pt()->boundary_node_pt(3,i)->pin_position(2);
   //Derived conditions
  mesh_pt()->boundary_node_pt(1,i)->pin_position(2,2);
  mesh_pt()->boundary_node_pt(3,i)->pin_position(2,2);
   //-----CLAMPING CONDITIONS-----
   //----Pin positions in the transverse directions-----
   // Comment these out to get the ring case
  mesh_pt()->boundary_node_pt(1,i)->pin_position(0);
  mesh_pt()->boundary_node_pt(3,i)->pin_position(0);
   //Derived conditions
   mesh_pt() \rightarrow boundary_node_pt(1, i) \rightarrow pin_position(2, 0);
  mesh_pt() \rightarrow boundary_node_pt(3, i) \rightarrow pin_position(2, 0);
  mesh_pt()->boundary_node_pt(1,i)->pin_position(1);
  mesh_pt()->boundary_node_pt(3,i)->pin_position(1);
   //Derived conditions
   mesh_pt()->boundary_node_pt(1,i)->pin_position(2,1);
  mesh_pt()->boundary_node_pt(3,i)->pin_position(2,1);
   // Set the axial gradients of the transverse coordinates to be
   // zero --- need to be enforced for ring or tube buckling
   //Pin dx/dz and dy/dz
  mesh\_pt() -> boundary\_node\_pt(1, i) -> pin\_position(1, 0);
  \verb|mesh_pt()->boundary_node_pt(1,i)->pin_position(1,1);\\
  mesh_pt()->boundary_node_pt(3,i)->pin_position(1,0);
  mesh_pt()->boundary_node_pt(3,i)->pin_position(1,1);
   //Derived conditions
  mesh_pt()->boundary_node_pt(1,i)->pin_position(3,0);
  mesh_pt()->boundary_node_pt(1,i)->pin_position(3,1);
  mesh_pt() \rightarrow boundary_node_pt(3, i) \rightarrow pin_position(3, 0);
  mesh_pt()->boundary_node_pt(3,i)->pin_position(3,1);
 //Now loop over the sides and apply symmetry conditions
 unsigned n_side = mesh_pt()->nboundary_node(0);
 for(unsigned i=0;i<n_side;i++)</pre>
  //At the side where theta is 0, pin in the y direction
```

```
mesh_pt()->boundary_node_pt(0,i)->pin_position(1);
   //Derived condition
   mesh_pt()->boundary_node_pt(0,i)->pin_position(1,1);
   //Pin dx/dtheta and dz/dtheta
   mesh\_pt() -> boundary\_node\_pt(0,i) -> pin\_position(2,0);
   mesh_pt()->boundary_node_pt(0,i)->pin_position(2,2);
   //Pin the mixed derivative
   mesh_pt()->boundary_node_pt(0,i)->pin_position(3,0);
   mesh_pt() \rightarrow boundary_node_pt(0, i) \rightarrow pin_position(3, 2);
   //At the side when theta is 0.5\mathrm{pi} pin in the x direction
   mesh_pt()->boundary_node_pt(2,i)->pin_position(0);
   //Derived condition
   mesh_pt()->boundary_node_pt(2,i)->pin_position(1,0);
   //Pin dy/dtheta and dz/dtheta
   mesh_pt()->boundary_node_pt(2,i)->pin_position(2,1);
   mesh_pt() \rightarrow boundary_node_pt(2, i) \rightarrow pin_position(2, 2);
   //Pin the mixed derivative
   mesh_pt()->boundary_node_pt(2,i)->pin_position(3,1);
   mesh_pt()->boundary_node_pt(2,i)->pin_position(3,2);
//
//
//
       //Set an initial kick to make sure that we hop onto the
      //non-axisymmetric branch
      if((i>1) && (i<n_side-1))
        mesh_pt()->boundary_node_pt(0,i)->x(0) += 0.05;
        mesh_pt()->boundary_node_pt(2,i)->x(1) -= 0.1;
 // Setup displacement control
// //Setup displacement control
   //Fix the displacement at the mid-point of the tube in the "vertical"
   //(v) direction.
    //Set the displacement control element (located halfway along the tube)
// Disp_ctl_element_pt = dynamic_cast<ELEMENT*>(mesh_pt()->element_pt(3*Ny-1));
// //The midpoint of the tube is located exactly half-way along the element // Vector<double> s(2); s[0] = 1.0; s[1] = 0.0; //s[1] = 0.5 // //Fix the displacement at this point in the y (1) direction
// Disp_ctl_element_pt->fix_displacement_for_displacement_control(s,1);
    //Set the pointer to the prescribed position
// Disp_ctl_element_pt->prescribed_position_pt() = &Prescribed_y;
 // Choose element in which displacement control is applied: This
 // one is located about halfway along the tube -- remember that
 // we've renumbered the elements!
 unsigned nel_ctrl=0;
Vector<double> s_displ_control(2);
 // Even/odd number of elements in axial direction
 if (nx%2==1)
   nel_ctrl=unsigned(floor(0.5*double(nx))+1.0)*ny-1;
   s_displ_control[0]=0.0;
   s displ control[1]=1.0;
 else
   nel_ctrl=unsigned(floor(0.5*double(nx))+1.0)*ny-1;
   s_displ_control[0]=-1.0;
   s_displ_control[1]=1.0;
 // Controlled element
 SolidFiniteElement* controlled_element_pt=
  dynamic_cast<ELEMENT*>(mesh_pt()->element_pt(nel_ctrl));
 // Fix the displacement in the y (1) direction...
unsigned controlled direction=1;
 // Pointer to displacement control element
 DisplacementControlElement* displ_control_el_pt;
 // Build displacement control element
 displ control el pt=
  new DisplacementControlElement(controlled element pt,
                                   s_displ_control,
                                    controlled_direction,
                                    &Global_Physical_Variables::Prescribed_y);
 // Doc control point
 Vector<double> xi(2);
```

```
Vector<double> x(3);
controlled_element_pt->interpolated_xi(s_displ_control,xi);
 controlled_element_pt->interpolated_x(s_displ_control,x);
 std::cout « std::endl;
 std::cout « "Controlled element: " « nel_ctrl « std::endl;
std::cout « "Displacement control applied at xi = ('
          « xi[0] « ", " « xi[1] « ")" « std::endl;
 std::cout « "Corresponding to
          « x[0] « ", " « x[1] « ", " « x[2] « ")" « std::endl;
 // The constructor of the DisplacementControlElement has created
 // a new Data object whose one-and-only value contains the // adjustable load: Use this Data object in the load function:
 Global_Physical_Variables::Pext_data_pt=displ_control_el_pt->
 displacement_control_load_pt();
 // Add the displacement-control element to the mesh
mesh_pt()->add_element_pt(displ_control_el_pt);
 // Complete build of shell elements
 //Find number of shell elements in mesh
unsigned n_element = nx*ny;
 //Explicit pointer to first element in the mesh
 ELEMENT* first_el_pt = dynamic_cast<ELEMENT*>(mesh_pt()->element_pt(0));
 //Loop over the elements
 for (unsigned e=0;e<n_element;e++)</pre>
   //Cast to a shell element
  ELEMENT *el_pt = dynamic_cast<ELEMENT*>(mesh_pt()->element_pt(e));
   //Set the load function
  el_pt->load_vector_fct_pt() = & Global_Physical_Variables::press_load;
  //Set the undeformed surface
  el_pt->undeformed_midplane_pt() = Undeformed_midplane_pt;
  //The external pressure is external data for all elements
  el_pt->add_external_data(Global_Physical_Variables::Pext_data_pt);
   //Pre-compute the second derivatives wrt Lagrangian coordinates
   //for the first element only
   if(e==0)
   {
     el_pt->pre_compute_d2shape_lagrangian_at_knots();
   //Otherwise set the values to be the same as those in the first element
   //this is OK because the Lagrangian mesh is uniform.
   else
   {
     el_pt->set_dshape_lagrangian_stored_from_element(first_el_pt);
   }
 //Set pointers to two trace nodes, used for output
 Trace_node_pt = mesh_pt()->finite_element_pt(2*ny-1)->node_pt(3);
Trace_node2_pt = mesh_pt() ->finite_element_pt(ny) ->node_pt(1);
 // Do equation numbering
cout « std::endl;
cout « "# of dofs " « assign_eqn_numbers() « std::endl;
cout « std::endl;
}
// /Define the solve function, disp ctl and then continuation
//-----
template<class ELEMENT>
void ShellProblem<ELEMENT>::solve()
 //Increase the maximum number of Newton iterations.
//Finding the first buckled solution requires a large(ish) number
 //of Newton steps -- shells are just a bit twitchy
Max_newton_iterations = 40;
Max_residuals=1.0e6;
 //Open an output trace file
```

1.1 PDF file 7

```
ofstream trace("trace.dat");
 //Gradually compress the tube by decreasing the value of the prescribed
 //position
 for (unsigned i=1;i<11;i++)</pre>
   Global_Physical_Variables::Prescribed_y -= 0.05;
   // Solve
   newton_solve();
   //Output the pressure (on the bending scale)
   trace « Global_Physical_Variables::external_pressure()/(pow(0.05,3)/12.0)
         "//Position of first trace node

"Trace_node_pt->x(0) " " " Trace_node_pt->x(1) " "

//Position of second trace node

"Trace_node2_pt->x(0) " " " Trace_node2_pt->x(1) " std::endl;
   // Reset perturbation
   Global_Physical_Variables::Pcos=0.0;
 //Close the trace file
trace.close();
//Output the tube shape in the most strongly collapsed configuration ofstream file("final_shape.dat");
mesh_pt()->output(file,5);
file.close();
/// Driver
int main()
//Length of domain
double L = 10.0;
double L_phi=0.5*MathematicalConstants::Pi;
 //Set up the problem
ShellProblem<StorableShapeSolidElement<DiagHermiteShellElement> >
 problem(5,3,L,L_phi);
 //Solve the problem
problem.solve();
```

1.1 PDF file

A pdf version of this document is available.